

FORD A4LD SERVO IDENTIFICATION

INTERMEDIATE SERVO COMPONENTS

1985 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY - INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D.
85GT-ABA, ACA	2.3L-1V	84DT-7D027-CA*	83DT-7E221-C1A	80DT-7D028-AA (Blue)	74DT-7D396-GB@	G@
85GT-AEA, AGA, ALA, AMA, BAA, BCA	2.8L-2V	84DT-7D027-CA*	83DT-7E221-C1A	80DT-7D028-AA (Blue)	74DT-7D396-GB@	G@

1986 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY - INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D,
85GT-ACA, 86GT-AAA 85GT-AMA, BCA	2.3L (EFI) 2.8L-2V	84DT-7L493-CB*	83DT-7E221-C1A	80DT-7D028-AA (Blue)	74DT-7D396-GB@	G@
86GT-ABA, ACA, BAA, CAA, DAA, EAA	2.9L (EFI)	84DT-7L493-BB°	78DT-7E221-B2A	74DT-7D028-AB (Orange)	74DT-7D396-EB@	E@
86GT–KAA, LAA	3.0L (EFI)	84DT-7L493-BB*	78DT-7E221-B2A	74DT-7D028-AB (Orange)	74DT-7D396-EB@	E@

1987 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY - INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D.
87GT-ABA, CAA, CAB	2.3L (EFI)	84DT-7L493-CB°	83DT-7E221-C1A	80DT-7D028-AA (Blue)	74DT-7D396-GB@	G@
87GT-AAA, BAA	2.3L (Turbo)	84DT-7L493-BB*	83DT-7E221-B2A	80DT-7D028-AA (Blue)	74DT-7D396-EB@	E@
87GT-DAA, FAA, HAA, KAA, DAC, FAD, HAE, KAG	2.9L (EFI)	84DT-7L493-BB*	78DT-7E221-B2A	74DT-7D028-AB (Orange)	74DT-7D396-EB@	E@
87GT-MAA, NAA	3.0L (EFI)	84DF-7L493-BB*	78DT-7E221-B2A	74DF-7D028-AB (Orange)	74DT-7D396-EB@	E@

Part number cast on cover

Identification letter on lever

Copyright © 2000 ATSG



INTERMEDIATE SERVO COMPONENTS

1988 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY - INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D.
88GT-GAA, KAA	2.3L (EFI TURBO)	84DT-7L493-BB*	78DT-7E221-B2A	80DT-7D028-AA (Blue)	74DT-7D396-EB@	E@
88GT–ABB, HAA, NAA	2.3L (EFI)	84DT-7L493-CB*	83DT-7E221-C1A	80DT-7D028-AA (Blue)	74DT-7D396-GB@	G@
88GT–BAA, CAA, DAA, EAA 88GT–LAA, MAA	2.9L (EFI) 3.0L (EFI)	84GT-7L493-BB*	78DT-7E221-B2A	74DT-7D028-AB (Orange)	74DT-7D396-EB@	E@

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D.
89GT-RAA, SAA	2.3L (EFI)	84DT-7L493-CB*	83DT-7G221-C1A	84GT-7D028-AA (Yellow)	74DT-7D396-GB@	G@
89GT-AAB, BBB	2.3L (EFI)	84DT-7L493-CB*	83DT-7E221-C1A	74DT-7D028-AB (Orange)	74DT-7D396-GB@	G@
89GT–AAA, BAA, CAA, DAA 89GT–EAA, GAA	2.9L (EFI) 3.0L (EFI)	84DT-7L493-BB*	83DT-7E221-B1A	74DT-7D028-AB (Orange)	74DT-7D396-EB@	E@

Part number cast on cover

[@] Identification letter on lever



INTERMEDIATE SERVO COMPONENTS

1990 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY - INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D.
90GT-TAA, TBA	2.3L (EFI)	90GT-EB*	90GT-E1A	83DT-AA (Green)	84GT-EB@	EØ
90GT-TCA	2.3L (EFI)	90GT-FB*	90GT-F1A	80DT-AA (Blue)	90GT-DB@	D@
90GT-GAA, GBA, GCA	2.3L (EFI)	90GT-FB*	90GT-F1A	84GT-AA (Yellow)	90GT-DB@	D@
90GT-KAA, LAA, LCA, MAA, NAA	2.9L (EFI)	90GT-DB*	90GT-D1A	74DT-AB (Orange)	84GT-AB@	A@
90GT-RAA, SAA, RBA, SBA	3.0L (EFI)	90GT-FB*	90GT-F1A	83DT-AA (Green)	84GT-AB@	A@
90GT-EAA, FAA, CAA, EBA, FBA, DAA	4.0L (EFI)	84DT-BB*	83GT-B1A	74DT-AB (Orange)	84GT-AB@	A@
90GT-ADA, ADD, AAA, AEA, AEE, BAA	4.0L (EFI)	84DT-BB*	83GT-B1A	74DT-AB (Orange)	84GT-AB@	A@

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D.
91GT-MUA, MUB	2.3L (EFI)	90GT-FB*	90GT-F1A	80DT-AA (Blue)	90GT-DB@	D@
91GT-TPA, TPB	2.3L (EFI)	90GT-FB*	90GT-F1A	84GT-AA (Yellow)	90GT-DB@	D@
91GT-RAA, RBA	2.9L (EFI)	90GT-DB°	90GT-D1A	74DT-AB (Orange)	84GT-AB@	A@
91GT-AEA, AEB, AEC, AED, RCA, RDA	3.0L (EFI)	90GT-FB*	90GT-F1A	83DT-AA (Green)	84GT-AB@	A@
91GT-GAA, HAA, KAA, LAA, MAA, NAA, SAA, SBA, SCA, SDA, SEA, SFA	4.0L (EFI)	84DT-BB*	83DT-B1A	74DT-AB (Orange)	84GT-AB@	A@
91GT–AAA, BAA, DAA, EAA	4.0L (EFI)	84DT-BB°	83DT-B1A	84GT-AA (Yellow)	84GT-AB@	A@

Part number cast on cover

[@] Identification letter on lever



INTERMEDIATE SERVO COMPONENTS

1992 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D.
91GT-MUA, MUB	2.3L (EFI)	90GT-FB*	90GT-F1A	80DT-AA (Blue)	90GT-DB@	D@
92GT-BDB, BGB	2.3L (EFI)	90GT-FB*	90GT-F1A	80GT-AA (Blue)	90GT-DB@	D@
91GT-RAA, RBA	2.9L (EFI)	90GT-DB°	90GT-D1A	74DT-AB (Orange) 83DT-AA (Green)	84GT-AB@	A@
92GT-ABA, ACA, ADA, AEA, AFA, AGA	3.0L (EFI)	90GT-FB*	90GT-F1A		84GT-AB@	A@
92GT-DBA, DCA, DDA, DEA, AHA, AKA, ALA, AMA, ANA, ARA, ASA, ATA	4.0L (EFI)	84DT-BB*	83DT-B1A	74DT-AB (Orange)	84GT-AB@	A@
92GT-CBA, CDA, CEA, CFA	4.0L (EFI)	84DT-BB*	83DT-B1A	84GT-AA (Yellow)	84GT-AB@	A@

1993 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER INTERM	PISTON & ROD ASSY - INTERM	SERVO SPRING INTERM	SERVO LEVER INTERM	I.D.
93GT-RBA, SBA	2.3L (EFI)	90GT-FB*	90GT-F1A	80DT-AA (Blue)	90GT-DB@	D@
93GT-AAA, BAA	2.3L (EFI)	90GT-EB*	90GT-E1A	84GT-AA (Yellow)	84GT-EB@	D@
93GT-CAA, DAA, TAA, UAA, FBA, GBA	3.0L (EFI)	90GT-FB*	90GT-F1A	83DT-AA (Green)	84GT-AB@	A@
93GT-EAA, FAA	3.0L (EFI)	90GT-DB*	90GT-D1A	74DT-AB (Orange)	84GT-AB@	A@
93GT-BBA, CBA, HBA, KBA, DBA, EBA, MBA, NBA, GAA, HAA, MAA, NAA, RAA, SAA, KAA, LAA	4.0L (EFI)	84DT-BB*	78DT-B2A	74DT-AB (Orange)	84GT-AB@	A@
93GT-LBA, SBB	4.0L (EFI)	84DT-BB*	78DT-B2A	90GT-AA (Lt. Blue)	84GT-AB@	A@

Part number cast on cover

@ Identification letter on lever



OVERDRIVE SERVO COMPONENTS

1985 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY - O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
85GT-ABA, ACA	2.3L-1V	84DT-7D027-AA*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-GA@	G@
85GT-AEA, AGA, ALA, AMA, BAA, BCA	2.8L-2V	84DT-7D027-AA*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-GA@	G@

1986 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY - O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
85GT-ACA, 86GT-AAA 85GT-AMA, BCA	2.3L (EFI) 2.8L-2V	84DT-7L493-AB*	74DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-GA@	G@
86GT-ABA, ACA, BAA, CAA, DAA, EAA	2.9L (EFI)	84DT-7L493-AB*	78DT-7E221-A2A	83DT-7D028-AA (Green)	84GT-7D396-EA@	E@
86GT-KAA, LAA	3.0L (EFI)	84DT-7L493-AB*	78DT-7E221-A2A	83DT-7D028-AA (Green)	84DT-7D396-EA@	E@

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY - O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
87GT-ABA, CAA, CAB	2.3L (EFI)	84DT-7L493-AB*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-GA@	G@
87GT-AAA, BAA	2.3L (Turbo)	84DT-7L493-AB*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-AA@	A@
87GT-DAA, FAA, HAA, KAA, DAC, FAD, HAE, KAG	2.9L (EFI)	84DT-7L493-AB*	78DT-7E221-A2A	83DT-7D028-AA (Green)	84GT-7D396-EA@	E@
87GT-MAA, NAA	3.0L (EFI)	84DT-7L493-AB*	78DT-7E221-A2A	83DT-7D028-AA (Green)	84GT-7D396-EA@	E@

Part number cast on cover

[@] Identification letter on lever



OVERDRIVE SERVO COMPONENTS

1988 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY - O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
88GT–ABB	2.3L (EFI)	84GT-7L493-AB*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-GA@	G@
88GT-HAA, NAA	2.3L (EFI)	84GT-7L493-AB*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-GB@	G@
88GT-GAA, KAA	2.3L (EFI) (Turbo)	84GT-7L493-AB*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-AB@	A@
88GT-LAA, MAA	3.0L (EFI)	84GT-7L493-AB*	78DT-7E221-A2A	83DT-7D028-AA (Green)	84GT-7D396-AB@	A@
88GT-BAA, CAA, DAA, EAA	2.9L (EFI)	84GT-7L493-AB*	78DT-7E221-A2A	83DT-7D028-AA (Green)	88GT-7D396-CB@	C@

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY - O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
89GT-AAB, BBB	2.3L (EFI)	84GT-7L493-AB*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-EB@	E@
89GT-RAA, SAA	2.3L (EFI)	84GT-7L493-AB*	78DT-7E221-A2A	80DT-7D028-AA (Blue)	84GT-7D396-GB@	G@
89GT-EAA, GAA	3.0L (EFI)	84GT-7L493-AB*	78DT-7E221-A2A	83DT-7D028-AA (Green)	88GT-7D396-CB@	C@
89GT-AAA, BAA, CAA, DAA	2.9L (EFI)	84GT-7L493-AB*	78DT-7E221-A2A	83DT-7D028-AA (Green)	84GT-7D396-AB@	A@

Part number cast on cover

Identification letter on lever



OVERDRIVE SERVO COMPONENTS

1990 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY – O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
90GT-TAA, TBA	2.3L (EFI)	84GT-AB*	78DT-A2A	80DT-AA (Blue)	84GT-GB@	G@
90GT-TCA	2.3L (EFI)	84GT-AB*	78DT-A2A or	80DT-AA (Blue)	84GT-EB@	E@
90GT-GAA, GBA, GCA	2.3L (EFI)	84GT-AB*	83DT-A1A 78DT-A2A	80DT-AA (Blue)	84GT-EB@	E@
90GT-KAA, LAA, LCA, MAA, NAA	2.9L (EFI)	84GT-AB*	or 83DT-A1A 78DT-A2A	83DT-AA (Green)	88GT-CB@	C@
90GT-RAA, SAA, RBA, SBA	3.0L (EFI)	84GT-AB*	or 83DT-A1A 78DT-A2A	83DT-AA (Green)	84GT-AB@	A@
90GT-EAA, FAA, CAA, EBA, FBA, DAA, ADA, ADD,	4.0L (EFI)	84GT-AB*	or 83DT-A1A 78DT-A1A or	83DT-AA (Green)	88GT-CB@	C@
AAA, AEA, AEE, BAA			83DT-A1A			

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY - O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
91GT-MUA, MUB, TPA, TPB	2.3L (EFI)	84DT-AB*	78DT-A2A	80DT-AA (Blue)	84GT-EB@	E@
91GT-RAA, RBA	2.9L (EFI)	84DT-AB*	78DT-A2A	83DT-AA (Green)	88GT-CB@	C@
91GT-AEA, AEB, AEC, AED, RCA, RDA	3.0L (EFI)	84GT–AB*	78DT-A2A	83DT-AA (Green)	84GT-AB@	A@
91GT-AAA, BAA, DAA, EAA, GAA, HAA, KAA, LAA, MAA, NAA, SAA, SBA, SCA, SDA, SEA, SFA	4.0L (EFI)	84DT-AB*	78DT-A2A	83DT-AA (Green)	88GT-CB@	C@

^{*} Part number cast on cover

[@] Identification letter on lever



OVERDRIVE SERVO COMPONENTS

1992 MODEL YEAR TRANSMISSIONS

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY - O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
91GT-MUA, MUB	2.3L (EFI)	84DT-BB*	78DT-B2A	80DT-AA (Blue)	84GT-EB@	E@
92GT-BDB, BGB	2.3L (EFI)	84DT-AB*	78DT-A2A	84GT-AA (Yellow)	84GT-EB@	E@
91GT-RAA, RBA	2.9L (EFI)	84DT-AB*	78DT-A2A	83DT-AA (Green)	88GT-CB@	C@
92GT-ABA, ACA, ADA, AEA, AFA, AGA	3.0L (EFI)	84DT-AB*	78DT-A2A	83DT-AA (Green)	84GT-AB@	A@
92GT-DBA, DCA, DDA, DEA, AHA, AKA, ALA, AMA, ANA, ARA, ASA, ATA, CBA, CDA, CEA, CFA	4.0L (EFI)	84DT-AB*	78DT-A2A	83DT-AA (Green)	84GT-AB@	A@

MODEL APPLICATION	ENGINE	SERVO COVER O/D	PISTON & ROD ASSY - O/D	SERVO SPRING O/D	SERVO LEVER O/D	I.D.
93GT-RBA, SBA	2.3L (EFI)	84DT-BB*	83DT-B1A	80DT-AA (Blue)	84GT-EB@	EØ
93GT-AAA, BAA	2.3L (EFI)	84DT-AB*	78DT-A2A	84GT-AA (Yellow)	84GT-EB@	D@
93GT-CAA, DAA, TAA, UAA, FBA, GBA	3.0L (EFI)	84DT-AB*	78DT-A2A	83DT-AA (Green)	84GT-AB@	A@
93GT-EAA, FAA	3.0L (EFI)	84DT-AB*	78DT-A2A	83DT-AA (Green)	84GT-CB@	C@
93GT-BBA, CBA, HBA, KBA, DBA, EBA, MBA, NBA, GAA, HAA, MAA, NAA, RAA, SAA, KAA, LAA LBA, SBB	4.0L (EFI)	84DT-AB*	78DT-A2A	83DT-AA (Green)	84GT-AB@	A@

^{*} Part number cast on cover

[@] Identification letter on lever