

Technical Service Information

ACURA 4 SPEED PROPER SPRAG ROTATION

This bulletin purpose is to show the technician the proper sprag installation. Figure 1 shows freewheel counter clockwise, locks clockwise.




Figure 1

Copyright © 2000 ATSG

88-40 Page 1 of 1