
No lathe upper bolt instructions



Materials

 $5/8"\ metal\ rod\ \underline{https://www.homedepot.com/pep/Everbilt-5-8-in-x-36-in-Zinc-Plated-Round-Rod-802337/204273979}$


3/4" metal tube with 1/16" wall https://www.homedepot.com/pep/Everbilt-36-in-x-3-4-in-x-1-16-in- Plain-Steel-Round-Tube-801237/204225742

Process

1. Cut the rod and tube to length and shape the chamfer on the back of the rod with something like a belt sander or grinder



2. Use a vice to hold the assembly in the correct position



- 3. Weld together. There are several ways to do this.
 - I found welding a few spots through the tube works the best.
 - You can also drill a few holes in the tube then weld it together or cut a slit in the tube and weld it together.
- 4. Grind/sand off the welds to make it smooth.