Unofficial Print Guide for WTF/MOD9

These settings were not based on engineer/designer recs. Other people may have different opinions/suggestions on printing, but these are what I used and what worked for me and others. Print settings are all based on CURA stock Ender 3 profile settings. Keep all stock profile settings and change only what is noted in red text.

Print temps are not suggested because location, filament brand, and atmosphere vary. Print out a tempature test tower from thingaverse to see what temps will work best for you.

Support blocker tool will make things much easier. If you do not know how to use support blocker, look it up on youtube. It is very easy to use. Use support blocker for all small holes. Holes are designed small to be reamed out with drill bits because perfect circles are not consistent with 3D printers. Support density should be set at 10 with all parts requiring supports. Be sure to keep a clean build plate, use iso alcohol to clean bed and let the heat evaporate it fully before printing. For help with printing, I reccomend youtube videos by "Tomb Of 3D Printed Horrors". He should have a video for anything you need help with, for both slicing and printing. Be sure to know all your local, state, and federal laws and regulations. Don't call a magazine a "clip" and ALWAYS practice gun saftey at all times. The development and hosting of 3D printed firearm/files is legal and protected under free speech at the time of this writing. The WTF9 is identified as a pistol under ATF specifications and NFA.

Special thanks to Derwood and Mussy for making the WTF9 design available to the public.


This print guide should be universal to WTF9MV, WTF9H, MOD9, and other variants of the WTF9.


Feel free to view public folder on keybase for custom/remixed/modified parts for MOD9

-chuckschumer (keybase)


Barrel Retainer

CURA stock profile
0.2mm layer height (standard)
95% infill
Supports touching buildplate
Support blocker on rails
Skirt only






Ejector, Ejector Mount, Mag catch, Feed ramp




End Cap


Stock CURA profile settings
0.2mm layer height
Standard quality
90% infill
2 walls
Supports touching buildplate only
Skirt only



Lower Reciever

Stock CURA profile settings
0.2mm layer height
Standard quality
1.6mm walls (4 walls)
95% infill
Supports everywhere
Support blockers in small holes
No skirt, brim, or raft
Proper adhesion important





Stock Adapter (threaded)

Stock CURA profile settings 90% infill

0.2mm layer height

Standard Quality

Supports touching buildplate only

