

Cabin Safety & Environmental Guides

FlySmart reference document · Revision A

ATA 30 Ice & Rain Protection

De-icing hold-over time

Hold-over times depend on fluid type and OAT. For Type I fluid in light snow the range is approximately 6 to 11 minutes per the table; begin take-off within the hold-over window.

ATA 21 Air Conditioning / Pressurisation

Cabin pressure schedule

The cabin pressure controller schedules cabin altitude against aircraft altitude to keep the differential within limits; at cruise the cabin sits near 6,000–8,000 ft equivalent.

ATA 35 Oxygen

Passenger mask deployment

The passenger oxygen masks deploy automatically at a cabin altitude of approximately 14,000 ft, or can be deployed manually from the flight deck.

ATA 25 / 26 Cabin Equipment

Emergency lighting test

Select the EMER EXIT LT switch to ON and confirm all exit signs, floor path lighting and exterior lights illuminate, then return the switch to ARMED.

Cargo smoke detector test

Select the cargo SMOKE TEST; confirm the cargo SMOKE warning, the associated lights and the agent-armed indication, then release the test.

Cabin Safety & Environmental Guides (MOCK). For training/demonstration only.