# Fluid Mechanics

# Contents

1	Introduction	3
	1.1 Assessment	3
	1.2 Recommended Reading	3
<b>2</b>	Basic Characteristics of Fluids and Flows	4
	2.1 The Continuum Assumption	4
	2.2 Types of Problems	
3	Conservation Laws	5
4	Energy Balance	6
	4.1 Simplified Energy Balance - Bernoulli Equation	6
	4.2 Full Energy Balance for Incompressible Fluids	
5	Commercial Pipes	8
	5.1 Local (Minor) Viscous Losses	9

#### 1 Introduction

This module deals with using and understanding the conservation laws of mass, energy and momentum.

Lectures are recorded and will be uploaded to blackboard, along with slides, solved problems, and visualiser notes.

Office hours will be on Tuesday 10:00-12:00 in A122 Engineering Central. It is recommended to come to this if you have a problem as he is unlikely to reply to emails.

#### 1.1 Assessment

100% of the marks are from a final exam at the end of the year. In this exam:

- 35% is from multiple choice questions
- 25% is from a problem similar to those seen in class or in the excersises. This is again a multiple choice question with negative marks if you get the wrong answer
- 40% will be from an aditional question based on the taught material. This will be a standard question (e.g not multiple choice)

### 1.2 Recommended Reading

- Fluid Mechanics: Fundamentals and Applications YunusA. engel, John M. Cimbala, McGraw Hill
- Applied Fluid Mechanics: Global Edition Robert L. Mott, Joseph A. Untener, Pearsons

## 2 Basic Characteristics of Fluids and Flows

# 2.1 The Continuum Assumption

Fluids are considered a continuum on length scales larger than the molecular ones. For example, you can't measure individual water 'grains' until you look at the molecular level.

# 2.2 Types of Problems

Macroscopic - Deals with the overall flow (e.g amount of water entering and leaving a pipe)

Microscopic - Deals with a specific section of the flow (properties of the fluid flow within a small section of this pipe)

# 3 Conservation Laws

Mass

$$\frac{\delta V}{\delta t} = v_1 A_1 - v_2 A_2$$

Energy

$$\frac{1}{2}v_1^2 + gh_1 + \frac{p_1}{\rho} - \frac{1}{2}v_2^2 - gh_2 - \frac{p_2}{\rho} - l_v + \delta W_s = 0$$

Momentum

$$\rho Q_1 \vec{v_1} - \rho Q_2 \vec{v_2} + p_1 + A_1 - p_2 A_2 + \int_1^2 \rho g \delta V - \vec{F} = \vec{0}$$

# 4 Energy Balance

#### 4.1 Simplified Energy Balance - Bernoulli Equation

Bernoullis equations assumes there is no energy loss or gain in the system. There are six assumptions that have to be true for bernoullis equation to be applicable.

- 1. Uniform velocity profile
- 2. No frictional losses
- 3. No mechanical shaft work (so no pumps or turbines)
- 4. Steady state
- 5. Incompressible flow
- 6. No chemical reactions

$$e_{total} = e_{kinetic} + e_{potential} + e_{flow}$$

$$KE = \frac{1}{2}\rho V v^{2}$$

$$PE = \rho V hg$$

$$P = \rho gh$$

$$e_{flow} = PV$$

$$\frac{1}{2}\rho_1V_1v_1^2 + \rho_1V_1h_1g + P_1V_1 = \frac{1}{2}\rho_2V_2v_2^2 + \rho_2V_2h_2g + P_2V_2$$

$$\rho_1 = \rho_2 \text{ as incompressible fluid}$$

$$V_1 = V_2 \text{ mass conserved in closed system}$$

$$\frac{1}{2}\rho v_1^2 + \rho h_1 g + P_1 = \frac{1}{2}\rho v_2^2 + \rho h_2 g + P_2$$

#### 4.2 Full Energy Balance for Incompressible Fluids

The molecules of a fluid experience cohesive forces and collisions between each other. These are linked to viscosity, which leads to viscous energy losses in flows  $(l_v)$ . Work done by a shaft  $(W_s)$  is negative for a device that pulls energy out of the system, such as a turbine, and positive for a device that adds energy to the system, such as a pump.

$$\frac{1}{2}\rho v_1^2 + \rho h_1 g + P_1 - \frac{1}{2}\rho v_2^2 - \rho h_2 g - P_2 + \delta W_s - l_v = 0$$

In hydrostatic problems  $v_1 = v_2 = \delta W_s = l_v = 0$ . So,  $P_1 - P_2 = \rho g \Delta h$ . This is known as Stevino's Law.

# 5 Commercial Pipes

Real world pipes are not perfectly smooth, and have an amount of roughness on their inner diameter. This is very important when transporting fluids long distances as the frictional losses can be significant.

The roughness (k) of a pipe is the average difference in height between a trough and a peak on the interior wall of the pipe. The relative roughness is

Relative Roughness 
$$=\frac{k}{D}$$

where (D) is the inner diameter of the pipe.

There are several steps you should go through when evaluating the distribution of losses

- 1. Determine the Reynolds Number
- 2. Determine the relative roughness
- 3. Depending on the flow regime use the correct formula or use the Moody Chart
- 4. Use the correct formula to determine the friction factor
- 5. Evaluate the viscous losses

To calculate the reynold number we use the formula

$$Re = \frac{\rho v D}{\mu} \tag{1}$$

Where:

$$\mu = \text{Viscosity of the Fluid}$$

To calculate the friction factor (f) we can use two differet formulas, one for laminar flow (Re < 2100)

$$f = \frac{16}{Re}$$

And the Colebrook formula for turbulent flows  $(4000 < Re < 10^5)$ 

$$\frac{1}{\sqrt{f}} = 4log_{10} \left(\frac{k}{D} + \frac{4.67}{Re\sqrt{f}}\right) + 2.28$$

For (2100 < Re < 4000) this is the transition region, and no empirical relations are available to calculate the friction factor. We will not be dealing with any flows in this region.

To calculate the viscous losses we use

$$l_v = 2fv^2 \frac{L}{D}$$

## 5.1 Local (Minor) Viscous Losses

The equations only calculate the losses that occur in a straight pipe, however there's normally more to a system than just a straight pipe. Things like valves, corners, and junctions all create local viscous losses. These losses can be calculated using

$$l_v = \frac{1}{2}v^2 K_f$$

where  $(K_f)$  is a coefficient dependant on the cause of the local visocus loss. Values for  $(K_f)$  can be found in "Perry's Chemical Engineering Handbook" or in other similar manuals on fluid mechanics.