

Team 503

Configure the Android Phones

Frog Tech University, FRC Team 503 September 1, 2017


Course 102



The goal of todays session is to set up your Android phones to control your robot




New Point to Point Communication System
Pair of Android phones provide 'Wi-Fi Direct' Communication





Acknowledgement




Many of todays slides are based on the work of Team #2843 in the PushBot Build Guide Series and the FTC Training Manual

Many thanks for your efforts!!!!



Android Phone Set-up

7 Easy Steps !!!!



- 1. Remove the SIM Cards
- 2. Configure both phones
- 3. Install USB driver on Robot Controller
- 4. Update USB driver on Robot Controller
- 5. Deploy the Robot Controller
- 6. Deploy the Driver Station
- 7. Network Cleanup

If talking to a robot were this easy ...



Step 1 – Remove the SIM Cards

1. To prevent the phones from attempting connections to the Cell Phone network



- Power off both cell phones
- Remove the back covers leaving the phones face down
- There is a gap between the front and back covers located on the lower right hand corner of the device that can be used to remove the back cover.
- Inserting a fingernail all around the case will cause the case to pop apart.



Step 1 – Remove the SIM Cards

2. Remove SIM card



- The batteries are on the left and the SIM cards are on the right
- Gently push the SIM cards into the phone and release
- Pushing the SIM cards into the phone will activate the spring mechanism allowing the springs to push the SIM card out of the phone.
- Remove the SIM cards and put the min a safe place.
- · Replace the back covers




Step 1 – Remove the SIM Cards 3. Turn on Phones



- Turn the phones face up
- Turn the power on each phone by depressing the power button



1. Accept Default Talkback Setting



<u>Guide</u>

· Click 'Next' to accept default Talkback setting



2. Accept English



Guide

Click 'Next' to accept language default of 'English'



3. Configure WI-FI




<u>Guide</u>

Click 'Next' to accept WI-FI



4. Configure WI-FI



- Do not select a WI-FI connection at this time.
- · Click 'Next' to continue



5. Resolve UICC Error




<u>Guide</u>

- Ignore UICC Error
- · Click 'OK' to continue



6. Hands Free Activation






- When the Hands Free Activation first starts it shows the ability to make an emergency call, but this will change to the second screen on the right.
- · Click 'Activate' to continue



7. Failed Hands Free Activation



- The Hands Free Activation will fail as we have removed the SIM cards.
- · Click 'Done' to continue



8. Select Application Activity



<u>Guide</u>

- Android will return to the home screen.
- Select the application activity icon (shown in red circle)



9. Open Settings Activity



<u>Guide</u>

- Open the settings activity by selecting it's icon
- It may be necessary to swipe the screen left or right to find the icon.



10. Put phones into Airplane mode




<u>Guide</u>

• Slide the button from left to right until icon comes into view



11. Turn on WI-FI





<u>Guide</u>

• Slide the button from left to right until icon comes into view



12. Select WI-FI




<u>Guide</u>

· Click on the Wi-Fi button



12. Select WI-FI




Guide

• Select the overflow settings (three dots at bottom right)



Step 2 – Configure both phones 13. Select WI-FI Direct



Guide

Select Wi-Fi Direct



14. Select Rename Device



- If rename device is not shown at the bottom of the screen then select the overflow settings (three dots) and then select "Rename device"
- Note in the image to the left, the phone had already been renamed. New phones will have a generic name




14. Select Rename Device



- If rename device is not shown at the bottom of the screen then select the overflow settings (three dots) and then select "Rename device"
- Note in the image to the left, the phone had already been renamed. New phones will have a generic name




15. Rename Device



- Enter the new name according as follows:
 - The first portion of the name will be the team number
 - The driver station will have a suffix of -DS
 - The Robot Controller will have a suffix of -RC
 - Example:
 - 503-DS or 503-RC
- Click "Rename device" when ready



16. Confirm Rename Device




Guide

• Click "OK"



17. Return to Settings Activity






- From the page shown at the far left, return to the settings activity by pressing the back button.
- It may take several presses to return to the settings activity page.
- The page you are looking for is on the right labelled "Settings"




18. Find About Phone on the Robot Controller



- Select the Robot controller phone
- Scroll downward on the 'Settings' page until you find the 'About phone'



19. Enable Debugging Mode on the Robot Controller






- The 'About phone' page allows a developer to enable debugging.
- Scroll down until 'SW Version' is shown (right image)
 - On some Android phones the text says 'Build Number'
- Tap 'SW Version' 7 times
 - A toast (a message that is displayed for a short amount of time) should display as the number of taps increase and finally should indicate that debugging is enabled
 - From the page shown at the far left, return to the settings activity by pressing the back button.




20. Return to Settings Activity on the Robot Controller



- If Android hasn't already switched to the 'Settings' activity page, then do so now.
- Scroll to the bottom of the page and select 'Developer options'
 - Note: The developer options button is invisible until debugging is enabled!



21. Enable USB Debugging on the Robot Controller




<u>Guide</u>

Select the 'USB debugging' checkbox



22. Enable USB Debugging on the Robot Controller





- Select 'OK' to allow USB debugging between the phone and a computer when the phone is connected via USB to the computer hosting Android Studio.
- Note that the box has a check in it (right image)



Don't Give Up



Don't give up yet We are almost there ...



Step 3 – Install USB Driver on Robot Controller

1. Connect Computer to Robot Controller



- Power on your Robot Controller phone phone and get to the home screen (Where you can selet applications)
- Using the cell phones power cable (with the charging block removed so that one end is a USB connector) plug the USB connector into the USB port on the phone



Step 3 – Install USB Driver on Robot Controller

2. Select "Install Driver" on Phone




- Once you plug in the USB cable you will see the page on the left on your cell phone.
- Select "Install Driver" on phone



Step 3 – Install USB Driver on Robot Controller

3. Confirm Driver Install



- When the "Install Driver" is selected on the phone the computer will detect the connection.
- Confirm the computers prompt
- Note this will look very different on other versions of Windows



4. Confirm Driver Install

CD Drive (E:) USB_Driver

Choose what to do with this disc.

Install or run program from your media



Run AutoRun.exe
Published by ZTE CORPORATION

Other choices



Open folder to view files File Explorer



Take no action

- After confirming the prompt, another prompt will be displayed similar to the page at left.
- Click "Run AutoRun.exe"



5. Select Language



<u>Guide</u>

- Set language to "English" (Should be the default)
- Click "OK"



6. Confirm ZTE Driver Setup




Guide

Click "Next"



7. Confirm Install Location



- · Accept default install location for driver
- Click "Next"



8. Confirm Shortcut Location



- · Accept default install folder location
- Click "Next"



9. Install the Driver




Guide

Click "Install



10. Progress bar during install



Guide

• Fuel gauge displays install progress



11. Install Confirmation




Guide

Click 'Finish' to close install process

Congratulations you have installed the USB Driver!!!



1. Execute Device Manager on Windows PC



Guide


- Press the 'Windows' key
- Enter "device manager" in the search box and press "enter"

On Windows 7:

- Click on the Windows key
- Select Devices and Printers
- Select Android




2. select Update Driver Software



- Find 'Other devices' in device tree
- Click on 'Other devices'
- Right click on 'ADB Interface'
- Select 'Update Driver Software'
- On Windows 7:
 - Right Click on Android icon
 - Select Properties
 - Select Hardware tab
 - Select Properties
 - Click "Change Settings"
 - Select Driver Tab
 - Click "Update Driver"



3. Browse Computer for Driver Software




Guide

 Select "Browse my computer for driver software"



4. Pick Driver




Guide

 Select "Let me pick from a list of device drivers on my computer"




5. Enter Driver Location



- Ensure that the location is set to:
 - C:\Program Files\ZTE_Handset_USB_Driver
- Click "Next"



6. Driver Update Confirmation



Guide

- Windows confirms that the driver was updated correctly.
- · Click 'Close"

Congratulations you have Updated the USB Driver!!!



7. The Android Phone is now connected to the PC



- On The PC:
 - Note that the device is now connwcted
 - This window can be closed.
 - Click "X" in upper right hand corner




1. Start up Android Studio



- Go to the Windows Start Menu
- Click on "All Programs"
- · Locate the Android Studio folder, click to open folder
- · Select Android Studio application by clicking on it
- · You should see the start up screen on the left




1. Start up Android Studio



- Android Stuio will pick up where it left off by loading the FTC app-master project
- Find the green right arrow button (RUN) to run the application
- · Click "Run"




2. Allow USB Debugging



- On the Android phone
 - Note that the cell phone is now displaying the 'Allow USB debugging' window
 - Click 'OK'
- If you see 'Unauthorized' message on PC:
 - Click the OK on the Android phone Allow USB debugging message
 - Click 'Cancel' on the windows PC
 - Then Click 'Run' button again




3. Android Studio now shows an Android Device



- Android Studio has found the Robot Controller phone.
- Click 'OK' to download software



4. Application Starts on Robot Controller



Guide

 The Android phone will display the page at the left indicating that the application has started.

Congratulations you have a working FTC Robot Controller!!!



1. Open Application Activity




Guide

• Open the application activity page by selecting it's icon (red circle).



2. Open Settings Activity



- Open the settings activity page by selecting it's icon (red circle).
- Note: it may ne necessary to swiupe left or right until the icon comes into view



3. Click on "Wi-Fi"




<u>Guide</u>

 Click on the word "Wi-Fi", not the on-off button



4. Connect to External Internet Connection



- Connect to a Wi-Fi network that can reach the internet.
- Obtain Wi-FI logon information from host
- Once Provided , network will be shown at page at left.
- Select network and connect to the internet



5. Launch Google Play




Guide

- Return to Home Screen
- Launch Google "Play Store" (red circle)
- The Play store might prompt you for login information to an existing Google account or ask you to create one. Follow the on screen instructions.
- The Driver station app is free and no payment method is required.
- If a screen requests a credit card or other form of payment select the skip button.

Note: You will need to have a Google account to download the Driver station. If you don't already have an account you will need to create one. There is no charge or cost for this software.



6. Select Search



<u>Guide</u>

· Select the Search icon



7. Search for FTC Driver Station



Guide

 Enter 'FTC driver station' in the search text box



7. Search for FTC Driver Station



Guide

 Enter 'FTC driver station' in the search text box



8. Execute Search




Guide

 Press the magnifying glass in the bottom right corner of the keyboard to execute the search.



9. Select Driver Station




<u>Guide</u>

Select the FTC Driver Station block



Step 6 – Deploy the Driver Station 10. Install




<u>Guide</u>

· Select "Install"



Step 6 – Deploy the Driver Station 11. Accept



Guide

Select "Accept"



12. Return to Home Page



Guide

- Return to Home Screen
- Note the FTC Driver Icon has been installed!
- Important
 - You must delete (forgotten) the internet connection that you have setup on this device to prevent connection issues between the Driver Station and Robot Controller
 - Continue onto next steps

Congratulations you have a working FTC Driver Station!!!



1. Open Application Activity




Guide

• Open the application activity page by selecting it's icon (red circle).




2. Open Settings Activity



- Open the settings activity page by selecting it's icon (red circle).
- Note: it may ne necessary to swiupe left or right until the icon comes into view



3. Click on "Wi-Fi"




<u>Guide</u>

 Click on the word "Wi-Fi", not the on-off button



4. Select Wi-Fi Internet Connection




<u>Guide</u>

- Find the Wf-FI network that connects to the Internet
- Long hold the name of the network



5. Forget Wi-Fi Internet Connection



- Select 'Forget network'
- In general, the Driver Station and the Robot Controller cell phones should not be connected to any wireless networks with the exception of the 'Wi-Fi Direct' connection between the two cell phones.





Congratulations you have a working robot Communication environment!!!!!!





Questions?





What we are doing today will transform tomorrow's culture.

