Boeing 777-300

Checklists for FlightGear 2.4.0



Pre-Start Checklist

Parking brake SET
Throttle IDLE
Fuel flow CUTOFF

BATT switch ON
APU generator switch OFF
APU starter knob OFF

Bleed air valves ALL OFF

Gear lever CHECK DOWN

Flaps UP

Spoiler RETRACTED

Fuel quantity CHECK
Engine Instruments CHECK
De-ice/Aircraft lighting OFF

Flight controls FREE AND CORRECT Check Weather ATIS, Flight Services

De-Ice TEST/CHECK

Request Clearance

Beacon ON

Startup Checklist

Thrust levers
Engine area
Eng 1 starter switch
Fuel flow
N1 increasing as N2 incr.
Eng 2 starter switch
Fuel flow
CHECK
START
CHECK
START
CHECK
N1 increasing as N2 incr.
CHECK
CHECK
CHECK
CHECK

N1 increasing as N2 incr. CHECK

Oil pressure CHECK

De-ice AS REQUIRED

Before Taxi Checklist

Nav lights ON
Taxi lights ON
Altimeter SET
ADIRU ON

Standby instruments CHECK

Radios and avionics SET FOR DEPARTURE

Wipers CHECK

Autopilot SET, don't activate Autothrottle SET, don't activate

F/D ON Autobrake RTO

Elevator trim SET for T/O

Request Taxi Clearance

Taxi Checklist

Parking brake RELEASED

Brakes/Gyro/Turn coordinator CHECK during taxi and turns

Taxi to assigned runway SPEED Max. 20 knots

Before Take-off Checklist

Brakes SET Throttle IDLE

Flaps AS REQUIRED

Spoilers RETRACTED

Flight instruments CHECKED

Engine instruments CHECK

Takeoff data (V1, VR, V2) CHECK

Nav equipment CHECK Landing lights ON

Taxi lights ON Strobe light ON

De-ice AS REQUIRED

Request Takeoff Clearance

Take-off Checklist

Smoothly increase thrust to 40% N1 let spool up

Takeoff thrust FULL

Brakes RELEASE

V1 = 155 KIAS (descision) Vr = 160 KIAS (rotate) Pitch 10 deg. nose up

V2 = 165 KIAS (safety speed)

At Positive Climb Rate Touch Brakes

Landing gear RETRACT

At 190 KIAS RETRACT flaps to 1 deg

At 210 KIAS RETRACT flaps up

Climb-out Checklist

Throttle AS REQUIRED

Speed 250 KIAS

Autothrottle ARM and SET Autopilot ON and SET

Autobrake OFF

Below 10000ft max. speed 250 KIAS

ATC AS REQUIRED

Landing Lights OFF

Above 10000ft speed 280 KIAS

Cruise Checklist

At Transition Altitude (FL80) set Altimeter to 29.92inHg (1013mb)

Accelerate to cruise speed

FL180 0.67 mach FL240 0.75 mach FL280 0.80 mach FL330 0.84 mach

Engine instruments CHECK Fuel quantity CHECK

Radios TUNED and SET Lights AS REQUIRED

Descent Checklist

Atis/Airport Information CHECK

Altimeter CHECK

Radios SET

De-Ice AS REQUIRED

Descent Speed to FL240 0.75 mach

to FL180 0.65 mach to FL120 300 KIAS below 10000ft 240 KIAS

At Transition Altitude (FL80) reset Altimeter to local

Fuel quantities and balance CHECK
Flaps/Landing Gear CHECK UP

Check Weather (ATIS, Flight Services)

Approach Checklist

Localizer Level Flight

Avionics + Radios SET

Speed: Establish 210 KIAS

MFD EICAS
Landing Lights ON
Auto Spoilers ARM
Autobrake SET

Flaps 5-10 degrees Speed: Establish 180 KIAS

Flaps 20 degrees

Speed: Establish 160 KIAS

Landing Gear DOWN

Turning toward runway: set flaps 30 degrees or FULL

Final Glideslope Descent

Speed Establish
Park brakes
De-Ice
De-Ice
155 KIAS
VERIFY OFF
AS REQUIRED



http://arminair.tk/