

User Guide

Table of Contents

There are

Query Attributes

Table 3. NvPmApiQuery Output

NAME	ID	TYPE	HINT	PERF_DOMAIN	API_DOMAIN	

Table 5 lists the Simplified Experiments.

The counter name and unCounterID can be used to query additional counter attributes. CounterIDs are only guaranteed to be consecutive. The section [Enumerating Available Counters](#)

The caller is responsible to force CPU/GPU synchronize before calling EndObject. Failure to flush the work will result in an error from EndObject.

