



## 3.6 Coral Station

A total of 4 Coral Station Stations need to be built. The large weldment should be attached to the field during the construction of the field border.

## 3.6.1 Tools & Equipment (for 1x Coral Station)

2x 7/16" wrenches

10x 1/4-20 x 1" hex head bolts

6x 1/4-20 x 2.5" hex head bolts

8x 2-5/16" quick release pin

8x 1/4-20 Nylock nuts

40x 50lb cable ties

22x 120lb cable ties


## 3.6.2 Assembly


RESERVED BY FRESENTED BY FRESEN


















Slide the Chute Ramp Assembly onto the bottom set of flanges until it hits the weldment. Pin this in place with 1" long 1/4-20 hex head bolts into the PEM nuts in the Chute Ramp.



S SOLIDWORKS


Modeling Solutions Partner





PRESENTED BY -11445

firstinspires.org/robotics/frc











PRESENTED BY -4/14/15

firstinspires.org/robotics/frc











PRESENTED BY -///45

firstinspires.org/robotics/frc









Attach the Kickstands to the structure with pins. Make sure that the bottom of the kickstand is resting flat against the floor.

Southwest Southwest Modeling Solutions Partner

