





4 Practice Field



This is the recommended layout for the Practice Field, spacing the Reef, Processor, Coral Station and Barge apart to deter teams from testing multiple game piece autonomous routines. This layout intentionally does not space field elements apart in a representative orientation to the playing field. See the Practice Field Attendant Instructions for more information about running the practice field.







4.1 Practice Field Coral Station

A total of 1 Practice Field Single Coral Station needs to be built.

4.1.1 Tools & Equipment

- 7/16" Wrenches/Sockets
- 4x 1.5" 1/4-20 Hex Head Bolts
- 4x 1/4-20 Wingnuts
- 30x 120lb Cable Ties

4.1.2 Assembly










firstinspires.org/robotics/frc


2.




























4.2 Practice Field Processor

A total of 1 Practice Field Processor needs to be built.

4.2.1 Tools & Equipment

- 7/16" Wrenches/Sockets
- 4x 1" 1/4-20 Hex Head Bolts
- 4x 1/4-20 Wingnuts
- 16x 120lb Cable Ties


4.2.2 Assembly


















PRESENTED BY -1/14-5

4. ID 3 Fasten AprilTag ID 3 to the assembly using 1" ¼-20 Hex Head bolts and ¼-20 wingnuts. S SOLIDWORKS **Modeling Solutions Partner**





4.3 Practice Field Barge

A total of 1 Practice Field Barge needs to be built.

4.3.1 Tools & Equipment

- 50lb cable ties
- 3/4" wrenches/sockets
- 7/16" wrench/sockets
- 4x 1/4-20 x 2" hex head bolts
- 4x 1/4-20 x 1.5" hex head bolts
- 4x 1/4-20 x 1" hex head bolts
- 4x 1/4-20 wing nuts
- 1x 1/2-13 x 1.25" hex head bolt
- 2x 1/2" washers
- 1x 1/2" nylock nut

4.3.2 Assembly

1.





Building the PF Barge










Apply 2x strips of hook tape to the bottom of each of the 4 brace assemblies.


















It can be easier to perform this step with the structure angled down so that the end of the Beam is resting on the ground.



5.



Using 6x 1/4-20 x 2" hex bolts and wing nuts, installed the remaining Upright Assembly as shown.





SOLIDWORKS

Modeling Solutions Partner






6.

Using 4x 1/4-20 x 2" hex bolts and wing nuts, fasten the Small Endcap to the inside of 1x of the Upright Assemblies with the bolt heads towards the inside as shown.






presented by Qualcomm


FIRST® DIVESM





8.













10


Using 50lb cable ties, install the Net on the top of the assembly. The cable ties should fasten to the Net Pipes and the pairs of holes in the Endcaps.



During the installation process, tension the net to maintain the gap between the bottom of the net and the top of the Beam to 2" as shown above. Tension can be adjusted by installing more cable ties or using openings in the net further from the edge to "gather" the net.




11



Using 2x 1/4-20 x 1-1/2" hex bolts and 2x wing nuts, install the LH & RH AprilTag Brackets onto either side of one of the Endcaps as shown.

Ensure the orientation of the brackets matches this image.



S SOLIDWORKS


Modeling Solutions Partner







12




Using 2x 1/4-20 x 1" hex bolts and 2x wing nuts, install the AprilTag panel with ID 5 onto the brackets. Ensure that the tag is upright using the text printed on it.



13

Install the Eye Nut on the bottom of the Beam using 1x 1/2-13 x 1-1/4" hex bolt. Use the access window in the side of the Beam to install the bolt.











14




Using 1x 1/2-13 nylock nut and 2x 1/2" washers, install the Eye Bolt on the top of the Cage.



The number of washers can be adjusted to calibrate the height of the Cage from the floor if needed later.



15



Using the Chain and 2x Carabiners, hang the Cage from the Eye Nut on the Beam. The Cage can be changed between the "deep" and "shallow" configurations during practice by removing the chain and 1x carabiner.








4.4 Practice Field Reef

4.4.1 Tools & Equipment

- 2x 7/16" wrenches
- 10x ¼-20 x 1" hex head bolts
- 14x ¼-20 x 1" counter sunk Phillips (#3) bolts
- 8x ¼" x 2.3125" quick pull pins
- 2x 1/4"-20 Wingnuts

4.4.2 Assembly

1.




Modeling Solutions Partner









Fasten two sections of the reef to the anchor plate with bolts. It is recommended to set these reef sections on a sheet of HDPE while fastering them to prevent the hook tape from engaging with the carpet until they are fixed.

1" 1/4-20 hex head bolt

Ax


SoliDworks


Modeling Solutions Partner

Modeling Solutions Partner



















7. 2x 1" 1/4-20 Wingnut 1" 1/4-20 hex head bolt Attach AprilTag ID 6 to the structure with the hardware shown. **ÓS SOLID**WORKS **Modeling Solutions Partner**

PRESENTED BY -4/4/45

firstinspires.org/robotics/frc

