



SOP-400 — Complete PPF Installation Workflow

Section 5: Paint Protection Film

SOP · Version 1.0

Organization: _____

Document ID: sop-400-complete-ppf-installation-
workflow

Effective Date: _____

Approved By: _____

SOP-400 — Complete PPF Installation Workflow

Forge Standard Operating Procedures v1.0

Section 5: Paint Protection Film

Purpose

End-to-end procedure for paint protection film from surface prep through edge sealing.

Scope

All PPF services — partial, full front, track, and full body. Follow PPF Master Install Manual for panel specifics.

Procedure

Pre-install

1. Complete SOP-200 through SOP-204.
2. Confirm paint correction completed if required and approved.
3. Pull patterns; verify kit completeness against coverage map.

Surface prep

1. SOP-201 wash → SOP-202 decon on all panels receiving film.
2. Final IPA wipe panel-by-panel immediately before each piece.
3. Never apply dressing before or during install.

Film application

1. Spray slip solution on panel and adhesive side of film.
2. Position; anchor hinge or center tack per panel geometry.
3. Squeegee with overlapping strokes; evacuate all solution.
4. Wrap edges; post-heat 90–120°C per film spec using IR thermometer.

Complex areas

1. Bumpers and mirrors: relief cuts only per manual — no freehand slashing.
2. Sensors and ADAS: follow manual clearance zones; recalibrate if disturbed.
3. Seams: overlap 3mm minimum where double-layer required.

QC

1. Complete SOP-205 and SOP-206.
2. Document install with photos for warranty file.

Quality standards

- ☐ No visible fingers, contamination, or edge lift at delivery
- ☐ Post-heat logged on work order for full-front and above

Related documents

Document	ID
PPF Master Install Manual	ppf-master-install
PPF Workbook	ppf-workbook
PPF Package Pricing Guide	ppf-pricing-guide

Revision history

Version	Date	Author	Changes
1.0	2026-07-23	Forge Operations	Initial release

Confidential — Skill Forge training operations.