Scilab Textbook Companion for Electronic Communication Systems: Fundamentals Through Advanced by W. Tomasi¹

Created by
Harish Shenoy
B.Tech
Electronics Engineering
NMIMS University
College Teacher
No Teacher
Cross-Checked by
Lavitha Pereira

July 11, 2017

¹Funded by a grant from the National Mission on Education through ICT, http://spoken-tutorial.org/NMEICT-Intro. This Textbook Companion and Scilab codes written in it can be downloaded from the "Textbook Companion Project" section at the website http://scilab.in

Book Description

Title: Electronic Communication Systems: Fundamentals Through Advanced

Author: W. Tomasi

Publisher: Pearson/Prentice Hall

Edition: 3

Year: 2003

ISBN: 9780130494924

Scilab numbering policy used in this document and the relation to the above book.

Exa Example (Solved example)

Eqn Equation (Particular equation of the above book)

AP Appendix to Example(Scilab Code that is an Appednix to a particular Example of the above book)

For example, Exa 3.51 means solved example 3.51 of this book. Sec 2.3 means a scilab code whose theory is explained in Section 2.3 of the book.

Contents

Lis	ist of Scilab Codes	
1	Introduction to Electronic Communciations	5
2	Signal Analysis and Mixing	22
3	Oscillator Phase Locked Loops and Frequency Synthesizer	23
4	Amplitude Modulation Transmission	27
5	Amplitude Modulation Reception	38
6	Single Sideband Communication Systems	47
7	Angle Modulation Transmission	53
8	Angle Modulation Reception and FM Stereo	66
9	Digital Modulation	70
10	Digital Transmission	74
12	Metallic Cable Transmission Media	7 9
13	Optical Fiber Transmission Media	86
14	Electromagnetic Wave Propagation	92
15	Antennas and Waveguides	95

17 The Telephone Circuit	104
19 Cellular Telephone Concepts	106
20 Cellular Telephone Systems	110
24 Microwave Radio Communications and System Gain	112
25 Satellite Communication	118

List of Scilab Codes

Exa 1.1	Convert the absolute power ratio of 200 to a power gain	۲
T 4.0	in dB	5
Exa 1.3	Convert the following absolute powers to dBm	6
Exa 1.4	Convert the following into absolute power	6
Exa 1.5	Determine The input power in dBm output power in watts and dBm the dB gain of each of the three stages	—
.	and the overall gain in dB	7
Exa 1.6	Find the overall of the threestage system in dB the out-	
	put power of the system in dBm for an input power of	
	100uW	9
Exa 1.7	Determine the total power when a signal with a power	
	level if 20dBm is combined with a second signal of with	
	a power level of 21dBm	10
Exa 1.8	Determine the corresponding wavelength ranges for the	
	following ITUT specified frequenny bands Medium Fre-	
	quenices Ultra High Frequenices Very High Frequencies	11
Exa 1.9	Determine the Shannon limit for information capacity	12
Exa 1.10	Convert the following temperatures in kelvin	13
Exa 1.11	Determine thermal noise power in watts and dBm rms noise voltage for 100 ohm internal resistance and 100	
	ohm load resistance	13
Exa 1.12	Determine 2nd 3rd and 12th Harmonics for a 1kHz re-	
	peative wave percent second order third order and total	
	harmonics distortion	14
Exa 1 13		
1.10		
		16
Exa 1.13	Determine first three harmonics present in the output for each input frequency cross product frequencies produced for value m and of 1 and 2	16

Exa 1.14	Determine the information carrying capacity of a com- munication channel if the bandwidth of the channel is	
	100MHz and signal to noise ratio is 30dB and signal to	
	noise ratio is increased by 4 times over 30dB	16
Exa 1.15	Determine the signal to noise power ratio	17
Exa 1.16	Determine Input SN ratio Output SN ratio Noise factor	
	and noise figure	18
Exa 1.17	Determine the total noise figure	20
Exa 1.18	Determine noise figure for an equivalent noise temper-	
	ature of 75 K and equivalent noise temperature for a	
	noise figure of 6dB	20
Exa 2.3	Determine the dc component the peak amplitude of the	
	10 harmonics plot the sin x by x function sketch the	
	frequency spectrum	22
Exa 3.1	Determine the frequency of operation if the temperature	
	increases by 10 degree C decreases by 5 degree C \dots	23
Exa 3.2	Determine PLL open loop gain change in VCO frequency	
	necessary to achieve lock PLL output voltage phase de-	
	tector output voltage static phase error	24
Exa 4.1	Determine frequency limits for the upper and lower side-	
	bands bandwidth upper and lower side frequencies pro-	
	duced when the modulating signal is a single frequency	
	3kHz tone draw the frequency spectrum	27
Exa 4.2	Determine upper and lower frequencies modulation co-	
	efficient and percent modulation peak amplitude of the	
	modulation carrier and the upper and lower side fre-	
	quency voltages maximum and minimum amplitudes of	
.	the envelope	29
Exa 4.3	Obtain the total average power of the modulated signal	
	in dB watts and dBm the peak and RMS voltages of the	0.1
D 4.4	modulated signal	31
Exa 4.4	Determine 1 power of the carrier and the upper and	
	lower sidebands 2 total sideband power 3 total power of	20
D 4 F	the modulated wave 4 change m for 1 to 3	32
Exa 4.5	Find the power in each sideband of a DSBFC signal .	34
Exa 4.6	Determine 1 maximum and minimum voltage gains 2 maximum and minimum amplitude for Vout	35
	- maximum and minimum ambiliade for volle	

Exa 4.7	Determine carrier frequency AND upper and lower side frequencies	36
Exa 5.1	Determine the improvement in the noise figure for a receiver with an RF bandwidth equal to 200kHz and an IF bandwidth equal to 10kHz	38
Exa 5.2	Determine the bandwidth at the low and high ends of RF spectrum	39
Exa 5.3	Determine the IF carrier upper side frequency and lower side frequency	39
Exa 5.5	Determine 1 image frequency 2 image frequency rejection ratio for a Q of 120 for the tuned circuit in the preselector of the receiver 3 IFRR if the preselector of 2 is followed by another RF tuned of IFR	40
Exa 5.6	Determine 1 local oscillator frequency 2 image frequency 3 IFRR for a preselector Q of 160 4 preselector Q required to achieve the IFRR as that achieved for an RF carrier of 600kHz	42
Exa 5.7	Calculate 2 IFRR 2 IFRR in dB 3 IFRR for an IF of 455kHz 4 Q of primary and secondary circuit of the IF transformer is 40 and 50 so find critical coupling factor	43
Exa 5.8 Exa 6.1	Determine the net receiver gain and the audio signal level Determine the quality factor necessary for a single side- band filter with a 1MHz carrier frequency 80dB un- wanted sideband suppression and the following frequency	45
Exa 6.2	spectrum Determine demodulated first IF frequency band and demodulated information frequency band and demodulated information frequency band if the RF local oscillator frequency drift	48
Exa 6.3	Determine the demodulated first IF frequency band and demodulated information frequency band and demodulated information frequency band	49
Exa 6.4	Determine for a single sideband suppressed carrier transmission the output frequency spectrum and a load resistance and the PEP and average power	51
Exa 7.1	Determine 1 the peak frequency deviation and modula- tion index for an FM modulator 2 the peak phase devi-	
	ation for a PM modulation	53

Exa 7.2	Determine 1 carrier frequency 2 modulation frequency	
	3 modulation index 4 peak phase deviation	54
Exa 7.3	Determine 1 Number of sets of significant side frequenices	
	2 Amplitude of the frequencies 3 Draw the spectrum .	55
Exa 7.4	Determine 1 actual minimum bandwidth from the Bessel	
	function table 2 approximate minimum bandwidth us-	
	ing Carsons rule 3 plot the output frequency spectrum	
	for the Bessel approximation	56
Exa 7.5	Determine the deviation ratio and bandwidth for 1 the	00
LAG 1.0	worst case modulation index 2 an equal modulation index	58
Exa 7.6	Determine 1 the modulation indexes and sketch the out-	90
Exa 1.0	put spectrum 2 change the modulating signal amplitude	
	to 4Vp for 1 3 change the modulating signal frequency	
	to 1kHz for 1	59
E 77		59
Exa 7.7	Determine 1 the unmodulated carrier power for the FM	<i>C</i> 1
D . 70	modulator 2 the total power in the angle modulated wave	61
Exa 7.8	Determine 1 frequency of the demodulated interference	
	signal 2 peak phase and frequency deviations due to the	
	interfering signal 3 voltage signal to noise ratio at the	00
D = 44	output of the demodulator	62
Exa 7.11	Determine 1 master oscillator centre frequency 2 fre-	
	quency deviation at output for a frequency deviation of	
	75kHz at antenna 3 deviation ratio for fm 4 deviation	
	ratio of antenna	64
Exa 8.1	Determine the peak output voltage	66
Exa 8.2	Determin the minimum receive carrier power necessary	
	to achieve a postdetection signal to noise ratio 37dB .	67
Exa 8.3	Determine the pre and postdetection SN ratios	68
Exa 8.4	Determine the minimum receive signal level	68
Exa 9.2	Determine the peak frequency deviation minimum band-	
	width baud rate for a binary FSK signal	70
Exa 9.3	Determine the minimum bandwidth for the FSK signal	71
Exa 9.15	Determine the minimum bandwidth required	72
Exa 10.1	Determine the largest value capacitor that can be used	
	in figure	74
Exa 10.3	Determine the quantized voltage quantization error and	
	PCM code	75

Exa 10.4	Calculate 1 the resolution and quantization error 2 the	
	coding efficiency for a resolution	76
Exa 10.8	Determine the minimum line speed in bits per second	
	to transmit speech signal of 1 a 7 bit PCM 2 an 8 bit	
	PCM	77
Exa 12.1	Determine the characteristic impedance for an air di-	
	electric two wire parallel transmission line	79
Exa 12.2	Determine the characteristic impedence for coaxial cable	80
Exa 12.3	Charecteristic impedence for RG-59A coaxial cable	80
Exa 12.4	Determine the velocity of propagation and the velocity	
	factor	81
Exa 12.5	Determine reflection coefficient and SWR	82
Exa 12.6	Determine the physical length and characteristic impe-	
	dence for a quarter wavelength transformer	83
Exa 12.7	How far down the cable is the impairment	84
Exa 12.8	Determine the time elapsed from the beginning of the	-
-	pulse to the reception of the echo	84
Exa 13.1	Determine the angle of refraction	86
Exa 13.2	Calculate the refractive index of the cladding	87
Exa 13.3	Calculated the optical power	88
Exa 13.4	Calculate the maximum data rate through a 6 km long	
	step index fibre	88
Exa 13.5	Determine the maximum digital transmission rates for	
	return to zero and nonreturn to zero	89
Exa 13.6	Determine th optical power received in dBm and watts	90
Exa 14.1	Determine power density from source at 1000m and 2000m	92
Exa 14.2	Determine the height of the receiving antenna and the	-
	maximum transmission distance	93
Exa 14.3	Determine the fade margin	94
Exa 15.1	Determine antenna efficiency antenna gain radiated power	-
	in watts dBm dBW and EIRP in watts dBm dBW	95
Exa 15.2	Determine the antenna input radiated power EIRP and	
211a 10.2	receive power density	97
Exa 15.3	Determine captured power in dBm and watts	99
Exa 15.4	Determine beamwidth transmit and receive power gain	
2100 10.1	and EIRP	100
Exa 15.5	Determine Cutoff frequency and wavelength group and	100
2110 10.0	phase velocity	101
	processing the contract of the	- U -

Exa 15.6	Determine the cutoff frequency and the characteristic of	
	TE10	103
Exa 17.1	Determine the power level in dBm and the difference	
	between them	104
Exa 19.1	Determine the number of channels per cluster and total	
	channel capacity	106
Exa 19.2	Determine for a cell area	107
Exa 19.3	Determine the following	108
Exa 20.1	Determine the transmit and receive carrier frequencies	
	for AMPS channels 3 and 91	110
Exa 20.2	Determine the transmit power for a CDMA	111
Exa 24.1	Determine the free space path loss in dB	112
Exa 24.2	Determine the frequency of operation of the microwave	
	link	113
Exa 24.3	Determine the noise power	114
Exa 24.4	Determine the minimum receive carrier power and the	
	minimum transmit power	115
Exa 24.5	Determine the following	115
Exa 25.2	Determine the energy per bit for a transmission rate of	
	50Mbps	118
Exa 25.5	Determine the noise density and equivalent noise tem-	
	nerature	119

Chapter 1

Introduction to Electronic Communciations

Scilab code Exa 1.1 Convert the absolute power ratio of 200 to a power gain in dB

```
1 clc
2 //Example 1.1
3 //Page no 6
5 //Solution
  disp("Substituting into Eq 1.3 (ref pg no 4) yeilds,
     ");
9 ap=10*log10(200); //absolute power ratio in dB
10
11 disp('dB',ap,"The absolute power ratio is:");
12
  //ab solute ratio: 200 = 100 \times 2"
13
14
15 disp("Applying the product rule for logarithms, the
     power gain in dB is:");
16
```

```
17 Ap=10*log10(100)+10*log10(2); //power gain in dB
18
19 //Result
20 disp('dB',Ap,"The power gain is, ")
```

Scilab code Exa 1.3 Convert the following absolute powers to dBm

```
1 clc;
2 //Example 1.3
3 //Page no 8
5 //Solution
7 //(a)
9 dBm1=10*log10([500*(10^-3)]/[1*(10^-3)]);
10
11 disp('dBm', dBm1, ''(a)) 500 mW in dbm = ");
12
13 //(b)
14
15 dBm2=10*log10([10*(10^-9)]/[1*(10^-3)]);
16
17 disp('dBm', dBm2, "(b)) 10 nW in dbm = ");
18
19 //(c)
20
21 dBm3=10*log10([100*(10^-6)]/[1*(10^-3)]);
22
23 disp('dBm', dBm3, "(c) 100 uW in dbm = ");
```

Scilab code Exa 1.4 Convert the following into absolute power

```
1 clc;
 2 //Example 1.4
 3 //Page no 8
5 // Solution
7 //(a)
 9 p1=(10^-2.7)*(10^-3);
11 disp('W', p1,"-27dBm in absolute power is, ");
12
13 //(b)
14
15 p2=(10^1.3)*(10^-3);
17 disp('W', p2,"13dBm in absolute power is, ");
18
19 //(c)
20
21 p3 = (10^4) * (10^-3);
22
23 disp('W', p3,"40dBm in absolute power is, ");
24
25 // (d)
26
27 p4 = (10^{-5.3}) * (10^{-3});
28
29 \operatorname{disp}(\mathrm{W'}, \mathrm{p4}, \mathrm{"-53dBm} \ \mathrm{in} \ \mathrm{absolute} \ \mathrm{power} \ \mathrm{is}, \mathrm{"});
```

Scilab code Exa 1.5 Determine The input power in dBm output power in watts and dBm the dB gain of each of the three stages and the overall gain in dB $^{\circ}$

```
1 clc;
```

```
2 //Example 1.5
3 //Page no 9
5
6
7 pin=0.1*(10^-3);
8 \text{ ap1}=100;
9 \text{ ap2=40};
10 ap3=0.25;
11
12 // Solution
13
14 //(a)
15
16 disp("(a) The input power in dBm ");
17
18 Pin=10*log10(pin/0.001);
19
20 disp('dBm', Pin, "The input power in dBm is, ");
21
22 //(b)
23
24 disp("(b) The output power is simply the input power
      multiplied by the three power gains: ");
25
26 Pout=(pin)*ap1*ap2*ap3;
27
28 Pout1=10*log10(Pout/0.001);
29
30 disp('dBm', Pout1, 'W', Pout," The output power in watts
       and dBm is ,");
31
32 //(c)
33
34 disp("(c)The decibel value for the three gains are
      determined by substituting into equation 1-3 (
      Pgno 4)");
35
```

```
36 \text{ Ap1}=10*\log 10 \text{ (ap1)};
37
38 disp('dB', Ap1, "Ap1 = ");
39
40 Ap2=10*log10(ap2);
41
42 disp('dB', Ap2, "Ap2 = ");
43
44 Ap3=10*log10(ap3);
45
46 disp('dB', Ap3, "Ap3 = ");
47
48 // (d)
49
50 disp("(d)The overall power gain in dB (Apr) can be
      determined by simply adding the individual dB
      power gains, ");
51
52 \text{ Apr} = \text{Ap1} + \text{Ap2} + \text{Ap3};
53
54 disp('dB',Apr,"Apr = ");
55
56 disp("The output power in dBm is the input power in
      dBm plus the sum of the gains of the three stages
      : ");
57
58 Pout2=Pin+Apr;
59
60 disp('dBm', Pout2, "Pout = ");
```

Scilab code Exa 1.6 Find the overall of the threestage system in dB the output power of the system in dBm for an input power of 100uW

```
1 clc;
2 //Example 1.6
```

```
//Page no 10
4
5
6
7 //Solution
  //(a)
9
10
11 a = 100 * 5
12
13 disp(a,"(a) Overall gain of the system is the product
       of the individual gain, that is ");
14
15 ap=10*log10(a);
16
17 disp('dB',ap,"Thus, the overall gain in dB is,")
18
19 //(b)
20
21 b = [100*(10^-6)]*500;
22
23
  disp('W',b,"(b)Output power = Input power to the
      system X Overall power gain, that is ")
24
25 bp=10*log10(b/[1*(10^-3)]);
26
27 disp('dBm', bp," Therefore, Output power expressed in
      dB is , ");
```

Scilab code Exa 1.7 Determine the total power when a signal with a power level if 20dBm is combined with a second signal of with a power level of 21dBm

```
1 clc;
2 //Example 1.7
```

```
3 // Page no 11
4 // Solution
5
6 a=21+2.5;
7
8 disp('dBm',a,"The difference in the two power levels
    is 1 dB. Therefore, from table 1-5, the
    combining term is 2.5 dB and the total power is,
    ");
```

Scilab code Exa 1.8 Determine the corresponding wavelength ranges for the following ITUT specified frequency bands Medium Frequences Ultra High Frequences Very High Frequences

```
1 clc;
2 //Example 1.8
3 //Page no 17
  //Solution
  //Refer to figure 1-5 on page no 17
9
  //(a)
10
  disp("(a) Medium Frequencies as per ITU-T range
11
      between 0.3MHz and 3MHz.");
12
13
  lm1 = ([3*(10^8)]/[0.3*(10^6)]);
14
  lm2 = ([3*(10^8)]/[3*(10^6)]);
15
16
  disp('m',lm2, 'and', 'm',lm1," Therefore, wavelengths
17
      range for MF are between ");
18
19 //(b)
```

```
20
21 disp("(b) Ultra High Frequencies as per ITU-T range
      between 300MHz and 3GHz.");
22
23 lm3 = ([3*(10^8)]/[300*(10^6)]);
24
25 \quad lm4 = ([3*(10^8)]/[3*(10^9)]);
26
  disp('m',lm4, 'and', 'm',lm3," Therefore, wavelengths
27
      range for UHF are between ");
28
  //(c)
29
30
31 disp("(c) Very High Frequencies as per ITU-T range
      between 30MHz and 300Mz.");
32
33 lm5 = ([3*(10^8)]/[30*(10^6)]);
34
35 \ lm6 = ([3*(10^8)]/[300*(10^6)]);
36
37 disp('m', lm6, 'and', 'm', lm5," Therefore, wavelengths
      range for VHF are between ");
```

Scilab code Exa 1.9 Determine the Shannon limit for information capacity

```
1 clc;
2 //Example 1.9
3 //Page no 20
4
5
6
7 //Solution
8
9 disp("The Shannon limit for capacity is determined")
```

```
by substituting into equation 1-12b");
10
11 I=(3.32)*(2700)*log10(1+1000);
12
13 disp('bps',I);
```

Scilab code Exa 1.10 Convert the following temperatures in kelvin

```
1 clc;
2 //Example 1.10
3 //Page no 22
4
5 //Solution
6
7 disp("The formula T = C+273 is used to convert degree C into Kelvin.");
8
9 T1=100+273;
10 T2=0+273;
11 T3=-10+273;
12 disp('K',T1,"(a) ");
14 disp('K',T2,"(b) ");
15 disp('K',T3,"(c) ");
```

Scilab code Exa 1.11 Determine thermal noise power in watts and dBm rms noise voltage for 100 ohm internal resistance and 100 ohm load resistance

```
1 clc;
2 //Example 1.11
3 //Page no 24
4
5 //Solution
```

```
6
7 R = 100;
9 T=17+273;
10
11 N = ([1.38*(10^-23)]*[T]*[1*(10^4)]);
12
13 disp(W',N,"N = ");
14
15 disp("Substituting in equation 1-16 (refer pgno 23)
      give the noise power in dBm: ");
16
17 N1 = -174 + [10 * log10 (10000)];
18
19 disp('dBm', N1, "N = ");
20
21 //(b)
22
23 disp("(b) The rms noise voltage is found by
      substituting into equation 1-17 (refer pgno 23):
      ");
24
25 \ V = sqrt (4*R*N);
26
27 \text{ disp}('V',V,"Vn = ");
```

Scilab code Exa 1.12 Determine 2nd 3rd and 12th Harmonics for a 1kHz repeative wave percent second order third order and total harmonics distortion

```
1 clc;
2 //Example 1.12
3 //Page no 25
4
5
```

```
6 // Solution
8 V1=8;
9 V2 = 0.2;
10 \quad V3 = 0.1;
11
12 / (a)
13
14
15 h1 = 2 * 1;
16
17 disp('kHz',h1,"2nd harmonic = ");
18
19 h2=3*1;
20
21 disp('kHz',h2,"3rd harmonic = ");
22
23 h3=12*1;
24
25 disp('kHz',h3,"12th harmonic = ");
26
27 //(b)
28
29 disp("(b) ")
30
31 p1=(V2/V1)*100;
32
33 disp('\%',p1,"\%2nd order = ");
34
35 p2=(V3/V1)*100;
36
37 disp('\%',p2,"\%3nd order = ");
38
39 THD=([sqrt((0.2^2)+(0.1^2))]/8)*100;
41 \operatorname{disp}('\%', \operatorname{THD}," \operatorname{Total harmonic distortion} = ");
```

Scilab code Exa 1.13 Determine first three harmonics present in the output for each input frequency cross product frequencies produced for value m and of 1 and 2

```
1 clc;
2 //Example 1.13
3 //Page no 26
4
5 //Theory
```

Scilab code Exa 1.14 Determine the information carrying capacity of a communication channel if the bandwidth of the channel is 100MHz and signal to noise ratio is 30dB and signal to noise ratio is increased by 4 times over 30dB

```
1 clc;
2 //Example 1.14
3 // Page no 27
5
  //solution:
8 //(a)
9 disp("Given B=100MHZ, S/N=30dB = 1000");
10
11
12
13 B = (100 * (10^6));
14
  Sn = 1000;
15
16 I=3.32*B*log10(Sn+1);
17
```

```
18 disp('bps',I,"I = ");
19
20 //(b)
21
22 disp("(b) If the SNR is increased by 4 times, the new ")
23
24 SNR=Sn*4;
25
26 disp(SNR,"SNR = ");
27
28 i=3.32*B*log10(SNR+1);
29
30 disp('bps',i,"Therefore, the new information carrying capactiy is ")
```

Scilab code Exa 1.15 Determine the signal to noise power ratio

```
1 clc;
2 //Example 1.15
3 //Page no 28
4
5
6 //solution
7
8 v1=4;
9
10 v2=0.005;
11
12
13
14 sn=20*log10(v1/v2);
15
16 disp('dB',sn,"S/N = ");
```

 ${f Scilab\ code\ Exa\ 1.16}$ Determine Input SN ratio Output SN ratio Noise factor and noise figure

```
1 clc;
 2 //Example 1.16
3 //Page no 30
 5
 6 disp("Given: For a non ideal amplifier and the
       following parameters ");
7 disp("Input signal power = 2 \times 10^{-10} \text{ W}");
8 disp("Input noise power = 2 \times 10^{-18} \text{ W}");
9 disp("Power Gain = 1 \times 10^6");
10 disp("Internal noise = 6 \times 10^{-12} \text{ W}");
11
12 // Solution
13
14 \text{ ip=2*(10^-10)};
15
16 in=2*(10^-18);
17
18 G=1*(10^6);
19
20 \text{ Nd} = 6*(10^-12);
21
22 //(a)
23
24
25
   sn=(ip/in);
26
27 \text{ SN} = 10 * \log 10 (\text{round}(\text{sn}));
28
29 disp('dB', round(SN), "S/N =");
30
```

```
31 / (b)
32
33 disp("(b) The output noise power is the sum of the
      internal noise and the amplified input noise,
      therefore ");
34
35 \text{ No}=(G*in)+Nd;
36
37 disp('W', No, "Nout = ");
38
39 disp("The output power is simply the product of the
      input power and the power gain. ");
40
41 Po=G*ip;
42
43 disp('W', Po, "Pout = ");
44
45 disp("For the output signal and noise power levels
      calculated and substituting in equation 1-22, the
       output S/N is ");
46
47
  sn1=(Po/No);
48
49 SN1=10*log10(round(sn1));
50
51 disp('dB',round(SN1),"S/N = ");
52
53 //(C)
54
55 disp("(c)The noise factor is found by substituting
      the result from step (a) and (b) into equation
      1-25 ");
56
57 F=([round(sn)]/[round(sn1)]);
59 \text{ disp}(F, "F = ");
60
61 disp("and the noise figure is calculated from
```

```
equation 1-26(refer pgno 25) ");
62
63 NF=10*log10(round(F));
64
65 disp('dB',round(NF),"NF = ");
```

Scilab code Exa 1.17 Determine the total noise figure

```
1 clc;
2 //Example 1.17
  //Page no 31
3
5
  //solution
8
9
10
  ft=2+((2-1)/10)+([2-1]/100);//Noise factor
12
  disp(ft,"Ft = ")
13
14
15
  disp("Thus, the total noise figure is");
16
17 nft=10*log10(ft);
18
19 disp('dB',nft,"NFt = ")
```

Scilab code Exa 1.18 Determine noise figure for an equivalent noise temperature of 75 K and equivalent noise temperature for a noise figure of 6dB

```
1 clc;
2 //Example 1.18
```

```
3 //Page no 33
5 //solution
7 //(a)
9 Te=75;
10
11 T = 290;
12
13
14
15 f=1+(Te/T); // Noise factor
16
17 disp(f, "F = ");
18
19 nf = 10 * log 10 (f);
20
21 disp('dB', round(nf), "NF = ");
22
23 //(b)
24
25 disp("(b) Noise factor is found by rearranging
       equation 1-26 ");
26
27 F = 10^{0}.6;
28
29 \operatorname{disp}(\operatorname{round}(F), "F = ");
30
31 disp("substituting into equation 1-31 gives, ")
32
33 \text{ te=T*(round(F)-1)};
34
35 \text{ disp}('K', round(te), "Te = ");
```

Chapter 2

Signal Analysis and Mixing

Scilab code Exa 2.3 Determine the dc component the peak amplitude of the 10 harmonics plot the $\sin x$ by x function sketch the frequency spectrum

```
1 clc;
2 //Example 2.3
3 //Page no 50
4
5 disp("For the pulse waveform shown in figure 2.12 (
    refer pgno 50)");
6
7 //Solution
8
9 //(a)
10 disp("(a)From Equation 2-16 (refer pgno 49), the dc
    component is ");
12
13 v=([1*{0.4*(10^-3)}/{2*(10^-3)}]);
14
15 disp('V',v,"V0 = ");
```

Chapter 3

Oscillator Phase Locked Loops and Frequency Synthesizer

Scilab code Exa 3.1 Determine the frequency of operation if the temperature increases by 10 degree C decreases by 5 degree C

```
1 clc;
2 //Example 3.1
3 //Page no 75
4
5
6
7 //Solution
8
9 fn=10*(10^6);
10 k=10;
11 c1=10;
12 c2=-5;
13
14 //(a)
15
16 disp("(a) Substituting into equation 3-6 and 3-7 (refer pgno 75) give us");
17
```

```
18 df = k*(10*c1);
19
20 \operatorname{disp}('Hz', \operatorname{round}(\operatorname{df}), ''dF = '');
21
22 fo=fn+(round(df));
23
24 disp('MHz',fo/(10^6),"F0 = ");
25
26 //(b)
27
28 disp("(b) Again, substituting into equation 3-6 and
       3-7 yields ");
29
30 	ext{ dF=k*(10*c2)};
31
32 \operatorname{disp}('Hz', \operatorname{round}(dF), "dF = ");
33
34 f1=fn+(round(dF));
35
36 disp('MHz',f1/(10^6),"F0 = ");
```

Scilab code Exa 3.2 Determine PLL open loop gain change in VCO frequency necessary to achieve lock PLL output voltage phase detector output voltage static phase error

```
1 clc;
2 //Example 3.2
3 //Page no 96
4
5 6 //Solution
7 8 fn=200*(10^3);
9 fi=210*(10^3);
10 Kd=0.2;
```

```
11 Kf = 1;
12 Ka=5;
13 Ko = 20;
14
15 //(a)
16
17 disp("(a) From equation 3-20 and 3-21 (refer pgno 95)
        , we get ");
18
19 Kl = Kd * Kf * Ka * Ko;
20
21 \operatorname{disp}('kHz/rad',Kl,"Kl = ");
22
23 Kv=2*(\%pi)*(Kl*(10^3));
24
25 disp('rad/s', Kv, "Kv = ");
26
27 \text{ KV} = 20 * \log 10 \text{ (Kv)};
28
29 \operatorname{disp}(\mathrm{'dB'}, \operatorname{round}(\mathrm{KV}), \mathrm{"Kv}(\mathrm{dB}) = \mathrm{"});
30
31 / (b)
32
33 	ext{ dF=fi-fn};
34
35 disp('kHz',(dF/(10^3)),"(b)dF = ");
36
37 / (c)
38
39 disp("(c) Rearranging equation 3-15 (refer pgno 89)
        gives us ");
40
41 Vo = ((dF/(10^3))/Ko);
42
43 disp('V', Vo, "Vout = ");
44
45 Vd=(Vo/(Kf*Ka));
46
```

Chapter 4

Amplitude Modulation Transmission

Scilab code Exa 4.1 Determine frequency limits for the upper and lower sidebands bandwidth upper and lower side frequencies produced when the modulating signal is a single frequency 3kHz tone draw the frequency spectrum

```
15 disp("(a) The lower sideband extends from the lowest
      possible lower side frequency to the carrier
      frequency or ");
16
17 lsb=(Fc-Fm);
18
19 disp("kHz", (Fc/(10^3)), "kHz to", (lsb/(10^3)), "LSB =
      ");
20
21 disp("The upper sideband extends from the carrier
      frequency to the highest possible upper side
      frequency is ");
22
23 usb=(Fc+Fm);
24
  disp("kHz", (usb/(10^3)), "kHz to", (Fc/(10^3)), "USB =
25
     ");
26
27 //(b)
28
29 disp("(b) The bandwidth is equal to the difference
      between the maximum upper side frequency and the
      minimum lower side frequency. ");
30
31 b = 2 * Fm;
32
33 disp("kHz", (b/(10^3)), "B = ");
34
35 //(c)
36
37 disp("(c)The upper side frequency is the sum of the
      carrier and modulating frequency.");
38
39 Fu=Fc+fm;
40
41 disp("kHz", (Fu/(10^3)), "Fusf = ");
42
43 disp("The lower side frequency is the difference
```

```
between the carrier and modulating frequency.");
44
45 Fl=Fc-fm;
46
47 disp("kHz",(Fl/(10^3)),"Flsf = ");
48
49 //(d)
50
51 disp("(d)The output frequency spectrum is shown in figure.");
```

Scilab code Exa 4.2 Determine upper and lower frequencies modulation coefficient and percent modulation peak amplitude of the modulation carrier and the upper and lower side frequency voltages maximum and minimum amplitudes of the envelope

```
1 clc;
2 //Example 4.2
  //Page no 123
4
  //solution
6
8 Fc=500; //kHz
9 Fm=10; //kHz
10 Ec = 20;
11 Em = 7.5;
12
13 disp("(a) The upper and lower side frequencies are
      simply the sum and difference frequencies,
      respectively ");
14
15 fu=Fc+Fm;
16 fl=Fc-Fm;
17
```

```
18 disp('kHz',fl,'kHz and Flsf = ',fu,"Fusf = ");
19
20 //(b)
21
22 disp("(b) The modulation coefficient is determined
      from equation 4-1 (refer pgno 120)");
23
24 \text{ m=Em/Ec};
25
26 \text{ disp}(m, "m = ");
27
   disp ("Percent modulation is determine from equation
      4-2 (refer pgno 120)");
29
30 M = 100 * m;
31
32 disp('\%',M,"M = ");
33 //(c)
34
35 disp("(c)The peak amplitude of the modulated carrier
       and the upper and lower side frequencies is ");
36
37 eu = ((m*Ec)/2);
38
39 disp('Vp',eu,"Eusf(modulated) = ");
40
41 / (d)
42
43 disp("(d) The maximum and minimum amplitude of the
      envelope are, ");
44
45 Vm = Ec + Em;
46 \text{ vm} = \text{Ec} - \text{Em};
47
48 disp('Vp', vm, 'Vp and Vmin = ', Vm, "Vmax = ");
```

Scilab code Exa 4.3 Obtain the total average power of the modulated signal in dB watts and dBm the peak and RMS voltages of the modulated signal

```
1 clc;
2 //Example 4.3
3 //Page no 128
4 //solution
6 \text{ Fc=1}; / \text{MHz}
7 Fm=5; //kHz
8 \text{ M=60; } /\%
9 m = (M/100);
10 Pc=6; /KW
11
12
13 //(a)
14
15 disp("(a) Total average power delivered to the load "
      );
16
17 Rl=(Pc*[1+m^2/2]);
18
19 disp('KW',Rl,"Rl = ");
20
21 //(b)
22
23 disp("(b) The modulation signal power");
24
  Vs = sqrt(100*(10^3)*R1);
25
26
27 disp('KV',(Vs/(10^3)),"Vs(RMS) = ");
28
29
  a=Vs*sqrt(2);
30
```

31 disp('KV',(a/(10^3)),"Therefore, peak value of
 modulation signal =")

Scilab code Exa 4.4 Determine 1 power of the carrier and the upper and lower sidebands 2 total sideband power 3 total power of the modulated wave 4 change m for 1 to 3

```
1 clc;
\frac{2}{\sqrt{\text{Example } 4.4}}
3 //Page no 128
5 Vc = 10; //Vp
6 m = 1;
7 R1 = 10;
8 m1=0.5;
10 //(a)
11
12 disp("(a) The carrier power is found by substituting
       into equation 4-18 (pgno 126): ");
13
14 Pc = ((R1^2)/(2*R1));
15
16 disp('W', Pc, "Pc = ");
17
18 disp("The upper and lower sideband power is found by
        substituting into equation 4-21 (pgno 127):");
19
20 P = (((m^2)*Pc)/4);
21
22 \operatorname{disp}(\mathrm{W}', P, \mathrm{Pusb} = \mathrm{Plsb} = \mathrm{"});
23
24 //(b)
25
26 disp("(b)The total sideband power is ");
```

```
27
28 Ps = (((m^2)*Pc)/2);
29
30 disp('W', Ps, "Psbt = ");
31
32 //(c)
33
34 disp("(c)The total power in the modulated is found
      by substituting into equation 4-25 (pgno 127)");
35
36 Pt = (5*[1+(m^2)/2]);
37
38 disp('W', Pt, "Pt = ");
39
40 // (d)
41
42 disp("(d) The carrier power is found by substituting
      into equation 4-18 ");
43
44 Pc1=Pc;
45
46 disp('W', Pc1, "Pc ");
47
48 disp("The upper and lower sideband power is found by
       substituting into equation 4-21 (pgno 127):");
49
50 P1 = (((m1^2)*Pc)/4);
51
52 \text{ disp}(\text{'W',P1,"Pusb} = \text{Plsb} = \text{")};
53
54 disp("The total sideband power is ");
55
56 Ps1 = (((m1^2)*Pc)/2);
57
58 disp('W', Ps1, "Psbt = ");
59
60 disp("The total power in the modulated is found by
      substituting into equation 4-25 (pgno 127)");
```

```
61
62 Pt1=(5*[1+(m1^2)/2]);
63
64 disp('W',Pt1,"Pt = ");
```

Scilab code Exa 4.5 Find the power in each sideband of a DSBFC signal

```
1 clc;
2 //Example 4.5
3 //Page no 131
5 // Solution
7 R1=100; //ohm
          //\mathrm{MHz}
8 \text{ Fc=1};
9 Fm1=2; //kHz
10 Fm2=3; //kHz
11 Fm3=5; //kHz
12 Ec=100; //V
13 Em1=10; //V
14 Em2=20; //V
15 Em3=30; //V
16
17 m1 = (Em1/Ec);
18
19 disp(m1, "m1 = ");
20
21 m2=(Em2/Ec);
22
23 disp(m2, "m1 = ");
24
25 \text{ m3} = (\text{Em3/Ec});
26
27 \text{ disp}(m3,"m1 = ");
28
```

```
29 m=sqrt((m1^2)+(m2^2)+(m3^2));
30
31 disp(m,"Overall modulation index m = ");
32
33 disp("Power in both the upper and lower sideband is same, which is given by ");
34
35 Psb=((Ec^2*m^2)/(2*R1*4));
36
37 disp('W',Psb,"Psb = ");
```

Scilab code Exa 4.6 Determine 1 maximum and minimum voltage gains 2 maximum and minimum amplitude for Vout

```
1 clc;
2 //Example 4.6
3 //Page no 133
4 //Solution
6 m = 0.8;
7 Aq=100;
8 Fc=500; //kHz
9 Vc=5*(10^-3); /mV
10 Fm=1000; //Hz
11
12 //(a)
13
14 disp("(a) Substituting into equation 4-34(pgno 132),
      ");
15
16 Am = Aq * (1+m);
17
18 disp(Am, "Amax = ");
19
20 am = Aq * (1-m);
```

```
21
22  disp(am, "Amin = ");
23
24  //(b)
25
26  Vom=Am*Vc;
27
28  vom=am*Vc;
29
30  disp('V', Vom, "(b) Vout(max) = ");
31  disp('V', vom, "Vout(min) = ");
```

Scilab code Exa 4.7 Determine carrier frequency AND upper and lower side frequencies

```
1 clc;
\frac{2}{\sqrt{\text{Example }4.7}}
3 // Page no 140
4 //solution
6 //(a)
8 V=12; //dc
9 Vm=2; //Vp
10 Fm=4; //kHz
11 Vb=4; //dc
12 R1=100*(10^3); //kohm
13 C1=0.001*(10^-6); //uF
14
15 //(a)
16
17 disp("(a)The carrier frequency is determine from
      equation 4-36 (refer pgno 137): ");
18
19 fc = (1/(R1*C1));
```

```
20 \text{ Fc=fc/(10^2)}
21
22 \operatorname{disp}('kHz',Fc,"fc = ");
23
24 //(b)
25
26 disp("(b) The upper and lower side frequency are
       simply the sum and difference frequencies between
        the carrier and the modulating signal. ");
27
28 fu=Fc+Fm;
29
30 \operatorname{disp}('kHz', \operatorname{fu}, "Fusf = ");
31
32 \text{ fl=Fc-Fm};
33
34 \operatorname{disp}('kHz',fl,"Flsf = ");
```

Chapter 5

Amplitude Modulation Reception

Scilab code Exa 5.1 Determine the improvement in the noise figure for a receiver with an RF bandwidth equal to 200kHz and an IF bandwidth equal to 10kHz

```
1 clc;
2 //Example 5.1
3 //Page no 159
4
5 //solution
6
7 Brf=200; //kHz
8 Bif=10; //kHz
9
10 //Bandwidth improvement is found by substituting into equati
11 BI=(Brf/Bif);
12
13 disp(BI, "BI = ");
14
15 disp("and noise figure improvement is found by substituting into equation 5-3 (refer pgno 157)")
```

```
;

16

17 NF=10*log10(BI);

18

19 disp('dB',NF,"NF = ")
```

Scilab code Exa 5.2 Determine the bandwidth at the low and high ends of RF spectrum

```
1 clc;
2 //Example 5.2
  //Page no 161
5
  //solution
8
9 Q = 54;
10
11 disp("The bandwidth at the low frequency end");
12
13 B = (540/Q);
14
15 disp('kHz',B,"B = ")
16
17 disp("The bandwidth at the high frequency end ");
18
19 B1 = (1600*(10^3)/Q);
20
21 disp('Hz',round(B1),"B = ")
```

Scilab code Exa 5.3 Determine the IF carrier upper side frequency and lower side frequency

```
1 clc;
2 //Example 5.3
3 //Page no 165
5
6
  //solution
9 fio=1355; //kHz
10 fRF=900; //kHz
11 fRFu=895; //kHz
12 fRF1=905; //kHz
13
14
15
16
  fIF=fio-fRF;
17
18
  disp('kHz',fIF,"fIF = ");
19
  disp("The upper and lower intermediate are");
20
21
22
  fIFu=fio-fRFu;
23
24 disp('kHz',fIFu,"fIF = ");
25
26 fIF1=fio-fRF1;
27
28 disp('kHz',fIF1,"fIF = ");
```

Scilab code Exa 5.5 Determine 1 image frequency 2 image frequency rejection ratio for a Q of 120 for the tuned circuit in the preselector of the receiver 3 IFRR if the preselector of 2 is followed by another RF tuned of IFR

```
1 clc;
```

```
2 //Example 5.5
3 //Page no 172
5
6
8 //solution
10 F1=1255; //kHz
11 Fif = 455; //kHz
12 FRF=800; //kHz
13 Q = 120;
14
15 //(a)
16
17 Fim=Fl+Fif;
18
19 disp('kHz',Fim,"(a)Image Frequency Fim = ");
20
21
22 //(b)
23
24 p=((Fim/FRF)-(FRF/Fim));
25
26 IFRR=sqrt(1+(Q^2)*(p^2));
27
28 disp(IFRR, "(b)IFRR = ");
29
30 //(c)
31
32 IFRR1=5.6;
33
34 IFRRt=IFRR*IFRR1;
35
36 disp(IFRRt, "(c)Combined IFRR of both the circuits =
      ");
```

Scilab code Exa 5.6 Determine 1 local oscillator frequency 2 image frequency 3 IFRR for a preselector Q of 160 4 preselector Q required to achieve the IFRR as that achieved for an RF carrier of 600kHz

```
1 clc;
2 //Example 5.6
 3 //Page no 172
   //Solution
 8 FRF=27000; //MHz
 9 Fif=455; //kHz
10 Q = 100;
11
12 / (a)
13
14 \operatorname{disp}("(a) \operatorname{From} \text{ equation } 5-7(\text{refer pgno } 165)");
15
16 flo=FRF+Fif;
17
18 Flo=(flo/(10<sup>3</sup>));
19
20 disp('MHz',Flo,"Flo = ");
21
22 //(b)
23
24 disp("(b))From equation 5-9 (refer pgno 171) ");
25
26 fim=flo+Fif;
27
28 \text{ Fim} = (\text{fim}/(10^3));
29
30 \operatorname{disp}('MHz', \operatorname{Fim},''\operatorname{Flo} = '');
```

```
31
32 //(c)
33
34 disp("(c)From equation 5-11 (refer pgno 171)");
35
36 p=((fim/FRF)-(FRF/fim));
37
38 IFRR=sqrt(1+(Q^2)*(p^2));
39
40 disp(IFRR, "IFRR = ");
41
42 // (d)
43
44 \text{ fr} = 600
45
46 fim1=fr+2*Fif;
47
48 p1=((fim1/fr)-(fr/fim1));
49
50 disp("(d) Rearranging equation 5-11");
51
52 q=sqrt(((IFRR^2)-1)/(p1^2));
53
54 \text{ disp}(q,"Q = ");
```

Scilab code Exa 5.7 Calculate 2 IFRR 2 IFRR in dB 3 IFRR for an IF of 455kHz 4 Q of primary and secondary circuit of the IF transformer is 40 and 50 so find critical coupling factor

```
1 clc;
2 //Example 5.7
3 //Page no 184
4
5
6 //solution
```

```
7
8 Fs=100; //MHz
9 Fif=10.7; //MHz
10 Q = 100;
11 Q1=40;
12 \quad Q2 = 50;
13
14
15 //(a)
16
17 disp("(a)");
18
19 flo=Fif+Fs;
20
21 \text{ Fim=Fs+2*Fif};
22
23 disp('MHz', Fim, "Fimage = ");
24
25 p=((Fim/Fs)-(Fs/Fim));
26
27 \text{ disp}(p, "p = ");
28
29 IFRR=sqrt(1+(Q^2)*(p^2));
30
31 disp(IFRR, "IFRR = ");
32
33 //(b)
34
35 disp("(b)");
36
37 ifrr=20*log10(IFRR);
38
39 disp('dB',ifrr,"IFRR in dB = ");
40
41 //(c)
42
43 disp("(c)");
44
```

```
fif = (455/(10^3));
46
47 fim=Fs+2*fif;
48
49 disp('MHZ',fim,"Fimage = ");
50
51 p1=((fim/Fs)-(Fs/fim));
52
53 disp(p1,"p = ");
54
55 IFRR1=sqrt(1+(Q^2)*(p1^2));
56
57 disp(IFRR1,"IFRR = ");
58
59 //(d)
60
61 disp("(d) Critical coupling factor of the primary and
       secondary circuit if IF transformer,");
62
63 kc = (sqrt(Q1*Q2))^{-1};
64
65 disp(kc, "Kc = ");
```

Scilab code Exa 5.8 Determine the net receiver gain and the audio signal level

```
1 clc;
2 //Example 5.8
3 //Page no 198
4
5
6
7
8 //solution
```

```
10 A = -80; //dB
11 G1=33; //dB
12 G2=47; //dB
13 G3=25; //dB
14
15 \text{ G=G1+G2+G3};
16
17 disp('dB',G,"The sum of the gains is, ");
18
19 L1=3; //dB
20 L2=6; //dB
21 L3=8; //dB
22
23 L=L1+L2+L3;
24
25 disp('dB',L,"The sum of the losses is, ");
26
27 \text{ G4=G-L};
28
29 disp('dB',G4,"Thus, net receiver gains is, ");
30
31 B = A + G4;
32
33 disp('dBm',B,"and the audio signal level is, ");
```

Chapter 6

Single Sideband Communication Systems

Scilab code Exa 6.1 Determine the quality factor necessary for a single sideband filter with a 1MHz carrier frequency 80dB unwanted sideband suppression and the following frequency spectrum

```
1 clc;
2 //Example 6.1
3 //Page no 224
4
5 //solution
6
7 f=1000; //kHz
8 s=80;
9 df=200; //khz
10
11 disp("Substituting into Equation 6-3 (refer pgno 223)");
12
13 Q=125000;
14
15 disp(Q,"Q = ");
```

Scilab code Exa 6.2 Determine demodulated first IF frequency band and demodulated information frequency band and demodulated information frequency band if the RF local oscillator frequency drift

```
1 clc;
2 //Example 6.2
  //Page no 230
   //solution
8 \text{ f0=30; } / \text{MHz}
9 f1=30.005 / MHz
10 flo=20; //MHz
11 fbfo=10; //MHz
12 d=(0.001/100); //\%
13
14 //(a)
15
16
17 disp("(a)The IF output from the RF mixer difference
      between the received signal frequency and the RF
      local oscillator frequency,");
18
19 fu=f0-flo;
20 fl=fl-flo;
21
22 disp('MHz',fl,"MHz to",fu,"Fif = ");
23
24
25 \text{ fm1=fu-fbfo};
  fm2=fl-fbfo;
26
27
28 disp('kHz',(fm2*(10^3)),"kHz to",fm1,"fm = ");
```

```
29
30 //(b)
31
32 disp("(b)A 0.001% drift would cause a decrease in
      the RF local oscillator frequency of ");
33
34 	ext{ df=d*flo};
35
  disp('Hz',(df*(10^6)),"df = ");
36
37
38
39 \text{ fl=(flo-df)};
40 fi=f0-f1;
41 ff=f1-f1;
42
   disp('MHz',ff,"MHz to",fi,"Fif = ");
44
45
46 \text{ fm3=fi-fbfo};
47 \quad fm4 = ff - fbfo;
48
  disp('Hz',(fm4*(10^6)),"Hz to",(fm3*(10^6)),"fm = ")
49
```

Scilab code Exa 6.3 Determine the demodulated first IF frequency band and demodulated information frequency band and demodulated information frequency band

```
1 clc;
2 //Example 6.3
3 //Page no 231
4
5
6
7 //Solution
```

```
9 fbfo=10; //MHz
10
11 //(a)
12
13 disp("(a) The solution is identical to that provieded
       in example 6-2 ");
14
15 Fi=30-20; //MHz
16 Ff = 30.005 - 20; /MHz
17
18 \operatorname{disp}('MHz', Ff, "MHz to", Fi, "Fif = ");
19
20 disp("The demodulated information signal spectrum is
       simply the difference between the intermediate
      frequency band and the BFO frequency");
21
22 \text{ fm1=Fi-fbfo};
23 \text{ fm}2=\text{Ff-fbfo};
24
25 disp('kHz',(fm2*(10^3)),"kHz to",fm1,"fm = ");
26
27 //(b)
28
29 disp("(b) ");
30
31 FI=30.0006-20.0004; //MHz
32 FF = 30.0056 - 20.0004; //MHZ
33
34 disp('MHz', FF, "MHz to", FI, "Fif = ");
35
36 disp ("The BFO frequency will also automatically
      adjust proportionally to 10.0002MHz, producing a
      demodulated information signal of ");
37
38 Fm=FI-10.0002; //MHz
39 Fm1=FF-10.0002; //MHz
40
```

```
41 disp('kHz',(Fm1*(10^3)),"kHz to",Fm,"fm = ");
```

Scilab code Exa 6.4 Determine for a single sideband suppressed carrier transmission the output frequency spectrum and a load resistance and the PEP and average power

```
1 clc;
2 //Example 6.4
3 //Page no 238
5
7 //solution
9 Frf=100; //kHz
10 fs1=1.5; //kHz
11 fs2=3; //kHz
12 R = 50; //Ohm
13 E=5; //V
14
15 //(a)
16
17 disp("(a)The output frequency spectrum contains the
       two upper side frequencies: ");
18
19 Fusf1=Frf+fs1;
20 Fusf2=Frf+fs2;
21
22 disp('kHz', Fusf2, "Fusf2 = ", 'kHz', Fusf1, "Fusf1 = ");
23
24 //(b)
25
26 disp("(b) Substituting in equation 6-6 yields, ");
27
28 PEP=([2*(0.707*E)^2]/R);
```

```
29
30 disp('W',PEP,"PEP = ")
31
32 disp("Substituting into equation 6-8 yields, ");
33
34 Pavg=(PEP/2);
35
36 disp('W',Pavg,"Pavg = ");
```

Chapter 7

Angle Modulation Transmission

Scilab code Exa 7.1 Determine 1 the peak frequency deviation and modulation index for an FM modulator 2 the peak phase deviation for a PM modulation

```
1 clc;
2 //Example 7.1
3 // Page No 253
4
  //Solution
8 //(a)
10 K1=5; //kHz/V
11 Ap=2; //V
12 k1 = 2.5; // rad/V
13 fm=2; //kHz
14
15 disp("(a) The peak frequency deviation is simply the
      product of the deviation sensitivity and the peak
       amplitude of the modulation signal, ");
16
17 df = K1 * Ap;
```

```
18
  disp('kHz',df,"df = ");
19
20
21 disp ("The modulation index is determined by
      substituting into equation 7-22(r)");
22
23 \text{ m=df/fm};
24
  disp(m, "m = ");
25
26
27 //(b)
28
29
  disp("The peak phase shift for a phase-modulation
      wave is the modulation index and is found by
      substituting into equation 7-15(refer pgno 250)")
30
31 \text{ m1} = \text{k1} * \text{Ap};
32
33 disp('rad',m1,"m = ");
```

Scilab code Exa 7.2 Determine 1 carrier frequency 2 modulation frequency 3 modulation index 4 peak phase deviation

```
1 clc;
2 //Example 7.2
3 //Page No 253
4
5
6 //Solution
7
8 wc=(6.28*10^6);
9 wm=(6.283*10^3);
10
11 disp(" Vpm(t)=A sin(wct + mp sin wmt) ","The
```

```
mathematical expression for a phase-modulated
      wave is given as, ");
12
13 fc=wc/(2*\%pi);
14
15
  disp('MHz',round(fc/10^6),"(a) Carrier Frequency
                     fc = ");
16
17 fm=wm/(2*\%pi);
18
19 disp('kHz',round(fm/10^3),"(b) Modulating Frequency
                  fm = ");
20
                                              mp = ");
  disp(10,"(c) Modulating index
21
22
  disp('rad',10,"(d)Peak phase deviation
23
     d0 = ");
```

Scilab code Exa 7.3 Determine 1 Number of sets of significant side frequencies 2 Amplitude of the frequencies 3 Draw the spectrum

```
1 clc;
2 //Example 7.3
3 //Page No 257
4
5 disp("Given: An FM modulator with a modulation index m=1, a modulating signal v,(t)=Vmsin(2pi1000t) and an unmodulated carrier vc(t)=10sin(2pi500kt).");
6
7 //Solution
8
9 //(a)
10 disp("(a)From Table 7.3, a modulation index of 1
```

```
yields a reduced carrier component and three sets
       of significant side frequencies. ");
12
13 //(b)
14
15 disp("(b) The relative amplitudes of the carrier and
      side frequencies are, ");
16
                                    J0= 0.77 x (10) = 7.7 V");
   disp("
17
18
                                    J1= 0.44 \times (10) = 4.4 \text{ V}");
  disp("
19
20
21
   disp("
                                    J2= 0.11 \times (10) = 1.1 \text{ V}");
22
  disp("
                                    J3 = 0.02 \times (10) = 0.2 \text{ V};
23
24
  disp("(c)The frequency spectrum is shown in figure
      7-6.");
```

Scilab code Exa 7.4 Determine 1 actual minimum bandwidth from the Bessel function table 2 approximate minimum bandwidth using Carsons rule 3 plot the output frequency spectrum for the Bessel approximation

```
1 clc;
2 //Example 7.4
3 //Page No 259
4
5 disp("Given: An FM modulator with a peak frequency deviation df=10kHz, a modulating signal frequency fm=10kHz, Vc=10V and a 500kHz carrier.");
6
7 //Solution
8
9 df=10;
10
```

```
11 fm = 10;
12
13 n=3;
14
15 //(a)
16
17 disp("(a) Substituting into equation 7-22(refer pgno
      251) ");
18
19 m=df/fm;
20
21 \text{ disp}(m, "m = ");
22
23 disp("From Table 7.3")
24
25 B=2*(n*fm);
26
27 disp('kHz',B,"B = ");
28
29 // (b)
30
31 disp("(b) Substituting into equation 7-34(refer pgno
       259), the bandwidth is ");
32
33 b=2*(df+fm);
34
35 disp('kHz',b,"B = ");
36
37 / (c)
38
39 disp("(c)The relative amplitudes of the carrier and
      side frequencies are, ");
40
                                   J0= 0.77 x (10) = 7.7 V");
41 disp("
42
43 disp("
                                   J1= 0.44 \times (10) = 4.4 \text{ V}");
44
                                   J2= 0.11x(10) = 1.1 V");
45 disp("
```

```
46
47 disp(" J3= 0.02x(10) = 0.2 V");
48
49 disp("The output frequency spectrum for the Bessel approximation is shown in figure 7-7.");
```

Scilab code Exa 7.5 Determine the deviation ratio and bandwidth for 1 the worst case modulation index 2 an equal modulation index

```
1 clc;
2 //Example 7.5
  //Page No 260
5
  //Solution
9 	ext{ df = 75};
10
11 fm=15;
12
13 //(a)
14
15 disp("(a) The deviation ratio is found by
      substituting into equation 7-35 (refer pgno), ");
16
17 DR=df/fm;
18
19 \operatorname{disp}(DR, "DR = ");
20
21 disp("From Table 7.3");
22
23 B=2*(8*fm);
24
25 disp('kHz',B,"B = ");
```

```
26
27 //(b)
28
29 disp("(b) For an 37.5kHz frequency deviation and
      modulating signal frequency fm=7.5, the
      modulation index is, ");
30
31 m = 37.5/7.5;
32
33 disp(m, "m = ");
34
  disp("and the bandwidth is, ");
35
36
37 b=2*(8*7.5);
38
  disp('kHz',b,"B = ");
39
```

Scilab code Exa 7.6 Determine 1 the modulation indexes and sketch the output spectrum 2 change the modulating signal amplitude to 4Vp for 1 3 change the modulating signal frequency to 1kHz for 1

```
1 clc;
2 //Example 7.6
3 //Page No 261
4
5
6
7 //solution
8
9 K=0.75;
10 fcp=500;
11 K1=1.5;
12 fcf=500;
13 vm=2;
14 fm=2;
```

```
15 Vm = 4;
16 Fm=1;
17
18 //(a)
19
20 disp("(a) FM Modulator ");
21
22 m = (vm * K1) / fm;
23
24 \text{ disp}(m, "m = ");
25
26 disp("PM Modulator");
27
28 m1 = vm * K;
29
30 \text{ disp}(m1, "m = ");
31
32 disp("Since the modulation indexes are same the
      output spectrum is also the same, which is in
      figure 7-8(a) ");
33
34 / (b)
35
36 disp("(b) FM Modulator ");
37
38 M = (Vm * K1) / fm;
39
40 disp(M, "m = ");
41
42 disp("PM Modulator");
43
44 M1 = Vm * K;
45
46 disp(M1, "m = ");
48 disp("Again, since the modulation indexes are same
      the output spectrum is also the same, which is in
       figure 7-8(b) ");
```

```
49
50 //(c)
51
52 disp("(a) FM Modulator ");
53
54 \text{ m2} = (\text{vm} * \text{K1}) / \text{Fm};
55
56 \text{ disp}(m2, "m = ");
57
58 disp("PM Modulator ");
59
60 m3 = vm * K;
61
62 disp(m3, "m = ");
63
64 disp("Since the modulation indexes are not same the
       output spectrum are given in figures 7-8(c) and
       7-8(d), respectively");
```

Scilab code Exa 7.7 Determine 1 the unmodulated carrier power for the FM modulator 2 the total power in the angle modulated wave

```
1 clc;
2 //Example 7.7
3 //Page No 265
4
5 disp("Given: Conditions as per example 7-3 and assume a load resistance Rl=50");
6
7 //solution
8
9 Rl=50;
10 Vc=10;
11 vc=7.7;
12 V1= 4.4;
```

```
13 \quad V2 = 1.1;
14 \quad V3 = 0.2;
15
16 //(a)
17
18 disp("(a) Substituting into equation 7-36 yields, ");
19
20 Pc = (Vc^2)/(2*R1);
21
22 \text{ disp}(\text{'W',Pc,"Pc} = \text{''})
23
24 //(b)
25
26 disp("(b) Substituting into equation 7-41 yields, ");
27
28 Pt = ((vc^2)/(2*R1)+(V1^2)*2/(2*R1)+(V2^2)*2/(2*R1)+(
      V3^2)*2/(2*R1));
29
30 \text{ disp}('W',Pt,"Pt = ");
```

Scilab code Exa 7.8 Determine 1 frequency of the demodulated interference signal 2 peak phase and frequency deviations due to the interfering signal 3 voltage signal to noise ratio at the output of the demodulator

```
1 clc;
2 //Example 7.8
3 //Page No 268
4
5
6
7 //solution
8
9 fc=110;
10 fn=109.985;
11 Vn=0.3;
```

```
12 Vc = 6;
13 \text{ fd}=75*(10^3);
14
15 //(a)
16
17 disp("(a) The frequency of the noise interference is
      the difference between the carrier frequency and
      the frequency of the single frequency interfering
       signal, ");
18
19 n=fc-fn;
20
21 disp('kHz',(n*10^3),"NI = ");
22
23 //(b)
24
25 disp("(b)) substituting into equation 7-43 yields, ");
26
27 t=Vn/Vc;
28
29 disp('rad',t,"dt = ");
30
31 disp("substituting into equation 7-47 yields, ");
32
33 df = (Vn*n)/Vc;
34
35 disp('Hz',(df*10^6),"df = ");
36
37 / (c)
38
39 \quad a=Vc/Vn;
40
41 disp(a, "(c) The voltage S/N ");
42
43 disp("The voltage S/N ratio after demodulation is
      found by substituting into equation 7-49");
44
45 \text{ sn=fd/(df*10^6)};
```

```
46
47 disp(sn,"S/N = ");
48
49 ip=20*log10(100/20);
50 ;
51 disp('dB',round(ip),"Thus, there is an signal to noise improvement of ")
```

Scilab code Exa 7.11 Determine 1 master oscillator centre frequency 2 frequency deviation at output for a frequency deviation of 75kHz at antenna 3 deviation ratio for fm 4 deviation ratio of antenna

```
1 clc;
2 //Example 7.11
3 //Page No 283
   //solution
8 N = 20;
9 \text{ ft=88.8;}
10 \, dF = 75;
11 fm=15;
12
13 //(a)
14
15 fc=ft/N;
16
  disp('MHz',fc,"(a)fc = ");
17
18
19
   //(b)
20
21 df = dF/20;
22
23 disp('Hz', (df*10^3), ''(b) df = '');
```

```
24

25 //(c)

26

27 dr=df/fm;

28

29 disp(dr,"(d)DR = ");

30

31 //(d)

32

33 DR=dr*N;

34

35 disp(DR,"(b)DR = ");
```

Angle Modulation Reception and FM Stereo

Scilab code Exa 8.1 Determine the peak output voltage

```
1 clc;
2 //Example 8.1
3 //Page no 298
4
5
6 //Solution
7
8 Kd=0.2; //V/kHz
9 df=20; //kHz
10
11 disp("Substituting into equation 8-2, the peak output voltage is ")
12
13 Vo=Kd*df;
14
15 disp('Vp',Vo,"vout(t) = ")
```

Scilab code Exa 8.2 Determin the minimum receive carrier power necessary to achieve a postdetection signal to noise ratio 37dB

```
1 clc;
2 //Example 8.2
3 //Page no 309
5
7 // Solution
9 B=200*(10^3); //kHz
10 NF=8; //dB
11 T=100; //K
12 m=1;
13
14 a=37-17; //dB
15
16 disp('dB',a," the prediction signal to noise ratio
     must be atleast, ");
17
18 b=20+8; //dB
19
20 disp('dB',b," Therefore, for an overall receiver
      noise figure equal to 8dB, the S/N ratio at the
      input to the receiver must be atleast, ");
21
22 disp("The receiver input noise power is, ");
23
24 \text{ K} = (1.38*(10^-23));
25
26 N=10*log10((K*T*B)/0.001);
27
28 disp('dBm', N, "N(dB) = ");
29
30 disp ("Consequently, the minimum receiver signal
      power for a 28dB S/N ratio is, ");
31
```

```
32 S=N+28;

33 disp('dBm',S,"S = ");
```

Scilab code Exa 8.3 Determine the pre and postdetection SN ratios

```
1 clc;
2 //Example 8.3
3 //Page No 309
5
7 // Solution
9 SN=29; //dB
10 NF=4; //dB
11 FMi=16; //dB
12
13 disp("The predetection signal to noise ratio is ");
14
15 pre=SN-NF;
16
17 \operatorname{disp}('dB', \operatorname{pre}, "S/N(\operatorname{pre}) = ");
18
19 disp("The postdetection signal to noise ratio is ");
20
21 pst=pre+FMi;
22
23 disp('dB',pst,"S/N(post) = ");
```

Scilab code Exa 8.4 Determine the minimum receive signal level

```
1 clc;
```

```
2 //Example 8.4
3 //Page no 310
5
7 //solution
9 SN=38; //dB
10 In=-112; //dBm
11 FMi=17; //dB
12 NF=5; //dB
13
14 sn=SN-FMi+NF;
15
16 disp('dB',sn,"The receiver input S/N is ");
17
18 rs=In+sn;
20 disp('dBm',rs,"Therefore, the minimum receive signal
      level is ");
```

Digital Modulation

Scilab code Exa 9.2 Determine the peak frequency deviation minimum bandwidth baud rate for a binary FSK signal

```
1 clc;
2 //Example 9.2
3 //Page no 339
5 //solution
7 \text{ fm} = 49;
8 \text{ fs} = 51;
9 fb=2; //nyquist rate
10
11
12 //(a)
13 disp("(a)The peak frequency deviation is determine
      from equation 9-14 (refer pgno 338)");
14
15 df = (fs - fm)/2;
16
17 disp('kHz',df,"df = ");
18
19 //(b)
```

```
20
21 disp("(b) The minimum bandwidth is determined from
      equation 9-15 (refer pgno 339)");
22
23 B=2*(df+fb);
24
  disp('kHz',B,"B = ");
25
26
  //(c)
27
28
29 disp("(c)For FSK, N=1 and the baud rate is
      determined from equation 9-11 as ");
30
31 n=1;
32
33 \text{ baud=fb*10^3/n};
34
35 disp(baud, "baud = ");
```

Scilab code Exa 9.3 Determine the minimum bandwidth for the FSK signal

```
1 clc;
2 //Example 9.3
3 //Page no 340
4
5
6
7 //solution
8
9 fm=49;
10 fs=51;
11 fb=2;
12
13 disp("The modulation index is determine from
```

```
equation 9-17(refer pgno 340)");

14
15 h=(fs-fm)/2;
16
17 disp(h,"h = ");
18
19 disp("From Bessel table, the bandwidth can be determine as follows, ");
20
21 b=2*(3*h);
22
23 disp('hz',b*10^3,"B = ");
```

Scilab code Exa 9.15 Determine the minimum bandwidth required

```
1 clc;
2 //Example 9.15
3 //Page No 382
6 //solution
8 \text{ ebn0} = 14.7;
9 \text{ cn} = 11.7;
10 fb=10;
11
12 disp("From Figure 9-48,");
13
14 bfb=ebn0-cn;
15
16 Bfb=exp(log10(bfb));
17
18 disp('dB', round(Bfb), "B/fb = ");
19
20 B = 2 * fb;
```

```
21
22 disp('MHz',B,'B = ');
```

Digital Transmission

Scilab code Exa 10.1 Determine the largest value capacitor that can be used in figure

```
1 clc;
2 //Example 10.1
3 //Page No 395
5
7 // Solution
9 i=10*10^-4;
10 dt = 10 * 10^-9;
11 dv = 10;
12
13 disp("The expression for the current through a
       capacitor is ");
14
15 \operatorname{disp}("i = C \operatorname{dv}/\operatorname{dt}");
16
17 disp("Rearranging and solving for c yields, ");
18
19 c=i*dt/dv;
```

```
disp('F',c,"C = ");
disp("t = RC","The charge time constant for C when
        Q1 in on is ");
disp("Therefore, rearranging the above equation and
        substituting the value of chaging time yields");
C=dt/(4.6*20);
disp('F',C/100,"C = ");
```

Scilab code Exa 10.3 Determine the quantized voltage quantization error and PCM code

```
1 clc;
2 //Example 10.3
3 // Page No 400
5 disp("Given: For figure, Analog sample voltage of
      +1.07 V.; ");
6
  //solution
9
10
11 a=1.07/1
12
13 disp(round(a));
14
15 disp ("The quantization error is the difference
     between the original sample voltage and the
      quantized level, or");
16
```

```
17  q=1.07-1;
18
19  disp(q,"Qe = ");
20
21  disp("From Table 10-2, the PCM code for 1 is 101");
```

Scilab code Exa 10.4 Calculate 1 the resolution and quantization error 2 the coding efficiency for a resolution

```
1 clc;
2 //Example 10.4
3 //Page No 403
5 disp("Given: For minimum line speed with an 8-bit
      PCM for speech signal ranging upto 1 V. ");
6
  //solution
9 v = 1;
10 n=8;
11
12
13 disp("Minimum line speed with an 8-bit PCM is 64Kbps
      .");
14
15 //(a)
16
17 r=v/(2^n-1);
18
19 \operatorname{disp}('V', r,"(a) \operatorname{Resolution} = ");
20
21 q=r;
22
23 disp('V',q," Therefore, Resolution = quantization, q=
      ");
```

```
24
25 \text{ qe=q/2};
26
27 disp('V',qe,"Quantization error = ");
28
29 //(b)
30
31 disp("(b)Dynamic range DR for 0.001 V resolution ");
32
33 dr = 20 * log 10 (v/0.01);
34
35 disp('db',dr,"DR = ");
36
  disp ("Minimum number of bits n required to achieve
      the dynamic range is given by ");
38
39 N = ((log(100+1))/(log(2)));
40
41 disp(N,"n = ");
42
43 c = (N/n) * 100;
44
45 disp('%',c," Therefore, coding efficiency = ");
```

Scilab code Exa 10.8 Determine the minimum line speed in bits per second to transmit speech signal of 1 a 7 bit PCM 2 an 8 bit PCM

```
1 clc;
2 //Example 10.8
3 //Page No 418
4
5 //solution
6
7
8
```

```
9 s = 8;
10
11 //(a)
12
13 disp("(a)With the 7 bit PCM,");
14
15 b=7;
16
17 r = s * b;
18
19 disp('kbps',r,"line speed = ");
20
21 //(b)
22
23 disp("(b)With the 8 bit PCM, ");
24
25 b1=8;
26
27 \text{ r1=s*b1};
28
29 disp('kbps',r1,"line speed = ");
```

Metallic Cable Transmission Media

Scilab code Exa 12.1 Determine the characteristic impedance for an air dielectric two wire parallel transmission line

```
1 clc;
2 //Example 12.1
3 //Page No 505
4
5 disp("Given: A D/r ratio of 12.22");
6
7 //solution
8
9 dr=12.22;
10
11 disp("Susbstituting into equation 12-14(refer pgno 505), we obtain ");
12
13 Z0=276*log10(dr);
14
15 disp('Ohm',round(Z0),"Z0 = ");
```

Scilab code Exa 12.2 Determine the characteristic impedence for coaxial cable

```
1 clc;
2 //Example 12.2
3 //Page No 506
5
  //Solution
8 d=0.025;
9 D=0.15;
10
  e = 2.23;
11
12 disp("Substituting into Equation 12-15(refer pgno506
      ) give us, ");
13
14 Z0 = -((138/sqrt(e))*(log10(d/D)));
15
16 disp('Ohms', Z0, "Z0 = ");
```

Scilab code Exa 12.3 Charecteristic impedence for RG-59A coaxial cable

```
9 L=0.118*10^-6;
10 C=21*10^-12;
11
12 disp("Substituting into Equation 12-15(refer pgno506
      ) give us,");
13
14 Z0=sqrt((L/C));
15
16 disp('ohm',round(Z0),"Z0 = ");
```

Scilab code Exa 12.4 Determine the velocity of propagation and the velocity factor

```
1 clc;
2 //Example 12.4
3 // Page No 509
4
5
  //solution
9 C=96.6*10^-12;
10 L=241.56*10^-9;
11 ep=2.3;
12 c=3*10^8;
13
14 disp("From equation 12-16");
15
16 Vp=(1/sqrt(C*L));
17
18 disp('m/s', Vp, "Vp = ");
19
20 disp("From equation 12-24");
21
22 Vf = (Vp/c);
```

```
23
24 disp(Vf,"Vf = ");
25
26 disp("From equation 12-26");
27
28 vf=(1/sqrt(ep));
29
30 disp(vf,"Vf = ");
```

Scilab code Exa 12.5 Determine reflection coefficient and SWR

```
1 clc;
2 //Example 12.5
3 //Page No 514
5
6 //solution
8 \text{ Ei} = 5;
9 \text{ Er} = 3;
10
11 disp("Substituting into equation 12-33 yield");
12
13 r=Er/Ei;
14
15 disp(r, "r = ");
16
17 disp("Substituting into equation 12-37 yield");
18
19 swr = (Ei + Er) / (Ei - Er);
20
21 \operatorname{disp}(\operatorname{swr}, \operatorname{"SWR} = ");
22
23 disp("Substituting into equation 12-45 yield");
24
```

```
25 r1=(swr-1)/(swr+1);
26
27 disp(r1,"r = ");
```

Scilab code Exa 12.6 Determine the physical length and characterictic impedence for a quarter wavelength transformer

```
1 clc;
2 //Example 12.6
3 //Page No 524
4
6 //solution
8 f = 150 * 10^6;
9 c=3*10^8;
10 z0=50;
11 zl = 150;
12
13 disp("The Physical length of the transformer depends
       on the wavelength of the signal. Substituting
      into equation 12-3 yields, ");
14
15 l=(c/f);
16
17 disp('m',l,'l = ');
18
19 1=1/4;
20
21 disp('m',1,'l = ');
22
23 disp("The characteristic impedance of the 0.5m
      transformer is determined from the equation 12-47
       ");
24
```

```
25 Z0=sqrt(z0*z1);
26
27 disp('Ohm',Z0,"Z0 = ")
```

Scilab code Exa 12.7 How far down the cable is the impairment

```
1 clc;
2 //Example 12.7
3 //Page No 526
4
5
6
7 //Solution
8
9 c=3*10^8;
10
11 disp("Substituting into equation 12-48");
12
13 d=((0.8)*c*(1*10^-6))/2;
14
15 disp('m',d,'d = ');
```

Scilab code Exa 12.8 Determine the time elapsed from the beginning of the pulse to the reception of the echo

```
1 clc;
2 //Example 12.8
3 //Page No 527
4
5
6
7 //solution
```

```
9  c=3*10^8;
10  d=3000;
11  k=0.9;
12
13  disp("Rearranging Equation 12-48 ");
14
15  t=((2*d)/(k*c));
16
17  disp('s',t,"t = ")
```

Optical Fiber Transmission Media

Scilab code Exa 13.1 Determine the angle of refraction

```
1 clc;
2 //Example 13.1
3 // Page No 545
5
7 //solution
9 n1=1.5;
10 \quad n2=1.36;
11 t1=30;
12
13 disp("From Table, ")
14
15 \operatorname{disp}(n1, "n1(\operatorname{glass}) = ");
16
17 \operatorname{disp}(n2, n2(\operatorname{alcohol}) = ");
18
19 disp ("Rearranging equation 13-9 and substituting, we
```

```
get ");
20
21 t=((n1/n2)*sin(%pi/6));
22
23 disp(t,"t2 = ");
24
25 t3=asin(t);
26
27 t2=t3*(180/%pi);
28
29 disp(t2,"t2 = ");
```

Scilab code Exa 13.2 Calculate the refractive index of the cladding

```
1 clc;
2 //Example 13.2
3 //Page No 554
4
5
6
7 //solution
9 n1=1.485;
10 a=50*10^-6;
11 N = 320;
12 \quad 1 = 0.850 * 10^{-6};
13
14 disp("Number of modes in a step-index fibre, N is
      given by equation 13-13, ");
15
16 r=(sqrt(320)*((1)/(%pi*2*a)));
17
18 n2=n1-r;
19
20 \text{ disp}(n2,"n2 = ");
```

Scilab code Exa 13.3 Calculated the optical power

```
1 clc;
2 //Example 13.3
3 //Page No
5
  //solution
  al=0.25*100;
10 Pt=1*10^-4;
11
12 disp("Substituting in equation 13-15,");
13
14 p=Pt*(10^(al/10));
16 disp('uW',p*10,"P = ");
17
18 P=10*log10(p*10^-5/0.001);
19
20 disp('uW',P,"P(dB) = ");
```

Scilab code Exa 13.4 Calculate the maximum data rate through a 6 km long step index fibre

```
1 clc;
2 //Example 13.4
3 //Page No 558
4
5
```

```
6 //solution
8 n1=1.48;
9 n2=1.46;
10 L=6000;
11
12 d=((n1-n2)/n1);
13
14 disp(d,"d = ");
15
16 t=((d*L)/(3*10^8));
17
18 \quad T = 0.03996;
19
20 disp('ns',T,"Intermodal delay t = ");
21
22 disp("Therefore, the maximum data rate Fmax is given
       by, ");
23
24 F = (1/(2*T));
25
26 disp('MHz',F,"Fmax = ");
```

Scilab code Exa 13.5 Determine the maximum digital transmission rates for return to zero and nonreturn to zero

```
1 clc;
2 //Example 13.5
3 //Page No 561
4
5
6 //solution
7
8 L=10000;
9 dt=5*10^-6;
```

```
10
11 disp("Substituting into equation 13-18 yields ");
12
13 fb=(1/(dt*L));
14
15 disp('Mbps',fb,"fb = ");
16
17 disp("Substituting into equation 13-19 yields ");
18
19 Fb=(1/((2*dt)*L));
20
21 disp('Mbps',Fb,"fb = ");
```

Scilab code Exa 13.6 Determine the optical power received in dBm and watts

```
1 clc;
2 //Example 13.8
3 //Page No 575
5
6
7 //solution
9 P=30*10^-3;
10 \text{ cl=0.5};
11 conl=2;
12 ltc=1.9;
13 ctd=2.1;
14
15
16
17 disp("The LED output power is converted to dBm using
       equation 13-6");
18
```

```
19 Po=10*log10(P/0.001);
20
21 disp('dBm',Po,"Po = ");
22
23
24
25 t = 20 * c1;
26
27 disp('dB',t,"total cable loss = ");
28
29
30
31 c=3*con1;
32
33 disp('dB',c,"total connector loss = ");
34
35 //light source to cable and cable to light detector
      losses
36
37 tl=t+c+ltc+ctd;
38
39 disp('dB',tl,"total loss = ");
40
41 disp("The receive power is determined by
      substituting into equation 13-22 ");
42
43 Pr=Po-t1;
44
45 disp('dBm',Pr,"Pr = ");
```

Electromagnetic Wave Propagation

Scilab code Exa 14.1 Determine power density from source at 1000m and 2000m

```
1 clc;
2 //Example 14.1
3 //Page No. 584
4
5
6
7 //Solution
8
9 Prad=100;
10 r1=1000;
11 r2=2000;
12
13 //(a)
14
15 disp("(a) Substituting into equation 14-7 yields, ");
16
17 p1=((Prad)/(4*%pi*(r1^2)));
18
```

```
19 disp('uW/m^2',p1*10^6,"P1 = ");
20
21 //(b)
22
23 disp("(b) Substituting into equation 14-7 yields, ");
24
25 p2=((Prad)/(4*%pi*(r2^2)));
26
27 disp('uW/m^2',p2*10^6,"P2 = ");
```

Scilab code Exa 14.2 Determine the height of the receiving antenna and the maximum transmission distance

```
1 clc;
2 //Example 14.2
3 // Page No 597
4
5
7 // Solution
9 //(a)
10
11 d=48.7;
12 ht=40;
13
14 disp("(a) As per equation 14-23, ");
15
16 hr = (((d-sqrt(17*ht))^2)/17);
17
18 hr=round(hr);
19
20 disp('m',hr,"hr = ");
21
22 //(b)
```

```
23

24  Ht=2*ht;

25  Hr=2*hr;

26

27  D=((sqrt(17*Ht))+(sqrt(17*Hr)));

28

29  disp('km',D,"(b)Dmax = ");
```

Scilab code Exa 14.3 Determine the fade margin

```
1 clc;
2 //Example 14.3
3 //Page No 603
4
5 //Solution
6
7 D=40;
8 f=1.8;
9 o=0.9999;
10
11 disp("Substituting into equation 14-34, ");
12
13 Fm=([30*log10(D)]+[10*log10([6*4*0.5*f])]-[10*log10(1-o)]-70);
14
15 disp('dB',Fm,"Fm = ")
```

Antennas and Waveguides

Scilab code Exa 15.1 Determine antenna efficiency antenna gain radiated power in watts dBm dBW and EIRP in watts dBm dBW

```
1 clc;
2 //Example 15.1
3 //Page No 616
5
7 //solution
9 \text{ Rr} = 72;
10 Re=8;
11 D=20;
12 Pin=100;
13
14 //(a)
15
16 disp("(a) Antenna efficiency is found by substituting
       into equation 15-3 ");
17
18 n=(Rr/[Rr+Re])*100;
19
```

```
20 \text{ disp}('\%',n,"n = ");
21
22 //(b)
23
24 disp("(b)Antenna gain ");
25
26 A = (n/100) * (D);
27
28 disp('and', 'dB', A, "A = ");
29
30 \quad A1 = 10 * log 10 (A);
31
32 \text{ disp}('dB', A1, "A = ");
33
34 //(c)
35
36 disp("(c) Radiated power");
37
38 \text{ Prad} = (n/100) * Pin;
39
40 disp('W', Prad, "Prad = ");
41
42 prad=10*log10(Prad/0.001);
43
44 \operatorname{disp}(\operatorname{'dBm'},\operatorname{prad},\operatorname{"Prad}(\operatorname{dBm}) = \operatorname{"});
45
46 pRad=10*log10(Prad);
47
48 \operatorname{disp}('\operatorname{dBW}',\operatorname{pRad},''\operatorname{Prad}(\operatorname{dBW}) = ");
49
50 //(c)
51
52 disp("(d)EIRP is found by substituting into
        equations 15-7d, e and f");
53
54 EIRP=Pin*A;
55
56 disp('W', EIRP, "EIRP = ");
```

```
57
58 EIRP1=10*log10(EIRP/0.001);
59
60 disp('dBm',EIRP1,"EIRP(dBm) = ");
61
62 EIRP2=10*log10(EIRP)
63
64 disp('dBW',EIRP2,"EIRP(dBW) = ");
```

Scilab code Exa 15.2 Determine the antenna input radiated power EIRP and receive power density

```
1 clc;
2 //Example 15.2
3 //Page No 616
5
7 //solution
9 Dt1=1;
10 Dt2=10;
11 n1=1;
12 \quad n2=0.5;
13 At = 5;
14 Lp=50;
15 Lf=3;
16 Pout = 40;
17
18 //(a)
19
20 disp("(a)The antenna input power in dBm is ")
21
22 Pin=Pout-Lf;
23
```

```
24 disp('dBm', Pin, "Pin = ");
25
26 disp("Radiated power in dBm is");
27
28 N1 = 10 * log 10 (n1);
29
30 Prad=Pin+N1;
31
32 disp('dBm', Prad, "Prad = ");
33
34 \text{ At1=Dt1*n1};
35
36 EIRP1=Prad+(10*log10(At1));
37
38 disp('dBm', EIRP1, "EIRP = ");
39
40 P1 = EIRP1 - Lp;
42 disp('dBm',P1,"P = ");
43
44 //(b)
45
46 disp("(b)The antenna input power in dBm is ")
47
48 Pin=Pout-Lf;
49
50 disp('dBm', Pin, "Pin = ");
51
52 disp("Radiated power in dBm is");
53
54 N2=10*log10(n2);
55
56 \operatorname{Prad=Pin+N2};
57
58 disp('dBm',round(Prad),"Prad = ");
59
60 EIRP2=Prad+(10*log10(Dt2));
61
```

```
62 disp('dBm',round(EIRP2),"EIRP = ");
63
64 P2 = EIRP2 - Lp;
65
66 disp('dBm', round(P2), "P = ");
67
68 //(c)
69
70 disp("(c)The antenna input power in dBm is ")
71
72 Pin=Pout-Lf;
73
74 \operatorname{disp}(\operatorname{'dBm'},\operatorname{Pin},\operatorname{"Pin} = \operatorname{"});
75
76 disp("Radiated power in dBm is");
77
78 N3=10*log10(n2);
79
80 Prad=Pin+N3;
81
82 disp('dBm', round(Prad), "Prad = ");
83
84 EIRP3=Prad+(10*log10(At));
85
86 disp('dBm',round(EIRP3),"EIRP = ");
87
88 \quad P3 = EIRP3 - Lp;
89
90 \operatorname{disp}(\operatorname{'dBm'}, \operatorname{round}(P3), \operatorname{"P} = \operatorname{"});
```

Scilab code Exa 15.3 Determine captured power in dBm and watts

```
1 clc;
2 //Example 15.3
3 //Page No620
```

```
4
 5
6 //solution
 7
 8 P = 10;
 9 Ac = 0.2;
10
11 disp("Substituting into equation 15-12 yields ");
12
13 Pcap=P*Ac;
14
15 disp('uW', Pcap, "Pcap = ");
16
17 pcap=10*log10(Pcap*10^-6/0.001);
18
19 \operatorname{disp}(\operatorname{'dBm'}, \operatorname{round}(\operatorname{pcap}), \operatorname{"Pcap}(\operatorname{dBm})));
```

Scilab code Exa 15.4 Determine beamwidth transmit and receive power gain and EIRP

```
1 clc;
2 //Example 15.4
3 //Page No 643
4
5
6 //solution
7
8 D=2;
9 c=3*10^8;
10 f=6;
11 Pt=10;
12
13 disp("(a)The beam width is found by substituting into equation 15-29 ");
14
```

```
15 O=([70*c]/[(f*10^9)*D]);
16
17 disp(0, T = );
18
19 disp("(b) The transmit power gain is found by
      substituting into equation 15-31c, ");
20
21 A = ([20*log10(f*10^3)] + [20*log10(2)] - 42.2);
22
23 disp('dB', A, "Ap(dB) = ");
24
  disp("(c)The receive power gain is found by
      substituting into equation 15-33c, ");
26
27  1=(c/(f*10^9));
28
29 disp('m/cycle',1,"l = ");
30
31 Ap=10*log10(5.4*[(D/1)^2]);
32
33 disp('dB', Ap, "Ap(dB) = ");
34
35 disp("(d) The EIRP is the product of the radiated
      power times the transmit antenna gain, ");
36
37 EIRP=Ap+(10*log10(Pt/0.001));
38
39 disp('dB', EIRP, "EIRP = ");
```

Scilab code Exa 15.5 Determine Cutoff frequency and wavelength group and phase velocity

```
1 clc;
2 //Example 15.5
3 //Page No 651
```

```
4
5
7 //solution
9 f = 6;
10 a=0.03;
11 c=3*10^8;
12
13 disp("(a) The cutoff frequency is determined by
      substituting into equation 15-41, ");
14
15 fc=(c/(2*a));
16
17 fc=fc/10<sup>9</sup>;
18
19 disp('GHz',fc,"fc = ");
20
21 disp("(b)The cutoff wavelength is determined by
      substituting into equation 15-42, ");
22
23 \ 1c = 2*(a);
24
25 \text{ disp}('m',lc,"lc = ")
26
27 disp("(c)The phase velocity is found using equation
      15-41, ");
28
29 vph=(c/[sqrt(1-({fc/f}^2))]);
30
31 disp('m/s', vph, "vph = ");
32
33 disp("(d)The group velocity is found by rearranging
      equation 15-36, ");
34
35 \text{ vg} = ([c^2]/\text{vph});
36
37 \text{ disp}('m/s', vg, "vg = ");
```

Scilab code Exa 15.6 Determine the cutoff frequency and the characteristic of TE10

```
1 clc;
 2 //Example 15.6
 3 // Page No 652
 6 //solution
 8 a=9;
 9 b=4.5;
10 f = 4;
11 c=3*10^10;
12
13 disp("(a) Cutoff frequency, ");
14
15 fc=(c/(2*a));
16
17 fc=fc/10<sup>9</sup>;
18
19 \operatorname{disp}(\operatorname{'GHz'},\operatorname{fc},\operatorname{"fc} = \operatorname{"});
20
   disp("(b) Characteristic impedence, ");
21
22
23 Zte=(377/[sqrt(1-({fc/f}^2))]);
24
25 \operatorname{disp}(\operatorname{'ohm'},\operatorname{Zte},\operatorname{"}\operatorname{Zte} = \operatorname{"});
```

The Telephone Circuit

Scilab code Exa 17.1 Determine the power level in dBm and the difference between them

```
1 clc;
2 //Example 17.1
3 //Page No 690
5
7 //solution
9 p1=10*10^-3;
10 p2=0.5*10^-3;
11
12 disp("(a)The power levels, ");
13
14 P1=10*log10(p1/0.001);
15
16 disp('dBm',P1,"P = ");
17
18 P2=10*log10(p2/0.001)
19
20 \operatorname{disp}(\operatorname{'dBm'}, \operatorname{round}(P2), \operatorname{"P} = \operatorname{"});
```

```
21
22 disp("(b)The difference ");
23
24 P=10*log10(p1/p2);
25
26 disp('dBm',round(P),"diff = ");
27
28 disp("The 10mW power level is 13dB higher than 0.5W power level.");
```

Cellular Telephone Concepts

Scilab code Exa 19.1 Determine the number of channels per cluster and total channel capacity

```
1 clc;
2 //Example 19.1
3 //Page No 749
4
5 //solution
6
7 disp("The total number of full-duplex channels is,");
8
9 F=10*7
10
11 disp("channel per cluster",F,"F = ");
12
13 disp("The total channel capacity is,")
14
15 C=10*7*10;
16
17 disp("channel total",C,"C = ");
```

Scilab code Exa 19.2 Determine for a cell area

```
1 clc;
2 //Example 19.2
3 // Page No 752
4
6 //solution
8 \text{ Asys} = 1520;
9 Acell=4;
10 n=1140;
11 j=2;
12 i=3;
13
14 //(a)
15
16 disp("(a) Number of cells in a cluster, N ");
17
18 N=(i^2)+(i*j)+(j^2);
19
20 \text{ disp}(N,"N = ");
21
22 //(b)
23
24 disp("(b) Number of clusters in the systems = area of
       the system / area of each cluster");
25
  ac=N*Acell;
26
27
28 \text{ N1=(Asys/ac)};
29
30 disp(N1, "Number of clusters = ");
31
```

```
32 //(c)
33
34 disp('Km^2',ac,"(c)Area of each celler cluster = ")
35
36 // (d)
37
38 \text{ sc}=N1*n;
39
40 disp('channels', sc,"(d) System capacity with
      frequency reuse = number of cluster X number of
      channels without frequency reuse, i.e.");
41
42 //(e)
43
44 disp("(e) Number of channels allocated to each cell,
      ");
45
46 c = (Asys/Acell);
47
48 disp(c,"(i) without frequency reuse = ");
49
50 C = (n/N);
51
52 disp(C,"(ii)With frequency reuse = ");
```

Scilab code Exa 19.3 Determine the following

```
1 clc;
2 //Example 19.3
3 //Page No 755
4
5
6 //solution
```

```
8 //(a)
10 c=10*7;
11
12 disp('channel/area',c,"(a)Channel capacity = ");
13
14 //(b)
15
16 disp("(b) Splitting each macrocell");
17
18 c1=10*28
19
20 disp('channel/area',c1,"Channel capacity = ");
21
22 //(c)
23
24 disp("(c)Further splitting minicell into four
      microcells ");
25
26 c2=10*112
27
28 disp('channel/area',c2,"Channel capacity = ");
```

Cellular Telephone Systems

Scilab code Exa 20.1 Determine the transmit and receive carrier frequencies for AMPS channels 3 and 91

```
1 clc;
2 //Example 20.1
3 //Page No 768
5 //solution
7 N1 = 3;
8 N2 = 991;
10 //(a)
11
12 disp("(a)The transmit and receive carrier
      frequencies");
13
14 ft = ((0.03*N1)+825);
15
16 disp('MHz',ft,"transmit ft = ");
17
18 fr=ft+45;
19
```

Scilab code Exa 20.2 Determine the transmit power for a CDMA

```
1 clc;
2 //Example 20.2
3 //Page No 792
4
5
6
7 //solution
8
9 Pr=-100;
10
11 disp("Substituing into equation 20-4, ");
12
13 Pt=-76-(Pr);
14
15 disp('dBm',Pt,"Pt = ")
```

Microwave Radio Communications and System Gain

Scilab code Exa 24.1 Determine the free space path loss in dB

```
1 clc;
2 //Example 24.1
3 //Page No 981
4
5
6
7 //soution
8
9 f=18*10^9;
10 D=16*10^3;
11 c=3*10^8
12
13 disp("free space path loss based on inverse square law, which yields, ");
14
15 lp=((4*%pi*D*f)/c)^2;
16
```

```
17 disp(lp,"Lp = ");

18

19 Lp=10*log10(lp);

20

21 disp('db',Lp,"Lp(dB) = ");
```

Scilab code Exa 24.2 Determine the frequency of operation of the microwave link

```
1 clc;
2 //Example 24.2
3 //Page No 988
5 disp("Given: d1=18.6Km, d=14.4Km, Hn=H1=200 meters, n
      =1");
6
  //solution
9 d1=18.6;
10 d=14.4;
11 H1=0.2;
12 n=1;
13 c=3*10^8;
14
  disp("From equation 24-10, the height of the nth]
15
      fresnel zone Hn is, ");
16
17 l = (((H1^2)*d)/(n*d1*(d1-d)));
18
19 1=1*10^3;
20
21 \text{ disp}('m',1,"l = ")
22
23 f = (c/1);
24
```

```
25 f=f/10^6;
26
27 disp('MHz',f,"f = ");
```

Scilab code Exa 24.3 Determine the noise power

```
1 clc;
2 //Example 24.3
3 //Page No 988
5 disp("Given: Noise bandwidth is 10MHz");
7 //solution
9 f=10*10^6;
10
11 disp("Substituting in equation 24-16 yields, ");
12
13 N = -174 + (10 * \log 10(f));
14
15 disp('dBm',N,"N = ");
16
17 disp("If the minimum C/N requirement for a receiver
      ");
18
19 Cmin = 24 + N;
20
21 \operatorname{disp}('\operatorname{dBm}',\operatorname{Cmin},"N = ");
22
23 disp("For a system gain of 113.35dB, it would
       require a minimum transmit carrier power(Pt) of "
      )
24
25 \text{ Pt} = 113.35 + \text{Cmin};
26
```

```
27 disp('dBm', Pt, "N = ");
```

Scilab code Exa 24.4 Determine the minimum receive carrier power and the minimum transmit power

```
1 clc;
2 //Example 24.4
3 //Page No 990
5 disp("Given: Refer to figure");
7 //solution
9 disp("To achieve a S/N ratio of 32dB out of the FM
      demodulator, an input C/N of 15dB is required.
      Solving the receiver input carrier to noise
      ratios give, ");
10
11 \quad \text{Cmin} = 15 + 6.5
12
13 disp('dB',Cmin,"Cmin/N = ");
14
15 cmin = Cmin + (-104);
16
17 disp('dBm', cmin, "Cmin = ");
18
19 Pt=112+cmin;
20
21 disp('dBm',Pt,"Pt = ");
```

Scilab code Exa 24.5 Determine the following

```
1 clc;
```

```
2 //Example 24.5
3 //Page No 990
5 disp("Given: The system is shown in figure.");
7 //solution
8
9 \text{ cn} = 23;
10 NF=4.42;
11 B=68;
12
13 disp("The minimum C/N at the input to the FM
      receiver is 23dB, ");
14
15 cmin=cn+NF;
16
17 disp('dB',cmin,"CMin/N = ");
19 disp("Substituting into equation 24-16 yields, ");
20
21 N = -174 + B;
22
23 disp('dBm', N, "N = ");
24
25 Cmin = cmin + N;
26
27 \operatorname{disp}(\operatorname{'dBm'},\operatorname{Cmin},\operatorname{"Cmin} = ");
28
29 disp("Substituting into equation 24-14 yields, ");
30
   Fm = ((30*log10(50))+10*(log10(6*0.25*0.125*8))-(10*)
      log10(1-0.99999))-70);
32
33 disp('dB',Fm,"Fm = ");
35 disp("Substituting into equation 24-8 yields, ");
36
37 Lp=92.4+(20*log10(8))+(20*log10(50));
```

```
38

39 disp('dB',Lp,"Lp = ");

40

41 disp(" At=Ar= 37.8 dB"," Lf =

4.875"," Lb = 4 dB","From Table 24-3");
```

Satellite Communication

Scilab code Exa 25.2 Determine the energy per bit for a transmission rate of 50Mbps

```
1 clc;
2 //Example 25.2
3 //Page No 1018
5
7 //solution
9 \text{ Pt} = 1000;
10 fb=50*10^6;
11
12 Tb = (1/fb);
13
14 disp('s',Tb*10^1,"Tb = ");
15
16 Eb=Pt*Tb;
17
18 disp('J',Eb,"Eb = ");
19
20 disp("Expressed as a log with 1 Joule as the
```

```
reference, ");
21
22 eb=10*log10(Eb);
23
24 disp('dBJ',eb,"Eb = ")
25
26 disp("It is common to express Pt in dBW and Eb in dBW/bps. Thus, ");
27
28 pt=10*log10(Pt);
29
30 disp('dBW',pt,"Pt = ");
31
32 disp('dBW/bps',round(eb),"Eb = ");
```

Scilab code Exa 25.5 Determine the noise density and equivalent noise temperature

```
1 clc;
2 //Example 25.5
3 //Page No 1022
4
5
6
7 //solution:
8
9 B=10*10^6;
10 N=276*10^-16;
11 K=1.38*10^-23;
12
13 disp("Substituting into equation 25-12, we have");
14
15 NO=(N/B);
16
17 disp('W/Hz',NO,"NO = ");
```