collector current = 0.002495ampere

emitter current = 0.00252ampere

collector current with ib = 0.002475ampere

emitter current = 0.0025ampere

error = 0.007936508