Scilab Textbook Companion for Semiconductor Physics and Devices Basic Principles by D. A. Neamen¹

Created by
Reshma Sunil Konjari
Mtech
Electrical Engineering
VIT vellore
College Teacher
None
Cross-Checked by
None

June 8, 2016

¹Funded by a grant from the National Mission on Education through ICT, http://spoken-tutorial.org/NMEICT-Intro. This Textbook Companion and Scilab codes written in it can be downloaded from the "Textbook Companion Project" section at the website http://scilab.in

Book Description

Title: Semiconductor Physics and Devices Basic Principles

Author: D. A. Neamen

Publisher: McGraw-Hill

Edition: 3

Year: 2003

ISBN: 0-07-1-19862-8

Scilab numbering policy used in this document and the relation to the above book.

Exa Example (Solved example)

Eqn Equation (Particular equation of the above book)

AP Appendix to Example(Scilab Code that is an Appednix to a particular Example of the above book)

For example, Exa 3.51 means solved example 3.51 of this book. Sec 2.3 means a scilab code whose theory is explained in Section 2.3 of the book.

Contents

Lis	List of Scilab Codes		
1	The Crystal Structure of Solids	5	
2	Introduction to Quantum Mechanics	6	
3	Introduction to the Quantum Theory of Solids	9	
4	The Semiconductor in Equilibrium	13	
5	Carrier Transport Phenomena	21	
6	Nonequilibrium Excess Carriers in Semiconductors	26	
7	The pn Junction	30	
8	The pn Junction Diode	34	
9	Metal Semiconductor and Semiconductor Heterojunctions	39	
10	The Bipolar Transistor	45	
11	Fundamentals of the Metal Oxide Semiconductor Field Effect Transistor	52	

List of Scilab Codes

Exa 1.1	find volume density of atoms
Exa 1.3	Calculate suface density
Exa 2.1	Calculate photon energy
Exa 2.2	Calculate de broglie wavelength
Exa 2.3	Calculate first three energy levels
Exa 2.4	Calculate penetration depth
Exa 2.5	Calculate probability
Exa 3.1	Calculate change in KE
Exa 3.2	Determine lowest energy bandwidth
Exa 3.3	Calculate density of states
Exa 3.4	Determine possible no of ways
Exa 3.5	Determine possible no of ways
Exa 3.6	Calculate probability
Exa 3.7	Determine temp
Exa 4.1	Calculate probability
Exa 4.2	Calculate thermal equilibrium
Exa 4.3	Calculate intrinsic carrier
Exa 4.4	Calculate position
Exa 4.5	Calculate thermal equilibrium
Exa 4.6	Calculate electron concentration
Exa 4.7	Determine fraction of total electron
Exa 4.9	Calculate thermal equilibrium
Exa 4.10	Calculate thermal equilibrium
Exa 4.11	Calculate thermal equilibrium
Exa 4.12	Determine impurity concentration
Exa 4.13	Determine impurity concentration
Exa 4.14	Determine fermi level position
Exa 5.1	Drift current density

Exa 5.2	doping concentration
Exa 5.3	design semiconductor resistor
Exa 5.4	diffusion current density
Exa 5.5	Determine induced electric field
Exa 5.6	Determine diffusion coefficient
Exa 5.7	determine majority carrier
Exa 6.5	dielechic relaxation time constant
Exa 6.6	calculate the quasi Fermi energy levels
Exa 6.8	detrrming the steady state excess carrier concentration 2
Exa 6.10	determine the value of surface recombinaion velocity
Exa 7.1	calculate the built in potential barrier
Exa 7.2	calculate the space charge width
Exa 7.3	To calculate the width of the space charge region
Exa 7.4	design a pn junction
Exa 7.5	calculate the junction capacitance
Exa 7.6	determine the impurity doping concentrations
Exa 8.1	calculate the minority carrier hole concentration 3
Exa 8.2	ideal reverse saturation current density
Exa 8.3	design a pn junction diode
Exa 8.4	calculate the electric field
Exa 8.5	determine the change in the forward bias voltage
Exa 8.6	calculate the small signal admittance
Exa 8.7	determine the relative magnitudes
Exa 9.1	calculate the ilieorelical harrier height
Exa 9.2	calculate the semiconductor doping
Exa 9.3	calcular the Schottky barrier lowering
Exa 9.4	calculate the effective Richardson constant
Exa 9.5	calculate the reverse saturation current densities
Exa 9.6	calculate the forward bias voltage
Exa 9.7	calculate the space charge width
Exa 9.8	determine AE At and Vbi
Exa 10.1	design the ratio of emitter doping
Exa 10.2	design the base width
Exa 10.3	calculate the forujard biased
Exa 10.4	calculate the common emitter current gain
Exa 10.5	calculate the change in the neutral base width 4
Exa 10.7	determine the increase in pE0
Exa 10.8	design the collector doping

Exa 10.9	design a bipolar transistor	49
Exa 10.10	calculate the collector zmitter saturation voltage	50
Exa 10.12	calculate the emitter to collector transit time	50
Exa 11.1	calculate the maximum space charge width	52
Exa 11.2	calculate the metal semiconductor work function differ-	
	ence	52
Exa 11.3	calculate the flat band voltage	53
Exa 11.4	design the oxide thickness	54
Exa 11.5	calculate the threshold voltage	54
Exa 11.6	design the semiconductor dnping concentration	55
Exa 11.7	calculate Cox	56
Exa 11.8	design the width	57
Exa 11.9	determine the inversion carrier mobility	57
Exa 11.10	calculate the change in the threshold voltage	58
Eva 11 11	calculate the cutoff frequency	59

The Crystal Structure of Solids

Scilab code Exa 1.1 find volume density of atoms

```
1 clc
2
3 a=5*10^-8// a=5A = 5*10^-8cm
4 n=2
5 d=n/a^3
6 disp(d,"the value of d in atoms per cm^3 is")
```

Scilab code Exa 1.3 Calculate suface density

```
1 clc
2
3 a1=5*10^-8// a=5A = 5*10^-8cm
4 n=2// number of atoms is 2
5 d=n/(a1*a1*2^0.5)
6 disp(d,"the value of d in atoms per cm^2 is")
```

Introduction to Quantum Mechanics

Scilab code Exa 2.1 Calculate photon energy

```
1 clc
2
3 lambda=0.708*10^-8// cm
4 h=6.625*10^-34// J*s Plank's constant
5 c=3*10^10// cm/s
6 e=1.6*10^-19// eV
7 E=h*c/lambda// E=hv=hc/lambda
8 disp(E,"the value of E in J is")
9 E=E/e
10 disp(E,"the value of E in eV is")
```

Scilab code Exa 2.2 Calculate de broglie wavelength

```
1 clc
2
3 m=9.11*10^-31// kg*m/s
```

```
4 v=10^5//m/s
5 h=6.625*10^-34//js
6
7 p=m*v
8 disp(p,"momentum is")
9 lambda=h/p
10 disp(lambda,"de broglie wavelength in meter is")
```

Scilab code Exa 2.3 Calculate first three energy levels

```
1 clc
a=5*10^-8// a=5A = 5*10^-8cm
4 h=1.054*10^-34// J*s Plank's constant
5 m=9.11*10^-31// kg*m/s
6 \text{ e=1.6*10}^-19// \text{ eV}
7
8 n=1
9 En=(h^2*n^2*\%pi^2)/(2*m*a^2)
10 disp(En," the value of En in J")
11 En=(En/e)
12 disp(En,"the value of En in eV")
13
14 n=2
15 E2=(h^2*n^2*\%pi^2)/(2*m*a^2)
16 disp(En,"the value of E2 in J")
17 E2 = (E2/e)
18 disp(E2,"the value of E2 in eV")
19
20 n=3
21 E3=(h^2*n^2*\%pi^2)/(2*m*a^2)
22 disp(E3,"the value of E3 in J")
23 E3 = (E3/e)
24 disp(E3,"the value of E3 in eV")
```

Scilab code Exa 2.4 Calculate penetration depth

```
1 clc
2
3 v=10^5// m/s
4 m=9.11*10^-31// kg*m/s
5 e=1.6*10^-19// eV
6 h=1.054*10^-34
7 E=0.5*m*v*v
8 disp(E,"the value of E in J is eV")
9 E1=E/e // value of E in eV
10 disp(E1,"eV=")
11 d=sqrt((h*h)/(2*m*E))
12 disp(d,"the value of d in m is ")
```

Scilab code Exa 2.5 Calculate probability

```
1 clc
2
3 E=2// eV
4 V0=20// eV
5 a=3*10^-10// a=3A = 3*10^-10 m
6 m=9.11*10^-31// kg*m/s
7 e=1.6*10^-19// eV
8 h=1.054*10^-34// J*s
9 K2=((2*m*(V0-E)*e)/(h*h))^0.5
10 disp(K2,"the value of K2 in m^-1 is")
11 T=16*(E/V0)*(1-E/V0)*exp(-2*K2*a)
12 disp(T,"the value of T is")
```

Introduction to the Quantum Theory of Solids

Scilab code Exa 3.1 Calculate change in KE

```
1 clc
2
3 v1=10^5 //m per sec
4 deltav=0.01 //m per sec
5 m=9.11*10^-31// kg*m/s
6 e=1.6*10**-9 //Coulombs
7
8 //deltaE=0.5*m*(v2**2-v1**2)
9 //deltav=v2-v1......deltav<<v1
10
11 deltaE=m*v1*deltav
12 disp(deltaE,"in J is")
13 deltaE=deltaE/e
14 disp(deltaE,"in eV is")</pre>
```

Scilab code Exa 3.2 Determine lowest energy bandwidth

```
1 clc
2
3 P = 10
4 a=5*10^-10 // a=5 Armstrong
5 h=1.054*10^-34
6 \text{ m} = 9.11 * 10^{-31} / \text{kg}
7
8 // alpha*a=\%pi
9 // sqrt((2*m*E2)/h^2)*a=\%pi
10 E2=(\%pi^2*h^2)/(2*m*a^2)
11 disp(E2, 'E2= \%f J\n')
12 E2=E2*6.2415*10^18
13 disp(E2, 'E2 = \%f eV')
14
15 E1=1.053 //eV
16 AE=E2-E1
17 disp(AE, 'AE= %f eV')
```

Scilab code Exa 3.3 Calculate density of states

```
1 clc
2
3 m=9.11*10^-31 //kg
4 E=1.6*10^-19 //C
5 h=6.625*10^-34 //J sec
6 N=(4*%pi*(2*m)^(3/2)*2*E^(3/2))/(h^3*3)
7 disp(N, 'E2= %f per meter^3\n')
```

Scilab code Exa 3.4 Determine possible no of ways

```
1 clc
2
3 y=10
```

```
4 Ni=10

5 gi=10

6 //(gi-Ni)!=1

7 z=(factorial(gi)/factorial(Ni)*factorial(gi-Ni))

8 printf('z=%f\n',z)
```

Scilab code Exa 3.5 Determine possible no of ways

```
1    clc
2    gi = 10
3    Ni = 9
4    x = gi - Ni
5
6    // factorial(gi - Ni) = 1
7    z = (factorial(gi)/factorial(Ni)*factorial(gi - Ni))
8    printf('z=%f\n',z)
```

Scilab code Exa 3.6 Calculate probability

```
1 clc
2
3 T=300 //K
4 //a=E-Ef
5 //a=3*k*T
6 //fF(E)=1/(1+exp(E-Ef/kT))
7 z=exp(3)
8 y=1/(1+z) //y=fF(E)
9 printf('fF(E)=%f\n',y)
```

Scilab code Exa 3.7 Determine temp

```
1 clc
2
3 Ef = 6.25 / eV
4 E=5.95 //eV
5 p=0.01
6 k= 8.617 *10^-5 //eV K^-1
8 / p=1-fF(E)
9 //fF(E) = 1/(1 + exp(E-Ef/kT))
10 //p=1-1/(1+\exp(E-Ef/kT))
                                               equation 1
11 \quad x = E - Ef
12
13 y=(1/(1-p))-1 // solving the above equtaion 1
14
15 T=x/(k*log(y))
16 printf ('T=\%f K \setminus n', T)
```

The Semiconductor in Equilibrium

Scilab code Exa 4.1 Calculate probability

```
1 clc
2
3 T=300 //K
4 Nc=2.8*10^19 //cm^-3
5 k=8.617 *10^-5 //eV K^-1
6 //E=Ec
7 //a=Ec-Ef
8 a=-0.25
9 //fF(E)=1/(1+exp(Ec-Ef/kT)) =exp(-(Ec-Ef)/kT)
10 //b=k*T
11 //disp(b)
12 c=k*T
13 fFE=exp(a/c)
14 disp(fFE, "fF(E) value is=")
15 n0=Nc*exp(-a/(k*T))
16 disp(n0,"n0 value in cm^-3 is")
```

Scilab code Exa 4.2 Calculate thermal equlilibrium

```
1 clc
2
3 T1=400 //K
4 T2=300 //K
5 N=1.04*10^19 //cm^-3
6 k=8.617*10^-5 //eV/K
7
8 Nv=N*(T1/T2)^(3/2)
9 disp(Nv,'Nv=%f cm^-3\n\n')
10
11 a=k*T2*(T1/T2)
12 disp(a,'kT=%f eV\n\n')
13
14 //p0=Nv*exp(-(Ef-Ev)/kT)
15 p0=Nv*exp(-0.27/a)
16 disp(p0,'p0=%f cm^-3 \n')
```

Scilab code Exa 4.3 Calculate intrinsic carrier

```
1 clc
2
3 T1=300 //K
4 T2=450 //K
5 Nc=4.7*10^17 //cm^-3
6 N=7*10^18 //cm^-3
7 k=8.617*10^-5 //eV/K
8 a=k*T1*(T2/T1)
9 disp(a, 'kT=%f eV\n\n')
10
11 ni=sqrt(Nc*N*exp(-1.42/(k*T1)))
12 disp(ni, 'ni=%f cm^-3\n\n')
13
14 ni=sqrt(Nc*N*(T2/T1)^3*exp(-1.42/a))
```

```
15 disp(ni, 'ni=\%f cm^-3\n\n')
```

Scilab code Exa 4.4 Calculate position

```
1 clc
2
3 T=300 //K
4 mn=1.08 //m0
5 mp=0.56 //m0
6 k=8.617*10^-5 //eV/K
7
8 //Efi-Emidgap=(3/4)k*T*log(mp/mn)
9 //a=Efi-Emidgap
10
11 a=(0.75)*k*T*log(mp/mn)
12 printf('Efi-Emidgap=%f eV',a) //textbook ans is wrong
```

Scilab code Exa 4.5 Calculate thermal equlilibrium

```
1 clc
2
3 T=300 //K
4 Nn=2.8*10^19 //cm^-3
5 Np=1.04*10^19 //cm^-3
6 //a=Ef-Ev
7 an=0.25 //eV
8 ap=0.87 //eV
9 k=8.617*10^-5 //eV/K
10
11 n0=Nn*exp(-an/(k*T))
12 disp(n0,"n0 in cm^-3 is=")
13
```

```
14 p0=Np*exp(-ap/(k*T))
15 disp(p0,"p0 in cm^-3 is=")
```

Scilab code Exa 4.6 Calculate electron concentration

```
1 clc
2
3 nf = 2
4 T = 300 //K
5 Nc = 2.8*10**19 //cm^-3
6
7 //n0 = (2/sqrt(%pi))*Nc*F12(nf)
8 //x=F12(nf) = 2.3
9 x = 2.3
10 n0 = (2/sqrt(%pi))*Nc*x
11 disp(n0,"n0 in cm^-3 is=")
```

Scilab code Exa 4.7 Determine fraction of total electron

```
1 clc
2
3 Nd=10**16 //cm^-3
4 Ne=2.8*10**19 //cm^-3
5 T=300 //K
6
7 //(nd/(n0+nd))=z=1/(1+(Ne/2*Nd)*exp(-(Ec-Ed)/kT))
8 //y=Ec-Ed
9 y=0.045
10 k=8.617*10^-5 //eV/K
11 z=1/(1+(Ne/(2*Nd))*exp(-y/(k*T)))
12 disp(z,"the donor states is=")
```

Scilab code Exa 4.9 Calculate thermal equlilibrium

```
1 clc
2
3 Nd=10**16 //cm^-3
4 Na=0
5 ni=1.5*10**10 //cm^-3
6 T=300 //K
7 k=8.617*10^-5 //eV/K
8
9 n0=((Nd-Na)/2)+sqrt((((Nd-Na)/2)^2)+ni^2)
10 disp(n0,"n0 in cm^-3 is")
11
12 p0=(ni^2)/n0
13 disp(p0,"p0 in cm^-3")
```

Scilab code Exa 4.10 Calculate thermal equilibrium

```
1 clc
2
3 Nd=5*10**13 //cm^-3
4 Na=0
5 ni=2.4*10**13 //cm^-3
6 T=300 //K
7 k=8.617*10^-5 //eV/K
8
9 n0=((Nd-Na)/2)+sqrt((((Nd-Na)/2)^2)+ni^2)
10 disp(n0,"n0 in cm^-3 is")
11
12 p0=(ni^2)/n0
13 disp(p0,"p0 in cm^-3")
```

Scilab code Exa 4.11 Calculate thermal equlilibrium

```
1 clc
 2
 3 T = 300 / K
 4 Nd=3*10**15 //cm**-3
5 Na=10**16 //\text{cm}**-3
 6 \text{ k=8.617*10^--5} //\text{eV/K}
 7 ni=1.5*10**16 //cm^-3
 9 a = ((Na - Nd)/2)
10 disp(a)
11 b=sqrt(((Na-Nd)/2)^2+(ni^2))
12 disp(b)
13
14 p0=a+b
15 \operatorname{disp}(p0, p0 \text{ in } \operatorname{cm}^-3 \text{ is}=")
                                                      //textbook ans is
         wrpng
16
17 n0=(ni^2)/p0
18 \operatorname{disp}(n0,"n0 \text{ in } \operatorname{cm}^-3 \text{ is}=")
                                                     //textbook ans is
         wrpng
```

Scilab code Exa 4.12 Determine impurity concentration

```
1 clc

2

3 T1=550 //K

4 T2=300 //K

5 Nc=2.8*10**19 //cm**-3

6 Ne=1.04*10**19 //cm**-3

7 k=8.617*10^-5 //eV/K
```

```
8 \text{ Eg} = 1.12
10 // \text{ni}^2 = \text{Nc} * \text{Ne} * \exp(-\text{Eg}/(k*T))
11
12 ni = sqrt(Nc*Ne*(T1/T2)^3*exp((-Eg/(k*T2))*(T2/T1)))
13 \operatorname{disp}(\operatorname{ni}, \operatorname{"ni} \operatorname{in} \operatorname{cm}^-3 \operatorname{is} = \operatorname{"})
14
15 / n0 = 1.05 * Nd
16 //n0 = (Nd/2) + sqrt((Nd/2)^2 + ni^2) equation 1
17
18 a=(((1.05*2)-1)/2)^2
                                                               //simplifying and
          sloving the about equaton 1
19 b=ni^2
20 c = ((4*a) - 1)/4
21 Nd=sqrt(b/c)
22 \operatorname{disp}(\operatorname{Nd}, \operatorname{Nd} \operatorname{value} \operatorname{in} \operatorname{cm}^-3 \operatorname{is}=")
```

Scilab code Exa 4.13 Determine impurity concentration

```
1 clc
2
3 T=300 //K
4 Na=10**16 //cm^-3
5 Nc=2.8*10**19 //cm**-3
6 k=8.617*10^-5 //eV/K
7
8 //a=Ec-Ef
9 a=0.20 //eV
10 //Ec-Ef=k*T*log(Ne/(Nd-Na))
11 //Nd-Na=Nc*exp(-(Ec-Ef)/k*T)
12
13 Nd=Na+Nc*exp(-a/(k*T))
14 disp(Nd,"Nd in cm^-3 is=")
```

Scilab code Exa 4.14 Determine fermi level position

```
1 clc
2
3 T=300 //K
4 k=8.617*10^-5 //eV/K
5 ni=1.5*10**10 //cm^-3
6 //Ef-Ea=a
7 a=3*k*T
8 //Ea-Ev=b
9 b=0.045 //eV
10 Eg=1.12 //eV
11
12 //Efi-Ef=(Eg/2)-(Ea-Ev)-(Ef-Ea)=kT*log(Na/ni)
13 c=(Eg/2)-(b)-(a)
14 Na=ni*exp(c/(k*T))
15 disp(Na,"Na in cm^-3 is=")
```

Carrier Transport Phenomena

Scilab code Exa 5.1 Drift current density

```
1 clc
3 Nd=10**16 //\text{cm}^-3
4 Na=0
5 ni=1.8*10**6 //\text{cm}^-3
6 T = 300 / K
7 k=8.617*10^{-5} //eV/K
8 E=10 //V/cm^2
9 e=1.6*10**-19
10 un=8500
11
12 n0 = ((Nd-Na)/2) + sqrt((((Nd-Na)/2)^2) + ni^2)
13 \operatorname{disp}(n0, "n0 \text{ in } \operatorname{cm}^-3 \text{ is}")
14
15 p0=(ni^2)/n0
16 disp(p0, "p0 in cm^-3")
17
18 // J dr f = e * (un * n0 + up * p0) * E = e * un * Nd * E
19 Jdrf=e*un*Nd*E
20 disp(Jdrf, "Jdrf in A/cm<sup>2</sup> is=")
```

Scilab code Exa 5.2 doping concentration

```
1 clc
 2
3 \text{ Na=10**17} //\text{cm**}-3
4 T = 300 / K
5 \text{ k=8.617*10^--5} //\text{eV/K}
6 E=10 //V/cm^2
7 e=1.6*10**-19 //C
8
9
10 / \sin a = e \cdot un \cdot n0 = e \cdot un \cdot (Nd-Na)
11 // if
12 Nd = 2*10**17 / cm**-3
13 sigma=8.16//ohm/cm
14 un=sigma/(e*(Nd-Na))
15 disp(un,"un in cm^2/Vs is=")
16
17 // if
18 \text{ Nd} = 5*10**17 //\text{cm}^{-3}
19 sigma=20.8//ohm/cm
20 \text{ un=sigma/(e*(Nd-Na))}
21 disp(un,"un in cm^2/Vs is=")
22
\frac{23}{1} // if
24 \text{ Nd} = 3.5 * 10 * * 17 // \text{cm}^{-3}
25 \text{ sigma=16//ohm/cm}
26 \text{ un=sigma/(e*(Nd-Na))}
27 disp(un,"un in cm^2/Vs is=")
```

Scilab code Exa 5.3 design semiconductor resistor

```
1 clc
3 V = 5 / v
4 R=10*10^3 //ohm
5 J=50 //A/cm^2
6 E = 100
7 Na=1.25*10**16 //\text{cm}^-3
8 Nd=5*10**15 //\text{cm}^-3
9 e=1.6*10**-19 //C
10 up=410 //\text{cm}**2/\text{Vs}
11
12 I = V/R
13 disp(I," I current in Ampere is=")
14
15 \quad A = I / J
16 disp(A,"A cross sectional area in cm^2 is=")
17
18 L=V/E
19 disp(L,"L length of resistor in cm is=")
20
21 \text{ sigma=L/(R*A)}
22 disp(sigma, "sigma conductivity in per ohm cm is=")
23
24 / sigma = e * up * p0 = e * up * (Na-Nd)
25 \text{ sigma=e*up*(Na-Nd)}
26 disp(sigma, "sigma conductivity in per ohm cm is=")
```

Scilab code Exa 5.4 diffusion current density

```
1 clc
2
3 T=300 // ..K
4 Dn=225 //cm^2/s
5 e=1.6*10^-19// C
6 deltax=0.10 //cm
```

```
7 deltan=(1*10**18-7*10**17) //cm^-3

8 9 //Jnxdif=e*Dx*derivative (n,x)=e*Dn*(deltan/deltax)

10 Jnxdif=e*Dn*(deltan/deltax)

11 disp(Jnxdif,"diffusion current density in A/cm^2 is=""")
```

Scilab code Exa 5.5 Determine induced electric field

```
1 clc
2
3 T=300 //K
4 k=8.617*10^-5 //eV/K
5 //derivative(Ndx,x)=a
6 a=-10**19 //cm**-4
7 Ndx=(10^16-10^19) //cm^3
8 l=1
9
10 //Ex=-(k*T/l)*(1/Ndx)*derivative(Ndx,x)
11 Ex=-(k*T/l)*(1/Ndx)*a*10^3
12 disp(Ex,"induced electric field in V/cm is=")
```

Scilab code Exa 5.6 Determine diffusion coefficient

```
1 clc
2
3 T=300 //K
4 u=1000 //cm^2/s
5 k=8.617*10^-5 //eV/K
6 e=1.6*10**-19 //C
7
8 //D=((k*T)/e)*u
9 D=k*T*u
```

```
10 disp(D, "diffusion coefficient in cm^2/s is =")
```

Scilab code Exa 5.7 determine majority carrier

```
1 clc
2
3 I = 10^{-3} / A
4 Bz=5*10**-2 //500 gauss
5 e=1.6810*10**-19 //C
6 Vh = -6.25*10^{-3} / V
7 Vx = 12.5 / V
8 W = 10 * * -4 / /m
9 d=10**-5 /m
10
11 u = -(I*Bz)/(e*Vh*d)
12 disp(u, "electron concemtration in m^-3 is=")
13
14 un=(I*I)/(e*Bz*Vx*W*d)
15 disp(un, "electron mobility in /Vs is=")//
      textbook ans is wrong
```

Nonequilibrium Excess Carriers in Semiconductors

Scilab code Exa 6.5 dielechic relaxation time constant

```
1 clc
3 \text{ k=8.617*10**-5//eV/K}
 4 e=1.6*10**-19 //C
5 un = 1200
 6 Nd=10^16 //\text{cm}^-3
7 \text{ esp0} = 8.85 * 10^{-14}
8 \text{ espr} = 11.7
10 \text{ sigma=e*un*Nd}
11 disp(sigma, "conductivity in per ohm cm is=")
12
13 \text{ esp=espr*esp0}
14 disp(esp, "permittivity of silicon in F/cm")
15
16 taud=esp/sigma
17 disp(taud," dielectric relaxtion time constant in sec
        is = ")
```

Scilab code Exa 6.6 calculate the quasi Fermi energy levels

```
1 clc
2
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 n0=10^15 /cm^-3
7 p0=10^5 /cm^-3
8 ni=10^10 / cm^-3
9 deltan=10**13 //cm**-3
10 deltap=10**13 //\text{cm}**-3
11
12 / Ef - Efi = a
13 a=(k*T)*log(n0/ni)
14 disp(a, "fermi level for thermal equlibrium in eV is=
15
16 / Efn - Efi = b
17 b=(k*T)*log((n0+deltan)/ni)
18 disp(b, "quasi fermi level for electrons in eV is=")
19
20 / Efi - Efp = c
21 c=(k*T)*log((p0+deltap)/ni)
22 disp(c, "quasi fermi level for holes in eV is=")
```

Scilab code Exa 6.8 detrrmine the steady state excess carrier concentration

```
1 clc
2
3 k=8.617*10**-5//eV/K
```

```
4 e=1.6*10**-19 //C
5 x=0
6 taup0=10**-6//ses
7 taup01=10**-7 // sec
8 deltapb=10**14 //\text{cm}**-3
9 Dn=10 / cm^2 / sec
10 \mathrm{Dp}=10~/\mathrm{cm}^2/\mathrm{sec}
11 B = -9 * 10^13
12
13 deltap=deltapb*(taup01/taup0)
14 \operatorname{disp}(\operatorname{deltap}, \operatorname{deltap} \operatorname{in} \operatorname{cm}^-3 \operatorname{is}=")
15
16 g=deltap/taup0
17 disp(g, "g generation in cm^-3s^-1 is=")
18
19 // \det a p x = 10^14 * (1 - 0.9 * \exp(-x/Lp))
20 Lp=sqrt(Dp*taup0)
21 disp(Lp,"Lp in meter is=")
22
23 deltapx=10^14*(1-0.9*exp(-x/Lp))
24 disp(deltapx, "distance from the surface is =")
```

Scilab code Exa 6.10 determine the value of surface recombination velocity

```
1 clc
2
3 k=8.617*10**-5//eV/K
4 e=1.6*10**-19 //C
5 Dp=10//cm^2/sec
6 Lp=31.6*10**-4 //m
7 g1taup0=10^14 //cm^-3
8 deltap0=10^13 //cm6-3
9
10 //deltap0=g1taup0*[g/((Dp/Lp)+s)]
11 s=(Dp/Lp)*((g1taup0/deltap0)-1)
```

12 disp(s,"surface recombination velocity in cm per sec is=")

The pn Junction

Scilab code Exa 7.1 calculate the built in potential barrier

```
1 clc
2
3 T=300//K
4 Na=1*10^18// Na=L*10^18 cm^-3
5 Nd=1*10^15// cm^-3
6 ni=1.5*10^10// cm^-3
7 e=1.6*10^-19// eV
8 k=1.3806*10^-23// JK^-1
9 Vbi=(((k*T)/e)*log(Na*Nd/ni^2))
10 disp(Vbi," the value of Vbi in V is")
11
12 //changing the Na value
13 Na=10^16// Na=l*10^16 cm^1
14 Vbi=(((k*T)/e)*log(Na*Nd/ni^2))
15 disp(Vbi," the value of Vbi in V is")
```

Scilab code Exa 7.2 calculate the space charge width

Scilab code Exa 7.3 Tocalculate the width of the space charge region

```
1 clc
2
3 T=300//K
4 Na=10^16// cm^-3
5 Nd=10^15// cm^-3
6 e=1.6*10^-19// eV
7 epsilon0=8.85*10^-14// F/m
8 epsilons=11.7
9 Vbi=0.635// V
10 Vr=5// V
11 W=(((2*(epsilons*epsilon0)*(Vbi+Vr))/e)*((Na+Nd)/(Na*Nd)))^0.5
12 disp(W,"the value of W in m is")
```

Scilab code Exa 7.4 design a pn junction

```
1 clc
2
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 Vr = 25 / V
7 Emax = 3*10^5 / V/cm
8 Na=10^18//cm^-3
9 \text{ esp} = 11.7
10 \text{ esp0=8.85*10^-14}
11
12 / \text{Emax} = \text{sqrt} ((2 * e * \text{Vr} * (\text{Na} + \text{Nd})) / (\text{esp} * (\text{Na} + \text{Nd}))
13 x = ((Emax^2) * esp*esp0)/(2*e*Vr)
                                                             //solving
       the above equation we get
14
15 Nd = (Na*x)/(Na-x)
16 disp(Nd, "doping concentration in cm^-3 is =")
```

Scilab code Exa 7.5 calculate the junction capacitance

```
1 clc
2
3 T=300//K
4 Na=10^16// cm^-3
5 Nd=10^15// cm^-3
6 e=1.6*10^-19// eV
7 epsilon0=8.85*10^-14// F/m
8 epsilons=11.7
9 Vbi=0.635// V
10 Vr=5// V
11 C=((e*(epsilons*epsilon0)*Na*Nd)/(2*(Vbi+Vr)*(Na+Nd)))^0.5
12 A=10^-4// cm^2
13 C=C*A
14 disp(C,"the value of c with cross section area in F
```

Scilab code Exa 7.6 determine the impurity doping concentrations

```
1 clc
2
3 T=300//K
4 ni=1.5*10^10// cm^-3
5 Nd=10^15// cm^-3
6 Vbi=0.855// V
7 e=1.6*10^-19// eV
8 k=1.3806*10^-23// JK^-1
9 S=1.32*10^15// Slope=1.32*10^-15 (F/cm^2)^-2*(V)-1
10 epsilon0=8.85*10^-14// F/m
11 epsilons=11.7
12 Nd=2/((e*(epsilons*epsilon0))*S)
13 Na=((ni*ni)/Nd)*exp((e*Vbi)/(k*T))
14 disp(Na,"the value of Na in cm^-3 is")
```

Chapter 8

The pn Junction Diode

Scilab code Exa 8.1 calculate the minority carrier hole concentration

```
1 clc
2
3 T=300// K
4 ni=1.5*10^10 //cm^-3
5 k=8.617*10^-5 //eV/K
6 Nd=10^16 //cm^-3
7 Va=0.60 //V
8
9 //pn=pn0*exp(e*Va/k*T)
10 pn0=ni^2/Nd
11 disp(pn0, "thermal equlibrium minority carrier hole concentration in cm^-3 is=")
12
13 pn=pn0*exp(Va/(k*T))
14 disp(pn, "minority carrier hole concentration in cm^-3 is=")
```

Scilab code Exa 8.2 ideal reverse saturation current density

```
1 clc
 2
 3 T = 300 / K
4 Na=10**16 //\text{cm}^-3
5 \text{ Nd} = 10 * * 16 //\text{cm}^{-3}
6 ni=1.5*10**10 //cm^-3
7 Dn=25 //\text{cm}^2/\text{s}
8 Dp=10 //\text{cm}^2/\text{s}
9 taup0=5*10^-7 //s
10 taun0=5*10^-7 //s
11 \text{ epsilon=} 11.7
12 e=1.6*10**-19 //C
13
14 //J = (E*D*np0/Ln) + (E*D*pn0/Lp)
15 Js=e*ni^2*[(1/Na)*sqrt(Dn/taun0)+(1/Nd)*sqrt(Dp/
       taup0)]
16 disp(Js, "reverse saturation current density in A/cm
       ^2 is=")
```

Scilab code Exa 8.3 design a pn junction diode

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 Jp=5 //A/cm^2
7 Jn=20 //A/cm^2
8 Va=0.65 //V
9 ni=1.5*10**10 //cm^-3
10 Dn=25 //cm^2/s
11 Dp=10 //cm^2/s
12 taup0=5*10^-7 //s
13 taun0=5*10^-7 //s
```

```
15  //Jn=(e*Dn*np0/Ln)*[exp(e*Va/k*T)-1]==e*sqrt(Dn/taun0)*(ni^2/Na)*[exp(e*Va/k*T)-1]
16
17  Na=e*sqrt(Dn/taun0)*(ni^2/Jn)*[(exp(Va/(k*T)))-1]
18  disp(Na,"Na electron diffusion current density in cm ^-3 is= ")
19
20  //Jp=(e*Dp*pn0/Lp)*[exp(e*Va/k*T)-1]==e*sqrt(Dp/taup0)*(ni^2/Nd)
21
22  Nd=e*sqrt(Dp/taup0)*(ni^2/Jp)*[(exp(Va/(k*T)))-1]
23  disp(Nd,"Nd hole diffusion current density in cm^-3 is= ")
```

Scilab code Exa 8.4 calculate the electric field

```
1 clc
2
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 Va=0.65 / V
7 Js=4.15*10^-11//A/cm^2
8 Nd=10**16 //cm**-3
9 un=1350 //\text{cm}^2/\text{Vs}
10 Jn=3.29 //A/cm^2
11
12 J=Js*[exp(Va/(k*T))-1]
13 disp(J, "current density in A/cm<sup>2</sup> is=")
14
15 E=Jn/(e*Nd*un)
16 disp(E, "electric field in V/cm is=")
```

Scilab code Exa 8.5 determine the change in the forward bias voltage

```
1 clc

2

3 T1=300 //K

4 T2=310 //K

5 k=8.617*10**-5//eV/K

6 e=1.6*10**-19 //C

7 Va1=0.60 //V

8 Va2=0.5827 //V

9 E=1.12 //eV

10

11 //J=exp(-Eg/(k*T))*exp((e*Va)/(k*T))

12

13 a=([e*Va2*k*T1]+[e*Va1*k*T2])/((k*T1)-(k*T2))

14 disp(a)
```

Scilab code Exa 8.6 calculate the small signal admittance

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 Vt=0.0259 //v
7 lp0=10^-3 //A
8 taup0=10^-7 //s
9 Idq=1*10**-3//A
10
11 Cd=(1*lp0*taup0)/(2*Vt)
12 disp(Cd," diffusion capacitance in F is=")
13
14 vd=(Vt/Idq)
15 disp(vd," diffusion in ohm is=")
```

Scilab code Exa 8.7 determine the relative magnitudes

```
1 clc
2
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 Na=10**16 //\text{cm}^-3
7 Nd=10**16 //\text{cm}^-3
8 ni=1.5*10**10 //cm^-3
9 \text{ tau0=}5*10^-7 //s
10 \text{ eps} = 11.7
11 //Vbr+Vr=z
12 z=5 /V
13
14 W=sqrt(((2*eps))*((Na+Nd)/Na*Nd)*z)
15 disp(W, "depletion width in cm is=")//
      textbook ans is wrong
16
17 Jgen=(e*ni*W)/(2*tau0)
18 disp(Jgen, generation current density in A/cm^2 is=
              textbook ans is wrong
```

Chapter 9

Metal Semiconductor and Semiconductor Heterojunctions

Scilab code Exa 9.1 calculate the ilieorelical harrier height

```
1 clc
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 \text{ e=1.6*10**-19} //C
6 Nd=10**16 //\text{cm}^-3
7 Nr=2.8*10**19 //\text{cm}^-3
8 \text{ Vbi} = 0.33
9 phim=4.55 //V
10 psi=4.01 / V
11 \text{ esp=} 11.7
12 \text{ esp0} = 8.85 * 10^{-14}
13
14 hb=phim-psi
15 disp(hb, "barrier height in V is=")
16
17 phiu=(k*T)*log(Nr/Nd)
18 disp(phiu, "schottky barrier height in V is=")
```

```
Vbt=hb-phiu
disp(Vbt,"in V is=")

xn=sqrt((2*esp*esp0*Vbi)/(e*Nd))
disp(xn,"space charge in cm is= ")

Emax=(e*Nd*xn)/(esp*esp0)
disp(Emax,"maxi electric field in V/cm is= ")
```

Scilab code Exa 9.2 calculate the semiconductor doping

```
1 clc
2
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 \text{ esp} = 11.7
7 \text{ esp0} = 8.85 * 10^{-14}
8 Nd=2.7*10**17 //\text{cm}^-3
9 Na=2.8*10**19 //\text{cm}^-3
10 \text{ Vbi} = 0.40
11
12 / (1/C)^2 = 2*(Vbi+Vr)/(e*esp*Nd)
13 // delta (1/C)^2 / delta Vr = z
14 z=4.4*10**13
15 \text{ Nd=2/(e*esp*esp0*z)}
16 disp(Nd, "semiconductor doping in cm^-3 is=")
17
18 phin=(k*T)*log(Na/Nd)
19 disp(phin, "in v is=")
20
21 phibn=Vbi+phin
22 disp(phibn, "schottky barrier height in V is=")
```

Scilab code Exa 9.3 calcular the Schottky barrier lowering

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 esp=11.7
7 esp0=8.85*10^-14
8 E=6.8*10**4 //V/cm
9
10 deltaphi=sqrt((e*E)/(4*%pi*esp*esp0))
11 disp(deltaphi, "schottky barrier lowring in V is =")
12
13 xm=sqrt(e/(16*%pi*esp*esp0*E))
14 disp(xm, "maxi barrier height in meter is=")
```

Scilab code Exa 9.4 calculate the effective Richardson constant

Scilab code Exa 9.5 calculate the reverse saturation current densities

```
1 clc
2
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 \text{ esp} = 11.7
7 \text{ esp0} = 8.85 * 10^{-14}
8 \text{ phibe=0.67} //V
9 A=114 //A/K^2-cm^2
10 Na=10^18 //\text{cm}^-3
11 Nd=10^16 //\text{cm}^-3
12 taup0=10^-7
13 taun0=10^-7
14 Dp=10 //\text{cm}^2/\text{s}
15 Dn = 25 / cm^2 / s
16 Lp=1.0*10**-3 //cm
17 Ln=1.58*10**-3 //cm
18 pn0=2.25*10**4 //\text{cm}^-3
19 np0=2.25*10**2 //\text{cm}^-3
20
21
22 \quad a=k*T
23 Jst=(A*T^2)*exp(-phibe/a)
24 disp(Jst, "Richardson constant in A/K^2-cm^2 is=")
25
26 \text{ Js} = ((e*Dn*np0)/Ln) + ((e*Dp*pn0)/Lp)
27 disp(Js, "reverse saturation current density in A/cm
       ^{\hat{}}2 is=")
```

Scilab code Exa 9.6 calculate the forward bias voltage

```
1 clc
2
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 \text{ esp} = 11.7
7 \text{ esp0} = 8.85 * 10^{-14}
8 J=10 //A/K^2-cm^2
9 Jst=5.98*10^-5/A/K^2-cm^2
10 Js=3.66*10^-11 //A/K^2-cm^2
11
12 //J = Jst * [exp(e*Va/k*T) - 1]
13 //Va=(k*T/e)*log(J/Jst)
14 Va=(k*T)*log(J/Jst)
15 disp(Va, "forward bias voltage in V is=")
16
17 Va=(k*T)*log(J/Js)
18 disp(Va, "forward bias voltage in V is=")
```

Scilab code Exa 9.7 calculate the space charge width

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 Nd=7*10^18 //cm^3
7 esp=11.7
8 esp0=8.85*10^-14
9 phibn=0.67 //V
10 Vbi=0.67
11
12 xn=sqrt((2*esp*esp0*Vbi)/(e*Nd))
13 disp(xn,"space charge width in cm is=")
```

Scilab code Exa 9.8 determine AE At and Vbi

```
1 clc
 3 T = 300 / K
 4 k=8.617*10**-5//eV/K
 5 e=1.6*10**-19 //C
6 ni=2.4*10^13 //\text{cm}^-3
 7 Na=7*10^18 / cm^3
 8 Nd=10^16 //\text{cm}^-3
9 pp0=6*10^18 //\text{cm}^-3
10 \text{ esp} = 11.7
11 \text{ esp0}=8.85*10^-14
12 \text{ xn} = 4.13
13 \text{ xp} = 4.07
14
15 / AE1 = e * (xn - xp)
16 AE = (xn - xp)
17 disp(AE, "AE in eV is=")
18
19 deltaE=1.43-0.67
20
21 AE1=deltaE-AE
22 disp(AE1,"AE1 in eV is=")
23
24 \text{ pn0}=(\text{ni}^2)/\text{Nd}
25 \operatorname{disp}(\operatorname{pn0}, \operatorname{pn0} \operatorname{in} \operatorname{cm}^-3 \operatorname{is}=")
26
27 \quad Vbi = AE1 + (k*T)*log((Nd*pp0)/(pn0*Na))
28 disp(Vbi, "Vbi in V is=")
```

Chapter 10

The Bipolar Transistor

Scilab code Exa 10.1 design the ratio of emitter doping

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 y=0.9967
7 //NB/NC=z
8 z=(1/y)-1
9 disp(z,"NB/NE value is=")
```

Scilab code Exa 10.2 design the base width

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 DB=10//cm^2/s
```

```
7 tauB0=10^-7//sec
8 alphatau=0.9967
9 //(xB/LB)=z
10 z=acosh(1/alphatau)
11 disp(z,"xB/LB is=")
12
13 LB=sqrt(DB*tauB0)
14 disp(LB,"LB in cm is=")
15 xB=z*10^-4
16 disp(xB,"xB in meter is=")
```

Scilab code Exa 10.3 calculate the forujard biased

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 Js0=10^-11//A/cm^2
7 Jr0=10^-8//A/cm^2
8 delta=0.9967
9 VBE=2*k*T*log(delta*10^3/(1-delta))
10 disp(VBE, "VBE in V is=")
```

Scilab code Exa 10.4 calculate the common emitter current gain

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 DE=10//cm^2/s
7 DB=25//cm^2/s
```

```
8 \text{ xB} = 0.70 \times 10^{-6} / \text{m}
9 \text{ xE=0.50*10^--6//m}
10 NE=1*10^18 //\text{cm}^-3
11 NB=1*10^16 //\text{cm}^-3
12 VBE=0.65//V
13 tauB0=5*10^-7//s
14 tauE0=1*10^-7//s
15 Jr0=5*10^-8/A/cm62
16 pE0=2.25*10^2/cm^-3
17 nB0=2.25*10^4/cm^-3
18 LE=10^{-3}/cm
19 LB=3.54*10^-3/cm
20
21 \quad \text{gamma1} = 1/(1+(pE0*DE*LB*tanh(0.0198))/(nB0*DB*LE*tanh)
      (0.050))
22 disp(gamma1, "gamma1 is=")
23 alphatau=1/cosh(xB/LB)
24 disp(alphatau, "alphatau is=")
25 \text{ Js0=(e*DB*nB0)/(LB*tanh(xB/LB))}
26 disp(Js0, "Js0 is A/cm^2")
27 delta=1/(1+(Jr0/Js0)*exp(-VBE/(2*0.0259)))
28 disp(delta, "delta is=")
29 a=gamma1*alphatau*delta
30 disp(a, "a is=")
31 \text{ beta1=a/(1-a)}
32 disp(beta1, "beta1 is=")//
                                           ans varies cause
      of long no. of digits
```

Scilab code Exa 10.5 calculate the change in the neutral base width

```
1 clc

2

3 T=300 //K

4 k=8.617*10**-5//eV/K

5 e=1.6*10**-19 //C
```

```
6 NB=5*10^16/\text{cm}^-3
7 NC=2*10^15//cm^-3
8 \text{ epsilons} = 11.7
9 eps=8.85*10^-14 //V
10 ni=1.5*10**10 //\text{cm}^-3
11 \quad x = 0.70 * 10^-6
12 a=9.96*10^-12///solving the equation
13 Vbi = ((k*T))*log((NB*NC)/ni^2)
14 disp(Vbi, "Vbi in V is=")
15
16 //for
17 \text{ VCB}=2 //V
18 xdB1=sqrt(a*(Vbi+VCB))
19 disp(xdB1, "xdB in meter is=")
20 \quad xB1=x-xdB1
21 disp(xB1, "xB in meter is=")//
                                      textbook ans
      are wrong
22
23 // for
24 \text{ VCB} = 10 / V
25 xdB2=sqrt(a*(Vbi+VCB))
26 disp(xdB2, "xdB in meter is=")
27 \quad xB2=x-xdB2
28 disp(xB2, "xB in meter is=")//
                                     textbook ans
      are wrong
```

Scilab code Exa 10.7 determine the increase in pE0

```
1 clc
2
3 T=300// K
4 k=1.3806*10^-23// JK^-1
5 e=1.6*10^-19// eV
6 ni=1.5*10^10// cm^-3
7 NE=10^18// cm^-3
```

```
8 pE01=(ni*ni)/NE// neglecting bandgap
9 disp(pE01,"pE01 the value of pE01 in cm^-3 is")
10 NE=10^19// cm^-3
11 pE03=(ni*ni)/NE// neglecting bandgap
12 disp(pE03,"pE03 the value of pE03 in cm^-3 is")
13 pE02=((ni*ni)/NE)*exp(0.030/(k*(T/e)))// including bandgap
14 disp(pE02,"pE02 the value of pE02 in cm^-3 is")
15 pE04=((ni*ni)/NE)*exp(0.1/(k*(T/e)))// including bandgap
16 disp(pE04,"pE04 the value of pE04 in cm^-3 is")
```

Scilab code Exa 10.8 design the collector doping

```
1 clc
2
3 T = 300 / / K
4 k=1.3806*10^-23//JK^-1
5 e=1.6*10^-19/eV
6 epsilon=8.85*10^-14 //V
7 \text{ eps} = 11.7
8 NB=10^16/\text{cm}-3
9 Vpt = 25 / V
10 WB = 0.5 * 10^{-4}
11
12
13 //Vpt = (e*WB^2*NB*(NC+NB))/(2*epsilon*eps*NC)
14 a=(Vpt*2*epsilon*eps)/(e*WB^2*NB)
15 disp(a)
16 \text{ NC=NB/(a-1)}
17 \operatorname{disp}(NC, "NC in cm^-3 is=")
```

Scilab code Exa 10.9 design a bipolar transistor

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 NB=10^17//cm^-3
7 beta=100
8 BVCE0=15//V
9
10 BVCB0=(beta)^(1/3)*BVCE0
11 disp(BVCB0,"in V is=")
```

Scilab code Exa 10.10 calculate the collector zmitter saturation voltage

```
1 clc
2
3 T=300 //K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 alphaF=0.99
7 alphaR=0.20
8 Ic=1//mA
9 IB=0.050//mA
10
11 Vcesat=k*T*log(((Ic*(1-alphaR)+IB)*alphaF)/((alphaF*IB-(1-alphaF)*Ic)*alphaR))
12 disp(Vcesat, "VCEsat in V is=")
```

Scilab code Exa 10.12 calculate the emitter to collector transit time

```
1 clc
2
3 T=300 //K
```

```
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 IE=1*10^-3/A
7 Cje=1*10^-12/F
8 \text{ xB=0.5*10}^{-4}/\text{cm}
9 Dn = 25 / cm2 / s
10 xdc = 2.4*10^-4 / cm
11 \text{ vs} = 10^7
12 \text{ rc} = 20 / \text{ohm}
13 Cu = 0.1 * 10^{-12} / F
14 \text{ Cs=0.1*10^--12//F}
15 \text{ beta} = 100
16
17 re1=(k*T)/IE
18 disp(re1, "re1 in ohm is=")
19 taue=re1*Cje
20 disp(taue, "taue in sec is=")
21 taub=xB^2/(2*Dn)
22 disp(taub,"taub in sec is=")
23 taub1=xdc/vs
24 disp(taub1,"taub in sec is=")
25 tauc=rc*(Cu+Cs)
26 disp(tauc,"tauc in sec is=")
27 tauec=taue+taub+taub1+tauc
28 disp(tauec, "tauec in sec is=")
29 ftau=1/(2*%pi*tauec)
30 disp(ftau, "ftau in GHz is=")
31 fbeta=ftau/beta
32 disp(fbeta, "fbeta in Hz is=")
```

Chapter 11

Fundamentals of the Metal Oxide Semiconductor Field Effect Transistor

Scilab code Exa 11.1 calculate the maximum space charge width

```
1 clc
2
3 T=300//K
4 Na=10^16// cm^-3
5 ni=1.5*10^10 // cm^-3
6 epsilon0=8.85*10^-14// F/m
7 epsilons=11.7
8 e=1.6*10^-19// eV
9 Vt=0.0259 // V
10 phifp=Vt*log(Na/ni)
11 disp(phifp, "the value of phisp in V is")
12 xdT=(4*(epsilons*epsilon0)*phifp/(e*Na))^0.5
13 disp(xdT, "the value of xdT in meter is")
```

Scilab code Exa 11.2 calculate the metal semiconductor work function difference

```
1 clc
2
3 phim=3.20// v
4 x=3.25// v
5 Eg=1.11//eV
6 Na=10^14// cm^-3
7 k=1.3806*10^-23// JK^-1
8 T=300// K
9 ni=1.5*10^10// cm^-3
10 e=1.6*10^-19// eV
11 phifp=(((k*T)/e)*log(Na/ni))
12 disp(phifp,"the value of phifp in V is")
13 phims=phim-(x+(Eg/2)+phifp)
14 disp(phims,"work function difference in V is ")
```

Scilab code Exa 11.3 calculate the flat band voltage

```
1 clc
2
3 Nd=10^16// cm^-3
4 tox=500*10^-8// a=500A =500*10^-8 cm
5 Qss=10^11// electronic charge per cm
6 phims=-1.1// V
7 e=1.6*10^-19// eV
8 epsilonox=3.9
9 epsilon0=8.85*10^-14// F/m
10 C=((epsilonox*epsilon0)/tox)
11 disp(C,"the value of C in F/cm^2 is")
12 Qss=10^11*e
13 disp(Qss,"the value of Qss in C/cm^2 is")
14 VFB=phims-(Qss/C)
15 disp(VFB,"the value of VFB in V is")
```

Scilab code Exa 11.4 design the oxide thickness

```
1 clc
2
3 T = 300 / / K
4 k=1.3806*10^-23//JK^-1
5 \text{ Na} = 3*10^16 // \text{ cm} -3
6 Qss=10^11// cm^-2
7 VTN = 0.65 / / V
8 phims = -1.13 / / V
9 epsilon0=8.85*10^-14//F/m
10 \text{ epsilons} = 11.7
11 \text{ epsilonox} = 3.9
12 ni=1.5*10^10// cm^-3
13 e=1.6*10^-19// eV
14 phifp=(((k*T)/e)*log(Na/ni))
15 disp(phifp,"the value of phifp in V is")
16 xdT=(4*(epsilons*epsilon0)*phifp/(e*Na))^0.5
17 disp(xdT,"the value of xdT in
                                      meter is")
18 QSD=e*Na*xdT// [QSD(max)]=e*Na*xdT
19 disp(QSD, "the value of QSD in C.cm<sup>2</sup> is")
20 tox=((VTN-phims-2*phifp)*(epsilonox*epsilon0))/(QSD
      -(Qss*e))
21 disp(tox, "in meter is")
```

Scilab code Exa 11.5 calculate the threshold voltage

```
1 clc
2
3 T=300// K
4 k=1.3806*10^-23// JK^-1
```

```
5 \text{ Na} = 10^14 / \text{ cm} - 3
6 Qss=10^10// \text{cm}^2
7 tox=500*10^-8// a=500A =500*10^-8 cm
8 phims = -0.83 / / V
9 epsilon0=8.85*10^-14//F/m
10 \text{ epsilons} = 11.7
11 \text{ epsilonox} = 3.9
12 ni=1.5*10^10// cm^-3
13 \text{ e=1.6*10}^-19 // \text{ eV}
14 phifp=(((k*T)/e)*log(Na/ni))
15 disp(phifp,"the value of phifp in V is")
16 xdT=(4*(epsilons*epsilon0)*phifp/(e*Na))^0.5
17 disp(xdT,"the value of xdT in microm is")
18 QSD=e*Na*xdT// [QSD(max)]=e*Na*xdT
19 disp(QSD,"the value of QSD in C/cm<sup>2</sup>")
20 VTN=(QSD-(Qss*e))*(tox/(epsilonox*epsilon0))+phims
      +2*phifp//VTN=(QSD(max)-Qss)*(tox/epsilonox)+
      phims+2*phifp
21 disp(VTN,"the value of VTN in V is")
```

Scilab code Exa 11.6 design the semiconductor dnping concentration

```
1 clc
2
3 T=300// K
4 k=1.3806*10^-23// JK^-1
5 Qss=10^10// cm^-2
6 tox=650*10^-8// tox=650A =650*10^-8 cm
7 epsilon0=8.85*10^-14// F/m
8 epsilons=11.7
9 epsilonox=3.9
10 ni=1.5*10^10// cm^-3
11 e=1.6*10^-19// eV
12 Nd=2.5*10^14// cm^-3
13 phifn=(((k*T)/e)*log(Nd/ni))//phifn=V1*log(Nd/ni)=((
```

Scilab code Exa 11.7 calculate Cox

```
1 clc
2
3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
6 \text{ espox} = 3.9
7 \text{ esp0=8.85*10^-14}
8 \text{ esp} = 11.7
9 tox=550*10^-8//550 Armstrong
10 Na=10^16//cm^-3
11 ni=1.5*10^10 //\text{cm}^-3
12
13 Cox = (espox * esp0) / tox
14 \operatorname{disp}(\operatorname{Cox}, \operatorname{"oxide capacitance in F/cm^2 is=")}
15
16 phi=(k*T)*log(Na/ni)
17 disp(phi, "mini capacitance in V is=")
18
19 xdt=sqrt((4*esp*esp0*phi)/(e*Na))
20 disp(xdt, "in cm^-4 is=")
21
```

Scilab code Exa 11.8 design the width

```
1 clc

2

3 T=300 //K

4 k=8.617*10**-5//eV/K

5 e=1.6*10**-19 //C

6 Cox=6.9*10^-8//F/cm2

7 esp0=8.85*10^-14

8 Vtau=0.65//V

9 VGS=5//V

10 L=1.25*10^-4//cm

11 u=650//cm^2/Vs

12 IDsat=4*10^-3//A

13

14 W=(IDsat*2*L)/(u*Cox*(VGS-Vtau)^2)

15 disp(W,"W in meter is=")
```

Scilab code Exa 11.9 determine the inversion carrier mobility

```
1 clc
 2
 3 T = 300 / K
4 k=8.617*10**-5//eV/K
5 e=1.6*10**-19 //C
 6 \cos = 6.9 \times 10^{-8} / F/cm^2
 7 \text{ esp0=8.85*10^-14}
8 Vtau=0.65//V
9 VGS1=1.5/V
10 VGS2 = 2.5 / V
11 VDS = 0.10 / /V
12 L = 2 * 10^{-6} / cm
13 u = 650 / cm^2 / Vs
14 ID1=35*10^-6/A
15 ID2 = 75 * 10^{-6} / A
16 \text{ W} = 15 * 10^{-6} / \text{m}
17
18 un = (ID2 - ID1) *L/(W*Cox*(VGS2 - VGS1)*VDS)
19 \operatorname{disp}(\operatorname{un}, \operatorname{un} \operatorname{in} \operatorname{cm}^2/\operatorname{Vs} \operatorname{is}=")
```

Scilab code Exa 11.10 calculate the change in the threshold voltage

```
1 clc
2
3 T=300// K
4 Na=3*10^16// cm^-3
5 tox=500*10^-8// tox=500A =500*10^-8 cm
6 k=1.3806*10^-23// JK^-1
7 VSB=1// V
8 epsilon0=8.85*10^-14// F/m
9 epsilons=11.7
10 epsilonox=3.9
11 ni=1.5*10^10// cm^-3
12 e=1.6*10^-19// eV
13 phifp=(((k*T)/e)*log(Na/ni))// phifp=V1*log(Na/ni)
```

Scilab code Exa 11.11 calculate the cutoff frequency

```
1 clc
2
3 micron=400// cm^2/V-s
4 L=4*10^-6// m
5 VT=1// V
6 VGS=3// V
7 ftau=(micron*(VGS-VT))/(2*%pi*L*L)
8 disp(ftau,"the value of fr is")
```