

Control System Training

Module 10 – Open / Closed Loop Control Concepts

Copyright Notice

These training materials, including the samples, exercises, and solutions, are copyrighted materials. Any reproduction, or use of any kind without the specific written approval of the author is strictly prohibited.

Permission for extra-curricular use by First FRC teams for FRC related training is granted, provided the original copyright and acknowledgements are retained.

© Jim Simpson, 2018



What is "Control"

- The actions taken to achieve a specific result
- I want the car to go 55 MPH.
 - Driver pushes the gas pedal
- I want the robot to go 13 FT/SEC.
 - Driver moves the joy stick




Open Loop Control

- Action taken to achieve the result with any feedback of what the result is.
 - Blindfolded driver pushes the gas pedal based on memory of where to push the pedal to achieve 55 MPH.
 - Robot driver, without seeing robot or dashboard, sets joystick based on memory of what has worked in the past to achieve 13 FT/SEC.
- Response is potentially fast, but can be inaccurate
 - Response is "anticipated"
 - Memory was based on a fresh battery.
 - Memory didn't account for rough terrain or the ramp.



Open Loop Control




Motor Demand = F(Desired Speed)

Closed Loop Control

- Action taken to achieve the result is based on continuously watching the result and adjusting.
 - Driver pushes the gas pedal while watching the speedometer to achieve 55 MPH.
 - Robot driver, while watching the dashboard speed and robot, sets joystick to achieve 13 FT/SEC.
- Control depends on using the actual speed as feedback
 - Output is adjusted based on the error between the actual speed and desired speed
 - Desired speed is achieved, but this could take some time as driver adjusts pedal or joystick.



Closed Loop Control



- Motor Demand = F(Desired Speed Actual Speed)
 - More on the "Function" later




Closed Loop Control with Feedforward

- Used both open loop (feedforward) memory and closed loop together.
 - Driver pushes the gas pedal based on memory and adjusts while watching the speedometer to achieve 55 MPH.
 - Robot driver, sets joystick based and memory and adjusts while watching the dashboard speed and robot to achieve 13 FT/SEC.



Closed Loop Control with Feedforward



Motor Demand = F(F(Desired Speed) + F(Speed Error))



Analog Control Terms

Target

 Eventual desired setpoint, prior to high / low limiting, rate limiting or other preprocessing. This is not a "universal" term.

Demand

 Desired setpoint after pre-processing has been performed. This is not a "universal" term.

Setpoint

What the desired outcome is. Example: Desired car speed.

Process Variable

Current value to compare with Setpoint. Example: Car speedometer.

Process Error


Difference between setpoint and process variable

Control Output

 Action that the control system takes to try and the process error closer to zero. Example: How far to push the car's gas pedal.



Extra Credit:) ... Complete PID with FF



Added error characterization F(x)

