



DPULDValue

Represents the (numerical) value of a LaunchData available as DPU output.

1. Static parameters:

LaunchToken Name of a LaunchData, whose value is to be provided as DPU output.

2. Outputs:

Out Value of LaunchData, or 0.0, if these were not defined
OutStr String output of LaunchData.

3. Functional principle:

Launch data are requested by the user at the start of the simulation. Please refer to "Reference SILAB Configuration and Operation" which possibilities for the definition of launch data exist.

4. Example:

```
SILAB System {  
    LaunchData1 = ("Please enter a number", LD_Name, LD_EDIT);  
};  
  
DPUConfiguration ... {  
    DPUPool ... {  
        ...  
        DPULDValue LDValue  
        {  
            Computer = {DATA};  
            Index = 10;  
  
            LaunchToken = "LD_Name"; # as in launch definition  
            # LDValue.Out is the value,  
            # the user has provided.  
        };  
    };  
};
```