



SILAB DRIVING SIMULATION

Version 7.1 documentation

DPUSystemInfo

DPUSystemInfo displays some static information about the computer and the SILAB configuration.

1. Outputs:

<i>ProjectPath</i>	name of the project folder
<i>ConfigFileName</i>	configuration file that is currently used
<i>ComputerPool</i>	selected computer pool that is currently used
<i>DPUPool</i>	selected DPU pool that is currently used
<i>ComputerName</i>	name of the computer this DPU is running on
<i>IPAddress</i>	IP address of the computer this DPU is running on

2. Example:

In order to use DPUSystemInfo it is merely necessary to include it in your script.

```
DPUSystemInfo info
{
    Computer= {COMPUTER};
    Index=1;
};
```

Note: Make sure to replace *COMPUTER* by the name or address of the computer(s) you want the information from.