
Camera View Matrix

Transform a point P in the UV cartesian plane to the XY cartesian plane.

Strategy 1:

Note: this first strategy only works when the UV plane is not rotated or rotated in multiples of 45° with respect to the XY plane! This only serves to demonstrate the concept => See strategy 2



Step 1: Normalize the Basis Vectors

The length of a vector (x, y) is given by:

$$\text{Length} = \sqrt{x^2 + y^2}$$

Normalize U = (1, 1):

Length of
$$U=\sqrt{1^2+1^2}=\sqrt{2}$$

$$\hat{U}=rac{1}{\sqrt{2}}(1,1)=(0.707,0.707)$$

Normalize V = (-1, 1):

Length of
$$V=\sqrt{(-1)^2+1^2}=\sqrt{2}$$

$$\hat{V}=rac{1}{\sqrt{2}}(-1,1)=(-0.707,0.707)$$

Step 2: Transformation Formula

A point $P_{UV}(u,v)$ in the UV plane is expressed in the XY plane as:

$$P_{XY} = u\hat{U} + v\hat{V}$$

Substituting the normalized basis vectors:

$$P_{XY} = u(0.707, 0.707) + v(-0.707, 0.707)$$

Expanding each term:

$$P_{XY} = (0.707u, 0.707u) + (-0.707v, 0.707v)$$

$$P_{XY} = (0.707u - 0.707v, 0.707u + 0.707v)$$

Step 3: Apply the Formula for $P_{UV}(u,v)=(1,2)$

For u=1 and v=2, substitute into the formula:

$$P_{XY} = (0.707(1) - 0.707(2), 0.707(1) + 0.707(2))$$

Compute the x-coordinate:

$$x = 0.707(1) - 0.707(2) = 0.707 - 1.414 = -0.707$$

Compute the y-coordinate:

$$y = 0.707(1) + 0.707(2) = 0.707 + 1.414 = 2.121$$

Step 4: Final Result

The transformed point in the XY plane is:

$$P_{XY} = (-0.707, 2.121)$$

Step 5: Geometric Intuition

- 1. The UV axes are oriented as:
 - \hat{U} points diagonally up-right (0.707, 0.707).
 - \hat{V} points diagonally up-left (-0.707, 0.707).
- 2. For $P_{UV}(u,v) = (1,2)$:
 - ullet u=1 moves the point 1 unit along \hat{U} , pulling it slightly right and up.
 - ullet v=2 moves the point 2 units along \hat{V} , pulling it strongly left and up.
- 3. The leftward pull from $v\hat{V}$ dominates the rightward pull from $u\hat{U}$, resulting in a negative x-coordinate.

Conclusion

For U=(1,1) and V=(-1,1), the transformed point $P_{UV}(1,2)$ is:

$$P_{XY} = (-0.707, 2.121)$$

If i'm not mistaken, this is the same as adding the the U and V vectors

\$

Yes, you're absolutely correct! When using normalized U and V vectors as a basis, the operation of mapping a point $P_{UV}(u,v)$ to P_{XY} through:

$$P_{XY} = u\hat{U} + v\hat{V}$$

is conceptually the same as scaling the U and V vectors by u and v, respectively, and then adding them together.

Here's why:

Step-by-Step Connection

- 1. Scaling the Basis Vectors:
 - $u\hat{U}$ scales the U vector by the factor u, giving a contribution proportional to U in the UV system.
 - $v\hat{V}$ scales the V vector by the factor v, giving a contribution proportional to V in the UV system.
- 2. Adding the Contributions:
 - By adding these scaled vectors, $u\hat{U}+v\hat{V}$, you're effectively summing their directional contributions to locate the point in the XY plane.
- 3. Geometric Interpretation:
 - The point $P_{UV}(u,v)$ can be visualized as a vector addition operation where the U vector is scaled and added to the scaled V vector.

Strategy 2:

Works for all possible rotations!

Explanation why strategy 1 only works for multiples of 45°

1. Special Case: Multiple of 45° Rotation

When the UV system is rotated by multiples of 45° relative to the XY system, the transformation becomes simpler because:

- The components of the basis vectors (U and V) often reduce to $\pm 1,0,$ or fractions like $1/\sqrt{2}$.
- · The resulting transformation matrix is easier to compute manually or reason about intuitively.

For example:

- A rotation of 45° aligns U with $(1/\sqrt{2},1/\sqrt{2})$ and V with $(-1/\sqrt{2},1/\sqrt{2})$.
- ullet A rotation of 90° swaps axes entirely, with U=(0,1) and V=(-1,0).

These special angles result in simpler normalized basis vectors, which makes the formulas and visualizations easier to understand.

2. General Case: Arbitrary Rotation Angle

If the UV system is rotated by an arbitrary angle θ (not necessarily a multiple of 45°), the process still works, but the basis vectors will not have such simple components.

The Basis Vectors:

For a rotation of θ :

- $U = (\cos \theta, \sin \theta)$
- $V = (-\sin\theta, \cos\theta)$

These vectors remain orthogonal (perpendicular to each other) and normalized (unit length), which ensures the transformation is mathematically valid.

Transforming $P_{UV}(u, v)$ to P_{XY} :

The transformation is still given by:

$$P_{XY} = uU + vV$$

Substituting the values for U and V:

$$P_{XY} = u(\cos\theta, \sin\theta) + v(-\sin\theta, \cos\theta)$$

Breaking it into components:

$$x = u\cos\theta - v\sin\theta$$

$$y = u \sin \theta + v \cos \theta$$

This is the general formula for transforming a point from the UV system to the XY system, regardless of the rotation angle.

3. Why Does It Seem Simpler for 45°?

When $heta=45^\circ$, the trigonometric values simplify:


- $\cos 45^\circ = \sin 45^\circ = \frac{1}{\sqrt{2}}$
- $-\sin 45^\circ = -\frac{1}{\sqrt{2}}$

This makes the transformation matrix straightforward:

$$U=(rac{1}{\sqrt{2}},rac{1}{\sqrt{2}})$$

$$V=(-rac{1}{\sqrt{2}},rac{1}{\sqrt{2}})$$

The same happens for other multiples of 45°, where trigonometric values align with simple fractions or integers.



Compensate for a possible translation of the origin of the UV cartesian plane with respect to the origin of the XY cartesian plane.

When the UV coordinate system is **translated** relative to the XY coordinate system, the transformation must also account for the translation. The process involves two steps:

- 1. Apply the rotation/scaling transformation (as before).
- 2. Add the translation offset to the resulting XY coordinates.

Extended Transformation Formula

A point $P_{UV}(u,v)$ in the UV coordinate system can be expressed in the XY system as:

$$P_{XY} = u\hat{U} + v\hat{V} + T$$

Where:

- \hat{U} and \hat{V} are the **normalized basis vectors** of the UV system.
- ullet $T=(t_x,t_y)$ is the **translation offset**, i.e., the XY-coordinates of the UV-origin.

Step-by-Step Solution

1. Normalize the Basis Vectors (as before).

Suppose U=(1,1), V=(-1,1), and their normalized forms are:

$$\hat{U}=(0.707,0.707),\quad \hat{V}=(-0.707,0.707)$$

2. Include the Translation Offset.

Let $T=(t_x,t_y)$, representing the UV-origin in XY-coordinates. For example, if T=(2,3), it means the UV-origin is located at (2,3) in the XY-plane.

3. Transform a Point $P_{UV}(u,v)$.

Using the formula:

$$P_{XY} = u\hat{U} + v\hat{V} + T$$

Substitute the basis vectors and the translation offset. For example, if $P_{UV}=\left(1,2
ight) :$

$$P_{XY} = 1(0.707, 0.707) + 2(-0.707, 0.707) + (2,3)$$

4. Expand the Terms.

Compute the contributions from each part:

$$P_{XY} = (0.707, 0.707) + (-1.414, 1.414) + (2, 3)$$

5. Add the Components.

Combine the x- and y-coordinates:

$$x = 0.707 - 1.414 + 2 = 1.293$$

$$y = 0.707 + 1.414 + 3 = 5.121$$

6. Final Result:

The transformed point is:

$$P_{XY} = \left(1.293, 5.121\right)$$

Generalized Formula

For any $P_{UV}(u,v)$, the transformation to P_{XY} is:


$$P_{XY} = (u\hat{U}_x + v\hat{V}_x + t_x,\,u\hat{U}_y + v\hat{V}_y + t_y)$$

Where:

- (\hat{U}_x,\hat{U}_y) and (\hat{V}_x,\hat{V}_y) are the components of the normalized basis vectors.
- (t_x, t_y) is the translation offset.

This formula accounts for both rotation/scaling (through \hat{U} and \hat{V}) and translation (through T).

Example:



The transformation done in a matrix multiplication:

