Ewent 7002 - 5.25" to 2.5" hdd/sdd bay converter

DO IT YOURSELF / REPAIR IT - KNOW-HOW

In general, ODD Bracket holes and vertical hard drive mounting don't work ...

So, for ODD Bracket holes you need in the following sequence:

- → 1 file (for boring)
- ↑ 1 self-tapping screw with a screwdriver (for threading)

Instead, for vertical hard drive mounting you need in the following sequence:

- ♦ 1 broken 2.5" hdd/sdd (you have to force the sdd insertion with pliers)
- ♦ 2 spring clamps
- ♦ You must leave the broken 2.5 hdd/sdd in the vertical hard drive mounting for at least 48 hours, blocking it with the clamps. The screw holes must fit together.

Antonío Bonaccorso





