Thermaltake CH00168 Core W&P Series Case DO IT YOURSELF / ODD BRACKETS - KNOW-HOW

In general, to build ODD Brackets you need ...

♦ 1 Straight Aviation Snips to cut Anodized Aluminium For example this:

https://www.bricoman.it/it/cesoia-stanley-demoltpl-dritta-250-mm-10003298/

♦ 1 Plate of Anodized Aluminium (in my case I used a plate of anodized aluminium for verandas)

For example this:

https://www.bricoman.it/it/aletta-sopra-gronda-sv150-mm-t-moro-2-m-12091937/

- → 1 digital caliper to take measurements
- ♦ 1 Rigid Body to create the right angles of ODD "DIY" bracket with a hammer
- ♦ 1 self-tapping screw to create the holes of ODD "DIY" bracket with a hammer and a screwdriver

Antonío Bonaccorso

