

# FYS Multi-roll consumable drying box

## Installation and Operation Instruction

☆ Please refer to this guide to complete the installation of the tool.





#### Parts List



M3 hexagon thin nuts (x12)



M3x8 Countersunk head hexagon socket screws(x10)



M3x5x4 studded nut(x140)



PC4-01 Pneumatic connector straight through black(x5)



M3x18 Hexagon socket head cap screws (x2)



M3x40 cheese M3x8 Hexagon socket head socket head head cap screws with round head (x140)



M3x10 Hexagon socket head cap screws with

6x3mm Neodimium Magnet(x8)



Orange buckle(x7)



Switch(x1)



round head (x4)

5x85mm Shaft(x10)



power supply(x1)




Tracheal claw(x7)



625 Bearing(x20)




7530 Fan(x2)



 First, download the STL file from the link.Make a print. (https://www.thingiverse.com/thing:6660002)


**Notice:** When printing, please note that the end face of the printed part must be vertical, otherwise the product will be deformed after assembly.


- a. Print the shrink tool in your material at 100% scale;
- b. Measure the size of the printed piece, the length should be 475mm;
- Divide 475mm by your measured value to get the shrinkage percentage;
  For example: the measured length is 475mm.
  Calculate shrinkage; 475 / 473 x 100 = 100.42%
  - To compensate for shrinkage, print at 100.42%
- d. Print the shrink tool again on the same material according to the found proportion;
- e. Verify the length of the tool. It should be 475mm. A deviation of 0.4 +/- is acceptable



- Welding M3 hot melt nuts on printed parts.And peel off the protective sticker on the acrylic board
- 3 Assemble according to the structural sequence shown in the figure and use M3x8 screws to fix it.
- 4 Assemble the tray frame and fix it with M3x8 screws.









- Install the components in step ⑤ to the frame in step③ and fix them with M3x8 screws at both ends;
- ① Installation: Follow the steps below to assemble the printed parts and use M3x8- 8 Pcs and M3x40- 4 Pcs for fixation







- Install step ⑦ on step ⑥ and use M3x8- 4 Pcs to fix it;
- Install the PC4-01 pneumatic connector on the Spout x5 bracket and install it on the material rack;
- Install the acrylic base plate and use M3x8- 12 Pcs for fixation;
- Install the power socket on the acrylic back panel and lock it with a flat head M3x8-2 Pcs+M3 nut;
- ② Install the back panel on ⑥ and use M3x8- 12 Pcs to fix it;






- Install acrylic panels on both sides and use M3x8-24 Pcs for fixation:
- (14) Install the upper cover and use M3x8-12 Pcs to fix it;
- Install Hinge, Handle, Door Stopper on the acrylic panel of the door panel and use M3x8- 12 Pcs+M3 nuts to fix it;







- ① Install the assembled ⑤ on ⑥ and use flat head M3x8- 8 Pcs to fix it:
- One end of the power supply is connected to the fan extension cord, and the other end is connected to the switching power cord of the socket; the fan extension cord is connected to the fan, and the power supply is placed on the back panel;
- Finally, insert the pneumatic switch claw at the interface, insert the Teflon tube, and the assembly is completed.







# Thanks!



#### 深圳市富源盛电子科技有限公司

公司官网: https://www.fysetc.com 服务热线: +86 159 8944 7740 电子邮箱: shop@fysetc.com / support@fysetc.com

公司地址:广东省深圳市龙华新区龙华街道油松梦丽园工业区2层 Mengluiyuan Industry Area Shenzhen Guangdong China



#### Shenzhen Fuyuansheng Electronic Technology Co., Ltd

Official Website: https://www.fysetc.com Business Tel: +86 159 8944 7740

E-mail: shop@fysetc.com / support@fysetc.com

Company Address: Mengluiyuan Industry Area Shenzhen Guangdong China