						Jueg	o de	Inst	rucci	iones	CPL	J6.0					
				UB											LB		
nstrucción	Mnemotecnico	Ciclo	Pines activados	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0	Descripcion	
000-0000	NA	1	Nada	0	0	0	0	0	0	0	0	0	0	0	0	Nada. Se usa para delay	
		2	Nada	0	0	0	0	0	0	0	0	0	0	0	0		
000-0001	STOP	1	Nada	0	0	0	0	0	0	0	0	0	0	0	0	Deshabilita el clock (detiene la computadora)	
000 0001	5151	2	STOP	0	0	0	0	0	0	0	0	0	0	0	1		
			3101					0									
000 0010	CORA	1	ODD LDA			0	0	0	1	0	0	1	0		0	Cargo al angrando en al Registro A	
0000-0010	CURA	1	OBD, LRA	0	0				1	0		1	0	0	0	Carga el operando en el Registro A	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
0000-0011	CORB	1	OBD, LRB	0	0	0	0	1	0	0	0	1	0	0	0	Carga el operando en el Registro B	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
					_	_				_	_		_				
0000-0100	CORC	1	OBD, LRC	0	0	0	0	1	1	0	0	1	0	0	0	Carga el operando en el Registro C	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
0000-0101	CORD	1	OBD, LRC	0	0	0	1	0	0	0	0	1	0	0	0	Carga el operando en el Registro D	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
0000-0110	CODIR	1	OBD, LDIR	0	0	0	1	0	1	0	0	1	0	0	0	Carga el operando en el Registro DIR	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
0000-0111	COALU	1	OBD, LALU	0	0	0	1	1	0	0	0	1	0	0	0	Carga el operando en el Registro ALU	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
		_															
0000-1000	CACCRA	1	ORACC, LRA	0	0	0	0	0	1	1	1	0	0	0	0	Carga el Registro ACC en el Registro A	
3000-1000	CAECNA	2	ORACC, ERA	0	0	0	0	0	0	1	1	0	0	0	0		
		<del>-</del>									_						

0000-1001	CACCRB	1	ORACC, LRB	0	0	0	0	1	0	1	1	0	0		0	Carga el Registro ACC en el Registro B
0000-1001	CACCRB	2	ORACC, LRB	0	0	0	0	0	0	1	1	0	0	0	0	Carga et Registro ACC ett et Registro B
			UNACC	0	U	U	U	U	U		1	U	0	U	U	
0000-1010	CACCRC	1	ORACC, LRC	0	0	0	0	1	1	1	1	0	0	0	0	Carga el Registro ACC en el Registro C
0000 1010	Criserie	2	ORACC	0	0	0	0	0	0	1	1	0	0	0	0	Janga er negistre i negistre e
											_					
0000-1011	CACCRD	1	ORACC, LRD	0	0	0	1	0	0	1	1	0	0	0	0	Carga el Registro ACC en el Registro D
		2	ORACC	0	0	0	0	0	0	1	1	0	0	0	0	
0000-1100	CACCDIR	1	ORACC, LRDIR	0	0	0	1	0	1	1	1	0	0	0	0	Carga el Registro ACC en el Registro DIR
		2	ORACC	0	0	0	0	0	0	1	1	0	0	0	0	
0000-1101	CACCALU	1	ORACC, LRALU	0	0	0	1	1	0	1	1	0	0	0	0	Carga el Registro ACC en el Registro ALU
		2	ORACC	0	0	0	0	0	0	1	1	0	0	0	0	
0000-1110	CRARB	1	ORA, LRB	0	0	0	0	1	0	0	1	0	0	0	0	Carga el Registro A en el Registro B
		2	ORA	0	0	0	0	0	0	0	1	0	0	0	0	
0000-1111	CRARC	1	ORA, LRC	0	0	0	0	1	1	0	1	0	0	0	0	Carga el Registro A en el Registro C
		2	ORA	0	0	0	0	0	0	0	1	0	0	0	0	
0001-0000	CRARD	1	ORA, LRD	0	0	0	1	0	0	0	1	0	0	0	0	Carga el Registro A en el Registro D
		2	ORA	0	0	0	0	0	0	0	1	0	0	0	0	
0001-0001	CRADIR	1	ORA, LRDIR	0	0	0	1	0	1	0	1	0	0	0	0	Carga el Registro A en el Registro DIR
		2	ORA	0	0	0	0	0	0	0	1	0	0	0	0	
0004 0045	60.4.4.4		004 104:::													
0001-0010	CRAALU	1	ORA, LRALU	0	0	0	1	1	0	0	1	0	0	0	0	Carga el Registro A en el Registro ALU
		2	ORA	0	0	0	0	0	0	0	1	0	0	0	0	
0001 0011	CDDDA	1	ODD IDA						1		4	1			0	Corgo al Degistro D en al Degistro A
0001-0011	CRBRA	1	ORB, LRA	0	0	0	0	0	1	0	1	1	0	0	0	Carga el Registro B en el Registro A
		2	ORB	0	0	0	0	0	0	0	1	1	0	0	0	
0001-0100	CRBRC	1	ORB, LRC	0	0	0	0	1	1	0	1	1	0	0	0	Carga el Registro R en el Registro C
0001-0100	CHBRC	1	ORB, LRC	0	0	0	0	0	0	0	1	1	0	0	O Carga el Registro B en el Registro C	
		2	OVD	U	U	U	U	U	U	U	1	1	U	U	U	

							i			1						
0001 0101	CRBRD	1	ODD 1DD			0	1		0	0	1	1			0	Carga al Bagistra B an al Bagistra D
0001-0101	CKRKD	1	ORB, LRD	0	0	0	1	0	0	0	1	1	0	0	0	Carga el Registro B en el Registro D
		2	ORB	0	0	0	0	0	0	0	1	1	0	0	0	
0001-0110	CRBDIR	1	ORB, LRDIR	0	0	0	1	0	1	0	1	1	0	0	0	Carga el Registro B en el Registro DIR
0001-0110	CRODIN	2	ORB	0	0	0	0	0	0	0	1	1	0	0	0	Carga et negistro b en et negistro bin
			OND		0	U	U	0	U	U		1	0	0	U	
0001-0111	CRBALU	1	ORB, LRALU	0	0	0	1	1	0	0	1	1	0	0	0	Carga el Registro B en el Registro ALU
0001 0111	CRBALEO	2	ORB	0	0	0	0	0	0	0	1	1	0	0	0	Garga et riegistro a en el riegistro / 120
			OND									_				
0001-1000	CRCRA	1	ORC, LRA	0	0	0	0	0	1	1	0	0	0	0	0	Carga el Registro C en el Registro A
		2	ORC	0	0	0	0	0	0	1	0	0	0	0	0	
0001-1001	CRCRB	1	ORC, LRB	0	0	0	0	1	0	1	0	0	0	0	0	Carga el Registro C en el Registro B
		2	ORC	0	0	0	0	0	0	1	0	0	0	0	0	
0001-1010	CRCRD	1	ORC, LRD	0	0	0	1	0	0	1	0	0	0	0	0	Carga el Registro C en el Registro D
		2	ORC	0	0	0	0	0	0	1	0	0	0	0	0	
0001-1011	CRCDIR	1	ORC, LRDIR	0	0	0	1	0	1	1	0	0	0	0	0	Carga el Registro C en el Registro DIR
		2	ORC	0	0	0	0	0	0	1	0	0	0	0	0	
0001-1100	CRCALU	1	ORC, LRALU	0	0	0	1	1	0	1	0	0	0	0	0	Carga el Registro C en el Registro ALU
		2	ORC	0	0	0	0	0	0	1	0	0	0	0	0	
0001-1101	CRDRA	1	ORD, LRA	0	0	0	0	0	1	1	0	1	0	0	0	Carga el Registro D en el Registro A
		2	ORD	0	0	0	0	0	0	1	0	1	0	0	0	
0001-1110	CRDRB	1	ORD, LRB	0	0	0	0	1	0	1	0	1	0	0	0	Carga el Registro D en el Registro B
		2	ORD	0	0	0	0	0	0	1	0	1	0	0	0	
					_	_					_		_			
0001-1111	CRDRC	1	ORD, LRC	0	0	0	0	1	1	1	0	1	0	0	0	Carga el Registro D en el Registro C
		2	ORD	0	0	0	0	0	0	1	0	1	0	0	0	
2212 222	622212															
0010-0000	CRDDIR	1	ORD, LRDIR	0	0	0	1	0	1	1	0	1	0	0	0	Carga el Registro D en el Registro DIR

		2	ORD	0	0	0	0	0	0	1	0	1	0	0	0		
			OND			0						_					
0010-0001	CRDALU	1	ORD, LRALU	0	0	0	1	1	0	1	0	1	0	0	0	Carga el Registro D en el Registro ALU	
0010 0001	CHB/IEG	2	ORD	0	0	0	0	0	0	1	0	1	0	0	0	anga annagati a an annagati a naa	
												_					
0010-0010	CI1RA	1	IN1, LRA	0	0	1	0	0	1	0	0	0	0	0	0	Carga la Entrada IN1 en el Registro A	
		2	IN1	0	0	1	0	0	0	0	0	0	0	0	0		
0010-0011	CI1RB	1	IN1, LRB	0	0	1	0	1	0	0	0	0	0	0	0	Carga la Entrada IN1 en el Registro B	
		2	IN1	0	0	1	0	0	0	0	0	0	0	0	0		
0010-0100	CI1RC	1	IN1, LRC	0	0	1	0	1	1	0	0	0	0	0	0	Carga la Entrada IN1 en el Registro C	
		2	IN1	0	0	1	0	0	0	0	0	0	0	0	0		
0010-0101	CI1RD	1	IN1, LRD	0	0	1	1	0	0	0	0	0	0	0	0	Carga la Entrada IN1 en el Registro D	
		2	IN1	0	0	1	0	0	0	0	0	0	0	0	0		
0010-0110	CI1DIR	1	IN1, LDIR	0	0	1	1	0	1	0	0	0	0	0	0	Carga la Entrada IN1 en el Registro DIR	
		2	IN1	0	0	1	0	0	0	0	0	0	0	0	0		
0010-0111	CI1ALU	1	IN1, LRALU	0	0	1	1	1	0	0	0	0	0	0	0	Carga la Entrada IN1 en el Registro ALU	
		2	IN1	0	0	1	0	0	0	0	0	0	0	0	0		
0010-1000	CI2RA	1	IN2, LRA	0	1	0	0	0	1	0	0	0	0	0	0	Carga la Entrada IN2 en el Registro A	
		2	IN2	0	1	0	0	0	0	0	0	0	0	0	0		
0010-1001	CI2RB	1	IN2, LRB	0	1	0	0	1	0	0	0	0	0	0	0	Carga la Entrada IN2 en el Registro B	
		2	IN2	0	1	0	0	0	0	0	0	0	0	0	0		
0010-1010	CI2RC	1	IN2, LRC	0	1	0	0	1	1	0	0	0	0	0	0	Carga la Entrada IN2 en el Registro C	
		2	IN2	0	1	0	0	0	0	0	0	0	0	0	0		
0010-1011	CI2RD	1	IN2, LRD	0	1	0	1	0	0	0	0	0	0	0	0	Carga la Entrada IN2 en el Registro D	
		2	IN2	0	1	0	0	0	0	0	0	0	0	0	0	0	

							i —						1		1		
0010-1100	CI2DIR	1	IN2, LRDIR	0	1	0	1	0	1	0	0	0	0	0	0	Carga la Entrada IN2 en el Registro DIR	
0010-1100	CIZDIK	_			1											Carga la Elitrada liva eli el Registro Din	
		2	IN2	0	1	0	0	0	0	0	0	0	0	0	0		
0010-1101	CI2ALU	1	IN2, LRALU	0	1	0	1	1	0	0	0	0	0	0	0	Carga la Entrada IN2 en el Registro ALU	
0010-1101	CIZALU	2	IN2, LRALO	0	1	0	0	0	0	0	0	0	0	0	0	Carga la Littrada IIV2 ell'el Registro ALO	
			IIVZ	U	1	U	U	U	U	U	U	U	U	U	U		
0010-1110	CI3RA	1	IN3, LRA	0	1	1	0	0	1	0	0	0	0	0	0	Carga la Entrada IN3 en el Registro A	
010-1110	CISINA	2	IN3	0	1	1	0	0	0	0	0	0	0	0	0	Carga la Entrada INS CII CI Negistio A	
			IIVS	0			0	U	U	U	U	U		U	U		
010-1111	CI3RB	1	IN3, LRB	0	1	1	0	1	0	0	0	0	0	0	0	Carga la Entrada IN3 en el Registro B	
	-OISTO	2	IN3	0	1	1	0	0	0	0	0	0	0	0	0	- In the second of the second of	
			5		_	_								<u> </u>			
0011-0000	CI3RC	1	IN3, LRC	0	1	1	0	1	1	0	0	0	0	0	0	Carga la Entrada IN3 en el Registro C	
		2	IN3	0	1	1	0	0	0	0	0	0	0	0	0		
011-0001	CI3RD	1	IN3, LRD	0	1	1	1	0	0	0	0	0	0	0	0	Carga la Entrada IN3 en el Registro D	
		2	IN3	0	1	1	0	0	0	0	0	0	0	0	0		
			-														
0011-0010	CI3DIR	1	IN3, LRDIR	0	1	1	1	0	1	0	0	0	0	0	0	Carga la Entrada IN3 en el Registro DIR	
		2	IN3	0	1	1	0	0	0	0	0	0	0	0	0	, and the second	
011-0011	CI3ALU	1	IN3, LRALU	0	1	1	1	1	0	0	0	0	0	0	0	Carga la Entrada IN3 en el Registro ALU	
		2	IN3	0	1	1	0	0	0	0	0	0	0	0	0		
011-0100	COOUT1	1	OBD, OUT1	1	0	0	0	0	0	0	0	1	0	0	0	Carga el Operando en la Salida OUT1	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
011-0101	CRAOUT1	1	ORA, OUT1	1	0	0	0	0	0	0	1	0	0	0	0	Carga el Registro A en la Salida OUT1	
		2	ORA	0	0	0	0	0	0	0	1	0	0	0	0		
011-0110	CRBOUT1	1	ORB, OUT1	1	0	0	0	0	0	0	1	1	0	0	O Carga el Registro B en la Salida OUT1		
		2	ORB	0	0	0	0	0	0	0	1	1	0	0			

0011-0111	CRCOUT1	1	ORC, OUT1	1	0	0	0	0	0	1	0	0	0	0	0	Carga el Registro C en la Salida OUT1	
0011-0111	CNCOOTI	2	ORC, OOTI	0	0	0	0	0	0	1	0	0	0	0	0	Carga et Negistro C ett la Salida COTT	
			ONC	0	U	U	0	U	U		U	U	0	U	U		
0011-1000	CRDOUT1	1	ORD, OUT1	1	0	0	0	0	0	1	0	1	0	0	0	Carga el Registro D en la Salida OUT1	
0011 1000	CRDOOTI	2	ORD	0	0	0	0	0	0	1	0	1	0	0	0	Carga et negistro B en la sanaa 0011	
			OND		0	U		U	U		U			U	U		
0011-1001	CACCOUT1	1	ORACC, OUT1	1	0	0	0	0	0	1	1	0	0	0	0	Carga el Registro ACC en la Salida OUT1	
		2	ORACC	0	0	0	0	0	0	1	1	0	0	0	0		
0011-1010	COOUT2	1	OBD, OUT2	1	0	1	0	0	0	0	0	1	0	0	0	Carga el Operando en la Salida OUT1	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
0011-1011	CRAOUT2	1	ORA, OUT2	1	0	1	0	0	0	0	1	0	0	0	0	Carga el Registro A en la Salida OUT2	
		2	ORA	0	0	0	0	0	0	0	1	0	0	0	0		
0011-1100	CRBOUT2	1	ORB, OUT2	1	0	1	0	0	0	0	1	1	0	0	0	Carga el Registro B en la Salida OUT2	
		2	ORB	0	0	0	0	0	0	0	1	1	0	0	0		
0011-1101	CRCOUT2	1	ORC, OUT2	1	0	1	0	0	0	1	0	0	0	0	0	Carga el Registro C en la Salida OUT2	
		2	ORC	0	0	0	0	0	0	1	0	0	0	0	0		
0011-1110	CRDOUT2	1	ORD, OUT2	1	0	1	0	0	0	1	0	1	0	0	0	Carga el Registro D en la Salida OUT2	
		2	ORD	0	0	0	0	0	0	1	0	1	0	0	0		
0011-1111	CACCOUT2	1	ORACC, OUT2	1	0	1	0	0	0	1	1	0	0	0	0	Carga el Registro ACC en la Salida OUT2	
		2	ORACC	0	0	0	0	0	0	1	1	0	0	0	0		
				$oxed{oxed}$													
0100-0000	COOUT3	1	OBD, OUT3	1	1	0	0	0	0	0	0	1	0	0	0	Carga el Operando en la Salida OUT3	
		2	OBD	0	0	0	0	0	0	0	0	1	0	0	0		
0100-0001	CRAOUT3	1	ORA, OUT3	1	1	0	0	0	0	0	1	0	0	0	0	Carga el Registro A en la Salida OUT3	
		2	ORA	0	0	0	0	0	0	0	1	0	0	0	0		
0100-0010	CRBOUT3	1	ORB, OUT3	1	1	0	0	0	0	0	1	1	0	0	0	Carga el Registro B en la Salida OUT3	
		2	ORB	0	0	0	0	0	0	0	1	1	0	0	0	0	

							i			<del>                                     </del>						
0100-0011	CRCOUT3	1	ORC, OUT3	1	1	0	0	0	0	1	0	0	0	0	0	Carga el Registro C en la Salida OUT3
0100-0011	CRCOUTS	1		1	1			_		1		1	0		0	Carga er Registro C eri la Salida 0013
		2	ORC	0	0	0	0	0	0	1	0	0	0	0	0	
0100-0100	CRDOUT3	1	ORD, OUT3	1	1	0	0	0	0	1	0	1	0	0	0	Carga el Registro D en la Salida OUT3
0100-0100	CKDOU13	2	ORD, OOTS	0	0	0	0	0	0	1	0	1	0	0	0	Carga er Registro D'erria Salida 0015
			OKD	U	U	U	U	U	U	1	U	1	U	U	U	
0100-0101	CACCOUT3	1	ORACC, OUT3	1	1	0	0	0	0	1	1	0	0	0	0	Carga el Registro ACC en la Salida OUT3
3100-0101	CACCOUTS	2	ORACC, OUTS	0	0	0	0	0	0	1	1	0	0	0	0	Carga er Negistro Acc en la Sanda OO13
			ONACC	0	0	U	0	U	U	1		U		U	U	
100-0110	CODOUT	1	OBD, DOUT	1	1	1	0	0	0	0	0	1	0	0	0	Carga el Operando en la Salida OUT1
100 0110	<u> </u>	2	OBD, DOOT	0	0	0	0	0	0	0	0	1	0	0	0	Salad C. Sperando en la Sanda GOTT
			355			U		0	0		U			0	U	
100-0111	CRADOUT	1	ORA, DOUT	1	1	1	0	0	0	0	1	0	0	0	0	Carga el Registro A en la Salida OUT2
,100 0111	CHABOOT	2	ORA	0	0	0	0	0	0	0	1	0	0	0	0	earga et registro / en la sanaa es 12
			Olux													
100-1000	CRBDOUT	1	ORB, DOUT	1	1	1	0	0	0	0	1	1	0	0	0	O Carga el Registro B en la Salida OUT2
100 1000	CHEBOOT	2	ORB	0	0	0	0	0	0	0	1	1	0	0		
												_				
100-1001	CRCDOUT	1	ORC, DOUT	1	1	1	0	0	0	1	0	0	0	0	0	Carga el Registro C en la Salida OUT2
		2	ORC	0	0	0	0	0	0	1	0	0	0	0	0	3 3
100-1010	CRDDOUT	1	ORD, DOUT	1	1	1	0	0	0	1	0	1	0	0	0	Carga el Registro D en la Salida OUT2
		2	ORD	0	0	0	0	0	0	1	0	1	0	0	0	
100-1011	CACCDOUT	1	ORACC, DOUT	1	1	1	0	0	0	1	1	0	0	0	0	Carga el Registro ACC en la Salida OUT2
		2	ORACC	0	0	0	0	0	0	1	1	0	0	0	0	
100-1100	AALUO	1	ADD, OBD, LRACC	0	0	0	1	1	1	0	0	1	0	1	0	Adición entre el Registro ALU y el Operando
		2	ADD, OBD	0	0	0	0	0	0	0	0	1	0	1	0	
100-1101	AALURA	1	ADD, ORA, LRACC	0	0	0	1	1	1	0	1	0	0	1	O Adición entre el Registro ALU y el Registro A	
		2	ADD, ORA	0	0	0	0	0	0	0	1	0	0	1		

0100-1110	AALURB	1	ADD, ORB, LRACC	0	0	0	1	1	1	0	1	1	0	1	0	Adición entre el Registro ALU y el Registro B
0100-1110	AALUND	2	ADD, ORB, ERACC	0	0	0	0	0	0	0	1	1	0	1	0	Adicion entre el Negistro ALO y el Negistro B
			ADD, ORB	U	0	U		U	U	U		1	0	T	U	
0100-1111	AALURC	1	ADD, ORC, LRACC	0	0	0	1	1	1	1	0	0	0	1	0	Adición entre el Registro ALU y el Registro C
		2	ADD, ORC	0	0	0	0	0	0	1	0	0	0	1	0	, ,
			,													
0101-0000	AALURD	1	ADD, ORD, LRACC	0	0	0	1	1	1	1	0	1	0	1	0	Adición entre el Registro ALU y el Registro D
		2	ADD, ORD	0	0	0	0	0	0	1	0	1	0	1	0	
0101-0001	NALUO	1	NAND, OBD, LRACC	0	0	0	1	1	1	0	0	1	0	1	1	NAND entre el Registro ALU y Operando
		2	NAND, OBD	0	0	0	0	0	0	0	0	1	0	1	1	
0101-0010	NALURA	1	NAND, ORA, LRACC	0	0	0	1	1	1	0	1	0	0	1	1	NAND entre el Registro ALU y el Registro A
		2	NAND, ORA	0	0	0	0	0	0	0	1	0	0	1	1	
0101-0011	NALURB	1	NAND, ORB, LRACC	0	0	0	1	1	1	0	1	1	0	1	1	NAND entre el Registro ALU y el Registro B
		2	NAND, ORB	0	0	0	0	0	0	0	1	1	0	1	1	
0101-0100	NALURC	1	NAND, ORC, LRACC	0	0	0	1	1	1	1	0	0	0	1	1	NAND entre el Registro ALU y el Registro C
		2	NAND, ORC	0	0	0	0	0	0	1	0	0	0	1	1	
0101-0101	NALURD	1	NAND, ORD, LRACC	0	0	0	1	1	1	1	0	1	0	1	1	NAND entre el Registro ALU y el Registro D
		2	NAND, ORD	0	0	0	0	0	0	1	0	1	0	1	1	
0101-0110	JIO	1	OBD	0	0	0	0	0	0	0	0	1	0	0	0	Salto incondicional a la posicion Operando (8 LB) +
		2	OBD, JI	0	0	0	0	0	0	0	0	1	1	0	0	Registro DIR (7 UB)
0101-0111	JIRA	1	ORA	0	0	0	0	0	0	0	1	0	0	0	0	Salto incondicional a la posicion Registro A (8 LB) +
		1	ORA, JI	0	0	0	0	0	0	0	1	0	1	0	0	Registro DIR (7 UB)
		2														
0101-1000	JIRB	1	ORB	0	0	0	0	0	0	0	1	1	0	0	0	Salto incondicional a la posicion Registro B (8 LB) +
		2	ORB, JI	0	0	0	0	0	0	0	1	1	1	0	0	Registro DIR (7 UB)
0101-1001	JIRC	1	ORC	0	0	0	0	0	0	1	0	0	0	0	0	Salto incondicional a la posicion Registro C (8 LB) +

			000 !!			•					•					Dogistro DID (7 LID)
		2	ORC, JI	0	0	0	0	0	0	1	0	0	1	0	0	Registro DIR (7 UB)
0101-1010	JIRD	1	ORD	0	0	0	0	0	0	1	0	1	0	0	0	Salto incondicional a la posicion Registro D (8 LB) +
		2	ORD, JI	0	0	0	0	0	0	1	0	1	1	0	0	Registro DIR (7 UB)
0101-1011	JCCO	1	OBD	0	0	0	0	0	0	0	0	1	0	0	0	Salto condicional por carry a la posicion Operando
		2	OBD, JCC	0	0	0	0	0	0	0	0	1	1	0	1	(8 LB) + Registro DIR (7 UB)
0101-1100	JCCRA	1	ORA	0	0	0	0	0	0	0	1	0	0	0	0	Salto condicional por carry a la posicion Registro A
		2	ORA, JCC	0	0	0	0	0	0	0	1	0	1	0	1	(8 LB) + Registro DIR (7 UB)
0101-1101	JCCRB	1	ORB	0	0	0	0	0	0	0	1	1	0	0	0	Salto condicional por carry a la posicion Registro B
		2	ORB, JCC	0	0	0	0	0	0	0	1	1	1	0	1	(8 LB) + Registro DIR (7 UB)
		<u> </u>									_	_			_	
0101-1110	JCCRC	1	ORC	0	0	0	0	0	0	1	0	0	0	0	0	Salto condicional por carry a la posicion Registro C
0101 1110	Jeene	2	ORC, JCC	0	0	0	0	0	0	1	0	0	1	0	1	(8 LB) + Registro DIR (7 UB)
			One, see								0				_	
0101-1111	JCCRD	1	ORC	0	0	0	0	0	0	1	0	1	0	0	0	Salto condicional por carry a la posicion Registro D
0101 1111	JCCND	2	ORC, JCC	0	0	0	0	0	0	1	0	1	1	0	1	(8 LB) + Registro DIR (7 UB)
			OKC, JCC	0	U	U	U	U	U		U	1	1	U	1	(O ED) * Negistro DIN (7 OD)
0110 0000	JCZO	1	ORD			0			_		0	1				Salto condicional por Zero a la posicion Operando
0110-0000	JCZU	1		0	0	0	0	0	0	0	0	1	0	0	0	(8 LB) + Registro DIR (7 UB)
		2	ORD, JCZ	0	0	0	0	0	0	0	0	1	1	1	0	(8 LB) + Registio DIR (7 OB)
0110 0001	ICZDA		ODD			0			0		4				0	Colta condicional non Zona a la masisian Desirtur A
0110-0001	JCZRA	1	ORB	0	0	0	0	0	0	0	1	0	0	0	0	Salto condicional por Zero a la posicion Registro A
		2	ORB, JCZ	0	0	0	0	0	0	0	1	0	1	1	0	(8 LB) + Registro DIR (7 UB)
											_					
0110-0010	JCZRB	1	ORC	0	0	0	0	0	0	0	1	1	0	0	0	Salto condicional por Zero a la posicion Registro B
		2	ORC, JCZ	0	0	0	0	0	0	0	1	1	1	1	0	(8 LB) + Registro DIR (7 UB)
0110-0011	JCZRC	1	ORC	0	0	0	0	0	0	1	0	0	0	0	0	Salto condicional por Zero a la posicion Registro C
		2	ORC, JCZ	0	0	0	0	0	0	1	0	0	1	1	0	(8 LB) + Registro DIR (7 UB)
0110-0100	JCZRD	1	ORD	0	0	0	0	0	0	1	0	1	0	0	0	Salto condicional por Zero a la posicion Registro D
		2	ORD, JCZ	0	0	0	0	0	0	1	0	1	1	1	0	(8 LB) + Registro DIR (7 UB)