

pcData (31 downto 23) Uso futuro	pcData(22 down to 21) 00: DISABLE 01: ALU 10: JMP 11: MOV	pcData (20 downto 17) opCode	pcData(16) 0: MEM 1: LIT	pcData (15 down to 0) opa	Instruccion en binario	Instruccion en hexa	Instrucción	ACC	C/B	zero	Negative	overflow	portRd	portWr
00000000_0	01	1000	1	_00000000_00000000	00000000_00110001_00000000_00000000	00310000	Sat = 0	0x0000	0	1	0	0		0x0000
00000000_0	01	0111	0	_00000000_00000000	00000000_00101110_00000000_00000000	002E0000	Carry = 0	0x0000	0	1	0	0		0x0000
00000000_0	11	0100	1	_10101010_10111011	00000000_01101001_10101010_10111011	0069AABB	PORT = 0xAABB	0x0000	0	1	0	0		0xAABB
00000000_0	11	0101	1	_00010010_00110100	00000000_01101011_00010010_00110100	006B1234	UART = 0x1234	0x0000	0	1	0	0		0xAABB
00000000_0	11	0000	0	_00000000_00000000	00000000_01100000_00000000_00000000	00600000	*(0x0000) = PORT	0x0000	0	1	0	0	0x5555	0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	11	0000	0	_00000000_00000001	00000000_01100000_00000000_00000001	00600001	*(0x0001) = PORT	0x0000	0	1	0	0	0x7FFF	0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	11	0000	0	_00000000_00000010	00000000_01100000_00000000_00000010	00600002	*(0x0002) = PORT	0x0000	0	1	0	0	0x8000	0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	11	0000	0	_00000000_00000011	00000000_01100000_00000000_00000011	00600003	*(0x0003) = PORT	0x0000	0	1	0	0	0xFFFF	0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	00	0000	0	_00000000_00000000	00000000_00000000_00000000_00000000	00000000	NOP	0x0000	0	1	0	0		0xAABB
00000000_0	01	0001	0	_00000000_00000000	00000000_00100010_00000000_00000000	00220000	ACC = ACC or *(0x0000)	0x5555	0	0	0	0		0xAABB
00000000_0	01	0000	1	_00000000_11111111	00000000_00100001_00000000_11111111	002100FF	ACC = ACC and 0x00FF	0x0055	0	0	0	0		0xAABB
00000000_0	01	0010	1	_11111111_11111111	00000000_00100101_11111111_11111111	0025FFFF	ACC = ACC xor 0xFFFF	0xFFAA	0	0	1	0		0xAABB
00000000_0	01	0110	1	_00000000_00000001	00000000_00101101_00000000_00000001	002D0001	ACC = 0x0001	0x0001	0	0	0	0		0xAABB
00000000_0	01	0011	0	_00000000_00000001	00000000_00100110_00000000_00000001	00260001	(Carry, ACC) = ACC + *(0x0001) + Carry	0x8000	0	0	1	1		0xAABB
00000000_0	01	0011	1	_11111111_11111111	00000000_00100111_11111111_11111111	0027FFFF	(Carry, ACC) = ACC + 0xFFFF + Carry	0x7FFF	1	0	0	1		0xAABB
00000000_0	01	0110	1	_00000000_00000000	00000000_00101101_00000000_00000000	002D0000	ACC = 0x0000	0x0000	1	1	0	1		0xAABB
00000000_0	01	0011	1	_00000000_00000000	00000000_00100111_00000000_00000000	00270000	(Carry, ACC) = ACC + 0x0000 + Carry	0x0001	0	0	0	0		0xAABB
00000000_0	01	1000	1	_11111111_11111111	00000000_00110001_11111111_11111111	0031FFFF	Sat = 1	0x0001	0	0	0	0		0xAABB
00000000_0	01	0011	0	_00000000_00000001	00000000_00100110_00000000_00000001	00260001	(Carry, ACC) = ACC + *(0x0001) + Carry	0x7FFF	0	0	0	1		0xAABB
00000000_0	01	0110	1	_10000000_00000000	00000000_00101101_10000000_00000000	002D8000	ACC = 0x8000	0x8000	0	0	1	1		0xAABB
00000000_0	01	0011	1	_11111111_11111111	00000000_00100111_11111111_11111111	0027FFFF	(Carry, ACC) = ACC + 0xFFFF + Carry	0x8000	1	0	1	1		0xAABB
00000000_0	01	0110	1	_00000000_00000001	00000000_00101101_00000000_00000001	002D0001	ACC = 0x0001	0x0001	1	0	0	1		0xAABB
00000000_0	01	0101	1	_00000000_00000001	00000000_00101011_00000000_00000001	002B0001	(Carry, ACC) = (Carry, ACC) << (0x0001)	0x0003	0	0	0	1		0xAABB
00000000_0	01	0101	0	_00000000_00000011	00000000_00101010_00000000_00000011	002A0003	(Carry, ACC) = (Carry, ACC) << *(0x0003)	0xA000	0	0	1	1		0xAABB
00000000_0	01	0111	1	_00000000_00000001	00000000_00101111_00000000_00000001	002F0001	Carry = 1	0xC000	1	0	1	1		0xAABB
00000000_0	10	0000	1	_00000000_00000000	00000000_01000001_00000000_00000000	00410000	IF (ZERO = 1) PC = 0x0000	0xC000	1	0	1	1		0xAABB
00000000_0	11	0100	1	_00000000_00000001	00000000_01101001_00000000_00000001	00690001	PORT = (0x0001)	0xC000	1	0	1	1		0x0001
00000000_0	10	0010	1	_00000000_00101001	00000000_01000101_00000000_00101001	00450029	IF (CARRY = 1) PC = 0x29	0xC000	1	0	1	1		0x0001
00000000_0	11	0100	1	_10101010_10101010	00000000_01101001_10101010_10101010	0069AAAA	PORT = (0xAAAA)	0xC000	1	0	1	1		0x0001
00000000_0	11	0100	1	_00000000_00000010	00000000_01101001_00000000_00000010	00690002	PORT = (0x0002)	0xC000	1	0	1	1		0x0002
00000000_0	11	0001	0	_00000000_00000100	00000000_01100010_00000000_00000100	00620004	*(0x0004) = UART	0xC000	1	0	1	1		0x0002
00000000_0	11	0100	0	_00000000_00000100	00000000_01101000_00000000_00000100	00680004	PORT = *(0x0004)	0xC000	1	0	1	1		0x0034
00000000_0	10	0100	1	_00000000_00000000	00000000_01001001_00000000_00000000	00490000	PC = 0x0000	0xC000	1	0	1	1		0x0034