

BATCH TRANSFER SEQUENCE

- 1

2

3

4

5

6

7

8

9

10
- CONNECTION SETUP
- BATCH TRANSFER
- PERSIST & ACK

Watch
(Peripheral)

Phone
(Central)

advertise
A100



scan + connect



request MTU



subscribe / CCCD



START



DATA x n



END

store SQLite



ACK count

mark synced

→ flow (solid) - → ACK (dashed)