

Setting Up the Arduino IDE in Raspberry PI

Before starting the interfacing experiments using arduino, ensure the Arduino IDE is properly set up on your Raspberry PI. Follow these steps:

- **Download the Arduino IDE:** Download the latest version of the Arduino IDE from the official website: <https://www.arduino.cc/en/software>

Note: Make sure to download the **LINUX (Arm 64 bits)** version of the IDE

- **Install the IDE:** Extract the files and select the **install.sh** file to install the IDE in your system.

Note: select *Execute in Terminal* during installation

- **Connect the Arduino Board:** Use a USB cable to connect the Arduino board to the computer.

- **Select the Board and Port:**

- Go to `Tools > Board` and select the appropriate Arduino board (e.g., Arduino Uno).
- Go to `Tools > Port` and select the COM port to which your Arduino is connected.

This setup ensures that the connected Arduino board is ready for programming and interfacing with external components.

- **Run an sample sketch to verify the installation:**

- Select `Files > Examples > 01. Basics > Blink` and Upload the sketch.
- Once the upload is done, check whether the onboard led is blinking or not.