



HRVATSKI
ENGLISH

UPUTE ZA HIDROMASAŽNU KADU HOT TUB INSTRUCTIONS

UKLJUČIVANJE KADE

- Pritisnite  za uključivanje ili isključivanje hidromasažne kade.
- Ako je kada isključena, na zaslonu će biti prikazane 3 crtice -- -
- Ako je kada uključena, crtice neće biti prikazane.
- Kada mora biti uključena kako bi se postavke mogle mijenjati (grijanje, temperature, mlaznice).

OTKLJUČAVANJE ZASLONA

- Pritisnite  dva puta (x2) za otključavanje zaslona.
- Zaslون se automatski zaključava nakon 30 minuta neaktivnosti kako bi se onemogućilo slučajno mijenjanje postavki.

ODABIR TEMPERATURE VODE

- Pritisnite  za provjeravanje trenutne postavke temperature vode.
- Nastavite pritiskati  za promjenu postavke temperature.
Temperatura se može postaviti između 15°C i 40°C.

UKLJUČIVANJE GRIJANJA

- Pritisnite  za uključivanje ili isključivanje grijanja vode.
- Kad je grijanje uključeno,  će se automatski aktivirati te će na zaslonu biti prikazana ikona .

UKLJUČIVANJE MLAZNICA

- Pritisnite  za uključivanje ili isključivanje masažnih mlaznica vode.

UKLJUČIVANJE LED SVJETLA

- Pritisnite  jednom (x1) za uključivanje svjetla u načinu rada s promjenom boja.
- Pritisnite  ponovno (x1) za zaključavanje trenutno prikazane boje svjetla.
- Pritisnite  još jednom (x1) za isključivanje svjetla.

TURNING ON THE HOT TUB

- Press  to turn the Hot Tub ON or OFF.
- If OFF, three dashes will be displayed -- -
- If ON, no dashes will be displayed.
- The Hot Tub must be turned ON to adjust other settings (heating, temperature, high jets).

UNLOCKING THE DISPLAY

- Press  twice (x2) to unlock the display.
- The display locks automatically after 30 minutes of inactivity to prevent accidental setting changes.

SET WATER TEMPERATURE

- Press  once (x1) to view the current temperature setting.
- Continue pressing  to cycle through temperature settings from 15°C to 40°C.

TURNING ON THE HEATING

- Press  to turn the heating on or off.
- When heating is turned on,  will automatically activate and the display will show the icon .

TURNING ON THE HIGH JETS

- Press  to turn the high jets on or off.

TURNING ON THE LED LIGHTS

- Press  once (x1) to turn ON the lights in a color cycling mode.
- Press  again (x1) to lock the color that is currently lit.
- Press  once more (x1) to turn OFF the lights.