

COMP310: Legacy Game Systems

1: Assembly language

Learning outcomes

- ► **Explain** the historical significance of the 6502 CPU
- ▶ **Identify** the key components of the 6502 architecture
- Read and write simple programs in 6502 assembly language







To better understand the history of videogame systems

- To better understand the **history** of videogame systems
- ➤ To study low-level machine architecture without diving straight into complex modern architectures

- To better understand the **history** of videogame systems
- ► To study low-level **machine architecture** without diving straight into complex modern architectures
- ► To make something under **constraints**:

- To better understand the **history** of videogame systems
- ► To study low-level **machine architecture** without diving straight into complex modern architectures
- ► To make something under **constraints**:
 - Inspires creativity

- To better understand the **history** of videogame systems
- ► To study low-level **machine architecture** without diving straight into complex modern architectures
- ► To make something under **constraints**:
 - Inspires creativity
 - Requires creative problem solving

- ➤ To better understand the **history** of videogame systems
- ➤ To study low-level machine architecture without diving straight into complex modern architectures
- ► To make something under **constraints**:
 - Inspires creativity
 - Requires creative problem solving
 - Makes you a better programmer

Assignment 1: Constrained Development Task



 Design and implement a de-make of a well-known game



- Design and implement a de-make of a well-known game
- Your de-make must run on the NES and be written in 6502 assembly

Assignment 1: Constrained Development Task

- Design and implement a de-make of a well-known game
- Your de-make must run on the NES and be written in 6502 assembly
- In week 3: present a proposal and Trello board

Assignment 1: Constrained Development Task

- Design and implement a de-make of a well-known game
- Your de-make must run on the NES and be written in 6502 assembly
- ► In week 3: present a proposal and Trello board
- Tip: scope carefully! Assembly programming is hard keep it simple

Assignment 2: Research Journal


Assignment 2: Research Journal

► As a group, make the ultimate NES programming wiki

Assignment 2: Research Journal

- ► As a group, make the ultimate NES programming wiki
- ➤ **Tip**: use the wiki to record what you're already learning for your project. Don't leave it until the last minute!!!













 Designed by Chuck Peddle and team at MOS Technology





- Designed by Chuck Peddle and team at MOS Technology
- ▶ 8-bit CPU, 16-bit addressing





- Designed by Chuck Peddle and team at MOS Technology
- ▶ 8-bit CPU, 16-bit addressing
- Clocked between 1MHz and 3MHz



- Designed by Chuck Peddle and team at MOS Technology
- ▶ 8-bit CPU, 16-bit addressing
- Clocked between 1MHz and 3MHz
- ► First produced in 1975



- Designed by Chuck Peddle and team at MOS Technology
- ▶ 8-bit CPU, 16-bit addressing
- Clocked between 1MHz and 3MHz
- ► First produced in 1975
- Still in production today











































We usually write numbers in decimal i.e.base 10

- We usually write numbers in decimal i.e.
 base 10
- ► Hexadecimal is base 16

- We usually write numbers in decimal i.e.
 base 10
- Hexadecimal is base 16
- Uses extra digits:
 - ► A=10, B=11, ..., F=15____

Recap: hexadecimal notation

- We usually write numbers in decimal i.e.
 base 10
- Hexadecimal is base 16
- Uses extra digits:
 - ► A=10, B=11, ..., F=15____

Hex	Dec	Hex	Dec	Hex	Dec
00	0	10	16	F0	240
01	1	11	17	F1	241
		:		:	
09	9	19	25	F9	249
0A	10	1A	26	FA	250
0B	11	1в	27	FB	251
0C	12	1C	28	FC	252
0D	13	1D	29	FD	253
ΟE	14	1E	30	FE	254
OF	15	1F	31	FF	255

Executes a series of instructions stored in memory

- Executes a series of instructions stored in memory
- An instruction is stored as an opcode followed by 0 or more arguments

- Executes a series of instructions stored in memory
- An instruction is stored as an opcode followed by 0 or more arguments
- ► CPU has several **registers**, each storing a single value

- Executes a series of instructions stored in memory
- An instruction is stored as an opcode followed by 0 or more arguments
- ► CPU has several **registers**, each storing a single value
- Instructions can read and write values in registers and in memory, and can perform arithmetic and logical operations on them

- Executes a series of instructions stored in memory
- An instruction is stored as an opcode followed by 0 or more arguments
- ► CPU has several registers, each storing a single value
- Instructions can read and write values in registers and in memory, and can perform arithmetic and logical operations on them
- ► The **program counter (PC)** register stores the address of the next instruction to execute

6502 is an 8-bit CPU, meaning each register stores 8
 bits of data

- 6502 is an 8-bit CPU, meaning each register stores 8
 bits of data
 - 1 byte

- 6502 is an 8-bit CPU, meaning each register stores 8
 bits of data
 - ▶ 1 byte
 - A number between 0 and 255

- 6502 is an 8-bit CPU, meaning each register stores 8
 bits of data
 - ▶ 1 byte
 - A number between 0 and 255
- ► A = accumulator

- 6502 is an 8-bit CPU, meaning each register stores 8
 bits of data
 - ▶ 1 byte
 - A number between 0 and 255
- ► A = accumulator
- ► X, Y = **index** registers

- 6502 is an 8-bit CPU, meaning each register stores 8
 bits of data
 - ▶ 1 byte
 - A number between 0 and 255
- ► A = accumulator
- ➤ X, Y = index registers
- ► SP = stack pointer register

- 6502 is an 8-bit CPU, meaning each register stores 8
 bits of data
 - ▶ 1 byte
 - ▶ A number between 0 and 255
- ► A = accumulator
- ➤ X, Y = index registers
- ► SP = stack pointer register
- ► PC = program counter register (16 bits)

- 6502 is an 8-bit CPU, meaning each register stores 8
 bits of data
 - ▶ 1 byte
 - A number between 0 and 255
- ► A = accumulator
- ➤ X, Y = index registers
- ► SP = stack pointer register
- ▶ PC = program counter register (16 bits)
- ► Status register

► Translates **directly** to machine code

- ► Translates **directly** to machine code
- ▶ I.e. 1 line of assembly = 1 CPU instruction

- ► Translates directly to machine code
- ▶ I.e. 1 line of assembly = 1 CPU instruction
- An assembler translates assembly to machine code

- Translates directly to machine code
- ▶ I.e. 1 line of assembly = 1 CPU instruction
- An assembler translates assembly to machine code
 - I.e. an assembler is a "compiler" for assembly language

- Translates directly to machine code
- ▶ I.e. 1 line of assembly = 1 CPU instruction
- An assembler translates assembly to machine code
 - I.e. an assembler is a "compiler" for assembly language
- Each CPU architecture has its own instruction set therefore its own assembly language



```
LDA #$01

STA $0200

LDA #$05

STA $0201

LDA #$08

STA $0202
```



```
LDA #$01
STA $0200
LDA #$05
STA $0201
LDA #$08
STA $0202
```

Try if out! http://skilldrick.github.io/easy6502/

LDA #\$01

► Store the value 01 (hexadecimal) into register A

- ► Store the value 01 (hexadecimal) into register A
- ► LDA ("load accumulator") stores a value in register A



- Store the value 01 (hexadecimal) into register A
- ► LDA ("load accumulator") stores a value in register A
- # denotes a literal number (as opposed to a memory address)

- Store the value 01 (hexadecimal) into register A
- ► LDA ("load accumulator") stores a value in register A
- # denotes a literal number (as opposed to a memory address)
- s denotes hexadecimal notation

STA \$0200

STA \$0200

Write the value of register A into memory address 0200 (hex)

STA \$0200

- Write the value of register A into memory address
 0200 (hex)
- STA ("store accumulator") copies the value of register
 A into main memory

STA \$0200

- Write the value of register A into memory address
 0200 (hex)
- STA ("store accumulator") copies the value of register
 A into main memory
- Note that address is a 16-bit number (2 bytes, 4 hex digits)

Our first assembly program

STA \$0200

- Write the value of register A into memory address
 0200 (hex)
- STA ("store accumulator") copies the value of registerA into main memory
- Note that address is a 16-bit number (2 bytes, 4 hex digits)
- ► In this emulator the display is "memory mapped", with 1 byte per pixel, starting from address 0200
 - ► This may **not** be the case on other 6502-based systems!



```
LDA #$01

STA $0200

LDA #$05

STA $0201

LDA #$08

STA $0202
```

```
LDA #$01
STA $0200
LDA #$05
STA $0201
LDA #$08
STA $0202
```

```
A9 01

8D 00 02

A9 05

8D 01 02

A9 08

8D 02 02
```

```
LDA #$01

STA $0200

LDA #$05

STA $0201

LDA #$08

STA $0202
```

```
A9 01

8D 00 02

A9 05

8D 01 02

A9 08

8D 02 02
```

Note that the 6502 is **little endian**

```
LDA #$01
STA $0200
LDA #$05
STA $0201
LDA #$08
STA $0202
```

```
A9 01
8D 00 02
A9 05
8D 01 02
A9 08
8D 02 02
```

Note that the 6502 is **little endian**

In 16-bit values, the "high" byte comes before the "low" byte

```
LDA #$01

STA $0200

LDA #$05

STA $0201

LDA #$08

STA $0202
```

```
A9 01
8D 00 02
A9 05
8D 01 02
A9 08
8D 02 02
```

Note that the 6502 is little endian

- In 16-bit values, the "high" byte comes before the "low" byte
- ► Intel x86 is also little endian

PC normally advances to the next instruction

- ► PC normally **advances** to the next instruction
- ► Some instructions **modify** the PC

- ▶ PC normally **advances** to the next instruction
- ► Some instructions **modify** the PC
- ► E.g. JMP (jump) sets the PC to the specified address

- PC normally advances to the next instruction
- ► Some instructions **modify** the PC
- ► E.g. MP (jump) sets the PC to the specified address

```
INC $0200 ; add 1 to the value at address 0200
JMP $0600 ; jump back to beginning of program
```

- PC normally advances to the next instruction
- ► Some instructions **modify** the PC
- ► E.g. MP (jump) sets the PC to the specified address

```
INC $0200 ; add 1 to the value at address 0200
JMP $0600 ; jump back to beginning of program
```

- ► In this emulator the program always starts at address 0600
 - ▶ This may **not** be the case on other 6502-based systems!



Don't use explicit jump locations in your code, it's not maintainable!

- Don't use explicit jump locations in your code, it's not maintainable!
- Can add a label to a line of code, by giving a name followed by a colon

- Don't use explicit jump locations in your code, it's not maintainable!
- Can add a label to a line of code, by giving a name followed by a colon
- ► Labels can then be used in instructions

- Don't use explicit jump locations in your code, it's not maintainable!
- Can add a label to a line of code, by giving a name followed by a colon
- Labels can then be used in instructions

```
start:
    INC $0200
    JMP start
```

- Don't use explicit jump locations in your code, it's not maintainable!
- Can add a label to a line of code, by giving a name followed by a colon
- Labels can then be used in instructions

```
start:
INC $0200
JMP start
```

▶ start is essentially a constant with value \$0600

- Don't use explicit jump locations in your code, it's not maintainable!
- Can add a label to a line of code, by giving a name followed by a colon
- Labels can then be used in instructions

```
start:
INC $0200
JMP start
```

- ▶ start is essentially a constant with value \$0600
- ► The assembled code is exactly the same as for the previous slide

```
LDX #$08 ; set X=8

decrement:

DEX ; subtract 1 from X

STX $0200 ; store X in top left pixel

CPX #$03 ; compare X to 3

BNE decrement ; if not equal, jump

STX $0201 ; store X in next pixel

BRK ; halt execution
```

```
LDX #$08 ; set X=8

decrement:

DEX ; subtract 1 from X

STX $0200 ; store X in top left pixel

CPX #$03 ; compare X to 3

BNE decrement ; if not equal, jump

STX $0201 ; store X in next pixel

BRK ; halt execution
```

```
X=8
do
X=X-1
memory[0200]=X
while X\neq 3
memory[0201]=X
```

 Assembly language does not have structured programming constructs such as if/else, switch/case, for, while, etc.

- Assembly language does not have structured programming constructs such as if/else, switch/case, for, while, etc.
- However all of these can be implemented using branch instructions

- Assembly language does not have structured programming constructs such as if/else, switch/case, for, while, etc.
- However all of these can be implemented using branch instructions
- ... which is exactly how compilers implement them

► JSR (jump to subroutine) works like JMP, but stores the current PC

- ► JSR (jump to subroutine) works like JMP, but stores the current PC
- ► RTS (return from subroutine) jumps back to the instruction after the JSR

- JSR (jump to subroutine) works like JMP, but stores the current PC
- ▶ RTS (return from subroutine) jumps back to the instruction after the JSR
- ► These are used to implement function calls

► Immediate: LDA #\$42

- ► Immediate: LDA #\$42
 - ► Load the literal value 42 (hex) into register A

► Immediate: LDA #\$42

Load the literal value 42 (hex) into register A

► Absolute: LDA \$42

- ► Immediate: LDA #\$42
 - Load the literal value 42 (hex) into register A
- ► Absolute: LDA \$42
 - Load the value stored at memory address 42 (hex) into register A

Addressing modes

- ► Immediate: LDA #\$42
 - Load the literal value 42 (hex) into register A
- ► Absolute: LDA \$42
 - Load the value stored at memory address 42 (hex) into register A
- ► That # makes a big difference!

Addressing modes

- ► Immediate: LDA #\$42
 - Load the literal value 42 (hex) into register A
- ► Absolute: LDA \$42
 - Load the value stored at memory address 42 (hex) into register A
- ► That # makes a big difference!
- Note that these actually assemble to different CPU instructions



LDA \$0200,X

LDA \$0200,X

► Look up the value stored at memory address

0200 + (value of X register)

and store it in A

LDA \$0200,X

▶ Look up the value stored at memory address

0200 + (value of X register)

and store it in A

► Can also do LDA \$0200, Y

LDA \$0200,X

Look up the value stored at memory address

0200 + (value of X register)

and store it in A

- ► Can also do LDA \$0200, Y
- ... but only x and y registers can be used for indexed addressing

```
LDX #0 ; X=0

loop:

TXA ; A=X

STA $0200,X ; store A to 0200+X

INX ; X++

JMP loop ; loop forever
```

```
LDX #0 ; X=0

loop:

TXA ; A=X

STA $0200,X ; store A to 0200+X

INX ; X++

JMP loop ; loop forever
```

▶ Why does it stop $\frac{1}{4}$ of the way down?

```
LDX #0 ; X=0

loop:

TXA ; A=X

STA $0200,X ; store A to 0200+X

INX ; X++

JMP loop ; loop forever
```

- ▶ Why does it stop $\frac{1}{4}$ of the way down?
- ► Hint: it stops after filling 256 pixels...

Next steps

Next steps

Work through the tutorials on http://skilldrick.github.io/easy6502/



Next steps

- Work through the tutorials on http://skilldrick.github.io/easy6502/
- ▶ Understand and try to modify the Snake game code