Xuecong Fan A01972388 Robert McKay A02080393 November 8, 2017


Lab 5

Introduction:

For this lab mainly we are used breadboard and LCD/touch screen for our lab equipment. The purposed of this lab is to show three button on the LCD/touch screen and use the button to control different color of LED light.

Lab Detail:

First in this lab we interfaced with an LCD. We wrote C functions to send "CMD" and "DAT" to GPIO to code the button we want. For button, we need three different button to show on the touch screen. For each button we used square shape to show them, they are color are red,green and yellow. Then we are interfaced the touchscreen to calculate and found out the "x" and "y" coordinate on the screen. Because the touch screen we are used is resistive touchscreen therefore we can find "X" and "Y", from Figure 1 and Figure 2 we can see how they are work on touch screen.



After we found "X" and "Y" coordinate, now we could specifically used them to found our buttons range position on the touchscreen. Next we used the button "X" and "Y" coordinate we found before to modify each button range we would touch. Then selected the range we want to changed color when we touched the button, the reason to do it is to show touch is worked on the touchscreen. At last, we used red, green and yellow buttons on the touch screen to control red, green and yellow LED light.

Software Design:

```
#include "lcd.h"

#include "lcd_configuration_test.h" //You can remove this line after you've rer

unsigned int* ssi0 = (unsigned int*) 0x40008000;
unsigned char* systemClock = (unsigned char*) 0x400FE000;
unsigned int* portA = (unsigned int*) 0x40004000;
unsigned int* portB = (unsigned int*) 0x40005000;
unsigned int* portB = (unsigned int*) 0x40005000;
unsigned int* corePeripheral = (unsigned int*) 0xE000E000;
unsigned int TxFEmask = 0;
unsigned int TxFEmask = 0;
unsigned int finaly;
unsigned int finaly;
unsigned int finaly;
unsigned int redcount = 0;
unsigned int yellowcount = 0;
unsigned int yellowcount = 0;
unsigned int i = 0;

| void redswitch(void) {
    redcount+;
    if (redcount % 2 == 1) {
        write_dat2(25);
        write_dat2(25);
        write_dat2(291);
        write_dat2(291);
        write_dat2(black);
        }
        portE[0x3FC/4] &= 0x6;
    }
    else {
        write_cmd(0x2A);
        write_dat2(284);
        write_dat2(156);
    }
}
```

Figure 3: code-1

```
write_cmd(0x2B);
    write_dat2(222);
    write_dat2(294);
    write_dat2(294);
    write_cmd(0x2C);
    for(i = 0; i < 72*72; i++) {
            write_dat2(red);
    }
    portE[0x3FC/4] |= 0x8;
}

portB[0x3FC/4] |= 0x8;

ivoid greenswitch(void) { ... }

ivoid yellowswitch(void) { ... }

ivoid greenswitch(void) { ... }

ivoid yellowswitch(void) { ... }

ivoid greenswitch(void) { ... }

ivoid greenswitch(void) { ... }

ivoid yellowswitch(void) { ... }

ivoid greenswitch(void) { ... }

ivoid greenswitch(void) { ... }

ivoid yellowswitch(void) { ... }

ivoid greenswitch(void) { .
```

Figure 4: code-2

Figure 5: code-3

```
portE[@x5L/4] = @xE; //Digital enable for PE1-PE3
//portA[@x5Z/4] = @x22020@; // Control register used in conjunction with AFSEL
ssi0[@x4/4] = @x8; //SSICR1 set to master configuration
ssi0[@x10/4] = @x8; //SSICR1 set to master configuration
ssi0[@x10/4] = @x8; //SSICR1 set to master configuration
ssi0[@x6/4] = @x8; //SCICR1 set to master clock
ssi0[@x4/4] = @x2; //Enable ssiModuleBaseAddress PFH and SPO, and also sets 8 bit data transfer and other options low.
ssi0[@x4/4] = @x8; //Enable ssiModuleBaseAddress
portE[@x3FC/4] = @x8;
lcd_init();
write_cmd(@x2A); //columns
write_dat2(200);
write_cmd(@x2A); //columns
write_dat2(200);
write_dat2
```

Figure 6: code-4

```
for(i = 0; i < 72*72; i++) {
        write_dat2(green);
    write_cmd(0x2A);
    write_dat2(84);
    write_dat2(156);
    write_cmd(0x2B);
    write_dat2(222);
    write_dat2(294);
    write_cmd(0x2C);
    for(i = 0; i < 72*72; i++) {
        write_dat2(red);
    portE[0x3FC/4] = 0xE;
    corePeripheral[0x100/4] = 1; //enable interrupt for GPIOA
    portA[0x404/4] = 0; //edge sensitive
    portA[0x408/4] = 0; //no double edge
portA[0x40C/4] = 0; //falling edge triggered
    portA[0x410/4] = 0x80; //Enables interrupt on PA7, for the touchscreen
    //After you have made sure that your ssi configuration and your gpio configuration are correct,
    // you can delete the call to test_configuration and write your own code to draw the buttons.
    // It is recommended that you write your LCD screen interfacing code in lcd.c and provide
    // corresponding function declarations in lcd.h. That will allow you to copy your lcd.c and lcd.h
    // files into any other project that requires the LCD screen.
    while(1);
}
```

Figure 7: code-5

Data transmit:

In this lab we would has data transmit. Figure 8 shows that it transmitting data between breadboard and LCD/touch screen.




Figure 8: signal shot

Issue:

In this lab the biggest issue is put wrong pins in the LCD/touch screen, because if you put wrong pins in the LCD/touch screen it would burn it. Other than that the hardest part

for code is to calculate the coordinate on the touch screen, this part is the longest time we spend in this lab.

Conclusions:

From this lab we studied how to set up touch screen and how to show LCD on it. We also learned how to show different color and size, how to find coordinate on the touch screen and make touch button on the touch screen work.