Data sheet

BNO055 Intelligent 9-axis absolute orientation sensor

Bosch Sensortec





- Quaternion
- Linear Acceleration
- Gravity
- Robust Heading

BNO055: data sheet

Document revision 1.2

Document release date November 2014

Document number BST-BNO055-DS000-12

Technical reference code(s) 0 273 141 209

Notes Data in this document are subject to change without notice. Product

photos and pictures are for illustration purposes only and may differ from

the real product's appearance.





BNO055

INTELLIGENT ABSOLUTE ORIENTATION SENSOR, 9-AXIS SENSOR FUSION **ALL-IN-ONE WINDOWS 8.x COMPLIANT SENSOR HUB**

Basic Description

Key features:

Quaternion, Euler angles, Rotation vector, Outputs fused sensor data

Linear acceleration, Gravity, Heading

an advanced triaxial 16bit gyroscope, a versatile, 3 sensors in one device

leading edge triaxial 14bit accelerometer and a

full performance geomagnetic sensor

LGA package 28 pins Small package

> Footprint 3.8 x 5.2 mm², height 1.13 mm² Intelligent Power Management: normal,

> > low power and suspend mode available

Common voltage supplies V_{DD} voltage range: 2.4V to 3.6V

Digital interface HID-I2C (Windows 8 compatible), I2C, UART

V_{DDIO} voltage range: 1.7V to 3.6V

MSL1, RoHS compliant, halogen-free Consumer electronics suite

Operating temperature: -40°C ... +85°C

Key features of integrated sensors:

Power Management

Accelerometer features

 Programmable functionality Acceleration ranges ±2g/±4g/±8g/±16g Low-pass filter bandwidths 1kHz - <8Hz

Operation modes:

Normal Suspend

Low power

Standby

Deep suspend

On-chip interrupt controller Motion-triggered interrupt-signal generation for

- any-motion (slope) detection

- slow or no motion recognition

- high-g detection



Page 3

Gyroscope features

• Programmable functionality

Ranges switchable from ±125°/s to ±2000°/s Low-pass filter bandwidths 523Hz - 12Hz Operation modes:

- Normal
- Fast power up
- Deep suspend
- Suspend
- Advanced power save

On-chip interrupt controller

Motion-triggered interrupt-signal generation for

- any-motion (slope) detection
- high rate

Magnetometer features

Flexible functionality

Magnetic field range typical ±1300µT (x-, y-axis); ±2500µT (z-axis)

Magnetic field resolution of ~0.3µT

Operating modes:

- Low power
- Regular
- Enhanced regular
- High Accuracy

Power modes:

- Normal
- Sleep
- Suspend
- Force

Typical applications

- Navigation
- Robotics
- · Fitness and well-being
- Augmented reality
- Context awareness
- Tablets and ultra-books



Page 4

General description

The BNO055 is a System in Package (SiP), integrating a triaxial 14-bit accelerometer, a triaxial 16-bit gyroscope with a range of ±2000 degrees per second, a triaxial geomagnetic sensor and a 32-bit cortex M0+ microcontroller running Bosch Sensortec sensor fusion software, in a single package.

The corresponding chip-sets are integrated into one single 28-pin LGA 3.8mm x 5.2mm x 1.1 mm housing. For optimum system integration the BNO055 is equipped with digital bidirectional I^2C and UART interfaces. The I^2C interface can be programmed to run with the HID-I2C protocol turning the BNO055 into a plug-and-play sensor hub solution for devices running the Windows 8.0 or 8.1 operating system.

Contents

BASIC DESCRIPTION	
SPECIFICATION	12
1.1 ELECTRICAL SPECIFICATION	
1.2 ELECTRICAL AND PHYSICAL CHARACTERISTICS, MEASUREMENT PERFORMANCE	13
2. ABSOLUTE MAXIMUM RATINGS	17
3. FUNCTIONAL DESCRIPTION	18
3.1 Architecture	
3.2 Power management	18
3.2.1 NORMAL MODE	19
3.3 OPERATION MODES	20
3.3.2 Non-Fusion Modes	22
3.4 AXIS REMAP	24
3.5 SENSOR CONFIGURATION	26
3.5.1 DEFAULT SENSOR CONFIGURATION	27 28
3.6 Output data	30
3.6.1 Unit selection	30 31 31
3.7 Interrupts	38
3.7.1 INTERRUPT PIN	
3.8 Self-Test	46
3.8.1 POWER ON SELF TEST (POST)	
3.9 BOOT LOADER	46
3.10 CALIBRATION	47
3.10.1 ACCELEROMETER CALIBRATION	47 47



I. REGISTER DESCRIPTION	49
4.1 GENERAL REMARKS	49
4.2 REGISTER MAP	50
4.2.1 REGISTER MAP PAGE 0	50
4.2.2 REGISTER MAP PAGE 1	
4.3 REGISTER DESCRIPTION (PAGE 0)	54
4.3.1 CHIP ID 0x00	54
4.3.2 ACC_ID 0x01	54
4.3.3 MAG_ID 0x02	
4.3.4 GYR_ID 0x03	
4.3.5 SW_REV_ID_LSB0x04	
4.3.6 SW_REV_ID_MSB0x05	
4.3.7 BL_REV_ID 0x06	
4.3.8 PAGE ID 0x07	
4.3.10 ACC_DATA_X_LSB0x084.3.10 ACC_DATA_X MSB0x09	
4.3.11 ACC DATA Y LSB0x04	
4.3.12 ACC DATA Y MSB0x0B	
4.3.13 ACC DATA Z LSB0x0C	
4.3.14 ACC DATA Z MSB0x0D	
4.3.15 MAG DATA X LSB0x0E	
4.3.16 MAG_DATA_X_MSB0x0F	
4.3.17 MAG DATA Y LSB0x10	
4.3.18 MAG_DATA_Y_MSB0x11	58
4.3.19 MAG_DATA_Z_LSB0x12	
4.3.20 MAG_DATA_Z_MSB0x13	
4.3.21 GYR_DATA_X_LSB0x14	
4.3.22 GYR_DATA_X_MSB0x15	
4.3.23 GYR_DATA_Y_LSB0x16	
4.3.24 GYR_DATA_Y_MSB0x17	
4.3.25 GYR_DATA_Z_LSB0x18 4.3.26 GYR_DATA_Z_MSB0x19	
4.3.27 EUL DATA X LSB0x14	
4.3.28 EUL DATA X MSB0x1B	
4.3.29 EUL DATA Y LSB0x1C	
4.3.30 EUL DATA Y MSB0x1D	
4.3.31 EUL DATA Z LSB0x1E	
4.3.32 EUL DATA Z MSB0x1F	
4.3.33 QUA DATA W LSB0x20	62
4.3.34 QUA_DATA_W_MSB0x21	62
4.3.35 QUA_DATA_X_LSB0x22	
4.3.36 QUA_DATA_X_MSB0x23	
4.3.37 QUA_DATA_Y_LSB0x24	
4.3.38 QUA_DATA_Y_MSB0x25	
4.3.39 QUA_DATA_Z_LSB0x26	
4.3.40 QUA_DATA_Z_MSB0x27	
4.3.41 LIA_DATA_X_LSB0x28	
4.3.42 LIA_DATA_X_MSB0x29 4.3.43 LIA_DATA_Y_LSB0x2A	
4.3.44 LIA DATA Y MSB0x2B	
4.3.45 LIA DATA Z LSB0x2C	
4.3.46 LIA DATA Z MSB0x2D	
4.3.47 GRV DATA X LSB0x2E	

4.3.48 GRV_DATA_X_MSB0x2F	
4.3.49 GRV_DATA_Y_LSB0x30	
4.3.50 GRV_DATA_Y_MSB0x31	
4.3.51 GRV_DATA_Z_LSB0x32	
4.3.52 GRV_DATA_Z_MSB0x33	
4.3.53 TEMP 0x34	
4.3.54 CALIB_STAT 0x35	
4.3.55 ST_RESULT 0x36	
4.3.56 INT_STA 0x37	
4.3.57 SYS_CLK_STATUS 0x38	
4.3.58 SYS_STATUS 0x39	
4.3.59 SYS_ERR 0x3A	
4.3.60 UNIT_SEL 0x3B	
4.3.61 OPR_MODE 0x3D	
4.3.62 PWR_MODE 0x3E	
4.3.63 SYS_TRIGGER 0x3F	
4.3.64 TEMP_SOURCE 0x40	
4.3.65 AXIS_MAP_CONFIG 0x41	
4.3.66 AXIS_MAP_SIGN 0x42	
4.3.67 ACC_OFFSET_X_LSB0x55	
4.3.68 ACC_OFFSET_X_MSB0x56	
4.3.69 ACC_OFFSET_Y_LSB0x57	
4.3.70 ACC_OFFSET_Y_MSB0x58	
4.3.71 ACC_OFFSET_Z_LSB0x59	
4.3.72 ACC_OFFSET_Z_MSB0x5A	
4.3.73 MAG_OFFSET_X_LSB0x5B	
4.3.74 MAG_OFFSET_X_MSB0x56C	
4.3.75 MAG_OFFSET_Y_LSB0x5D	
4.3.76 MAG_OFFSET_Y_MSB0x5E	
4.3.77 MAG_OFFSET_Z_LSB0x5F	
4.3.78 MAG_OFFSET_Z_MSB0x60	
4.3.79 GYR_OFFSET_X_LSB0x61	
4.3.80 GYR_OFFSET_X_MSB0x62	
4.3.81 GYR_OFFSET_Y_LSB0x63	
4.3.82 GYR_OFFSET_Y_MSB0x64	75
4.3.83 GYR_OFFSET_Z_LSB0x65	75
4.3.84 GYR_OFFSET_Z_MSB0x66	
4.3.85 ACC_RADIUS_LSB0x67	76
4.3.86 ACC_RADIUS_MSB0x68	
4.3.87 MAG_RADIUS_LSB0x69	76
4.3.88 MAG_RADIUS_MSB0x6A	76
4.4 REGISTER DESCRIPTION (PAGE 1)	77
·	
4.4.1 PAGE ID 0x07	77
4.4.2 ACC_CONFIG 0x08	77
4.4.3 MAG_CONFIG 0x09	77
4.4.4 GYR_CONFIG_0 0x0A	78
4.4.5 GYR_CONFIG_1 0x0B	78
4.4.6 ACC_SLEEP_CONFIG 0x0C	79
4.4.7 GYR_SLEEP_CONFIG 0x0D	80
4.4.8 INT_MSK 0x0F	
4.4.9 INT_EN 0x10	82
4.4.10 ACC_AM_THRES 0x11	
4.4.11 ACC_INT_SETTINGS 0x12	83
4.4.12 ACC_HG_DURATION 0x13	
4.4.13.ACC_HG_THRES.0y14	83



Page 8

4.4.14 ACC_NM_THRES 0x15	
4.4.15 ACC_NM_SET 0x16	
4.4.16 GYR_INT_SETTING 0x17 4.4.17 GYR HR X SET 0x18	
4.4.18 GYR_DUR_X 0x19	
4.4.19 GYR_HR_Y_SET 0x1A	86
4.4.20 GYR_DUR_Y 0x1B	
4.4.21 GYR_HR_Z_SET 0x1C 4.4.22 GYR_DUR_Z 0x1D	
4.4.23 GYR_AM_THRES 0x1E	87
4.4.24 GYR_AM_SET 0x1F	
4.5 DIGITAL INTERFACE	89
4.6 I2C Protocol	90
4.7 UART Protocol	93
4.8 HID over I2C	94
5. PIN-OUT AND CONNECTION DIAGRAM	95
5.1 PIN-OUT	95
5.2 Connection diagram I ² C	97
5.3 CONNECTION DIAGRAM UART	98
5.4 CONNECTION DIAGRAM HID-I2C	99
5.5 XOUT32 & XIN32 CONNECTIONS	100
5.5.1 EXTERNAL 32KHZ CRYSTAL OSCILLATOR	
6. PACKAGE	101
6.1 OUTLINE DIMENSIONS	101
6.2 Marking	102
6.3 Soldering Guidelines	102
6.4 HANDLING INSTRUCTIONS	102
6.5 TAPE AND REEL SPECIFICATION	103
6.6 ENVIRONMENTAL SAFETY	103
6.6.1 HALOGEN CONTENT6.6.2 INTERNAL PACKAGE STRUCTURE	
7. LEGAL DISCLAIMER	104
7.1 Engineering samples	
7.2 Product use	104
7.3 APPLICATION EXAMPLES AND HINTS	104
8. DOCUMENT HISTORY AND MODIFICATIONS	105



Page 9

Table of Figures

Figure 1: system architecture	18
Figure 2: Principle of any-motion detection	40
Figure 3: High rate interrupt	
Figure 4: Principle of any-motion detection	
Figure 5: I2C timing diagram	
Figure 6: I ² C write	
Figure 7: I2C multiple read	
Figure 8: Pin-out bottom view	
Figure 9: I ² C connection diagram	
Figure 10: UART connection diagram	
Figure 11: HID via IC connection diagram	
Figure 12: External 32kHz Crystal Oscillator with Load Capacitor	
Figure 13: Outline dimensions	

Page 10

List of Tables

Table 0-1: Electrical parameter specification	12
Table 0-2: Electrical characteristics BNO055	13
Table 2-1: Absolute maximum ratings (preliminary target values)	17
Table 3-1: power modes selection	19
Table 3-2: Low power modes - Interrupts	19
Table 3-3: Operating modes overview	20
Table 3-4: Default sensor settings	21
Table 3-5: operating modes selection	21
Table 3-6: Operating mode switching time	
Table 3-7: Default sensor configuration at power-on	
Table 3-8: Accelerometer configurations	27
Table 3-9: Gyroscope configurations	28
Table 3-10: Magnetometer configurations	29
Table 3-11: unit selection	30
Table 3-12: Fusion data output format	30
Table 3-13: Rotation angle conventions	
Table 3-14: Fusion output data rates	
Table 3-15: Accelerometer Default-Reg settings	
Table 3-16: Accelerometer G-range settings	
Table 3-17: Accelerometer Unit settings	
Table 3-18: Magnetometer Default-Reg settings	
Table 3-19: Magnetometer Unit settings	
Table 3-20: Gyroscope Default Reg-settings	32
Table 3-21: Gyroscope range settings	
Table 3-22: Gyroscope unit settings	33
Table 3-23: Radius Default-Reg settings	33
Table 3-24: Radius range settings	33
Table 3-25: Acceleration data	34
Table 3-26: Magnetic field strength data	34
Table 3-27: Yaw rate data	
Table 3-28: Compensated orientation data in Euler angles format	35
Table 3-29: Euler angle data representation	35
Table 3-30: Compensated orientation data in quaternion format	
Table 3-31: Quaternion data representation	35
Table 3-32: Linear Acceleration Data	
Table 3-33: Linear Acceleration data representation	36
Table 3-34: Gravity Vector Data	
Table 3-35: Gravity Vector data representation	36
Table 3-36: Temperature Data	
Table 3-37: Temperature data representation	37
Table 3-38: Temperature Source Selection	37
Table 3-39: No-motion time-out periods	39
Table 3-40: Timing of No-motion interrupt	39
Table 3-41: Any-motion Interrupt parameters and Axis selection	41
Table 3-42: High-G Interrupt parameters and Axis selection	41
Table 3-43: High Rate Interrupt parameters and Axis selection	43
Table 3-44: Axis selection and any motion interrupt	45
Table 3-45: Power on Self Test	
Table 3-46: Power on Self Test	
Table 4-1: Register Access Coding	50



Page 11

Table 4-2: Register Map Page 0	50
Table4-3: Register Map Page 1	
Table 4-4: protocol select pin mapping	
Table 4-5: Mapping of digital interface pins	
Table 4-6: Electrical specification of the interface pins	
Table 4-7: I2C address selection	
Table 4-8: I ² C timings	
Table 5-1: Pin description	
Table 5-2: Crystal Oscillator Source Connections	
Table 6-1: Marking of mass production parts	



Page 12

Specification

If not stated otherwise, the given values are over lifetime and full performance temperature and voltage ranges, minimum/maximum values are ±3 sigma.

1.1 Electrical specification

Table 0-1: Electrical parameter specification

OPERATING CONDITIONS BNO055						
Parameter	Symbol	Condition	Min	Тур	Max	Unit
Supply Voltage (only Sensors)	V_{DD}		2.4		3.6	V
Supply Voltage (µC and I/O Domain)	V_{DDIO}		1.7		3.6	V
Voltage Input Low Level (UART, I2C)	$V_{\text{DDIO_VIL}}$	$V_{DDIO} = 1.7-2.7V$			0.25	V_{DDIO}
LOW LEVEL (OART, 120)		$V_{DDIO} = 2.7-3.6V$			0.3	V_{DDIO}
Voltage Input High Level (UART, I2C)	$V_{\text{DDIO_VIH}}$	$V_{DDIO} = 1.7-2.7V$	0.7			V_{DDIO}
nigii Levei (UANT, 120)		$V_{DDIO} = 2.7-3.6V$	0.55			V_{DDIO}
Voltage Output Low Level (UART, I2C)	V _{DDIO_VOL}	$V_{DDIO} > 3V$, $I_{OL} = 20mA$		0.1	0.2	V _{DDIO}
Voltage Output High Level (UART, 12C)	$V_{\text{DDIO}_\text{VOH}}$	$V_{DDIO} > 3V$, $I_{OH} = 10mA$	0.9	0.8		V_{DDIO}
POR Voltage threshold on VDDIO-IN rising	V_{DDIO_POT+}	V _{DDIO} falls at 1 V/ms or slower		1.45		V
POR Voltage threshold on VDDIO-IN falling	$V_{\text{DDIO_POT-}}$			0.99		V
Operating Temperature	T _A		-40		+85	℃
Tot al supply current normal mode at T _A (9DOF @100Hz out put dat a rat e)	I _{DD} + I _{DDIO}	V_{DD} = 3V, V_{DDIO} = 2.5V			12.3	mA
Total supply current Low power mode at T_A	I _{DD_LPM}	V_{DD} = 3V, V_{DDIO} = 2.5V			0.4	mA
Total supply current suspend mode at T_A	I_{DD_SuM}	V_{DD} = 3V, V_{DDIO} = 2.5V			0.04	mA

Page 13

1.2 Electrical and physical characteristics, measurement performance

Table 0-2: Electrical characteristics BNO055

		OPERATING CONDITIONS	RN0055			
Parameter	Symbol	Condition	Min	Тур	Max	Unit
Start-Up time	T_Sup	From Off to configuration mode		400		ms
POR time	T_{POR}	From Reset to Normal mode		650		ms
Data Rate	DR	s. Par	Fusion Outpu	t data rates		
Data rate tolerance 9DOF @100Hz output data rate (if internal oscillator is used)	DR_tol			±1		%
	ОРЕ	RATING CONDITIONS ACC	ELEROMET	ER		
Parameter	Symbol	Condition	Min	Тур	Max	Units
Acceleration Range	g _{FS2g}	Select able via serial digit al int erface		±2		g
	g FS4g	via seriai digitai iriteriace		±4		g
	g _{FS8g}			±8		g
	g FS16g			±16		g
		OUTPUT SIGNAL ACCELER (ACCELEROMETER ONLY				
Parameter	Symbol			Тур	Max	Units
Parameter Sensitivity	Symbol S	(ACCELEROMETER ONLY	MODE)	Тур 1	Max	Units LSB/mg
	-	(ACCELEROMETER ONLY Condition	MODE)		Max ±4	
Sensitivity	S	(ACCELEROMETER ONLY Condition All g _{FSXg} Values, T _A =25°C	MODE)	1		LSB/mg
Sensitivity Sensitivity tolerance Sensitivity Temperature	S S _{tol}	(ACCELEROMETER ONLY Condition All g _{FSXg} Values, T _A =25°C Ta=25°C, g _{FS2g} Nominal V _{DD} supplies,	MODE)	1 ±1		LSB/mg %
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity	S S _{tol} TCS	(ACCELEROMETER ONLY Condition All g_{FSXg} Values, T_A =25°C Ta =25°C, g_{FS2g} Nominal V_{DD} supplies, Temp operating conditions g_{FS2g} , T_A =25°C,	MODE)	1 ±1 ±0.03	±4	LSB/mg % %/K
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity Supply Volt. Drift	S S _{tol} TCS S _{VDD}	(ACCELEROMETER ONLY Condition All g_{FSXg} Values, T_A =25°C Ta =25°C, g_{FS2g} Nominal V_{DD} supplies, Temp operating conditions g_{FS2g} , T_A =25°C, $V_{DD_min} \le V_{DD} \le V_{DD_max}$ g_{FS2g} , T_A =25°C, nominal V_{DD}	MODE) Min	1 ±1 ±0.03	±4	LSB/mg % %/K %/V
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity Supply Volt. Drift Zero-g Offset (x,y,z) Zero-g Offset	S Stol TCS SVDD Offxyz	(ACCELEROMETER ONLY Condition All g _{FSXg} Values, T _A =25°C Ta=25°C, g _{FS2g} Nominal V _{DD} supplies, Temp operating conditions g _{FS2g} , T _A =25°C, V _{DD_min} ≤ V _{DD} ≤ V _{DD_max} g _{FS2g} , T _A =25°C, nominal V _{DD} supplies, over life-time	MODE) Min	1 ±1 ±0.03 0.065	±4 0.2 +150	LSB/mg % %/K %/V mg
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity Supply Volt. Drift Zero-g Offset (x,y.z) Zero-g Offset Temperature Drift Zero-g Offset Supply	S Stol TCS SVDD Offxyz TCO	(ACCELEROMETER ONLY Condition All g_{FSXg} Values, T_A =25°C Ta =25°C, g_{FS2g} Nominal V_{DD} supplies, Temp operating conditions g_{FS2g} , T_A =25°C, $V_{DD_min} \le V_{DD} \le V_{DD_max}$ g_{FS2g} , T_A =25°C, nominal V_{DD} supplies, over life-time g_{FS2g} , T_A =25°C, T_A =26°C, T_A —26°C,	MODE) Min	1 ±1 ±0.03 0.065 ±80	±4 0.2 +150 +/-3.5	LSB/mg % %/K %/V mg
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity Supply Volt. Drift Zero-g Offset (x,y.z) Zero-g Offset Temperature Drift Zero-g Offset Supply Volt. Drift	S Stol TCS SVDD Offxyz TCO OffvDD		MODE) Min	1 ±1 ±0.03 0.065 ±80 ±1	±4 0.2 +150 +/-3.5	LSB/mg % %/K %/V mg mg/V
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity Supply Volt. Drift Zero-g Offset (x,y.z) Zero-g Offset Temperature Drift Zero-g Offset Supply Volt. Drift	S Stol TCS SVDD Offxyz TCO OffvDD bw8	(ACCELEROMETER ONLY Condition All g_{FSXg} Values, T_A =25°C Ta =25°C, g_{FS2g} Nominal V_{DD} supplies, Temp operating conditions g_{FS2g} , T_A =25°C, $V_{DD_min} \le V_{DD} \le V_{DD_max}$ g_{FS2g} , T_A =25°C, nominal V_{DD} supplies, over life-time g_{FS2g} , T_A =25°C, T_A =26°C, T_A —26°C,	MODE) Min	1 ±1 ±0.03 0.065 ±80 ±1 1.5	±4 0.2 +150 +/-3.5	LSB/mg % %/K %/V mg mg/k mg/V Hz
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity Supply Volt. Drift Zero-g Offset (x,y.z) Zero-g Offset Temperature Drift Zero-g Offset Supply Volt. Drift	S Stol TCS SVDD Offxyz TCO OffVDD bw8 bw16	(ACCELEROMETER ONLY Condition All g_{FSXg} Values, T_A =25°C Ta =25°C, g_{FS2g} Nominal V_{DD} supplies, Temp operating conditions g_{FS2g} , T_A =25°C, $V_{DD_min} \le V_{DD} \le V_{DD_max}$ g_{FS2g} , T_A =25°C, nominal V_{DD} supplies, over life-time g_{FS2g} , T_A =25°C, T_A =26°C, T_A —26°C,	MODE) Min	1 ±1 ±0.03 0.065 ±80 ±1 1.5 8	±4 0.2 +150 +/-3.5	LSB/mg % %/K %/V mg mg/K mg/V Hz
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity Supply Volt. Drift Zero-g Offset (x,y.z) Zero-g Offset Temperature Drift Zero-g Offset Supply Volt. Drift	S Stol TCS SVDD Offxyz TCO OffVDD bw8 bw16 bw31	(ACCELEROMETER ONLY Condition All g_{FSXg} Values, T_A =25°C Ta =25°C, g_{FS2g} Nominal V_{DD} supplies, Temp operating conditions g_{FS2g} , T_A =25°C, $V_{DD_min} \le V_{DD} \le V_{DD_max}$ g_{FS2g} , T_A =25°C, nominal V_{DD} supplies, over life-time g_{FS2g} , T_A =25°C, T_A =26°C, T_A —26°C,	MODE) Min	1 ±1 ±0.03 0.065 ±80 ±1 1.5 8 16 31	±4 0.2 +150 +/-3.5	LSB/mg % %/K %/V mg mg/K mg/V Hz Hz Hz
Sensitivity Sensitivity tolerance Sensitivity Temperature Drift Sensitivity Supply Volt. Drift Zero-g Offset (x,y.z) Zero-g Offset Temperature Drift Zero-g Offset Supply Volt. Drift	S Stol TCS SVDD Offxyz TCO OffvDD bw8 bw16 bw31 bw63	(ACCELEROMETER ONLY Condition All g_{FSXg} Values, T_A =25°C Ta =25°C, g_{FS2g} Nominal V_{DD} supplies, Temp operating conditions g_{FS2g} , T_A =25°C, $V_{DD_min} \le V_{DD} \le V_{DD_max}$ g_{FS2g} , T_A =25°C, nominal V_{DD} supplies, over life-time g_{FS2g} , T_A =25°C, T_A =26°C, T_A —26°C,	MODE) Min	1 ±1 ±0.03 0.065 ±80 ±1 1.5 8 16 31 63	±4 0.2 +150 +/-3.5	LSB/mg % %/K %/V mg mg/K Hz Hz Hz

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Bosch Sensorte

[©] Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany.

Note: Specifications within this document are subject to change without notice.



Page 14

	bw ₁₀₀₀			1,000		Hz
Nonlinearity	NL	best fit straight line, g_{FS2g}		0.5	2	%FS
Output Noise Density	n _{rms}	g _{FS2g} , T _A =25°C Nominal V _{DD} supplies Normal mode		150	190	µg/√Hz
	MECHAN	IICAL CHARACTERISTICS A	ACCELERO	MFTFR		
Parameter	Symbol	Condition	Min	Тур	Max	Units
Cross Axis Sensitivity	CAS	relative contribution between any two of the three axes		1	2	%
Alignment Error	E _A	relative to package outline		0.5	2	0
	0	PERATING CONDITIONS G	YROSCOPE			
Parameter	Symbol	Condition	Min	Тур	Max	Unit
Rate Range	R _{FS125}	Select able		125		%s
	R _{FS250}	via serial digit al interface		250		%s
	R _{FS500}			500		%s
	R _{FS1000}			1,000		%s
	R _{FS2000}			2,000		%s
		OUTPUT SIGNAL GYROS				
Gensitivity via register	S	(GYRO ONLY MODI Ta=25°C	Ε)	16.0		LSB/%s
Мар				900		rad/s
Sensitivity tolerance	S _{tol}	Ta=25°C, R _{FS2000}		±1	±3	%
ensitivity Change over Temperature	TCS	Nominal V_{DD} supplies $-40^{\circ}C \le T_A \le +85^{\circ}C R_{FS2000}$		±0.03	±0.07	%/K
Sensitivity Supply Volt. Drift	S _{VDD}	$T_A=25$ °C, $V_{DD_min} \le V_{DD} \le V_{DD_max}$		<0.4		%/V
Nonlinearity	NL	best fit straight line		±0.05	±0.2	%FS
		R _{FS1000} , R _{FS2000}				
Zero-rate Offset	Off $\Omega_{x} \; \Omega_{y}$ and Ω_{z}	Nominal V_{DD} supplies $T_A = 25$ °C, Slow and fast offset cancellation off	-3	±1	+3	%s
ero-Ω Offset Change over Temperature	TCO	Nominal V_{DD} supplies $-40^{\circ}C \le T_{A} \le +85^{\circ}C R_{FS2000}$		±0.015	±0.03	%s per K
Zero-Ω Offset Supply Volt. Drift	Off Ω _{VDD}	$T_A=25$ °C, $V_{DD_min} \le V_{DD} \le V_{DD_max}$		0.1		%s/V
Output Noise	n ms	rms, BW=47Hz		0.1	0.3	%s
	11115					

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Bosch Sensortec



Page 15

Bandwidth BW	f -3dB			523 230 116 64 47 32 23 12		Hz
	МЕСН	IANICAL CHARACTERISTIC	s Gyrosc	OPE		
Cross Axis Sensitivity	CAS	Sensitivity to stimuli in non-sense-direction		±1	±3	%
	ОРЕ	ERATING CONDITIONS MAC (MAGNETOMETER ONLY		ER		
Parameter	Symbol	Condition	Min	Тур	Max	Units
Magnetic field range ¹	Brg,xy	TA=25°C	±1200	±1300		μΤ
	Brg,z		±2000	±2500		μΤ
Magnetometer heading accuracy ²	As heading	30µT horizontal geomagnetic field component, TA=25°C			±2.5	deg
		MAGNETOMETER OUTPUT	SIGNAL			
Parameter	Symbol	Condition	Min	Тур	Max	Unit
Device Resolution	D _{res,m}	T _A =25℃		0.3		μT
Gain error ³	G _{err,m}	After API compensation T_A =25°C Nominal V_{DD} supplies		±5	±8	%
Sensitivity Temperature Drift	TCS _m	After API compensation $-40^{\circ}\text{C} \le T_{\text{A}} \le +85^{\circ}\text{C}$ Nominal V _{DD} supplies		±0.01	±0.03	%/K
Zero-B offset	OFF _m	T _A =25°C		±40		μT
Zero-B offset ⁴	$OFF_{m,cal}$	After calibration in fusion mode $-40^{\circ}\text{C} \le T_{\text{A}} \le +85^{\circ}\text{C}$		±2		μΤ
Zero-B offset Temperature Drift	TCO _m	$-40^{\circ}\text{C} \le T_{\text{A}} \le +85^{\circ}\text{C}$		±0.23	±0.37	μT/K
Full-scale Nonlinearity	$NL_{m, FS}$	best fit straight line			1	%FS

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

 $^{^{1}}_{\cdot}$ Full linear measurement range considering sensor offsets.

² The heading accuracy depends on hardware and software. A fully calibrated sensor and ideal tilt compensation are assumed.

³ Definition: gain error = ((measured field after API compensation)/(applied field)) - 1
⁴ Magnetic zero-B offset assuming calibration in fusion mode. Typical value after applying calibration movements containing various device orientations (typical device usage).

[@] Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



Page 16

Out put Noise	n _{rms,lp,m,xy}	Low power preset x, y-axis, T _A =25°C Nominal V _{DD} supplies	1.0	μТ
	$n_{\text{rms,lp,m,z}}$	Low power preset z-axis, T _A =25°C Nominal V _{DD} supplies	1.4	μТ
	n _{rms,rg,m}	Regular preset $T_{A}{=}25^{\circ}\text{C}$ Nominal V_{DD} supplies	0.6	μТ
	N _{rms,eh,m}	Enhanced regular preset $T_{\text{A}}{=}25^{\circ}\text{C}$ Nominal V_{DD} supplies	0.5	Τц
	n _{rms,ha,m}	High accuracy preset $T_{\mathbb{A}} {=} 25^{\circ} \mathbb{C}$ Nominal $V_{\mathbb{D} \mathbb{D}}$ supplies	0.3	μТ
Power Supply Rejection Rate	PSRR _m	$T_{\text{A}}{=}25^{\circ}\text{C}$ Nominal V_{DD} supplies	±0.5	μT/V



Page 17

2. Absolute Maximum Ratings

Table 2-1: Absolute maximum ratings (preliminary target values)

Parameter	Symbol	Condition	Min	Max	Units
Voltage at Supply Pin	V _{DD} Pin		-0.3	4.2	V
	V _{DDIO} Pin		-0.3	3.6	V
Voltage at any Logic Pin	V _{non-supply} Pin		-0.3	$V_{DDIO} + 0.3$	V
Passive Storage Temp. Range	Trps	≤ 65% rel. H.	-50	+150	°C
Mechanical Shock	MechShock _{200µs}	Duration ≤ 200µs		10,000	g
	MechShock _{1ms}	Duration ≤ 1.0ms		2,000	g
	MechShock _{freefall}	Free fall onto hard surfaces		1.8	m
ESD	ESD _{HBM}	HBM, at any Pin		2	kV
	ESD _{CDM}	CDM		400	V
	ESD _{MM}	MM		200	V

Note:

Stress above these limits may cause damage to the device. Exceeding the specified electrical limits may affect the device reliability or cause malfunction.



3. Functional Description

3.1 Architecture

The following figure shows the basic building blocks of the BNO055 device.




Figure 1: system architecture

3.2 Power management

The BNO055 has two distinct power supply pins:

- V_{DD} is the main power supply for the internal sensors
- V_{DDIO} is a separate power supply pin used for the supply of the μC and the digital interfaces

For the switching sequence of power supply VDD and VDDIO it is mandatory that VDD is powered on and driven to the specified level before or at the same time as VDDIO is powered ON. Otherwise there are no limitations on the voltage levels of both pins relative to each other, as long as they are used within the specified operating range.

The sensor features a power-on reset (POR), initializing the register map with the default values and starting in CONFIG mode. The POR is executed at every power on and can also be triggered either by applying a low signal to the nRESET pin for at least 20ns or by setting the RST SYS bit in the SYS TRIGGER register.

The BNO055 can be configured to run in one of the following power modes: normal mode, low power mode, and suspend mode. These power modes are described in more detail in section Power Modes



Page 19

Power Modes

The BNO055 support three different power modes: Normal mode, Low Power Mode, and Suspend mode.

The power mode can be selected by writing to the PWR_MODE register as defined in the table below. As default at start-up the BNO055 will run in Normal mode.

Table 3-1: power modes selection

Parameter	Value	[Reg Addr]: Reg Value
Power Mode	Normal Mode	[PWR_MODE]: xxxxx00b
	Low Power Mode	[PWR_MODE]: xxxxx01b
	Suspend Mode	[PWR_MODE]: xxxxx10b

3.2.1 Normal Mode

In normal mode all sensors required for the selected operating mode (see section 3.3) are always switched ON. The register map and the internal peripherals of the MCU are always operative in this mode.

3.2.2 Low Power Mode

If no activity (i.e. no motion) is detected for a configurable duration (default 5 seconds), the BNO055 enters the low power mode. In this mode only the accelerometer is active. Once motion is detected (i.e. the accelerometer signals an any-motion interrupt), the system is woken up and normal mode is entered. The following settings are possible.

Table 3-2: Low power modes - Interrupts

Descriptio n	Parameter	Value	Reg Value	Restriction
Entering to	Detection	No Motion	[ACC_NM_SET]: xxxxx1b	n/a
sleep: NO Motion Interrupt	Туре	Detection Axis	[ACC_INT_Settings] : bit4-bit2	Shares common bit with Any Motion interrupt axis selection
	Params	Duration	[ACC_NM_SET] : bit6-bit1	n/a
		Threshold	[ACC_NM_THRE] : bit7-bit0	n/a

Description	Parameter	Value	Reg Value
Waking up: Any Motion Interrupt	Detection Type	Detection Axis	[ACC_INT_Settings] : bit4-bit2
	Params	Duration	[ACC_INT_Settings] : bit1-bit0
		Threshold	[ACC AM THRES] : bit7-bit0

Additionally, the interrupt pins can also be configured to provide HW interrupt to the host.

The BNO055 is by default configured to have optimum values for entering into sleep and waking up. To restore these values, trigger system reset by setting RST_SYS bit in SYS_TRIGGER register.



Page 20

There are some limitations to achieve the low power mode performance:

- Only No and Any motion interrupts are applicable and High-G and slow motion interrupts are not applicable in low power mode.
- Low power mode is not applicable where accelerometer is not employed.

3.2.3 Suspend Mode

In suspend mode the system is paused and all the sensors and the microcontroller are put into sleep mode. No values in the register map will be updated in this mode. To exit from suspend mode the mode should be changed by writing to the PWR_MODE register (see Table 3-1).

3.3 Operation Modes

The BNO055 provides a variety of output signals, which can be chosen by selecting the appropriate operation mode. The table below lists the different modes and the available sensor signals.

Available sensor signals **Fusion Data Operating Mode** Relative **Absolute** Accel Mag Gyro orientation orientation **CONFIGMODE ACCONLY** Χ **Non-fusionmodes MAGONLY** Χ **GYROONLY** Χ ACCMAG Χ Χ **ACCGYRO** Χ Χ Χ **MAGGYRO** Χ Χ **AMG** Χ Χ IMU Χ χ Χ **COMPASS** Χ Χ Χ modes Fusion M4G Χ Χ χ

Table 3-3: Operating modes overview

The default operation mode after power-on is CONFIGMODE.

Χ

When the user changes to another operation mode, the sensors which are required in that particular sensor mode are powered, while the sensors whose signals are not required are set to suspend mode.

Χ

Χ

Χ

Χ

NDOF_FMC_OFF

NDOF

Χ

Χ



Page 21

The BNO055 sets the following default settings for the sensors. The user can overwrite these settings in the register map when in CONFIGMODE.

Table 3-4: Default sensor settings						
Sensor	Range	Bandwidth				
Accelerometer	4G	62.5 Hz				
Magnetometer	NA	10 Hz	/			

Gyroscope

Table 3-4: Default sensor settings

In any mode, the sensor data are available in the data register based on the unit selected. The axis of the data is configured based on the axis-remap register configuration.

2000 dps

32 Hz

The operating mode can be selected by writing to the OPR_MODE register, possible register values and the corresponding operating modes are shown in the table below.

Table 3-5: operating modes selection

Parameter	Value	[Reg Addr]: Reg Value
CONFIG MODE	CONFIGMODE	[OPR_MODE]: xxx0000b
Non-Fusion	ACCONLY	[OPR_MODE]: xxx0001b
Mode	MAGONLY	[OPR_MODE]: xxx0010b
	GYROONLY	[OPR_MODE]: xxxx0011b
	ACCMAG	[OPR_MODE]: xxx0100b
	ACCGYRO	[OPR_MODE]: xxx0101b
	MAGGYRO	[OPR_MODE]: xxx0110b
	AMG	[OPR_MODE]: xxx0111b
Fusion Mode	IMU	[OPR_MODE]: xxx1000b
	COMPASS	[OPR_MODE]: xxx1001b
	M4G	[OPR_MODE]: xxx1010b
	NDOF_FMC_OFF	[OPR_MODE]: xxx1011b
	NDOF	[OPR_MODE]: xxx1100b

Table 3-6 below shows the time required to switch between CONFIGMODE and the other operating modes.

Table 3-6: Operating mode switching time

From	То	Switching time
CONFIGMODE	Any operation mode	7ms
Any operation mode	CONFIGMODE	19ms

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Bosch Sensortec



Page 22

3.3.1 Config Mode

This mode is used to configure BNO, wherein all output data is reset to zero and sensor fusion is halted. This is the only mode in which all the writable register map entries can be changed. (Exceptions from this rule are the interrupt registers (INT and INT_MSK) and the operation mode register (OPR MODE), which can be modified in any operation mode.)

As being said, this mode is the default operation mode after power-on or RESET. Any other mode must be chosen to be able to read any sensor data.

3.3.2 Non-Fusion Modes

3.3.2.1 ACCONLY

If the application requires only raw accelerometer data, this mode can be chosen. In this mode the other sensors (magnetometer, gyro) are suspended to lower the power consumption. In this mode, the BNO055 behaves like a stand-alone acceleration sensor.

3.3.2.1 MAGONLY

In MAGONLY mode, the BNO055 behaves like a stand-alone magnetometer, with acceleration sensor and gyroscope being suspended.

3.3.2.2 GYROONLY

In GYROONLY mode, the BNO055 behaves like a stand-alone gyroscope, with acceleration sensor and magnetometer being suspended.

3.3.2.3 ACCMAG

Both accelerometer and magnetometer are switched on, the user can read the data from these two sensors.

3.3.2.4 ACCGYRO

Both accelerometer and gyroscope are switched on; the user can read the data from these two sensors.

3.3.2.5 MAGGYRO

Both magnetometer and gyroscope are switched on, the user can read the data from these two sensors.

3.3.2.6 AMG (ACC-MAG-GYRO)

All three sensors accelerometer, magnetometer and gyroscope are switched on.

3.3.3 Fusion modes

Sensor fusion modes are meant to calculate measures describing the orientation of the device in space. It can be distinguished between non-absolute or relative orientation and absolute orientation. Absolute orientation means orientation of the sensor with respect to the earth and its magnetic field. In other words, absolute orientation sensor fusion modes calculate the direction of the magnetic north pole.

In non-absolute or relative orientation modes, the heading of the sensor can vary depending on how the sensor is placed initially.

All fusion modes provide the heading of the sensor as quaternion data or in Euler angles (roll, pitch and yaw angle). The acceleration sensor is both exposed to the gravity force and to accelerations applied to the sensor due to movement. In fusion modes it is possible to separate the two acceleration sources, and thus the sensor fusion data provides separately linear acceleration (i.e. acceleration that is applied due to movement) and the gravity vector.



Page 23

3.3.3.1 IMU (Inertial Measurement Unit)

In the IMU mode the relative orientation of the BNO055 in space is calculated from the accelerometer and gyroscope data. The calculation is fast (i.e. high output data rate).

3.3.3.2 COMPASS

The COMPASS mode is intended to measure the magnetic earth field and calculate the geographic direction.

The earth magnetic field is a vector with the horizontal components xy and the vertical z component. It depends on the position on the globe and natural iron occurrence. For heading calculation (direction of compass pointer) only the horizontal components x and y are used. Therefore the vector components of the earth magnetic field must be transformed in the horizontal plane, which requires the knowledge of the direction of the gravity vector. To summarize, the heading can only be calculated when considering gravity and magnetic field at the same time.

However, the measurement accuracy depends on the stability of the surrounding magnetic field. Furthermore, since the earth magnetic field is usually much smaller than the magnetic fields that occur around and inside electronic devices, the compass mode requires calibration (see chapter 3.10)

3.3.3.3 M4G (Magnet for Gyroscope)

The M4G mode is similar to the IMU mode, but instead of using the gyroscope signal to detect rotation, the changing orientation of the magnetometer in the magnetic field is used. Since the magnetometer has much lower power consumption than the gyroscope, this mode is less power consuming in comparison to the IMU mode. There are no drift effects in this mode which are inherent to the gyroscope.

However, as for compass mode, the measurement accuracy depends on the stability of the surrounding magnetic field.

For this mode no magnetometer calibration is required and also not available.

3.3.3.4 NDOF_FMC_OFF

This fusion mode is same as NDOF mode, but with the Fast Magnetometer Calibration turned 'OFF'.

3.3.3.5 NDOF

This is a fusion mode with 9 degrees of freedom where the fused absolute orientation data is calculated from accelerometer, gyroscope and the magnetometer. The advantages of combining all three sensors are a fast calculation, resulting in high output data rate, and high robustness from magnetic field distortions. In this mode the Fast Magnetometer calibration is turned ON and thereby resulting in quick calibration of the magnetometer and higher output data accuracy. The current consumption is slightly higher in comparison to the NDOF FMC OFF fusion mode.



Page 24

3.4 Axis remap

The device mounting position should not limit the data output of the BNO055 device. The axis of the device can be re-configured to the new reference axis.

Axis configuration byte: Register Address: AXIS_MAP_CONFIG

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Rese	erved	Remapped	Z axis value	Remappe val		Remappe val	

There are two bits are used to configure the axis remap which will define in the following way,

Value	Axis Representation
00	X - Axis
01	Y - Axis
10	Z- Axis
11	Invalid

Also, when user try to configure the same axis to two or more then BNO055 will take this as invalid condition and previous configuration will be restored in the register map. The default value is: X Axis = X, Y Axis = Y and Z Axis = Z (AXIS REMAP CONFIG = 0x24).


Axis sign configuration byte: Register Address: AXIS_MAP_SIGN

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
		Reserved			Remappe d X axis sign	Remappe d Y axis sign	Remappe d Z axis sign

Value	Sign
0	Positive
1	Negative

The default value is 0x00.


The default values correspond to the following coordinate system







Page 25

Some example placement for axis vs. register settings:







For the above described placements, following would be the axis configuration parameters.

Placement	AXIS_REMAP_CONFIG	AXIS_REMAP_SIGN
P0	0x21	0x04
P1 (default)	0x24	0x00
P2	0x24	0x06
P3	0x21	0x02
P4	0x24	0x03
P5	0x21	0x01
P6	0x21	0x07
P7	0x24	0x05



Page 26

3.5 Sensor Configuration

The fusion outputs of the BNO055 are tightly linked with the sensor configuration settings. Due to this fact, the sensor configuration is limited when BNO055 is configured to run in any of the fusion operating mode. In any of the sensor modes the configuration settings can be updated by writing to the configuration registers as defined in the following sections.

3.5.1 Default sensor configuration

At power-on the sensors are configured with the default settings as defined in Table 3-8 below.

Table 3-7: Default sensor configuration at power-on

Sensors	Parameters	Value
Accelerometer	Power Mode	NORMAL
	Range	+/- 4g
	Bandwidth	62.5Hz
	Resolution	14 bits
Gyroscope	Power Mode	NORMAL
	Range	2000 %s
	Bandwidth	32Hz
	Resolution	16 bits
Magnetometer	Power Mode	FORCED
	ODR	20Hz
	XY Repetition	15
	Z Repetition	16
	Resolution x/y/z	13/13/15 bits



Page 27

3.5.2 Accelerometer configuration

The fusion outputs of the BNO055 are tightly linked with the accelerometer sensor settings. Therefore the configuration possibilities are restricted when running in any of the fusion operating modes. The accelerometer configuration can be changed by writing to the ACC_Config register, Table below shows different Accelerometer configurations

Table 3-8: Accelerometer configurations

Parameter	Values	[Reg Addr]: Reg Value	Restrictions	
G Range	2G	[ACC_Config]: xxxxx00b		
	4G	[ACC_Config]: xxxxx01b	User selectable in all	
	8G	[ACC_Config]: xxxxx10b	modes	
	16G	[ACC_Config]: xxxxx11b		
Bandwidth	7.81Hz	[ACC_Config]: xxx0000xxb		
	15.63Hz	[ACC_Config]: xxx001xxb		
	31.25Hz	[ACC_Config]: xxx010xxb		
	62.5Hz	[ACC_Config]: xxx011xxb	Auto controlled in fusion	
	125Hz	[ACC_Config]: xxx100xxb	mode	
	250Hz	[ACC_Config]: xxx101xxb		
	500Hz	[ACC_Config]: xxx110xxb		
	1000Hz	[ACC_Config]: xxx111xxb		
Operation Mode	Normal	[ACC_Config]: 000xxxxb		
	Suspend	[ACC_Config]: 001xxxxb		
	Low Power 1	[ACC_Config]: 010xxxxb	Auto controlled in fusion	
	Standby	[ACC_Config]: 011xxxxb	mode	
	Low Power 2	[ACC_Config]: 100xxxxb		
	Deep Suspend	[ACC_Config]: 101xxxxb		

The accelerometer sensor operation mode is not configurable by user when BNO power mode is configured as low power mode. BNO rewrites the user configured value to Normal mode when switching from config mode to any BNO operation mode. This used to achieve the BNO low power mode performance.



Page 28

3.5.3 Gyroscope configuration

The fusion outputs of the BNO055 are tightly linked with the angular rate sensor settings. Therefore the configuration possibilities are restricted when running in any of the fusion operating modes. The gyroscope configuration can be changed by writing to the GYR_Config register, Table below shows different Gyroscope configurations

Table 3-9: Gyroscope configurations

Parameter	Values	[Reg Addr]: Register value	Restrictions
Range	2000 dps	[GYR_Config_0]: xxxx0000b	
	1000 dps	[GYR_Config_0]: xxxx001b	
	500dps	[GYR_Config_0]: xxxx010b	
	250 dps	[GYR_Config_0]: xxxx011b	
	125 dps	[GYR_Config_0]: xxxx100b	
Bandwidth	523Hz	[GYR_Config_0]: xx000xxxb	
	230Hz	[GYR_Config_0]: xx001xxxb	
	116Hz	[GYR_Config_0]: xx010xxxb	
	47Hz	[GYR_Config_0]: xx011xxxb	Auto controlled in fusion mode
	23Hz	[GYR_Config_0]: xx100xxxb	
	12Hz	[GYR_Config_0]: xx101xxxb	
	64Hz	[GYR_Config_0]: xx110xxxb	
	32Hz	[GYR_Config_0]: xx111xxxb	
Operation Mode	Normal	[GYR_Config_1]: xxxx000b	
	Fast Power up	[GYR_Config_1]: xxxxx001b	
	Deep Suspend	[GYR_Config_1]: xxxx010b	
	Suspend	[GYR_Config_1]: xxxx011b	
	Advanced Powersave	[GYR_Config_1]: xxxx100b	



Page 29

3.5.4 Magnetometer configuration

The fusion outputs of the BNO055 are tightly linked with the magnetometer sensor settings. Therefore the configuration possibilities are restricted when running in any of the fusion operating modes. The magnetometer configuration can be changed by writing to the MAG_Config register, Table below shows different Magnetometer configurations.

Table 3-10: Magnetometer configurations

Parameter	Values	[Reg Addr]: Register value	Restrictions
Data output rate	2Hz	[MAG_Config]: xxxx0000b	
	6Hz	[MAG_Config]: xxxx001b	
	8Hz	[MAG_Config]: xxxx010b	
	10Hz	[MAG_Config]: xxxx011b	
	15Hz	[MAG_Config]: xxxx100b	
	20Hz	[MAG_Config]: xxxx101b	
	25Hz	[MAG_Config]: xxxx110b	
	30Hz	[MAG_Config]: xxxx111b	
Operation Mode	Low Power	[MAG_Config]: xxx00xxxb	Auto controlled in fusion mode
	Regular	[MAG_Config]: xxx01xxxb	
	Enhanced Regular	[MAG_Config]: xxx10xxxb	
	High Accuracy	[MAG_Config]: xxx11xxxb	
Power Mode	Normal	[MAG_Config]: x00xxxxb	
	Sleep	[MAG_Config]: x01xxxxb	
	Suspend	[MAG_Config]: x10xxxxb	
	Force Mode	[MAG_Config]: x11xxxxb	



3.6 Output data

Depending on the selected operating mode the device will output either un-calibrated sensor data (in non-fusion mode) or calibrated / fused data (in fusion mode), this section describes the output data for each modes.

3.6.1 Unit selection

The measurement units for the various data outputs (regardless of operation mode) can be configured by writing to the UNIT_SEL register as described in Table 3-9.

Table 3-11: unit selection

Data	Units	[Reg Addr]: Register Value
Acceleration, Linear	m/s ²	[UNIT_SEL] : xxxxx0b
Acceleration, Gravity vector	mg	[UNIT_SEL] : xxxxx1b
Magnetic Field Strength	Micro Tesla	NA
Angular Rate	Dps	[UNIT_SEL] : xxxxx0xb
	Rps	[UNIT_SEL] : xxxxx1xb
Euler Angles	Degrees	[UNIT_SEL] : xxxx0xxb
	Radians	[UNIT_SEL] : xxxx1xxb
Quaternion	Quaternion units	NA
Temperature	°C	[UNIT_SEL] : xxx0xxxxb
	°F	[UNIT_SEL] : xxx1xxxxb

3.6.2 Data output format

The data output format can be selected by writing to the UNIT_SEL register, this allows user to switch between the orientation definition described by Windows and Android operating systems.

Table 3-12: Fusion data output format

Parameter	Values	[Reg Addr]: Register value
Fusion data output	Windows	[UNIT_SEL]: 0xxxxxb
format	Android	[UNIT_SEL]: 1xxxxxb

The output data format is based on the following convention regarding the rotation angles for roll, pitch and heading / yaw (compare also section 3.4):

Table 3-13: Rotation angle conventions

Rotation angle	Range (Android format) Range (Windows format)	
Pitch	+180° to -180° (turning -180° to +180° (turing clock-clockwise decreases values)	
Roll	-90° to +90° (increasing with increasing inclination)	
Heading / Yaw	0° to 360° (turning clockwise increases values)	

Page 31

3.6.3 Fusion Output data rates

Table 3-14: Fusion output data rates

BNO055 Operating	Data input rate		Algo	Data output rate				
Mode	Accel	Mag	Gyro	calling rate	Accel	Mag	Gyro	Fusion data
IMU	100Hz	NA	100Hz	100Hz	100Hz	NA	100Hz	100Hz
COMPASS	20Hz	20Hz	NA	20Hz	20Hz	20Hz	NA	20Hz
M4G	50Hz	50Hz	NA	50Hz	50Hz	50Hz	NA	50Hz
NDOF_FMC_OFF	100Hz	20Hz	100Hz	100Hz	100Hz	20Hz	100Hz	100Hz
NDOF	100Hz	20Hz	100Hz	100Hz	100Hz	20Hz	100Hz	100Hz

3.6.4 Sensor calibration data

The following section describes the register holding the calibration data of the sensors (see chapter 3.10). The offset and radius data can be read from these registers and stored in the host system, which could be later used to get the correct orientation data after 'Power on Reset' of the sensor.

3.6.4.1 Accelerometer offset

The accelerometer offset can be configured in the following registers, shown in the table below. There are 6 bytes required to configure the accelerometer offset (2 bytes for each of the 3 axis X, Y and Z). Configuration will take place only when the user writes the last byte (i.e., ACC_OFFSET_Z_MSB).

Table 3-15: Accelerometer Default-Reg settings

Reg Name	Default Reg Value (Bit 0 – Bit 7)
ACC_OFFSET_X_LSB	0x00
ACC_OFFSET_X_MSB	0x00
ACC_OFFSET_Y_LSB	0x00
ACC_OFFSET_Y_MSB	0x00
ACC_OFFSET_Z_LSB	0x00
ACC_OFFSET_Z_MSB	0x00

The range of the offsets varies based on the G-range of accelerometer sensor.

Table 3-16: Accelerometer G-range settings

Accelerometer G-range	Maximum Offset range in mg
2G	+/- 2000
4G	+/- 4000
8G	+/- 8000
16G	+/- 16000

Table 3-17: Accelerometer Unit settings

Unit	Representation
m/s ²	$1 \text{ m/s}^2 = 100 \text{ LSB}$
mg	1 mg = 1 LSB

Page 32

3.6.4.2 Magnetometer offset

The magnetometer offset can be configured in the following registers,

Table 3-18: Magnetometer Default-Reg settings

Reg Name	Default Reg Value (Bit 0 – Bit 7)
MAG_OFFSET_X_LSB	0x00
MAG_OFFSET_X_MSB	0x00
MAG_OFFSET_Y_LSB	0x00
MAG_OFFSET_Y_MSB	0x00
MAG_OFFSET_Z_LSB	0x00
MAG_OFFSET_Z_MSB	0x00

There are 6 bytes required to configure the magnetometer offset (bytes (2 bytes for each of the 3 axis X, Y and Z). Configuration will take place only when the user writes the last byte (i.e., MAG_OFFSET_Z_MSB). Therefore the last byte must be written whenever the user wants to changes the configuration. The range of the magnetometer offset is +/-6400 in LSB.

Table 3-19: Magnetometer Unit settings

Unit	Representation
μΤ	1 μT = 16 LSB

3.6.4.3 Gyroscope offset

The gyroscope offset can be configured in the following registers, shown in the table below

Table 3-20: Gyroscope Default Reg-settings

Reg Name	Default Reg Value (Bit 0 - Bit 7)
GYR_OFFSET_X_LSB	0x00
GYR_OFFSET_X_MSB	0x00
GYR_OFFSET_Y_LSB	0x00
GYR_OFFSET_Y_MSB	0x00
GYR_OFFSET_Z_LSB	0x00
GYR OFFSET Z MSB	0x00

There are 6 bytes required to configure the gyroscope offset (bytes (2 bytes for each of the 3 axis X, Y and Z). Configuration will take place only when the user writes the last byte (i.e., GYR_OFFSET_Z_MSB). Therefore the last byte must be written whenever the user wants to changes the configuration. The range of the offset varies based on the dps-range of gyroscope sensor.

Page 33

Table 3-21: Gyroscope range settings

Gyroscope dps range	Maximum Offset range in LSB
2000	+/- 32000
1000	+/- 16000
500	+/- 8000
250	+/- 4000
125	+/- 2000

Table 3-22: Gyroscope unit settings

Unit	Representation
Dps	1 Dps = 16 LSB
Rps	1 Rps = 900 LSB

3.6.4.4 Radius

The radius of accelerometer, magnetometer and gyroscope can be configured in the following registers,

Table 3-23: Radius Default-Reg settings

Reg Name	Default Reg Value (Bit 0 – Bit 7)
ACC_RADIUS_LSB	0x00
ACC_RADIUS_MSB	0x00
MAG_RADIUS_LSB	0x00
MAG_RADIUS_MSB	0x00

There are 4 bytes (2 bytes for each accelerometer and magnetometer) to configure the radius. Configuration will take place only when user writes to the last byte (i.e., ACC_RADIUS_MSB and MAG_RADIUS_MSB). Therefore the last byte must be written whenever the user wants to changes the configuration. The range of the radius for accelerometer is +/-1000, magnetometer is +/-960 and Gyroscope is NA.

Table 3-24: Radius range settings

Radius for sensor	Maximum Range
Accelerometer	+/- 1000 LSB
Magnetometer	+/- 960 LSB

3.6.5 Output data registers

3.6.5.1 Acceleration data

In non-fusion mode uncompensated acceleration data for each axis X/Y/Z, can be read from the appropriate ACC_DATA_<axis>_LSB and ACC_DATA_<axis>_MSB registers.

In fusion mode the fusion algorithm output offset compensated acceleration data for each axis X/Y/Z, the output data can be read from the appropriate ACC_DATA_<axis>_LSB and ACC_DATA_<axis>_MSB registers. Refer table below for information regarding the data types for the acceleration data.

Page 34

Table 3-25: Acceleration data

Parameter	Data type	bytes
Accel_Data_X	signed	2
Accel_Data_Y	signed	2
Accel_Data_Z	signed	2

3.6.5.2 Magnetic Field Strength

In non-fusion mode uncompensated field strength data for each axis X/Y/Z, can be read from the appropriate MAG_DATA_<axis>_LSB and MAG_DATA_<axis>_MSB registers.

In fusion mode the fusion algorithm output offset compensated magnetic field strength data for each axis X/Y/Z, the output data can be read from the appropriate MAG_DATA_<axis>_LSB and MAG_DATA_<axis>_MSB registers. Refer table below for information regarding the data types for the magnetic field strength.

Table 3-26: Magnetic field strength data

Parameter	Data type	bytes
Mag_Data_X	signed	2
Mag_Data_Y	signed	2
Mag_Data_Z	signed	2

3.6.5.3 Angular Velocity

In non-fusion mode uncompensated angular velocity (yaw rate) data for each axis X/Y/Z, can be read from the appropriate $GYR_DATA_<axis>_LSB$ and $GYR_DATA_<axis>_MSB$ registers.

In fusion mode the fusion algorithm output offset compensated angular velocity (yaw rate) data for each axis X/Y/Z, the output data can be read from the appropriate GYR_DATA_<axis>_LSB and GYR_DATA_<axis>_MSB registers. Refer table below for information regarding the data types for the angular velocity.

Table 3-27: Yaw rate data

Parameter	Data type	bytes
Gyr_Data_X	signed	2
Gyr_Data_Y	signed	2
Gyr_Data_Z	signed	2

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Bosch Sensorted

Page 35

3.6.5.4 Orientation (Euler angles)

Orientation output only available in fusion operation modes.

The fusion algorithm output offset and tilt compensated orientation data in Euler angles format for each DOF Heading/Roll/Pitch, the output data can be read from the appropriate EUL<dof>_LSB and EUL_<dof>_MSB registers. Refer table below for information regarding the data types and the unit representation for the Euler angle format.

Table 3-28: Compensated orientation data in Euler angles format

Parameter	Data type	bytes
EUL_Heading	Signed	2
EUL_Roll	Signed	2
EUL_Pitch	Signed	2

Table 3-29: Euler angle data representation

Unit	Representation
Degrees	1 degree = 16 LSB
Radians	1 radian = 900 LSB

3.6.5.5 Orientation (Quaternion)

Orientation output only available in fusion operating modes.

The fusion algorithm output offset and tilt compensated orientation data in quaternion format for each DOF w/x/y/z, the output data can be read from the appropriate QUA_DATA_<dof>_LSB and QUA_DATA_<dof>_MSB registers. Refer table below for information regarding the data types and the unit representation for the Orientation output.

Table 3-30: Compensated orientation data in quaternion format

Parameter	Data type	bytes
QUA_Data_w	Signed	2
QUA_Data_x	Signed	2
QUA_Data_y	Signed	2
QUA_Data_z	Signed	2

Table 3-31: Quaternion data representation

Unit	Representation
Quaternion (unit less)	1 Quaternion (unit less) = 2^14 LSB

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Page 36

3.6.5.6 Linear Acceleration

Linear acceleration output only available in fusion operating modes.

The fusion algorithm output linear acceleration data for each axis x/y/z, the output data can be read from the appropriate LIA_DATA_<axis>_LSB and LIA_DATA_<axis>_MSB registers. Refer table below for further information regarding the data types and the unit representation for Linear acceleration

Table 3-32: Linear Acceleration Data

Parameter	Data type	bytes
LIA_Data_X	signed	2
LIA_Data_Y	signed	2
LIA_Data_Z	signed	2

Table 3-33: Linear Acceleration data representation

Unit	Representation
m/s ²	$1 \text{ m/s}^2 = 100 \text{ LSB}$
mg	1 mg = 1 LSB

3.6.5.7 Gravity Vector

Gravity Vector output only available in fusion operating modes.

The fusion algorithm output gravity vector data for each axis x/y/z, the output data can be read from the appropriate GRV_DATA_<axis>_LSB and GRV_DATA_<axis>_MSB registers. Refer table below for further information regarding the data types and the unit representation for the Gravity vector.

Table 3-34: Gravity Vector Data

Parameter	Data type	bytes
GRV_Data_X	signed	2
GRV_Data_Y	signed	2
GRV_Data_Z	signed	2

Table 3-35: Gravity Vector data representation

Unit	Representation
m/s ²	$1 \text{ m/s}^2 = 100 \text{ LSB}$
mg	1 mg = 1 LSB



Page 37

3.6.5.8 Temperature

The temperature output data can be read from the TEMP register. The table below describes the output data type and data representation (depending on selected unit). The temperature can be read from one of two sources, the temperature source can be selected by writing to the TEMP_SOURCE register as detailed below.

Table 3-36: Temperature Data

Parameter	Data type	bytes
TEMP	signed	1

Table 3-37: Temperature data representation

Unit	Representation
°C	1°C = 1 LSB
F	2 F = 1 LSB

Table 3-38: Temperature Source Selection

Source	[Reg Addr]: Register Value
Accelerometer	[TEMP_SOURCE]: xxxxx00b
Gyroscope	[TEMP_SOURCE]: xxxxx01b



Page 38

3.7 Interrupts

3.7.1 Interrupt Pin

INT is configured as interrupt pin for signaling an interrupt to the host. The interrupt trigger is configured as raising edge and is latched on to the INT pin. Once an interrupt occurs, the INT pin is set to high and will remain high until it is reset by host. This can be done by setting RST_INT in SYS_TRIGGER register.

Interrupts can be enabled by setting the corresponding bit in the interrupt enable register (INT EN) and disabled when it is cleared.

Interrupt Pin Masking

Interrupts can be routed to the INT pin by setting the corresponding interrupt bit in the INT_MSK register.

Interrupt Status

Interrupt occurrences are stored in the interrupt status register (INT_STA). All bits in this register are cleared on read.

3.7.2 Interrupt Settings

3.7.2.1 Accelerometer Slow/No Motion Interrupt

The slow-motion/no-motion interrupt engine can be configured in two modes.

Slow-motion Interrupt is triggered when the measured slope of at least one enabled axis exceeds the programmable slope threshold for a programmable number of samples. Hence the engine behaves similar to the any-motion interrupt, but with a different set of parameters. In order to suppress false triggers, the interrupt is only generated (cleared) if a certain number N of consecutive slope data points is larger (smaller) than the slope threshold given by $slo_no_mot_dur<1:0>$. The number is $N = slo_no_mot_dur<1:0> + 1$.

In no-motion mode an interrupt is generated if the slope on all selected axes remains smaller than a programmable threshold for a programmable delay time. Figure 11 shows the timing diagram for the no-motion interrupt. The scaling of the threshold value is identical to that of the slow-motion interrupt. However, in no-motion mode register slo_no_mot_dur defines the delay time before the no-motion interrupt is triggered. Table 3-39 lists the delay times adjustable with register slo_no_mot_dur. The timer tick period is 1 second. Hence using short delay times can result in considerable timing uncertainty.

If bit *SM/NM* is set to '1' ('0'), the no-motion/slow-motion interrupt engine is configured in the no-motion (slow-motion) mode. Common to both modes, the engine monitors the slopes of the axes that have been enabled with bits *AM/NM_X_AXIS*, *AM/NM_Y_AXIS*, and *AM/NM_Z_AXIS* for the x-axis, y-axis and z-axis, respectively. The measured slope values are continuously compared against the threshold value defined in register ACC_NM_THRES. The scaling is such that 1 LSB of ACC_NM_THRES corresponds to 3.91 mg in 2g-range (7.81 mg in 4g-range, 15.6 mg in 8g-range and 31.3 mg in 16g-range). Therefore the maximum value is 996 mg in 2g-range (1.99g in 4g-range, 3.98g in 8g-range and 7.97g in 16g-range). The time difference between the successive acceleration samples depends on the selected bandwidth and equates to 1/(2 * bw).



Table 3-39: No-motion time-out periods

slo_no_mot_dur	Delay time	slo_no_mot_dur	Delay time	slo_no_mot_d ur	Delay Time
0	1 s	16	40 s	32	88 s
1	2 s	17	48 s	33	96 s
2	3 s	18	56 s	34	104 s
•••		19	64 s.	•••	•••
14	15 s	20	72 s	62	328 s
15	16 s	21	80 s	63	336 s

Note: slo_no_mot_dur values 22 to 31 are not specified




Table 3-40: Timing of No-motion interrupt

Params	Value	[Reg Addr]: Register Value		
Detection Type	No Motion	[ACC_NM_SET]: xxxxxx0b		
Detection Type	Slow Motion	[ACC_NM_SET]: xxxxxx1b		
Interrunt Darameters	Threshold	[ACC_NM_THRE]: bit7:bit0		
Interrupt Parameters	Duration	[ACC_NM_SET]: bit6:bit1		
Axis selection	X-axis	[ACC_INT_Settings]: xxxx1xxb		
	Y-axis	[ACC_INT_Settings]: xxxx1xxxb		
	Z-axis	[ACC_INT_Settings]: xxx1xxxxb		

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

[©] Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany.

Note: Specifications within this document are subject to change without notice.



3.7.2.2 Accelerometer Any Motion Interrupt

The any-motion interrupt uses the slope between successive acceleration signals to detect changes in motion. An interrupt is generated when the slope (absolute value of acceleration difference) exceeds a preset threshold. It is cleared as soon as the slope falls below the threshold. The principle is made clear in Figure 2: Principle of any-motion detection.




Figure 2: Principle of any-motion detection

The threshold is defined through register ACC_AM_THRES. In terms of scaling 1 LSB of ACC_AM_THRES corresponds to 3.91 mg in 2g-range (7.81 mg in 4g-range, 15.6 mg in 8g-range and 31.3 mg in 16g-range). Therefore the maximum value is 996 mg in 2g-range (1.99g in 4g-range, 3.98g in 8g-range and 7.97g in 16g-range).

The time difference between the successive acceleration signals depends on the selected bandwidth and equates to 1/(2*bandwidth) ()t=1/(2*bw)). In order to suppress false triggers, the interrupt is only generated (cleared) if a certain number N of consecutive slope data points is larger (smaller) than the slope threshold given by ACC_AM_THRES. This number is set by the AM_DUR bits. It is $N = AM_DUR + 1$.

Example: *AM_DUR* = 00b, ..., 11b = 1decimal, ..., 4decimal.

Page 41

Enabling (disabling) for each axis:

Any-motion detection can be enabled (disabled) for each axis separately by writing '1' ('0') to bits AM/NM_X_AXIS, AM/NM_Y_AXIS, AM/NM_Z_AXIS. The criteria for any-motion detection are fulfilled and the slope interrupt is generated if the slope of any of the enabled axes exceeds the threshold ACC_AM_THRES for [AM_DUR +1] consecutive times. As soon as the slopes of all enabled axes fall or stay below this threshold for [AM_DUR +1] consecutive times the interrupt is cleared unless interrupt signal is latched.

Table 3-41: Any-motion Interrupt parameters and Axis selection

Params	Value	[Reg Addr]: Register Value
Interrupt Parameters	Threshold	[ACC_AM_THRES]: bit7:bit0
	Duration	[ACC_INT_Settings]: bit1:bit0
Axis selection	X-axis	[ACC_INT_Settings]: xxxx1xxb
	Y-axis	[ACC_INT_Settings]: xxxx1xxxb
	Z-axis	[ACC_INT_Settings]: xxx1xxxxb

3.7.2.3 Accelerometer High G Interrupt

This interrupt is based on the comparison of acceleration data against a high-g threshold for the detection of shock or other high-acceleration events.

The high-g interrupt is enabled (disabled) per axis by writing '1' ('0') to bits ACC_HIGH_G in the INT_EN register and enabling the axis in with bits HG_X_AXIS, HG_Y_AXIS, and HG_Z_AXIS, respectively in the ACC_INT_Settings register. The high-g threshold is set through the ACC_HG_THRES register. The meaning of an LSB of ACC_HG_THRES depends on the selected g-range: it corresponds to 7.81 mg in 2g-range, 15.63 mg in 4g-range, 31.25 mg in 8g-range, and 62.5 mg in 16g-range (i.e. increment depends from g-range setting).

The high-g interrupt is generated if the absolute value of the acceleration of at least one of the enabled axes ('or' relation) is higher than the threshold for at least the time defined by the ACC_HG_DURATION register. The interrupt is reset if the absolute value of the acceleration of all enabled axes ('and' relation) is lower than the threshold for at least the time defined by the ACC_HG_DURATION register. The interrupt status is stored in bit ACC_HIGH_G in the INT_STA register. The relation between the content of ACC_HG_DURATION and the actual delay of the interrupt generation is delay [ms] = [ACC_HG_DURATION + 1] * 2 ms. Therefore, possible delay times range from 2 ms to 512 ms.

Table 3-42: High-G Interrupt parameters and Axis selection

Params	Value	[Reg Addr]: Register Value				
late we get Deve as etc.	Threshold	[ACC_HG_THRES]: bit7 : bit0				
Interrupt Parameters	Duration	[ACC_HG_DURATION]: bit7 : bit0				
Axis selection	X-axis	[ACC_INT_Settings]: xx1xxxxb				
	Y-axis	[ACC_INT_Settings]: x1xxxxxb				
	Z-axis	[ACC_INT_Settings]: 1xxxxxxb				

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



3.7.2.4 Gyroscope High Rate Interrupt

This interrupt is based on the comparison of angular rate data against a high-rate threshold for the detection of shock or other high-angular rate events. The principle is made clear in Figure 3 below:




Figure 3: High rate interrupt

The high-rate interrupt is enabled (disabled) per axis by writing '1' ('0') to bits $GYRO_HIGH_RATE$ in the INT_EN register and for each axis by writing to the HR_X_AXIS , HR_Y_AXIS , and HR_Z_AXIS , respectively in the $GYR_INT_SETTING$ register. The high-rate threshold is set through the $HR_\langle axis \rangle$ _Threshold bits in the appropriate $GYR_HR_\langle axis \rangle$ _SET register. The meaning of an LSB of $HR_\langle axis \rangle$ _Threshold depends on the selected °/s-range: it corresponds to 62.5°/s in 2000°/s-range, 31.25°/s in 1000°/s-range, 15.625°/s in 500°/s -range ...). The $HR_\langle axis \rangle$ _Threshold register setting 0 corresponds to 62.26°/s in 2000°/s-range, 31.13°/s in 1000°/s-range, 15.56°/s in 500°/s-range Therefore the maximum value is 1999.76°/s in 2000°/s-range (999.87°/s 1000°/s-range, 499.93°/s in 500°/s -range ...).

A hysteresis can be selected by setting the $HR_\langle axis \rangle_THRES_HYST$ bits. Analogously to threshold, the meaning of an LSB of $HR_\langle axis \rangle_THRES_HYST$ bits is °/s-range dependent: The $HR_\langle axis \rangle_THRES_HYST$ register setting 0 corresponds to an angular rate difference of 62.26°/s in 2000°/s-range, 31.13°/s in 1000°/s-range, 15.56°/s in 500°/s-range The meaning of an LSB of $HR_\langle axis \rangle_THRES_HYST$ depends on the selected °/s-range too: it corresponds to 62.5°/s in 2000°/s-range, 31.25°/s in 1000°/s-range, 15.625°/s in 500°/s-range ...).

The high-rate interrupt is generated if the absolute value of the angular rate of at least one of the enabled axes ('or' relation) is higher than the threshold for at least the time defined by the $GYR_DUR_<axis>$ register. The interrupt is reset if the absolute value of the angular rate of all enabled axes ('and' relation) is lower than the threshold minus the hysteresis. In bit GYR_HIGH_RATE in the INT_STA the interrupt status is stored. The relation between the content of $GYR_DUR_<axis>$ and the actual delay of the interrupt generation is delay [ms] = [$GYR_DUR_<axis>+1$] * 2.5 ms. Therefore, possible delay times range from 2.5 ms to 640 ms.



Page 43

Table 3-43: High Rate Interrupt parameters and Axis selection

Params	Value	[Reg Addr]: Register Value			
	X-axis	[GYR_INT_SETTING]: xxxx1xxxb			
Axis selection	Y-axis	[GYR_INT_SETTING]: xxx1xxxxb			
	Z-axis	[GYR_INT_SETTING]: xx1xxxxb			
High Rate Filter	Filtered	[GYR_INT_SETTING]: 0xxxxxb			
settings	Unfiltered	[GYR_INT_SETTING]: 1xxxxxxb			
	Threshold	[GYR_HR_X_SET]: bit4 : bit0			
Interrupt Settings X- axis	Duration	[GYR_DUR_X]: bit7 : bit0			
ans	Hysteresis	[GYR_HR_X_SET]: bit6 : bit5			
	Threshold	[GYR_HR_Y_SET]: bit4 : bit0			
Interrupt Settings Y- axis	Duration	[GYR_DUR_Y]: bit7 : bit0			
u/uS	Hysteresis	[GYR_HR_Y_SET]: bit6 : bit5			
	Threshold	[GYR_HR_Z_SET]: bit4 : bit0			
Interrupt Settings X- axis	Duration	[GYR_DUR_Z]: bit7 : bit0			
ans	Hysteresis	[GYR_HR_Z_SET]: bit6 : bit5			



3.7.2.5 Gyroscope Any Motion Interrupt

Any-motion (slope) detection uses the slope between successive angular rate signals to detect changes in motion. An interrupt is generated when the slope (absolute value of angular rate difference) exceeds a preset threshold. It is deared as soon as the slope falls below the threshold. The principle is made clear in Figure 4.




Figure 4: Principle of any-motion detection

The threshold is defined through register GYR_AM_THRES. In terms of scaling 1 LSB of GYR_AM_THRES corresponds to 1 °/s in 2000°/s-range (0.5°/s in 1000°/s-range, 0.25°/s in 500°/s -range ...). Therefore the maximum value is 125°/s in 2000°/s-range (62.5°/s 1000°/s-range, 31.25 in 500°/s -range ...).

The time difference between the successive angular rate signals depends on the selected update rate(fs) which is coupled to the bandwidth and equates to 1/(4*fs) (t=1/(4*fs)). For bandwidth settings with an update rate higher than 400Hz (bandwidth =0,1,2) fs is set to 400Hz.

In order to suppress false triggers, the interrupt is only generated (cleared) if a certain number N of consecutive slope data points is larger (smaller) than the slope threshold given by GYR_AM_THRES. This number is set by the Slope Samples bits in the GYR_AM_SET register. It is N = [Slope Samples + 1]*4. N is set in samples. Thus the time is scaling with the update rate (fs).



Page 45

3.7.2.6 Enabling (disabling) for each axis

Any-motion detection can be enabled (disabled) for each axis separately by writing '1' ('0') to bits AM_X_AXIS , AM_Y_AXIS , AM_Z_AXIS in the $GYR_INT_SETTING$ register. The criteria for any-motion detection are fulfilled and the Any-Motion interrupt is generated if the slope of any of the enabled axes exceeds the threshold GYR_AM_THRES for [Slope Samples+1]*4 consecutive times. As soon as the slopes of all enabled axes fall or stay below this threshold for [Slope Samples +1]*4 consecutive times the interrupt is cleared unless interrupt signal is latched.

3.7.2.7 Axis of slope / any motion interrupt

The interrupt status is stored in bit *GYRO_AM* in the *INT_EN* register. The Any-motion interrupt supplies additional information about the detected slope.

Table 3-44: Axis selection and any motion interrupt

Params	Value	[Reg Addr]: Register Value			
	X-axis	[GYR_INT_SETING]: xxxxxx1b			
Axis selection	Y-axis	[GYR_INT_SETING]: xxxxx1xb			
	Z-axis	[GYR_INT_SETING]: xxxxx1xxb			
Any Motion Filter settings	Filtered	[GYR_INT_SETING]: x0xxxxxb			
	Unfiltered	[GYR_INT_SETING]: x1xxxxxb			
	Threshold	[GYR_AM_THRES]: bit6 : bit0			
Interrupt Settings	Slope Samples	[GYR_AM_SET]: bit1 : bit0			
	Awake Duration	[GYR_AM_SET]: bit3 : bit2			

Page 46

3.8 Self-Test

3.8.1 Power On Self Test (POST)

During the device startup, a power on self test is executed. This feature checks that the connected sensors and microcontroller are responding / functioning correctly. Following tests are executed

Table 3-45: Power on Self Test

Components	Test type
Accelerometer	Verify chip ID
Magnetometer	Verify chip ID
Gyroscope	Verify chip ID
Microcontroller	Memory Build In Self Test

The results of the POST are stored at register ST_RESULT, where a bit set indicates test passed and cleared indicates self test failed.

3.8.2 Build In Self Test (BIST)

The host can trigger a self test from CONFIG MODE. The test can be triggered by setting bit SELF_TEST in the in the SYS_TRIGGER register, the results are stored in the ST_RESULT register. During the execution of the system test, all other features are paused.

Table 3-46: Power on Self Test

Components	Test type
Accelerometer	built in self test
Magnetometer	built in self test
Gyroscope	built in self test
Microcontroller	No test performed

3.9 Boot loader

The boot loader is located at the start of the program memory and it is executed at each reset / power-on sequence. It first checks the status of the nBOOT_LOAD_PIN.

If the nBOOT_LOAD_PIN is pulled low during reset / power-on sequence, it continues execution in boot loader mode. Otherwise the device continues to boot in application mode.

In case there is a firmware update, then an application note would be available in time with the necessary information to upgrade at the host side. Nevertheless it is recommended that the nBOOT LOAD PIN is connected as shown in section 5.



Page 47

3.10 Calibration

Though the sensor fusion software runs the calibration algorithm of all the three sensors (accelerometer, gyroscope and magnetometer) in the background to remove the offsets, some preliminary steps had to be ensured for this automatic calibration to take place.

The accelerometer and the gyroscope are relatively less susceptible to external disturbances, as a result of which the offset is negligible. Whereas the magnetometer is susceptible to external magnetic field and therefore to ensure proper heading accuracy, the calibration steps described below have to be taken.

Depending on the sensors been selected, the following simple steps had to be taken after every 'Power on Reset' for proper calibration of the device.

3.10.1 Accelerometer Calibration

- Place the device in 6 different stable positions for a period of few seconds to allow the accelerometer to calibrate.
- Make sure that there is slow movement between 2 stable positions
- The 6 stable positions could be in any direction, but make sure that the device is lying at least once perpendicular to the x, y and z axis.
- The register <u>CALIB_STAT</u> can be read to see the calibration status of the accelerometer.

3.10.2 Gyroscope Calibration

- Place the device in a single stable position for a period of few seconds to allow the gyroscope to calibrate
- The register CALIB_STAT can be read to see the calibration status of the gyroscope.

3.10.3 Magnetometer Calibration

Magnetometer in general are susceptible to both hard-iron and soft-iron distortions, but majority of the cases are rather due to the former. And the steps mentioned below are to calibrate the magnetometer for hard-iron distortions.

Nevertheless certain precautions need to be taken into account during the positioning of the sensor in the PCB which is described in our HSMI (Handling, Soldering and Mounting Instructions) application note to avoid unnecessary magnetic influences.

Compass, M4G & NDOF_FMC_OFF:

- Make some random movements (for example: writing the number '8' on air) until the CALIB_STAT register indicates fully calibrated.
- It takes more calibration movements to get the magnetometer calibrated than in the NDOF mode.

NDOF:

- The same random movements have to be made to calibrate the sensor as in the FMC_OFF mode, but here it takes relatively less calibration movements (and slightly higher current consumption) to get the magnetometer calibrated.
- The register CALIB STAT can be read to see the calibration status of the magnetometer.



Page 48

3.10.4 Reuse of Calibration Profile

Once the device is calibrated, the calibration profile can be reused to get the correct orientation data immediately after 'Power of Reset' (prior to going through the steps mentioned in the above section). However, once the sensor enters the internal calibration routine, the calibration profile is overwritten with the newly obtained sensor offsets and sensor radius. Depending on the application, necessary steps had to be ensured for proper calibration of the sensor.

Reading Calibration profile

The calibration profile includes sensor offsets and sensor radius. Host system can read the offsets and radius only after a full calibration is achieved and the operation mode is switched to CONFIG MODE. Refer to sensor offsets and sensor radius registers.

Setting Calibration profile

It is important that the correct offsets and corresponding sensor radius are used. Incorrect offsets may result in unreliable orientation data even at calibration accuracy level 3. To set the calibration profile the following steps need to be taken

- 1. Select the operation mode to CONFIG_MODE
- 2. Write the corresponding sensor offsets and radius data
- 3. Change operation mode to fusion mode



Page 49

4. Register description

4.1 General Remarks

The entire communication with the device is performed by reading from and writing to registers. Registers have a width of 8 bits. There are several registers which are either completely or partially marked as 'reserved'. Any reserved bit is ignored when it is written and no specific value is guaranteed when read. It is recommended not to use registers at all which are completely marked as 'reserved'. Furthermore it is recommended to mask out (logical and with zero) reserved bits of registers which are partially marked as reserved.

Read-Only Registers are marked as shown in Table 4-1: Register Access Coding. Any attempt to write to these registers is ignored.

There are bits within some registers that trigger internal sequences. These bits are configured for write-only access and read as value '0'.

Page 50

4.2 Register map

The register map is separated into two logical pages, Page 1 contains sensor specific configuration data and Page 0 contains all other configuration parameters and output data.

At power-on Page 0 is selected, the PAGE_ID register can be used to identify the current selected page and change between page 0 and page 1.

4.2.1 Register map Page 0

Table 4-1: Register Access Coding



Table 4-2: Register Map Page 0

Register Address	Register Name	Default Value	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
7F-6B	Reserved	NA								
6A	MAG_RADIUS_ MSB		Magnet omet er Radius							
69	MAG_RADIUS_ LSB			Magnet omet er Radius						
68	ACC_RADIUS_ MSB		Acceleromet er Radius							
67	ACC_RADIUS_L SB					Accelero	ometer Radio	us		
66	GYR_OFFSET_ Z_MSB	0x00				Gyroscope	Offset Z <1	5:8>		
65	GYR_OFFSET_ Z_LSB	0x00				Gyroscope	e Offset Z <	7:0>		
64	GYR_OFFSET_ Y_MSB	0x00				Gyroscope	Offset Y <1	5:8>		
63	GYR_OFFSET_ Y_LSB	0x00				Gyroscope	e Offset Y <	7:0>		
62	GYR_OFFSET_ X_MSB	0x00				Gyroscope	Offset X <1	5:8>		
61	GYR_OFFSET_ X_LSB	0x00				Gyroscope	e Offset X <	7:0>		
60	MAG_OFFSET_ Z_MSB	0x00				Magnet omet	er Offset Z	<15:8>		
5F	MAG_OFFSET_ Z_LSB	0x00	Magnetometer Offset Z <7:0>							
5E	MAG_OFFSET_ Y_MSB	0x00		Magnet omet er Offset Y <15:8>						
5D	MAG_OFFSET_ Y_LSB	0x00				Magnet ome	ter Offset Y	<7:0>		
5C	MAG_OFFSET_ X_MSB	0x00				Magnet omet	er Offset X	<15:8>		
5B	MAG_OFFSET_ X_LSB	0x00				Magnet ome	ter Offset X	<7:0>		
5A	ACC_OFFSET_ Z_MSB	0x00				Acceleromet	er Offset Z <	:15:8>		
59	ACC_OFFSET_ Z_LSB	0x00				Acceleromet	er Offset Z	<7:0>		
58	ACC_OFFSET_ Y_MSB	0x00	Accelerometer Offset Y <15:8>							
57	ACC_OFFSET_ Y_LSB	0x00	Accelerometer Offset Y <7:0>							
56	ACC_OFFSET_ X_MSB	0x00	Accelerometer Offset X <15:8>							
55	ACC_OFFSET_ X_LSB	0x00		Acceleromet er Offset X <7:0>						
43 - 54	Reserved	0x00								

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 51

Register Address	Register Name	Default Value	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
42	AXIS_MAP_SIG N	TBD						Remapped X axis sign	Remapped Y axis sign	Remapped Z axis sign
41	AXIS_MAP_CO NFIG	TBD				ped Z axis alue	Remapped	Y axis value		X axis value
40	TEMP_SOURC E	0x02							TEMP_Sc	urce <1:0>
3F	SYS_TRIGGER	0x00	CLK_SE L	RST_IN T	RST_S YS					Self_Test
3E	PWR_MODE	0x00							Power Mo	ode <1:0>
3D	OPR_MODE	0x1C						Operation N	Mode <3:0>	
3C	Reserved	0xFF								
3B	UNIT_SEL	0x80	ORI_An droid_Wi ndows			TEMP_Un it		EUL_Unit	GYR_Unit	ACC_Unit
3A	SYS_ERR	0x00				Syste	m Error Code	9		
39	SYS_STATUS	0x00				System	n Status Cod	le		
38	SYS_CLK_STA TUS	0x00								ST_MAIN _CLK
37	INT_STA	0x00	ACC_N M	ACC_A M	ACC_HI GH_G		GYR_HIG H_RATE	GYRO_A M		
36	ST_RESULT	0x0F					ST_MCU	ST_GYR	ST_MAG	ST_ACC
35	CALIB_STAT	0x00		ib Status :3		alib Status 0:3	ACC Calib	Status 0:3	MAG Calib	Status 0:3
34	TEMP	0x00				Tei	mperature			
33	GRV_Data_Z_M SB	0x00				Gravity Vec	tor Data Z <	15:8>		
32	GRV_Data_Z_L SB	0x00				Gravity Ve	ctorDataZ<	<7:0>		
31	GRV_Data_Y_M SB	0x00				Gravity Vec	torDataY <	15:8>		
30	GRV_Data_Y_L SB	0x00		Gravity Vector Data Y <7:0>						
2F	GRV_Data_X_M SB	0x00				Gravity Vec	tor Data X <	15:8>		
2E	GRV_Data_X_L SB	0x00				Gravity Ve	ctorDataX <	<7:0>		
2D	LIA_Data_Z_MB S	0x00			L	inear Accelera	ation Data Z	<15:8>		
2C	LIA_Data_Z_LS B	0x00				Linear Accele	ration Data Z	? <7:0>		
2B	LIA_Data_Y_MB S	0x00			L	inear Accelera	ation Data Y	<15:8>		
2A	LIA_Data_Y_LS B	0x00				Linear Accele	ration Data Y	<7:0>		
29	LIA_Data_X_MB S	0x00			L	inear Accelera	ation Data X	<15:8>		
28	LIA_Data_X_LS B	0x00					ration Data >			
27	QUA_Data_z_M SB	0x00					n z Data <15			
26	QUA_Data_z_LS B	0x00					on z Data < 7			
25	QUA_Data_y_M SB	0x00					n y Data <15			
24	QUA_Data_y_LS B QUA_Data_x_M	0x00					on y Data <7			
23	SB QUA_Data_x_LS	0x00					n x Data <15			
22	QUA_Data_x_LS B QUA_Data_w_M	0x00					on x Data <7			
21	SB QUA_Data_w_L	0x00		Quaternion w Data <15:8>						
20	SB	0x00					on w Data <7			
1F	EUL_Pitch_MSB	0x00					Data <15:8>			
1E	EUL_Pit ch_LSB	0x00				Pitch	Data < 7:0>			



Page 52

Register Address	Register Name	Default Value	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
1D	EUL_Roll_MSB	0x00				Roll D	Oata <15:8>					
1C	EUL_Roll_LSB	0x00				Roll I	Data < 7:0>					
1B	EUL_Heading_M SB	0x00				Heading	g Data <15:8	3>				
1A	EUL_Heading_L SB	0x00				Headin	g Data < 7:0>	•				
19	GYR_DATA_Z_ MSB	0x00				Gyroscope	e Data Z <15	:8>				
18	GYR_DATA_Z_L SB	0x00		Gyroscope Data Z <7:0>								
17	GYR_DATA_Y_ MSB	0x00				Gyroscope	Data Y <15	5:8>				
16	GYR_DATA_Y_ LSB	0x00				Gyroscop	e Data Y <7	:0>				
15	GYR_DATA_X_ MSB	0x00				Gyroscope	e Data X <15	:8>				
14	GYR_DATA_X_L SB	0x00				Gyroscop	e Data X < 7	:0>				
13	MAG_DATA_Z_ MSB	0x00				Magnet ome	ter Data Z <	15:8>				
12	MAG_DATA_Z_ LSB	0x00				Magnet ome	eterDataZ <	<7:0>				
11	MAG_DATA_Y_ MSB	0x00				Magnet omet	terDataY <	15:8>				
10	MAG_DATA_Y_ LSB	0x00		Magnetometer Data Y <7:0>								
F	MAG_DATA_X_ MSB	0x00				Magnet ome	ter Data X <	15:8>				
E	MAG_DATA_X_ LSB	0x00				Magnet ome	eterDataX <	<7:0>				
D	ACC_DATA_Z_ MSB	0x00				Acceleration	n Data Z <1	5:8>				
С	ACC_DATA_Z_L SB	0x00				Acceleration	on Data Z < 7	7:0>				
В	ACC_DATA_Y_ MSB	0x00				Acceleration	n Data Y <1	5:8>				
А	ACC_DATA_Y_L SB	0x00				Acceleration	on Data Y <7	7:0>				
9	ACC_DATA_X_ MSB	0x00				Acceleration	n Data X <1	5:8>				
8	ACC_DATA_X_L SB	0x00				Acceleration	on Data X < 7	7:0>				
7	Page ID	0x00				F	Page ID					
6	BL_Rev_ID	NA				Bootlo	ader Version					
5	SW_REV_ID_M SB	0x03 ⁵				SW Revi	ision ID <15:	8>				
4	SW_REV_ID_LS B	0x08 ⁶				SW Rev	vision ID < 7:0)>				
3	GYR_ID	0x0F		GYRO chip ID								
2	MAG_ID	0x32				MA	AG chip ID					
1	ACC_ID	0xFB				AC	C chip ID					
0	CHIP_ID	0xA0				BNO0	55 CHIP ID					

-

⁵ The current software version is 0.3.0.8 and therefore the SW_REV_ID_MSB is 0x03. However the register default value is subject to change with respect to the updated software.

⁶ The current software version is 0.3.0.8 and therefore the SW_REV_ID_LSB is 0x08. However the register default

The current software version is 0.3.0.8 and therefore the SW_REV_ID_LSB is 0x08. However the register defaul value is subject to change with respect to the updated software.



Page 53

4.2.2 Register map Page 1

Table4-3: Register Map Page 1

Register Address	Register Name	Defaul t	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
7F-60	Reserved	Value 0x00								
5F - 50	UNIQUE ID	n.a.				F	BNO unique I	D		
4F - 20	Reserved	0x00						_		
1F	GYR_AM_SET	0x0A					Awake	Duration ·0>	Slope S	amples <1:0>
1E	GYR_AM_THR ES	0x04				Gyro	Any Motion		6:0>	
1D	GYR_DUR_Z	0x19				Н	R_Z_Duratio	on .		
1C	GYR_HR_Z_SE T	0x01			HRES_H <1:0>		HF	R_Z_Thresho	old <4:0>	
1B	GYR_DUR_Y	0x19				Н	R_Y_Duration	on		
1A	GYR_HR_Y_S ET	0x01		HR_Y_THRES_H YST <1:0> HR_Y_Threshold <4:0>						
19	GYR_DUR_X	0x19		HR_X_Duration						
18	GYR_HR_X_SE T	0x01		YST	HRES_H <1:0>		HF	R_X_Thresho	old <4:0>	
17	GYR_INT_SETI NG	0x00	HR_FIL T	AM_FIL T	HR_Z_ AXIS	HR_Y_AX IS	HR_X_AX IS	AM_Z_AX IS	AM_Y_AX IS	AM_X_AXIS
16	ACC_NM_SET	0x0B		NO/SLOW Motion Duration <5:0> SM NM						
15	ACC_NM_THR E	0x0A		Accelerometer NO/SLOW motion threshold						
14	ACC_HG_THR ES	0xC0		Accelerometer High G Threshold						
13	ACC_HG_DURA TION	0x0F				Acceleron	neter High G	Duration		
12	ACC_INT_Setti ngs	0x03	HG_Z_ AXIS	HG_Y_ AXIS	HG_X_ AXIS	AM/NM_ Z AXIS	AM/NM_ Y AXIS	AM/NM_ X AXIS	AM_I	OUR <1:0>
11	ACC_AM_THR ES	0x14				Acceleromet	er Any motion	on threshold		
10	INT_EN	0x00	ACC_N M	ACC_A M	ACC_HI GH_G		GYR_HI GH_RAT E	GYRO_A M		
F	INT_MSK	0x00	ACC_N M	ACC_A M	ACC_HI GH_G		GYR_HI GH_RAT E	GYRO_A M		
E	Reserved	0x00								
D	GYR_Sleep_Co nfig	0x00			AUTO_S	LP_DURAT	ION <2:0>	SL	P_DURATIO	N <2:0>
С	ACC_Sleep_Con fig	0x00					SLP_DURA	TION <3:0>		SLP_MODE
В	GYR_Config_1	0x00						GYF	R_Power_Mo	ode <2:0>
Α	GYR_Config_0	0x38				_Bandwidth		(GYR_Range	<2:0>
9	MAG_Config	0x6D		MAG_Power_mod MAG_OPR_Mode MAG_Data_output_rate <2:0>					_rate <2:0>	
8	ACC_Config	0x0D	ACC_F	ACC_PWR_Mode <2:0> ACC_BW <2:0> ACC_Range <1:0>					Range <1:0>	
7	Page ID	0x01					Page ID			
6 - 0	Reserved	n.a.								

Page 54

4.3 Register description (Page 0)

4.3.1 CHIP_ID 0x00

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	1	0	1	0	0	0	0	0	
Content	BNO055 CHIP ID								

DATA	bits	Description
BNO055 CHIP ID	<7:0>	Chip identification code, read-only fixed value 0xA0

4.3.2 ACC_ID 0x01

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	R	r	
Reset	0xFB								
Content	ACC chip ID								

DATA	bits	Description
ACC chip ID	<7:0>	Chip ID of the Accelerometer device, read-only fixed value 0xFB

4.3.3 MAG_ID 0x02

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	R	r		
Reset		0x32								
Content		MAG chip ID								

DATA	bits	Description
MAG chip ID	<7:0>	Chip ID of the Magnetometer device, read-only fixed value 0x32

4.3.4 GYR_ID 0x03

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	rrrrRr								
Reset		0x0F								
Content	GRYO chip ID									

DATA	bits	Description
GYRO chip ID	<7:0>	Chip ID of the Gyroscope device, read-only fixed value 0x0F

Page 55

4.3.5 **SW_REV_ID_LSB 0x04**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset									
Content	SW Revision ID <7:0>								

DATA	bits	Description
SW Revision ID	<7:0>	Lower byte of SW Revision ID, read-only fixed value depending on SW revision programmed on
<7:0>		microcont roller

4.3.6 **SW_REV_ID_MSB 0x05**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset									
Content	SW Revision ID <15:8>								

DATA	bits	Description
SW Revision ID	<7:0>	Upper byte of SW Revision ID, read-only fixed value depending on SW revision programmed on
<15:8>		microcontroller

4.3.7 BL_REV_ID 0x06

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset								
Content				Bootloade	er Version			

DATA	bits	Description
Bootloader Version	<7:0>	Identifies the version of the bootloader in the microcontroller, read-only

4.3.8 **PAGE ID 0x07**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
Reset	0	0	0	0	0	0	0	0	
Content	Page ID								

DATA	bits	Description
Page ID	<7:0>	Read: Number of currently selected page Write: Change page, 0x00 or 0x01

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 56

4.3.9 ACC_DATA_X_LSB 0x08

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Acceleration Data X <7:0>								

DATA	bits	Description
Acceleration Data X <7:0>	<7:0>	Lower byte of X axis Acceleration data, read only The output units can be selected using the UNIT SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.10 ACC_DATA_X_MSB 0x09

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Acceleration Data X <15:8>								

DATA	bits	Description
Acceleration Data X <15:8>	<7:0>	Upper byte of X axis Acceleration data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.11 ACC_DATA_Y_LSB 0x0A

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Acceleration [Oata Y <7:0>			

DATA	bits	Description
Acceleration Data Y <7:0>	<7:0>	Lower byte of Y axis Acceleration data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.12 ACC_DATA_Y_MSB 0x0B

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Acceleration D	ata Y <15:8>			

DATA	bits	Description
Acceleration Data Y <15:8>	<7:0>	Upper byte of Y axis Acceleration data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3



Page 57

4.3.13 ACC_DATA_Z_LSB 0x0C

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Acceleration Data Z <7:0>								

DATA	bits	Description
Acceleration Data Z < 7:0>	<7:0>	Lower byte of Z axis Acceleration data, read only The output units can be selected using the UNIT SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.14 ACC_DATA_Z_MSB 0x0D

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Acceleration Data Z <15:8>								

DATA	bits	Description
Acceleration Data Z <15:8>	<7:0>	Upper byte of Z axis Acceleration data, read only The output units can be selected using the UNIT_SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.15 MAG_DATA_X_LSB 0x0E

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Magnet omet er Dat a X < 7:0>								

DATA	bits	Description
Magnetometer Data X <7:0>	<7:0>	Lower byte of X axis Magnetometer data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

4.3.16 MAG_DATA_X_MSB 0x0F

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0			
Access	r	r	r	r	r	r	r	r			
Reset	0	0	0	0	0	0	0	0			
Content		Magnetometer Data X <15:8>									

DATA	bits	Description
Magnetometer Data X <15:8>	<7:0>	Upper byte of X axis Magnetometer data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

Page 58

4.3.17 MAG_DATA_Y_LSB 0x10

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Magnet omet er Dat a Y <7:0>								

DATA	bits	Description
Magnetometer Data Y <7:0>	<7:0>	Lower byte of Y axis Magnetometer data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.18 MAG_DATA_Y_MSB 0x11

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Magnet omet er	Data Y <15:8>			

DATA	bits	Description
Magnetometer Data Y <15:8>	<7:0>	Upper byte of Y axis Magnetometer data, read only The output units can be selected using the UNIT SEL register and data output type can be
Duta 1 (20.0)		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.19 MAG_DATA_Z_LSB 0x12

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Magnet omet er	Data Z <7:0>			

DATA	bits	Description
Magnetometer Data Z < 7:0>	<7:0>	Lower byte of Z axis Magnetometer data, read only The output units can be selected using the UNIT_SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.20 MAG_DATA_Z_MSB 0x13

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Magnet omet er Dat a Z <15:8>								

Description
Upper byte of Z axis Magnetometer data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 59

4.3.21 GYR_DATA_X_LSB 0x14

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Gyroscope Data X <7:0>								

DATA	bits	Description
Gyroscope Data	<7:0>	Lower byte of X axis Gyroscope data, read only
X <7:0>		The output units can be selected using the UNIT_SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.22 **GYR_DATA_X_MSB 0x15**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Gyroscope Data X <15:8>								

DATA	bits	Description
Gyroscope Data X <15:8>	<7:0>	Upper byte of X axis Gyroscope data, read only The output units can be selected using the UNIT SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.23 **GYR_DATA_Y_LSB 0x16**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Gyroscope D	ata Y <7:0>			

DATA	bits	Description
Gyroscope Data Y <7:0>	<7:0>	Lower byte of Y axis Gyroscope data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

4.3.24 **GYR_DATA_Y_MSB 0x17**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Gyroscope Da	ta Y <15:8>			

DATA	bits	Description
Gyroscope Data Y <15:8>	<7:0>	Upper byte of Y axis Gyroscope data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3



Page 60

4.3.25 **GYR_DATA_Z_LSB 0x18**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Gyroscope Data Z <7:0>								

DATA	bits	Description
Gyroscope Data Z < 7:0>	<7:0>	Lower byte of Z axis Gyroscope data, read only The output units can be selected using the UNIT SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.26 **GYR_DATA_Z_MSB 0x19**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Gyroscope Da	at a Z <15:8>			

DATA	bits	Description
Gyroscope Data Z <15:8>	<7:0>	Upper byte of Z axis Gyroscope data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.27 EUL_DATA_X_LSB 0x1A

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Heading D	ata <7:0>			

DATA	bits	Description
Heading Data <7:0>	<7:0>	Lower byte of heading data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

4.3.28 EUL_DATA_X_MSB 0x1B

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Heading Data <15:8>								

DATA	bits	Description
Heading Data	<7:0>	Upper byte of heading data, read only
<15:8>		The output units can be selected using the UNIT_SEL register and data output type can be
		changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

Page 61

4.3.29 EUL_DATA_Y_LSB 0x1C

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Roll Dat	a <7:0>			

DATA	bits	Description						
Roll Data <7:0>	<7:0>	Lower byte of roll data, read only						
		The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3						

4.3.30 EUL_DATA_Y_MSB 0x1D

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Roll Data	a <15:8>			

DATA	bits	Description
Roll Data <15:8>	<7:0>	Upper byte of Y axis roll data, read only
		The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

4.3.31 EUL_DATA_Z_LSB 0x1E

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Pitch Dat	ta <7:0>			

DATA	bits	Description
Pitch Data <7:0>	<7:0>	Lower byte of pitch data, read only
		The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.32 EUL_DATA_Z_MSB 0x1F

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Pitch Data	a <15:8>			

DATA	bits	Description
Pitch Data	<7:0>	Upper byte of pitch data, read only
<15:8>		The output units can be selected using the UNIT_SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 62

4.3.33 **QUA_DATA_W_LSB 0x20**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Quat ernion D	Oata W < 7:0>			

DATA	bits	Description
Quaternion Data W <7:0>	<7:0>	Lower byte of w axis Quaternion data, read only
VV <1:U>		The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.34 **QUA_DATA_W_MSB 0x21**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Quaternion Da	ata W <15:8>			

DATA	bits	Description
Quaternion Data W <15:8>	<7:0>	Upper byte of w axis Quaternion data, read only The output units can be selected using the UNIT_SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.35 **QUA_DATA_X_LSB 0x22**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Quat ernion [Oata X < 7:0>			

DATA	bits	Description
Quaternion Data X <7:0>	<7:0>	Lower byte of X axis Quaternion data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

4.3.36 QUA_DATA_X_MSB 0x23

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Quaternion Da	ata X <15:8>			

DATA	bits	Description
Quaternion Data X <15:8>	<7:0>	Upper byte of X axis Quaternion data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

Page 63

4.3.37 QUA_DATA_Y_LSB 0x24

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Quaternion Data Y <7:0>								

DATA	bits	Description
Quaternion Data Y <7:0>	<7:0>	Lower byte of Y axis Quaternion data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

4.3.38 QUA_DATA_Y_MSB 0x25

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Quaternion Da	ata Y <15:8>			

DATA	bits	Description
Quaternion Data	<7:0>	Upper byte of Y axis Quaternion data, read only
Y <15:8>		The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.39 **QUA_DATA_Z_LSB 0x26**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Quat ernion [Oata Z < 7:0>			

DATA	bits	Description
Quaternion Data Z < 7:0>	<7:0>	Lower byte of Z axis Quaternion data, read only The output units can be selected using the UNIT SEL register and data output type can be
_ 11.0		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.40 **QUA_DATA_Z_MSB 0x27**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Quaternion Da	ata Z <15:8>			

DATA	bits	Description
Quaternion Data Z <15:8>	<7:0>	Upper byte of Z axis Quaternion data, read only The output units can be selected using the UNIT SEL register and data output type can be
2 <13:0>		changed by updating the Operation Mode in the OPR MODE register, see section 3.3



Page 64

4.3.41 LIA_DATA_X_LSB 0x28

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Linear Acceleration Data X <7:0>								

DATA	bits	Description
Linear	<7:0>	Lower byte of X axis Linear Acceleration data, read only
Acceleration		The output units can be selected using the UNIT_SEL register and data output type can be
Data X <7:0>		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.42 LIA_DATA_X_MSB 0x29

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Linear Acceleration Data X <15:8>								

DATA	bits	Description
Linear	<7:0>	Upper byte of X axis Linear Acceleration data, read only
Acceleration		The output units can be selected using the UNIT_SEL register and data output type can be
Data X <15:8>		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.43 LIA_DATA_Y_LSB 0x2A

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0			
Access	r	r	r	r	r	r	r	r			
Reset	0	0	0	0	0	0	0	0			
Content		Linear Acceleration Data Y <7:0>									

DATA	bits	Description
Linear Acceleration Data Y <7:0>	<7:0>	Lower byte of Y axis Linear Acceleration data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

4.3.44 LIA_DATA_Y_MSB 0x2B

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content			Liı	near Acceleratio	n Data Y <15:8	3>		

DATA	bits	Description
Linear	<7:0>	Upper byte of Y axis Linear Acceleration data, read only
Acceleration Data Y <15:8>		The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3



Page 65

4.3.45 LIA_DATA_Z_LSB 0x2C

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Linear Acceleration Data Z <7:0>								

DATA	bits	Description
Linear Acceleration	<7:0>	Lower byte of Z axis Linear Acceleration data, read only The output units can be selected using the UNIT SEL register and data output type can be
Data Z <7:0>		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.46 LIA_DATA_Z_MSB 0x2D

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Linear Acceleration Data Z <15:8>								

DATA	bits	Description
Linear Acceleration	<7:0>	Upper byte of Z axis Linear Acceleration data, read only The output units can be selected using the UNIT SEL register and data output type can be
Data Z <15:8>		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.47 GRV_DATA_X_LSB 0x2E

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Gravity Vector	Data X < 7:0>			

DATA	bits	Description
Gravity Vector Data X <7:0>	<7:0>	Lower byte of X axis Gravity Vector data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

4.3.48 GRV_DATA_X_MSB 0x2F

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Gravity Vector Data X <15:8>								

DATA	bits	Description
Gravity Vector Data X <15:8>	<7:0>	Upper byte of X axis Gravity Vector data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

Page 66

4.3.49 **GRV_DATA_Y_LSB 0x30**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Gravity Vector Data Y <7:0>								

Lower byte of Y axis Gravity Vector data, read only output units can be selected using the UNIT_SEL register and data output type can be anged by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.50 **GRV_DATA_Y_MSB 0x31**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Gravity Vector Data Y <15:8>								

DATA	bits	Description
Gravity Vector	<7:0>	Upper byte of Y axis Gravity Vector data, read only
Data Y <15:8>		The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.51 **GRV_DATA_Z_LSB 0x32**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				Gravity Vector	Data Z < 7:0>			

DATA	bits	Description
Gravity Vector Data Z < 7:0>	<7:0>	Lower byte of Z axis Gravity Vector data, read only The output units can be selected using the UNIT SEL register and data output type can be
		changed by updating the Operation Mode in the OPR MODE register, see section 3.3

4.3.52 **GRV_DATA_Z_MSB 0x33**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r	r	r	r	r	r	r	r		
Reset	0	0	0	0	0	0	0	0		
Content		Gravity Vector Data Z <15:8>								

DATA	bits	Description
Gravity Vector Data Z <15:8>	<7:0>	Upper byte of Z axis Gravity Vector data, read only The output units can be selected using the UNIT_SEL register and data output type can be changed by updating the Operation Mode in the OPR_MODE register, see section 3.3

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 67

4.3.53 **TEMP 0x34**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r	r	r	r	r	r	r	r	
Reset	0	0	0	0	0	0	0	0	
Content	Temperature								

DATA	bits	Description
Temperature	<7:0>	Temperature data, read only
		The output units can be selected using the UNIT_SEL register and data output source can be selected by updating the TEMP SOURCE register, see section 3.6.5.8

4.3.54 **CALIB_STAT 0x35**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content	SYS Calib Status < 0:1>		GYR Calib Status <0:1>		ACC Calib Status <0:1>		MAG Calib Status < 0:1>	

DATA	bits	Description
SYS Calib Status <0:1>	<7:6>	Current system calibration status, depends on status of all sensors, read-only Read: 3 indicates fully calibrated; 0 indicates not calibrated
GYR Calib Status <0:1>	<5:4>	Current calibration status of Gyroscope, read-only Read: 3 indicates fully calibrated; 0 indicates not calibrated
ACC Calib Status <0:1>	<3:2>	Current calibration status of Accelerometer, read-only Read: 3 indicates fully calibrated; 0 indicates not calibrated
MAG Calib Status <0:1>	<1:0>	Current calibration status of Magnetometer, read-only Read: 3 indicates fully calibrated; 0 indicates not calibrated

4.3.55 **ST_RESULT 0x36**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset					1	1	1	1
Content		Rese	erved		ST_MCU	ST_GYR	ST_MAG	ST_ACC

DATA	bits	Description
ST_MCU	3	Microcontroller self test result. Read: 1 indicated test passed; 0 indicates test failed
ST_GYR	2	Gyroscope self test result. Read: 1 indicated test passed; 0 indicates test failed
ST_MAG	1	Magnetometer self test result. Read: 1 indicated test passed; 0 indicates test failed
ST_ACC	0	Accelerometer self test result. Read: 1 indicated test passed; 0 indicates test failed

Page 68

4.3.56 INT_STA 0x37

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0		0	0		
Content	ACC_NM	ACC_AM	ACC_HIGH _G	Reserved	GYR_HIG H_RATE	GYRO_AM	Reserved	Reserved

DATA	bits	Description
ACC_NM	7	Status of Accelerometer no motion or slow motion interrupt, read only Read: 1 indicates interrupt triggered; 0 indicates no interrupt triggered
ACC_AM	6	Status of Accelerometer any motion interrupt, read only Read: 1 indicates interrupt triggered; 0 indicates no interrupt triggered
ACC_HIGH_G	5	Status of Accelerometer high-g interrupt, read only Read: 1 indicates interrupt triggered; 0 indicates no interrupt triggered
GYR_HIGH_RATE	3	Status of gyroscope high rate interrupt, read only Read: 1 indicates interrupt triggered; 0 indicates no interrupt triggered
GYRO_AM	2	Status of gyroscope any motion interrupt, read only Read: 1 indicates interrupt triggered; 0 indicates no interrupt triggered

4.3.57 **SYS_CLK_STATUS 0x38**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	ST_MAIN_ CLK
DATA	bits				Description	1		_
0	0	Indicat es t	Indicates that, it is Free to configure the CLK SRC (External or Internal)					
1	0	Indicat es t	that, it is in Co	nfiguration state	•			

4.3.58 SYS_STATUS 0x39

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	0
Content				System St	at us Code			

DATA	bits	Description
System Status Code	<7:0>	Read: 0 System idle, 1 System Error, 2 Initializing peripherals 3 System Initialization 4 Executing selftest, 5 Sensor fusion algorithm running, 6 System running without fusion algorithm



Page 69

4.3.59 **SYS_ERR 0x3A**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset								
Content				System E	Frror Code			

DATA	bits	Description
System Error Code	ofs <7:0>	Read the error status from this register if the SYS_STATUS (0x39) register is SYSTEM ERROR (0x01) Read: 0 No error 1 Peripheral initialization error 2 System initialization error 3 Self test result failed 4 Register map value out of range 5 Register map address out of range 6 Register map write error 7 BNO low power mode not available for selected operation mode 8 Accelerometer power mode not available 9 Fusion algorithm configuration error
		A Sensor configuration error

4.3.60 **UNIT_SEL 0x3B**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0			0	0	0	0	0
Content	ORI_Androi	reserved		TEMP_Unit	reserved	EUL_Unit	GYR_Unit	ACC_Unit

DATA	bits	Description
ORI_Android_Win dows	7	Read: Current selected orientation mode Write: Select orientation mode 0: Windows orientation 1: Android orientation See section 3.6.2 for more details
TEMP_Unit	5	Read: Current selected temperature units Write: Select temperature units 0: Celsius 1: Fahrenheit See section 3.6.1 for more details
EUL_Unit	3	Read: Current selected Euler units Write: Select Euler units 0: Degrees 1: Radians See section 3.6.1 for more details
GYR_Unit	2	Read: Current selected angular rate units Write: Select angular rate units 0: dps 1: rps See section 3.6.1 for more details
ACC_Unit	1	Read: Current selected acceleration units Write: Select acceleration units 0: m/s² 1: mg See section 3.6.1 for more details



Page 70

4.3.61 **OPR_MODE 0x3D**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access					r/w	r/w	r/w	r/w
Reset								
Content		Rese	erved			Operation N	1ode <3:0>	

DATA	bits	Description
Operation Mode <3:0>	<3:0>	Read: Current selected operation mode Write: Select operation mode See section 3.3 for details

4.3.62 **PWR_MODE 0x3E**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access							r/w	r/w
Reset								
Content			Rese	erved			Power Mo	ode <1:0>

DATA	bits	Description
Power Mode <1:0>	<1:0>	Read: Current selected power mode Write: Select power mode
		See section 0 for details

4.3.63 SYS_TRIGGER 0x3F

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	W	w	w					w
Reset	0	0	0					0
Content	CLK_SEL	RST_INT	RST_SYS					Self_Test

DATA	bits	Description
CLK_SEL	7	0: Use internal oscillator 1: Use external oscillator. Set this bit only if external crystal is connected
RST_INT	6	Set to reset all interrupt status bits, and INT output
RST_SYS	5	Set to reset system
Self_Test	0	Set to trigger self test

4.3.64 **TEMP_SOURCE 0x40**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access							r/w	r/w
Reset								
Content			Rese	erved			TEMP_Sc	ource <1:0>

DATA	bits	Description
TEMP_Source <1:0>	<1:0>	See section 3.6.5.8 for details

 ${\tt BST-BNO055-DS000-12 \mid Revision \ 1.2 \mid November \ 2014}$

Page 71

4.3.65 AXIS_MAP_CONFIG 0x41

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access			r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content	Reserved		Remapped Z axis value		Remapped Y axis value		Remapped	X axis value

DATA	bits	Description
Remapped Z axis value	<5:4>	See section 3.4 for details
Remapped Y axis value	<3:2>	See section 3.4 for details
Remapped X axis value	<1:0>	See section 3.4 for details

4.3.66 AXIS_MAP_SIGN 0x42

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access						r/w	r/w	r/w
Reset								
Content			Reserved			Remapped X axis sign	Remapped Y axis sign	Remapped Z axis sign

DATA	bits	Description
Remapped X axis sign	2	See section 3.4 for details
Remapped Y axis sign	1	See section 3.4 for details
Remapped Z axis sign	0	See section 3.4 for details

4.3.67 ACC_OFFSET_X_LSB 0x55

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Acceleromet er	Offset X <7:0>			

DATA	bits	Description
Accelerometer Offset X <7:0>	<7:0>	See section 3.6.4 for details

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Page 72

4.3.68 ACC_OFFSET_X_MSB 0x56

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Accelerometer C	Offset X < 15:8>			

DATA bits		Description
Accelerometer <7:0 Offset X <15:8>	S	ee section 3.6.4 for details

4.3.69 ACC_OFFSET_Y_LSB 0x57

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Acceleromet er	Offset Y <7:0>			

DATA	bits	Description
Accelerometer Offset Y <7:0>	<7:0>	See section 3.6.4 for details

4.3.70 ACC_OFFSET_Y_MSB 0x58

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content			,	Acceleromet er C	Offset Y <15:8>			

DATA	bits	Description
Accelerometer Offset Y <15:8>	<7:0>	See section 3.6.4 for details

4.3.71 ACC_OFFSET_Z_LSB 0x59

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Acceleromet er	Offset Z <7:0>			

DATA	bits	Description
Accelerometer Offset Z <7:0>	<7:0>	See section 3.6.4 for details

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Page 73

4.3.72 ACC_OFFSET_Z_MSB 0x5A

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Accelerometer (Offset Z <15:8>			

DATA	bits	Description
Accelerometer Offset Z <15:8>	<7:0>	See section 3.6.4 for details

4.3.73 MAG_OFFSET_X_LSB 0x5B

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Magnet omet er	Data X < 7:0>			

DATA	bits	Description
Magnetometer Offset X <7:0>	<7:0>	See section 3.6.4 for details

4.3.74 MAG_OFFSET_X_MSB 0x56C

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content			ı	Magnet omet er	Offset X < 15:8>	•		

DATA	bits	Description
Magnetometer Offset X <15:8>	<7:0>	See section 3.6.4 for details

4.3.75 MAG_OFFSET_Y_LSB 0x5D

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Magnet omet er	Offset Y <7:0>			

DATA	bits	Description
Magnetometer Offset Y <7:0>	<7:0>	See section 3.6.4 for details

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 74

4.3.76 MAG_OFFSET_Y_MSB 0x5E

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content			N	/lagnetometer (Offset Y <15:8>			

DATA	bits	Description
Magnetometer Offset Y <15:8>	<7:0>	See section 3.6.4 for details

4.3.77 MAG_OFFSET_Z_LSB 0x5F

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Magnet omet er	Offset Z <7:0>			

DATA	bits	Description
Magnetometer Offset Z < 7:0>	<7:0>	See section 3.6.4 for details

4.3.78 MAG_OFFSET_Z_MSB 0x60

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content			ı	Magnetometer (Offset Z <15:8>	>		

DATA	bits	Description
Magnetometer Offset Z <15:8>	<7:0>	See section 3.6.4 for details

4.3.79 GYR_OFFSET_X_LSB 0x61

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Gyroscope D	Oata X < 7:0>			

DATA	bits	Description
Gyroscope Offset X <7:0>	<7:0>	See section 3.6.4 for details

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 75

4.3.80 GYR_OFFSET_X_MSB 0x62

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Gyroscope Off	set X <15:8>			

DATA	bits	Description
Gyroscope Offset X <15:8>	<7:0>	See section 3.6.4 for details

4.3.81 GYR_OFFSET_Y_LSB 0x63

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Gyroscope Ol	fset Y <7:0>			

DATA	bits	Description
Gyroscope Offset Y <7:0>	<7:0>	See section 3.6.4 for details

4.3.82 GYR_OFFSET_Y_MSB 0x64

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Gyroscope Off	set Y <15:8>			

DATA	bits	Description
Gyroscope Offset Y <15:8>	<7:0>	See section 3.6.4 for details

4.3.83 GYR_OFFSET_Z_LSB 0x65

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Gyroscope O	ffset Z <7:0>			

DATA	bits	Description
Gyroscope Offset Z < 7:0>	<7:0>	See section 3.6.4 for details

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 76

4.3.84 GYR_OFFSET_Z_MSB 0x66

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Gyroscope Off	set Z <15:8>			

DATA	bits	Description
Gyroscope Offset Z <15:8>	<7:0>	See section 3.6.4 for details

4.3.85 ACC_RADIUS_LSB 0x67

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Acceleromet er	Radius <7:0>			

DATA	bits	Description
Gyroscope	<7:0>	See section 3.6.4 for details

4.3.86 ACC_RADIUS_MSB 0x68

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Acceleromet er	Radius <15:8>			

DATA	bits	Description
Gyroscope Offset Z <15:8>	<7:0>	See section 3.6.4 for details

4.3.87 MAG_RADIUS_LSB 0x69

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Magnet omet e	r Radius <7:0>			

DATA	bits	Description
Gyroscope	<7:0>	See section 3.6.4 for details

4.3.88 MAG_RADIUS_MSB 0x6A

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content				Magnet omet er	Radius <15:8>			

DATA	bits	Description
Gyroscope Offset Z <15:8>	<7:0>	See section 3.6.4 for details

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Page 77

4.4 Register description (Page 1)

4.4.1 Page ID 0x07

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w							
Reset	0	0	0	0	0	0	0	0
Content				Pag	e ID			

DATA	bits	Description
Page ID	<7:0>	Read: Number of currently selected page Write: Change page, 0x00 or 0x01

4.4.2 ACC_Config 0x08

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	0	1	1	0	1
Content	ACC	_PWR_Mode <	2:0>		ACC_BW <2:0>		ACC_Rai	nge <1:0>

DATA	bits	Description
ACC_PWR_Mode <2:0>	<7:5>	Read: current selected power mode Write: can only be changed in sensor mode, see section 3.5.2
ACC_BW <2:0>	<4:3>	Read: current selected bandwidth Write: can only be changed in sensor mode, see section 3.5.2
ACC_Range <1:0>	<2:0>	Read: current selected range Write: can only be changed in sensor mode, see section 3.5.2

4.4.3 MAG_Config 0x09

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	0	1	0	1	1
Content	reserved	MAG_Power	_mode <1:0>	MAG_OPR_	Mode <1:0>	MAG_Da	ata_output_rat	e <2:0>

DATA	bits	Description
MAG_Power_mode <1:0>	<6:5>	Read: current selected power mode Write: can only be changed in sensor mode, see section 3.5.4
MAG_OPR_Mode <1:0>	<4:3>	Read: current selected operation mode Write: can only be changed in sensor mode, see section 3.5.4
MAG_Data_output_ rate < 2:0>	<2:0>	Read: current selected data output rate Write: can only be changed in sensor mode, see section 3.5.4

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 78

4.4.4 GYR_Config_0 0x0A

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	1	1	1	0	0	0
Content	rese	rved	GYF	R_Bandwidth <2	2:0>	G'	YR_Range <2:0)>

DATA	bits	Description
GYR_Bandwidth <2:0>	<5:3>	Read: current selected bandwidth Write: can only be changed in sensor mode, see section 3.5.3
GYR_Range <2:0>	<2:0>	Read: current selected range Write: can only be changed in sensor mode, see section 3.5.3

4.4.5 **GYR_Config_1 0x0B**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	0	0	0	0	0
Content			reserved			GYR_	_Power_Mode <	<2:0>

DATA	bits	Description
GYR_Power_Mode	<2:0>	Read: current selected power mode
<2:0>		Write: can only be changed in sensor mode, see section 3.5.3



Page 79

4.4.6 ACC_Sleep_Config 0x0C

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content		reserved			SLP_DURA	TION <3:0>		SLP_MOD

DATA	bits	Desc	ription
SLP_DURATION <3:0>	<4:1>		power mode can be only configured in the sensor Following sleep phase duration is possible to set.
		SLP_DURATION	Accelerometer Sleep Phase Duration
		0000b	0.5 ms
		0001b	0.5 ms
		0010b	0.5 ms
		0011b	0.5 ms
		0100b	0.5 ms
		0101b	0.5 ms
		0110b	1 ms
		0111b	2 ms
		1000b	4 ms
		1001b	6 ms
		1010b	10 ms
		1011b	25 ms
		1100b	50 ms
		1101b	100 ms
		1110b	500 ms
		1111b	1 ms
SLP_MODE	0	operation mode where r Write 0: use event d	ower mode can be only configured in the sensor no fusion library is running Iriven time-base mode mpling time-base mode



Page 80

4.4.7 GYR_Sleep_Config 0x0D

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset								
Content	rese	rved	AUTO_S	SLP_DURATIO	N <2:0>	SLP	_DURATION <	2:0>

DATA	bits	Desc	ription
AUTO_SLP_DURAT ION <2:0>	<5:3>	This can be only done if the selected operation m wake up duration of gyroscope during the duty	d power mode to optimize the power consumption. ode in sensor mode. The auto sleep duration is the cycling between normal and fast-power up mode. or auto sleep duration are:
		Auto sleep duration	Time (ms)
		000b	Not allowed
		001b	4 ms
		010b	5 ms
		011b	8 ms
		100b	10 ms
		101b	15 ms
		110b	20 ms
		111b	40 ms
		The O conservation has a self-conservation than and conservation	distribution and the control of the
SLP_DURATION <2:0>	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling bet configuration for	d power mode to optimize the power consumption. ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are:
	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling bet configuration for Sleep duration	ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are: Time (ms)
	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling between the configuration for Sleep duration	ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are: Time (ms) 2 ms
	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling between configuration for Sleep duration 000b 001b	ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are: Time (ms) 2 ms 4 ms
	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling between configuration for Sleep duration 000b 001b 010b	ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are: Time (ms) 2 ms 4 ms 5 ms
	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling between configuration for Sleep duration 000b 001b 010b 011b	ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are: Time (ms) 2 ms 4 ms 5 ms 8 ms
	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling between configuration for Sleep duration O00b 001b 010b 011b 100b	ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are: Time (ms) 2 ms 4 ms 5 ms 8 ms 10 ms
	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling between configuration for Sleep duration O00b 001b 010b 011b 100b 101b	ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are: Time (ms) 2 ms 4 ms 5 ms 8 ms 10 ms 15 ms
	<2:0>	This can be only done if the selected operation me time of gyroscope during the duty cycling between configuration for Sleep duration O00b 001b 010b 011b 100b	ode in sensor mode. The sleep duration is the sleep ween normal and fast-power up mode. Possible sleep duration are: Time (ms) 2 ms 4 ms 5 ms 8 ms 10 ms

The only restriction for the use of the power save mode comes from the configuration of the digital filter bandwidth of gyroscope. For each bandwidth configuration, minimum auto sleep duration must be ensured. For example, for bandwidth = 47Hz, the minimum auto sleep duration is 5ms. This is specified in the table below. For sleep duration, there is no restriction.

Gyroscope bandwidth (Hz)	Mini Autosleep duration (ms)
32 Hz	20 ms
64 Hz	10 ms
12 Hz	20 ms
23 Hz	10 ms
47 Hz	5 ms
116 Hz	4 ms
230 Hz	4 ms
Unfiltered (523 Hz)	4 ms



Page 81

4.4.8 INT_MSK 0x0F

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0		0	0		
Content	ACC_NM	ACC_AM	ACC_HIGH _G	reserved	GYR_HIG H_RATE	GYRO_AM	reserved	reserved

D 4 T 4	1.4	5
DATA	bits	Description
ACC_NM	7	Masking of Accelerometer no motion or slow motion interrupt, when enabled the interrupt will update the INT_STA register and trigger a change on the INT pin, when disabled only the INT_STA register will be updated. Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable
ACC_AM	6	Masking of Accelerometer any motion interrupt, when enabled the interrupt will update the INT_STA register and trigger a change on the INT pin, when disabled only the INT_STA register will be updated. Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable
ACC_HIGH_G	5	Masking of Accelerometer high-g interrupt, when enabled the interrupt will update the INT_STA register and trigger a change on the INT pin, when disabled only the INT_STA register will be updated. Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable
GYR_HIGH_RATE	3	Masking of gyroscope high rate interrupt, when enabled the interrupt will update the INT_STA register and trigger a change on the INT pin, when disabled only the INT_STA register will be updated. Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable
GYRO_AM	2	Masking of gyroscope any motion interrupt, when enabled the interrupt will update the INT_STA register and trigger a change on the INT pin, when disabled only the INT_STA register will be updated. Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable



Page 82

4.4.9 INT_EN 0x10

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0		0	0		
Content	ACC_NM	ACC_AM	ACC_HIGH _G	reserved	GYR_HIG H_RATE	GYRO_AM	reserved	reserved

DATA	bits	Description
ACC_NM	7	Status of Accelerometer no motion or slow motion interrupt Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable interrupt
ACC_AM	6	Status of Accelerometer any motion interrupt Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable interrupt
ACC_HIGH_G	5	Status of Accelerometer high-g interrupt Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable interrupt
GYR_HIGH_RATE	3	Status of gyroscope high rate interrupt Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable interrupt
GYRO_AM	2	Status of gyroscope any motion interrupt Read: 1: Enabled / 0: Disabled Write: 1: Enable / 0: Disable interrupt

4.4.10 ACC_AM_THRES 0x11

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
Reset	0	0	0	1	0	1	0	0	
Content	Accelerometer Any motion threshold								

DATA	bits	Description
Accelerometer Any motion threshold	<7:0>	Threshold used for the any-motion interrupt. The threshold value is dependent on the accelerometer range selected in the ACC_Config register. 1 LSB = 3.91 mg (2-g range) 1 LSB = 7.81 mg (4-g range) 1 LSB = 15.63 mg (8-g range) 1 LSB = 31.25 mg (16-g range)

Page 83

4.4.11 ACC_INT_Settings 0x12

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	0	0	0	1	1
Content	HG_Z_AXI S	HG_Y_AXI S	HG_X_AXI S	AM/NM_Z_ AXIS	AM/NM_Y_ AXIS	AM/NM_X_ AXIS	AM_DUR <1:0>	

DATA	bits	Description
HG_Z_AXIS	7	Select which axis of the accelerometer is used to trigger a high-G interrupt 1: Enabled; 0: Disabled
HG_Y_AXIS	6	Select which axis of the accelerometer is used to trigger a high-G interrupt 1: Enabled; 0: Disabled
HG_X_AXIS	5	Select which axis of the accelerometer is used to trigger a high-G interrupt 1: Enabled; 0: Disabled
AM/NM_Z_AXIS	4	Select which axis of the accelerometer is used to trigger a any motion or no motion interrupt 1: Enabled; 0: Disabled
AM/NM_Y_AXIS	3	Select which axis of the accelerometer is used to trigger a any motion or no motion interrupt 1: Enabled; 0: Disabled
AM/NM_X_AXIS	2	Select which axis of the accelerometer is used to trigger a any motion or no motion interrupt 1: Enabled; 0: Disabled
AM_DUR <1:0>	<1:0>	Any motion interrupt triggers if [AM_DUR<1:0>+1] consecutive data points are above the any motion interrupt threshold define in ACC_AM_THRES register

4.4.12 ACC_HG_DURATION 0x13

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
Reset	0	0	0	0	1	1	1	1	
Content	Accelerometer High G Duration								

DATA	bits	Description
Accelerometer High G Duration	<7:0>	The high-g interrupt trigger delay according to [ACC_HG_DURATION + 1] * 2 ms in a range from 2 ms to 512 ms;

$4.4.13~{\color{red}\textbf{ACC_HG_THRES~0x14}}$

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
Reset	1	1	0	0	0	0	0	0	
Content	Accelerometer High G Threshold								

DATA	bits	Description
Accelerometer High G Threshold	<7:0>	Threshold used high-g interrupt. The threshold value is dependent on the accelerometer range selected in the ACC_Config register. 1 LSB = 7.81 mg (2-g range) 1 LSB = 15.63 mg (4-g range) 1 LSB = 31.25 mg (8-g range) 1 LSB = 62.5 mg (16-g range)



Page 84

4.4.14 ACC_NM_THRES 0x15

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
Reset	0	0	0	0	1	0	1	0	
Content	Accelerometer NO/SLOW motion threshold								

DATA	bits	Description
Accelerometer NO/SLOW motion threshold	<7:0>	Threshold used for the Slow motion or no motion interrupt. The threshold value is dependent on the accelerometer range selected in the ACC_Config register. 1 LSB = 3.91 mg (2-g range) 1 LSB = 7.81 mg (4-g range) 1 LSB = 15.63 mg (8-g range) 1 LSB = 31.25 mg (16-g range)

4.4.15 ACC_NM_SET 0x16

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w		
Reset		0	0	0	1	0	1	1		
Content	reserved		slo no mot dur <5:0>							

DATA	bits	Description
slo_no_mot_dur <5:0>	<6:1>	Function depends on whether the slow-motion or no-motion interrupt function has been selected. If the slow-motion interrupt function has been enabled (SMNM = '0') then [slo_no_mot_dur<1:0>+1] consecutive slope data points must be above the slow/no-motion threshold (ACC_NM_THRES) for the slow-/no-motion interrupt to trigger. If the no-motion interrupt function has been enabled (SMNM = 1) then slo_no_motion_dur<5:0> defines the time for which no slope data points must exceed the slow/no-motion threshold (ACC_NM_THRES) for the slow/no-motion interrupt to trigger. The delay time in seconds may be calculated according with the following equation: slo_no_mot_dur<5:4>='b00' → [slo_no_mot_dur<3:0> + 1] slo_no_mot_dur<5:4>='b01' → [slo_no_mot_dur<3:0> * 4 + 20] slo_no_mot_dur<5>='1' → [slo_no_mot_dur<4:0> * 8 + 88]
SMNM	0	Select slow motion or no motion interrupt 1: Slow motion; 0: No motion



Page 85

4.4.16 GYR_INT_SETTING 0x17

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	0	0	0	0	0
Content	HR_FILT	AM_FILT	HR_Z_AXI S	HR_Y_AXI S	HR_X_AXI S	AM_Z_AXI S	AM_Y_AXI S	AM_X_AXI

DATA	bits	Description
HR_FILT	7	1'(0) selects unfiltered (filtered) data for high rate interrupt
AM_FILT	6	1'(0) selects unfiltered (filtered) data for any motion interrupt
HR_Z_AXIS	5	1'(0') enables (disables) high rate interrupt for z-axis
HR_Y_AXIS	4	1'('0') enables (disables)) high rate interrupt for y-axis
HR_X_AXIS	3	1' ('0') enables (disables)) high rate interrupt for x-axis
AM_Z_AXIS	2	1' ('0') enables (disables) any motion interrupt for z-axis
AM_Y_AXIS	1	1'(0) enables (disables) any motion interrupt for y-axis
AM_X_AXIS	0	1' (0') enables (disables) any motion interrupt for x-axis

4.4.17 **GYR_HR_X_SET 0x18**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	0	0	0	0	1
Content	reserved	HR_X_THRES_HYST <1:0>		HR_X_Threshold <4:0>				

DATA	bits	Description
HR_X_THRES_HY ST <1:0>	<6:5>	High rate hyst eresis for X axis = $(255 + 256 * HR_X_THRES_HYST) *4 LSB$ The high rate value scales with the range setting 1 LSB = 62.26% s in 2000% s-range 1 LSB = 31.13% s in 1000% s-range 1 LSB = 15.56% s in 500% s-range
HR_X_Threshold <4:0>	<4:0>	High rate threshold is for the gyroscope X axis. The threshold value is dependent on the gyroscope range selected in the GRY_Config_0 register. 1 LSB = 62.5% in 2000%-range 1 LSB = 31.25% in 1000%-range 1 LSB = 15.625% in 500% -range

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 86

4.4.18 GYR_DUR_X 0x19

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
Reset	0	0	0	1	1	0	0	1	
Content	HR X Duration								

DATA	bits	Description
HR_X_Duration	<7:0>	High rate duration = (1 + HR_X_Duration)*2.5ms

4.4.19 **GYR_HR_Y_SET 0x1A**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	1
Content	reserved	HR_Y_THF	RES_HYST :0>		HR_	Y_Threshold <4	1:0>	

DATA	bits	Description
HR_Y_THRES_HY ST <1:0>	<6:5>	High rate hysteresis for Y axis = (255 + 256 * HR_Y_THRES_HYST) *4 LSB The high rate value scales with the range setting 1 LSB = 62.26% in 2000%-range 1 LSB = 31.13% in 1000%-range 1 LSB = 15.56% in 500% - range
HR_Y_Threshold <4:0>	<4:0>	High rate threshold is for the gyroscope Y axis. The threshold value is dependent on the gyroscope range selected in the GRY_Config_0 register. 1 LSB = 62.5% in 2000%-range 1 LSB = 31.25% in 1000%-range 1 LSB = 15.625% in 500% - range

4.4.20 **GYR_DUR_Y 0x1B**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	1	1	0	0	1
Content	HR Y Duration							

DATA	bits	Description
HR_Y_Duration	<7:0>	High rate duration = (1 + HR_Y_Duration)*2.5ms

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 87

4.4.21 **GYR_HR_Z_SET 0x1C**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r	r	r	r	r	r	r	r
Reset	0	0	0	0	0	0	0	1
Content	reserved	HR_Z_THRES_HYST <1:0>		HR_Z_Threshold <4:0>				

DATA	bits	Description
HR_Z_THRES_HY ST <1:0>	<6:5>	High rate hysteresis for Z axis = (255 + 256 * HR_Z_THRES_HYST) *4 LSB The high rate value scales with the range setting 1 LSB = 62.26% in 2000%-range 1 LSB = 31.13% in 1000%-range 1 LSB = 15.56% in 500% - range
HR_Z_Threshold <4:0>	<4:0>	High rate threshold is for the gyroscope Z axis. The threshold value is dependent on the gyroscope range selected in the GRY_Config_0 register. 1 LSB = 62.5% in 2000%s-range 1 LSB = 31.25% in 1000%s-range 1 LSB = 15.625% in 500%s-range

4.4.22 **GYR_DUR_Z 0x1D**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	1	1	0	0	1
Content		HR_Z_Duration						

DATA	bits	Description
HR_Z_Duration	<7:0>	High rate duration = (1 + HR_Z_Duration)*2.5ms

4.4.23 **GYR_AM_THRES 0x1E**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	0	0	1	0	0
Content	reserved		Gyro Any Motion Threshold <6:0>					

DATA	bits	Description
Gyro Any Motion Threshold <6:0>	<6:0>	Any motion threshold is for the gyroscope any motion interrupt. The threshold value is dependent on the gyroscope range selected in the GRY_Config_0 register. $1 \ \text{LSB} = 1 \ \text{\%s in } 2000 \text{\%s-range} \\ 1 \ \text{LSB} = 0.5 \text{\%s in } 1000 \text{\%s-range} \\ 1 \ \text{LSB} = 0.25 \text{\%s in } 500 \text{\%s-range} \\ \dots$

BST-BNO055-DS000-12 | Revision 1.2 | November 2014



Page 88

4.4.24 **GYR_AM_SET 0x1F**

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w
Reset	0	0	0	0	1	0	1	0
Content		rese	rved		Awake Duration <1:0>		Slope Samples <1:0>	

DATA	bits	Description
Awake Duration <1:0>	<3:2>	0=8 samples, 1=16 samples, 2=32 samples, 3=64 samples
Slope Samples <1:0>	<1:0>	Any motion interrupt triggers if [Slope Samples + 1]*4 consecutive data points are above the any motion interrupt threshold define in GYRO AM THRES register

Page 89

4.5 Digital Interface

The BNO055 supports two digital interfaces for communication between the salve and host device: I²C which supports the HID-I2C protocol and I2C Standard and Fast modes; and the UART interface.

The active interface is selected by the state of the protocol select pins (PS1 and PS0), Table 4-4 shows the mapping between the protocol select pins and the selected interface mode.

Table 4-4: protocol select pin mapping

PS1	PS0	Functionality
0	0	Standard/Fast I2C Interface
0	1	HID over I2C
1	0	UART Interface
1	1	Reserved

It is not allowed to keep the protocol select pins floating.

Both digital interfaces share partially the same pins, the pin mapping for each interface is shown in Table 4-5.

Table 4-5: Mapping of digital interface pins

PIN	I2C Interfaces (PS1=0b0)	UART Interface (PS1.PS0=0b10)
COM0	SDA	Tx
COM1	SCL	Rx
COM2	GNDIO	
COM3	I2C address select	

The following table shows the electrical specifications of the interface pins:

Table 4-6: Electrical specification of the interface pins

Parameter	Symbol	Condition	Min	Тур	Max	Units
Pull-up Resistance, COM3 pin	R_{up}	Internal Pull-up Resistance to VDDIO	20	40	60	kΩ
Input Capacitance	C _{in}			5	10	pF
I ² C Bus Load Capacitance (max. drive capability)	C _{I2C_Load}				400	pF

Page 90

4.6 I2C Protocol

The I²C bus uses SCL (= SCx pin, serial clock) and SDA (= SDx pin, serial data input and output) signal lines. Both lines are connected to V_{DDIO} externally via pull-up resistors so that they are pulled high when the bus is free.

The I²C interface of the BNO055 is compatible with the I²C Specification UM10204 Rev. 03 (19 June 2007), available at http://www.nxp.com. The BNO055 supports I²C standard mode and fast mode, only 7-bit address mode is supported. The BNO055 I²C interface uses clock stretching.

The default I²C address of the BNO055 device is 0101001b (0 \times 29). The alternative address 0101000b (0 \times 28), in I2C mode the input pin COM3 can be used to select between the primary and alternative I2C address as shown in Table 4-7.

Table 4-7: I2C address selection

I2C configuration	COM3_state	I2C address
Slave	HIGH	0x29
Slave	LOW	0x28
HID-I2C	Χ	0x40

The timing specification for I²C of the BNO055 is given in Table 4-8: I²C timings:

Table 4-8: I²C timings

Parameter	Symbol	Condition	Min	Max	Units
Clock Frequency	f _{SCL}			400	kHz
SCL Low Period	t _{LOW}		1.3		
SCL High Period	t _{HIGH}		0.6		
SDA Setup Time	t _{SUDAT}		0.1		
SDA Hold Time	t _{HDDAT}		0.0		
Setup Time for a repeated Start Condition	t _{SUSTA}		0.6		μS
Hold Time for a Start Condition	t _{HDSTA}		0.6		
Setup Time for a Stop Condition	t _{susto}		0.6		
Time before a new Transmission can start	t _{BUF}		1.3		
Idle time between write accesses, normal mode, standby mode, low-power mode 2	t _{IDLE_wacc_nm}		2		μs
Idle time between write accesses, suspend mode, low-power mode 1	t _{IDLE} wacc su		450		μs

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

Figure 5: I²C timing diagram shows the definition of the I²C timings given in Table 4-8:




Figure 5: I2C timing diagram

The I2C protocol works as follows:

START: Data transmission on the bus begins with a high to low transition on the SDA line while SCL is held high (start condition (S) indicated by I2C bus master). Once the START signal is transferred by the master, the bus is considered busy.

STOP: Each data transfer should be terminated by a Stop signal (P) generated by master. The STOP condition is a low to HIGH transition on SDA line while SCL is held high.

ACK: Each byte of data transferred must be acknowledged. It is indicated by an acknowledge bit sent by the receiver. The transmitter must release the SDA line (no pull down) during the acknowledge pulse while the receiver must then pull the SDA line low so that it remains stable low during the high period of the acknowledge dock cycle.

In the following diagrams these abbreviations are used:

Start Р Stop

ACKS Acknowledge by slave Acknowledge by master **ACKM** Not acknowledge by master NACKM

Read / Write RW

A START immediately followed by a STOP (without SCL toggling from 'VDDIO' to 'GND') is not supported. If such a combination occurs, the STOP is not recognized by the device.

I²C write access:

I²C write access can be used to write a data byte in one sequence. The sequence begins



Page 92

with start condition generated by the master, followed by 7 bits slave address and a write bit (RW = 0). The slave sends an acknowledge bit (ACK = 0) and releases the bus. Then the master sends the one byte register address. The slave again acknowledges the transmission and waits for the 8 bits of data which shall be written to the specified register address. After the slave acknowledges the data byte, the master generates a stop signal and terminates the writing protocol.

Example of an I²C write access to the BNO055 (i2c address in this case: 0101000b = 0x28):



Figure 6: I2C write

I²C read access:

I²C read access also can be used to read one or multiple data bytes in one sequence. A read sequence consists of a one-byte I²C write phase followed by the I²C read phase. The two parts of the transmission must be separated by a repeated start condition (Sr). The I²C write phase addresses the slave and sends the register address to be read. After slave acknowledges the transmission, the master generates again a start condition and sends the slave address together with a read bit (RW = 1). Then the master releases the bus and waits for the data bytes to be read out from slave. After each data byte the master has to generate an acknowledge bit (ACK = 0) to enable further data transfer. A NACKM (ACK = 1) from the master stops the data being transferred from the slave. The slave releases the bus so that the master can generate a STOP condition and terminate the transmission.

The register address is automatically incremented and, therefore, more than one byte can be sequentially read out. Once a new data read transmission starts, the start address will be set to the register address specified in the latest I²C write command. By default the start address is set at 0x00. In this way repetitive multi-bytes reads from the same starting address are possible.

Example of an I²C read access to the BNO055:




Figure 7: I²C multiple read



Page 93

4.7 UART Protocol

The BNO055 supports UART interface with the following settings: 115200 bps, 8N1 (8 data bits, no parity bit, one stop bit). The maximum length support for read and write is 128 Byte. The packet structure for register read and write are described below.

Register write

Command:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	••••	Byte (n+4)
Start Byte	Write	Reg addr	Length	Data 1	••••	Data n
0xAA	0x00	<>	<>	<>	••••	<>

Acknowledge Response:

Acknowledge nesponse:					
Byte 1	Byte 2				
Response Header	Status				
0xEE	0x01: WRITE_SUCCESS 0x03: WRITE_FAIL 0x04: REGMAP_INVALID_ADDRESS 0x05: REGMAP_WRITE_DISABLED 0x06: WRONG_START_BYTE 0x07: BUS_OVER_RUN_ERROR 0X08: MAX_LENGTH_ERROR 0x09: MIN_LENGTH_ERROR 0x0A: RECEIVE_CHARACTER_TIMEOUT				

Register read

Command:

Byte 1	Byte 2	Byte 2	Byte 3
Start Byte	Read	Reg addr	Length
0xAA	0x01	<>	<>

Read Success Response:

Byte 1	Byte 2	Byte 3	••••	Byte (n+2)
ResponseByte	length	Data 1	••••	Data n
0xBB	<>			

Read Failure or Acknowledge Response:

Byte 1	Byte 2				
Response Header	Status				
0xEE	0x02: READ_FAIL				
	0x04: REGMAP_INVALID_ADDRESS				
	0x05: REGMAP_WRITE_DISABLED				
	0x06: WRONG_START_BYTE				
	0x07: BUS_OVER_RUN_ERROR				
	0X08: MAX_LENGTH_ERROR				
	0x09: MIN_LENGTH_ERROR				
	0x0A: RECEIVE_CHARACTER_TIMEOUT				



Page 94

4.8 HID over I2C

HID over I2C is a standard interface protocol to connect devices with hosts via I2C. The main advantage of HID is that there exist generic drivers for different input devices (such as sensors) which can be used with sensors that implement the corresponding well defined HID profiles. HID over I2C describes how messages (reports and events) are exchanged between the device and the host. A descriptor of the structure of these reports is provided by the device and read by the host during initialization of the device at host system start. For detailed information on HID please refer to the HID over I2C documentation from Microsoft.



5. Pin-out and connection diagram

5.1 Pin-out

The pin-out of the LGA package is shown in Figure 8 and the pin function is described in Table 5-1.




Figure 8: Pin-out bottom view



Page 96


Table 5-1: Pin description

Pin#	Name	I/O Type	Description		Function	
				I2C	UART	HID- I2C
1	PIN1		Do not connect		DNC	
2	GND	Ground	GND		GND	
3	VDD	Supply	VDD		VDD	
4	nBOOT_LOAD_PIN	Digital I/O	Bootloader mode select pin (active low)	nBOO	DT_LOAD	_PIN
5	PS1	Digital in	Protocol select pin 1	GNDIO	VDDIO	GNDIO
6	PS0	Digital in	Protocol select pin 2	GNDIO	GNDIO	VDDIO
7	PIN7		Do not connect		DNC	
8	PIN8		Do not connect		DNC	
9	CAP		External capacitor		CAP	
10	PIN10	Ground	connect to GNDIO		GNDIO	
11	nRESET		Reset pin (active low)		nRESET	
12	PIN12		Do not connect		DNC	
13	PIN13		Do not connect		DNC	
14	INT	Digital Out	Interrupt output	Interrupt		
15	PIN15	Ground	Connect to GNDIO		GNDIO	
16	PIN16	Ground	Connect to GNDIO		GNDIO	
17	COM3	Digital I/O	Digital interface pin 3	I2C address select	GNDIO	GNDIO
18	COM2	Digital I/O	Digital interface pin 2		GNDIO	
19	COM1	Digital I/O	Digital interface pin 1	SCL	Rx	SCL
20	COM0	Digital I/O	Digital interface pin 0	SDA	Tx	SDA
21	PIN21		Do not connect		DNC	
22	PIN22		Do not connect	DNC		
23	PIN23		Do not connect	DNC		
24	PIN24		Do not connect	DNC		
25	GNDIO	Ground	GNDIO	GNDIO		
26	XOUT32	Digital Out	Optional OSC port	OSC Output		ıt
27	XIN32	Digital In	Optional OSC port	(OSC Input	
28	VDDIO	Supply	VDDIO		VDDIO	



5.2 Connection diagram I²C


Figure 9: I²C connection diagram





5.3 Connection diagram UART


Figure 10: UART connection diagram





5.4 Connection diagram HID-I2C

Figure 11: HID via IC connection diagram



Page 100

5.5 XOUT32 & XIN32 Connections

The BNO055 can run from an internal or external 32 KHz dock source. By default, the internal dock is selected.

An External clock can be selected by setting bit CLK_SEL in the SYSTEM_TRIGGER register. An external 32 KHz crystal oscillator has to be connected to the pins XIN32 and XOUT32 as shown below.

To get the best performance out of BNO055, it is recommended to use the external crystal.

5.5.1 External 32kHz Crystal Oscillator

Figure 12: External 32kHz Crystal Oscillator with Load Capacitor




Table 5-2: Crystal Oscillator Source Connections

Pin Name	Recommended Pin Connection	Description
XIN32	Load capacitor 22pF ⁷⁸	Timer oscillator input
XOUT32	Load capacitor 22pF ⁷⁸	Timer oscillator output

5.5.2 Internal clock mode

The internal clock can be selected by dearing bit CLK_SEL in the SYSTEM_TRIGGER register. When an internal clock is used, both pins XIN32 and XOUT32 can be left open. The internal clock of the BNO055 can have clock deviation up to $\pm 3\%$

BST-BNO055-DS000-12 | Revision 1.2 | November 2014

⁷ These values are given only as typical example.

⁸ Decoupling capacitor should be placed close to the device for each supply pin pair in the signal group.



6. Package

6.1 Outline dimensions

The sensor package is a standard LGA package; dimensions are shown in the following diagram. Units are in mm. Note: Unless otherwise specified tolerance = decimal ±0.1mm. The chapter 3.5 provides information regarding the sensor axis orientation.




Figure 13: Outline dimensions

Page 102

6.2 Marking

Table 6-1: Marking of mass production parts

Labeling	Name	Symbol	Remark
	Pin 1 identifier	•	
701 TTTT	Product number	701	3 numeric digits, internal identification for product type
ccc	Second Row	Т	Internal use
	Third Row	С	Numerical counter

6.3 Soldering Guidelines

The moisture sensitivity level of the BNO055 sensors corresponds to JEDEC Level 1, see also

- IPC/JEDEC J-STD-020C "Joint Industry Standard: Moisture/Reflow Sensitivity Classification for non-hermetic Solid State Surface Mount Devices"
- IPC/JEDEC J-STD-033A "Joint Industry Standard: Handling, Packing, Shipping and Use of Moisture/Reflow Sensitive Surface Mount Devices"

The sensor fulfils the lead-free soldering requirements of the above-mentioned IPC/JEDEC standard, i.e. reflow soldering with a peak temperature up to 260°C.

6.4 Handling instructions

Micromechanical sensors are designed to sense acceleration with high accuracy even at low amplitudes and contain highly sensitive structures inside the sensor element. The MEMS sensor can tolerate mechanical shocks up to several thousand g's. However, these limits might be exceeded in conditions with extreme shock loads such as e.g. hammer blow on or next to the sensor, dropping of the sensor onto hard surfaces etc.

We recommend avoiding g-forces beyond the specified limits during transport, handling and mounting of the sensors in a defined and qualified installation process.

This device has built-in protections against high electrostatic discharges or electric fields (e.g. 2kV HBM); however, anti-static precautions should be taken as for any other CMOS component. Unless otherwise specified, proper operation can only occur when all terminal voltages are kept within the supply voltage range. Unused inputs must always be tied to a defined logic voltage level.

For more details on recommended handling, soldering and mounting please contact your local Bosch Sensortec sales representative and ask for the "Handling, soldering and mounting instructions" document.



Page 103

6.5 Tape and reel specification

The BNO055 is shipped in a standard cardboard box. For details please refer to the 'Shipment packaging details' document.

6.6 Environmental safety

The BNO055 sensor meets the requirements of the EC restriction of hazardous substances (RoHS and RoHS2) directive, see also:

Directive 2002/95/EC of the European Parliament and of the Council of 27 January 2003

on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

6.6.1 Halogen content

The BNO055 is halogen-free. For more details on the analysis results please contact your Bosch Sensortec representative.

6.6.2 Internal package structure

Within the scope of Bosch Sensortec's ambition to improve its products and secure the mass product supply, Bosch Sensortec qualifies additional sources (e.g. 2nd source) for the LGA package of the BNO055.

While Bosch Sensortec took care that all of the technical packages parameters are described above are 100% identical for all sources, there can be differences in the chemical content and the internal structural between the different package sources.

However, as secured by the extensive product qualification process of Bosch Sensortec, this has no impact to the usage or to the quality of the BMNO55 product.



Page 104

7. Legal disclaimer

7.1 Engineering samples

Engineering Samples are marked with an asterisk (*) or (e) or (E). Samples may vary from the valid technical specifications of the product series contained in this data sheet. They are therefore not intended or fit for resale to third parties or for use in end products. Their sole purpose is internal client testing. The testing of an engineering sample may in no way replace the testing of a product series. Bosch Sensortec assumes no liability for the use of engineering samples. The Purchaser shall indemnify Bosch Sensortec from all claims arising from the use of engineering samples.

7.2 Product use

Bosch Sensortec products are developed for the consumer goods industry. They may only be used within the parameters of this product data sheet. They are not fit for use in life-sustaining or security sensitive systems. Security sensitive systems are those for which a malfunction is expected to lead to bodily harm or significant property damage. In addition, they are not fit for use in products which interact with motor vehicle systems.

The resale and/or use of products are at the purchaser's own risk and his own responsibility. The examination of fitness for the intended use is the sole responsibility of the Purchaser.

The purchaser shall indemnify Bosch Sensortec from all third party claims arising from any product use not covered by the parameters of this product data sheet or not approved by Bosch Sensortec and reimburse Bosch Sensortec for all costs in connection with such claims.

The purchaser must monitor the market for the purchased products, particularly with regard to product safety, and inform Bosch Sensortec without delay of all security relevant incidents.

7.3 Application examples and hints

With respect to any examples or hints given herein, any typical values stated herein and/or any information regarding the application of the device, Bosch Sensortec hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights or copyrights of any third party. The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics. They are provided for illustrative purposes only and no evaluation regarding infringement of intellectual property rights or copyrights or regarding functionality, performance or error has been made.

Page 105

8. Document history and modifications

Rev. No	Chapter	Description of modification/changes	Date
0.1		Initial version	2013-09-02
0.2		Completely revised version (BMF055 added)	2013-10-15
0.9		Preliminary version with feature set of Firmware version 0.2.B.0	2014-04-25
1.0		Complete review	2014-07-11
1.1	3	Rearrangement of subsections in chapter 3 for better readability.	
	3.3	Table 3.1 is updated for better readability and all the operation modes are elaborated	
	3.11	Chapter on calibration included	
	3.7, 3.10	Update	2014-11-05
	4.2	The default value of the UNIT_SEL register is updated	
	4.6	I2C communication example figures are updated.	
	5.1, 5.2, 5.3,	Induded table 5.1 Pin description.	
	5.4	Connection diagram updated	
1.2	5	Updated pin description and connection diagram	
	6.1	Updated outline dimensions	
	6.2	Chapter removed and the respective information is updated in the Handling, soldering and mounting instructions application note.	

Bosch Sensortec GmbH Gerhard-Kindler-Strasse 8 72770 Reutlingen / Germany

contact@bosch-sensortec.com www.bosch-sensortec.com

Modifications reserved | Printed in Germany Specifications subject to change without notice Document number: BST-BNO055-DS000-11 Revision 1.1 201408