

Models: (Chapter 2, text)

Given a physical system we want to obtain its mathematical model, i.e. a mathematical relationship between the input and the output.

In this class we will deal only with FDLTI systems. Hence the mathematical models will be either
 1) an ordinary differential equation (O.D.E) with constant coeff
 or
 2) a rational transfer function

Only exception: systems containing a time delay

$$r(t) \rightarrow \boxed{\text{delay } T \text{ sec}} \rightarrow v(t-T) \rightarrow G(s) \rightarrow y(t)$$

- Section 2.2: Electrical Circuits read text book

- Mechanical Translational Systems: (section 2.5)

Basic law Newton's second law $M\ddot{x} = \Sigma F$

Elements: a) Spring
b) Viscous Damping & Friction

- Model of an ideal spring (Hooke's law):

$$F = -k(x - x_0)$$

↓ ↑
 spring constant actual length
 natural length




- Model of viscous damping & friction: $F = -b\dot{x}$

always opposes motion

Examples:

1)



$$M\ddot{x} = -kx - b\dot{x} + f$$


$$M\ddot{x} + b\dot{x} + kx = f$$

Taking Laplace Transforms on both sides yields:



$$(M_1 s^2 + b_1 s + k_1) X_1(s) + (I_1 C_1) = F(s)$$

$$\Rightarrow \text{Transfer function } G(s) = \frac{X_1(s)}{F(s)} \Big|_{I.C.=0} = \frac{1}{M_1 s^2 + b_1 s + k_1}$$

Example 2: Simplified model of an automobile suspension:



Free body diagrams:



$$M_1 \ddot{x}_1 = -k_1(x_1 - x_2) - b_1(\dot{x}_1 - \dot{x}_2)$$

$$M_2 \ddot{x}_2 = -k_1(x_2 - x_1) - b_2(\dot{x}_2 - \dot{x}_1) - k_2 x_2 + f$$

Taking Laplace Transforms (assume 0 initial conditions) yields:

$$(M_1 s^2 + b_1 s + k_1) X_1 - (b_1 s + k_1) X_2 = 0$$

$$-(b_2 s + k_2) X_2 + (M_2 s^2 + b_2 s + k_1 + k_2) X_2 = F(s)$$


If we want to find the T.F from $F(s)$ to $X_1(s)$ we need to solve these simultaneous equations. For instance, we can use Cramer's formula. Later on we will see an alternative solution method using signal flow graphs.


- Mechanical Rotational Systems (section 2.6)

Elements = moment of inertia (similar to mass)
friction
torsion


Basic Law: Newton's equation for rotational systems:

$$J \ddot{\theta} = \sum \text{Torques}$$

Torsion Spring:  $C = k(\theta_2 - \theta_1)$

Viscous friction:  $C = B(\dot{\theta}_2 - \dot{\theta}_1)$


- Example: A rotating rigid satellite; with torque applied by 2 thrusters



$$J \frac{d^2\theta}{dt^2} = T(t)$$

- Electromechanical Systems: (2.7)

- Generator (rotating at constant speed)




1) Field circuit: $e_f = R_f i_f + L_f \frac{di_f}{dt}$ // $E_f(s) = (R_f + L_f s) I_f(s)$

2) Generator circuit: $e_g = R_a i_a + L_a \frac{di_a}{dt} + E_a$ // $E_g(s) = E_a(s) + (R_a + sL_a) I_a(s)$

3) Electromechanical equation: $e_g = k \Phi \dot{\theta}$
 linear assumption: $\Phi = k \Phi i_f$

$$\left. \begin{aligned} e_g &= k \Phi i_f \\ &\quad (\text{constant velocity}) \end{aligned} \right\}$$

Block Diagram of the generator:




Transfer function: $G(s) = \frac{Z_e K_g}{(R_f + sL_f)(sL_a + R_a + Z_L)}$

Note that $G(s)$ depends on Z_e !!

$$\left. \begin{aligned} E_a(s) &= E_a(s) + (sL_a + R_a) I_a(s) \\ E_a(s) &= Z_L I_a \end{aligned} \right\} \quad \begin{aligned} E_a &= (Z_L + sL_a + R_a) I_a(s) \\ I_a(s) &= \left(\frac{1}{Z_L + sL_a + R_a} \right) E_a \\ E_a &= Z_L I_a \end{aligned}$$


• DC Motor (with independent excitation)



- 1) Electrical equation: $I_a = R_m I_a + L_m \frac{dI_a}{dt} + e_m \quad // \quad E_a(s) = (sL_m + R_m)I_a(s) + E_m(s)$
- 2) Back emf: $e_m = k_m \dot{\theta} \quad // \quad E_m(s) = k_m s \theta(s)$
- 3) Mechanical equation: $Z = K_z I_a$
- 4) Finally: Newton's second equation: $J_L \frac{d\dot{\theta}}{dt} + B_L \dot{\theta} = Z \quad // \quad (J_L^2 + sB_L)\theta = Z(s)$

Putting everything together yields the following block diagram

From (1): $I_a = \left(\frac{E_a(s) - E_m(s)}{sL_m + R_m} \right); \quad E_m(s) = s k_m \theta(s)$



New feature: the system has built-in feedback (through the emf)

If we want to find $\theta(s)$ as a function of $E_a(s)$ we need to solve:

$$\begin{aligned} E_a &= (sL_m + R_m) I_a + s k_m \theta(s) \\ 0 &= -K_z I_a + (s^2 J_L + s B_L) \theta \end{aligned}$$

or, in matrix form:

$$\begin{bmatrix} sK_m & sL_m + R_m \\ s^2J_L + sB_L & -k_z \end{bmatrix} \begin{pmatrix} 0 \\ I_a \end{pmatrix} = \begin{pmatrix} E_q \\ 0 \end{pmatrix}$$

Using Cramer's rule we have:


$$\theta = \frac{\Delta_0}{\Delta}$$

$$\Delta = -k_z k_m s + (R_m + sL_m)(sJ_L + B_L)s$$

$$\Delta_0 = -k_z E_a$$

$$\Rightarrow \theta = \frac{\Delta_0}{\Delta} = \frac{k_z}{k_m k_z s + (R + sL)(sJ_L + B_L)s} E_a \#$$

Note that the system has the general form:



$$E = R - HC \quad \left. \begin{array}{l} \\ \end{array} \right\} \quad C = GE$$

$$C = GR - GHC$$

$$\text{or } \frac{C}{R} = \frac{1}{1+GH} \#$$

This is a special case of Mason's Formula

- Signal Flow Diagrams (sections 2.3, 2.4)

They provide an alternative representation of Transfer Function relationships. They also provide an alternative to Cramer's rule for computing T.F.

Rules:

- Each signal is represented by a node
- Each T.F. is represented by a branch (arrow)



Block Diagram:

$$x(s) = G(s) r(s)$$


Signal flow:



- Summing junctions are represented implicitly: all the inputs converging to a node are added together




Example: signal flow graph representation of the DC motor



Some Terminology:

source node: A node that has all signals flowing away from it.



sink node: A node with incoming signals only




Path: Continuous connection of branches between 2 nodes (directed)

Loop: Closed path (i.e. starting node = finishing node)

Path (loop) gain: product of all T.F. of all the branches in the path (loop)

Non Touching loops: Loops that do not have any nodes (paths) in common.

Example:



2 loops: $-G_2 H_1$ (L_1)
 $-G_4 H_2$ (L_2)

Path $G_3 G_4 G_5$ does not touch L_1
 Path $G_1 G_2 G_3 G_4 G_5$ touches both L_1 and L_2

- Mason's Formula (section 2.4) provides an alternative to Cramer's rule or elimination for finding Transfer functions

$$T_{CR} = \frac{1}{\Delta} \sum_{k=1}^P M_k \Delta_k = \frac{1}{\Delta} (M_3 \Delta_3 + \dots + M_P \Delta_P)$$

Where :


- $\Delta = 1 - \left(\sum_{\text{loops}}^{\text{gains individual}} \right) + \sum \left(\frac{\text{products of pairs of non-touching loops}}{\text{loops}} \right)$
- $- \sum \left(\text{products of triplets of non-touching loops} \right)$
- $+ \dots$

- $M_k = \text{Gain of the } k^{\text{th}} \text{ path between } R \text{ and } C$
- $\Delta_k = \text{Value of } \Delta \text{ when the nodes in the path } M_k \text{ are removed from the graph}$


50 SHEETS
100 SHEETS
200 SHEETS

22-141
22-142
22-144

Example 1: DC motor:



Signal flow graph:




1 loop: $L_3 = -\frac{k_z km s}{(R+Ls)(Js+B)s} \Rightarrow \Delta = 1 + \frac{k_z km s}{(R+Ls)(Js+B)s}$


Only 3 path from E_a to Θ : $M_3 = \frac{k_z}{(R+Ls)(Js+B)s}$
 $\Delta_3 = 1$

$$T_{\Theta E_a} = \frac{1}{\Delta} \cdot M_3 \Delta_3 = \\ = \frac{\frac{k_z}{(R+Ls)(Js+B)s}}{1 + \frac{k_z km s}{(R+Ls)(Js+B)s}} = \frac{k_z}{(R+Ls)(Js+B)s + k_m k_z s} \quad \#$$

Note: This is a special case of:



In signal flow form:




$$L_3 = -6H$$

$$\Delta = 1 - L_3 = 1 + 6H$$

$$T_{y r} = \frac{M}{\Delta} = \frac{6}{1 + 6H} \quad \#$$

Example 2: (Example 2.14 text)



Number of paths between $r \& c = 2$

$$- M_1 = G_1 G_2 G_3 G_4 G_5 \\ M_2 = G_6 G_4 G_5$$

Number of loops: 2

$$L_1 = -G_2 H_1 \quad (\text{loop touching}) \\ L_2 = -G_4 H_2$$

$$\Delta = 1 - \sum \text{loops} + \sum \text{pairs} = 1 + G_2 H_1 + G_4 H_2 + G_2 G_4 H_1 H_2 \\ (\text{N.T.})$$

Path M_1 touches both loops $\Rightarrow \Delta_1 = 1$
Path M_2 touches only $L_2 \Rightarrow \Delta_2 = 1 + G_2 H_1$

$$T_{cr} = \frac{1}{\Delta} (M_1 \Delta_1 + M_2 \Delta_2) = \frac{G_1 G_2 G_3 G_4 G_5 (1 + G_2 H_1)}{1 + G_2 H_1 + G_4 H_2 + G_2 G_4 H_1 H_2}$$

Important: Technically, Mason's formula is valid to compute the TF ONLY from a source node to a sink node

The restriction of the output being a sink node is easy to remove: add an extra branch with gain 1




(This essentially says $y = y_1$)


However, the restriction of the input being a source node can't be dealt with in this form.

- Basic operations on systems (Block Diagrams)


Here we are going to learn how to operate on block diagrams. This will allow us to obtain simpler (hopefully) diagrams, easier to solve.
The basic operations are:




2) Moving a summing junction behind a block




3) Moving a summing junction ahead of a block




4) Moving a "tap" ahead of a block



5) Moving a "tap" behind a block




6) Eliminating a feedback loop:




(This follows from Mason's formula)

- Example of application:



Want to find T_{CR}


- Step 1: Move the tap for H_2 behind G_4



- Step 2: Eliminate the feedback loop $G_3 G_4 H_1$

$$-\frac{G_3 G_4}{1 - G_3 G_4 H_1}$$

Now we have:



- Step 3: Eliminate the inner loop:


$$R \rightarrow \frac{G_2 G_3 G_4}{1 - G_3 G_4 H_1 + G_2 G_3 H_2} \rightarrow c$$

- Step 4: Collapse the final loop
(i.e. use Mason's again)

$$R \longrightarrow \boxed{\frac{G_1 G_2 G_3 G_4}{1 - G_3 G_4 H_1 + G_2 G_3 H_2 + G_2 G_3 G_4 G_1 H_3}} \longrightarrow C$$

Alternative solution:

Transform to a signal flow graph and use
Mason's



Loops:

$$\begin{aligned} & -G_2 G_3 H_2 \\ & G_3 G_4 H_1 \\ & -G_1 G_2 G_3 G_4 H_3 \end{aligned}$$

(all touching)


$$\Rightarrow \frac{M}{\Delta} = \dots G_2 G_3 H_2 \frac{1 \cdot 2 \cdot 3 \cdot 4}{-G_3 G_4 H_1 + G_1 G_2 G_3 G_4 H_3}$$

Forward path (only one) $M = G_1 G_2 G_3 G_4$



• 2 additional elements: Transformers & Gears (Section 2.11)

1) Electrical transformer




$$\frac{N_1}{N_2} = \text{turns ratio}$$

Assuming ideal transformer (no magnetic flux lost) we get

$$N_1 I_1 = N_2 I_2$$

Since no power is lost: $e_1 I_1 = e_2 I_2 \Rightarrow \frac{e_1}{N_1} = \frac{e_2}{N_2} // \boxed{\frac{e_2}{e_1} = \frac{N_2}{N_1} = \frac{I_1}{I_2}}$

Suppose now that we load the secondary with a load Z_L . What happens to the primary circuit?



$$e_2 = Z_L I_2$$

$$\frac{N_2}{N_1} e_1 = Z_L \left(\frac{N_1}{N_2} \right) I_1 // e_1 = \left(\frac{N_1}{N_2} \right)^2 Z_L I_1$$


$$I_1 = Z_{eq} I_1$$

$$Z_{eq} = \left(\frac{N_1}{N_2} \right)^2 Z_L$$

The load is "reflected" in the primary circuit as an equivalent load equal to $\left(\frac{N_1}{N_2} \right)^2 Z_L$



2) Gear train: 2 gears with teeth meshing perfectly (i.e. no slipping)



if there is no slipping then

$$r_1 \dot{\theta}_1 = r_2 \dot{\theta}_2 \quad (\text{same linear velocity at the contact point})$$

From power considerations:


$$\tau_1 \dot{\theta}_1 = \tau_2 \dot{\theta}_2 \Rightarrow \frac{\tau_1}{\eta} = \frac{\tau_2}{r_2}$$

or

$$\boxed{\frac{\tau_2}{\tau_1} = \frac{r_2}{r_1} = \frac{\dot{\theta}_1}{\dot{\theta}_2}}$$

Note τ transforms as θ
 $\dot{\theta}$ transforms as i

Example:



$$\frac{J_1}{J_2} = \frac{n^2}{r_1^2}$$

$$\frac{\theta_1}{\theta_2} = \frac{r_2}{r_1}$$




$$T_2 = J_L \frac{d^2 \theta_2}{dt^2} \Rightarrow T_2 \left(\frac{r_2}{r_1} \right) = J_L \frac{d^2}{dt^2} \left(\frac{r_1}{r_2} \theta_1 \right) = J_L \left(\frac{r_1}{r_2} \right) \frac{d^2 \theta_1}{dt^2}$$

$$\Rightarrow T_1 = J_L \left(\frac{r_1}{r_2} \right)^2 \frac{d^2 \theta_1}{dt^2} \Rightarrow J_{eq} = J_L \left(\frac{r_1}{r_2} \right)^2$$

\Rightarrow Inertia transforms following the same rules of impedances

- Example: (A Robotic Control System) (Section 2.12)


Single joint robotic arm:



$$\text{Here } J_{eq} = \text{DC motor inertia} + (\text{arm inertia}) \cdot n^2 = J_m + J_{arm} \cdot n^2$$

$$B_{eq} = B_m + B_{arm} \cdot n^2$$

Notes 1) You get a third order system unless you neglect L_m



$$J_L \ddot{\theta}_L + B_L \dot{\theta}_L = Z_L$$

$$Z_L = Z_m/n$$

$$\theta_L = n \theta_m$$


$$J_L \cdot n \ddot{\theta}_m + B_L n \dot{\theta}_m = Z_m/n$$

$$n^2 J_L \ddot{\theta}_m + n^2 B_L \dot{\theta}_m = Z_m \Rightarrow J_{eq} = J_L n^2$$

$$B_{eq} = B_L n^2$$

Linearization (section 2.14 book)

So far we have considered only linear models. What happens if we want to analyze (or control) a nonlinear system, for instance a pendulum:



Newton's equation for rotational motion yields:

$$ml^2 \ddot{\theta} = -mg l \sin \theta$$

$$\Rightarrow \ddot{\theta} = -\frac{g}{l} \sin \theta$$


Assume we have an initial condition $\theta(0) = \theta_0$, $\dot{\theta}(0) = 0$ and we want to find $\theta(t)$

Q: can we use Laplace transform?

A: No! the right hand side of the equation is non-linear in the variable

Q: Can we get some sort of "linear approximation" so that we can use our linear toolbox?

A: Yes, depending on the value of θ .



If θ is small, then $\sin \theta \sim \theta$

On the other hand, if $\theta \sim \frac{\pi}{2}$
the natural approximation
would be $\sin \theta \sim 0$

For small θ we get $\ddot{\theta} = -\frac{g}{l} \sin \theta \Rightarrow \theta(t) = \theta_0 \cos \sqrt{\frac{g}{l}} t$

which matches quite closely the motion (as long as θ_0 is small)

On the other hand, for $\theta \sim \frac{\pi}{2}$ we get $\ddot{\theta} = 0$
 $\Rightarrow \theta(t) = \theta_0$

which is clearly wrong!

In general, given an equation of the form:

$$\dot{x} = f(x)$$

Suppose that we want to linearize it around an equilibrium point x_0 (i.e. $f(x_0) = 0$)

Taking a Taylor series expansion of $f(x)$ around x_0 yields:

$$\dot{x} \approx f(x_0) + f'(x_0)(x - x_0) + \frac{1}{2}f''(x_0)(x - x_0)^2 + \text{higher order terms}$$

\Rightarrow if all derivatives (except the first) are small and if $(x - x_0)$ is small then

$$\dot{x} \approx f'(x_0)(x - x_0)$$

(or, if we define $\delta x = x - x_0$)

$$\dot{\delta x} = f'(x_0) \delta x$$

(a linear approximation)
valid for small δx

In the case of the pendulum:

- At $\theta=0$ we have

$$\begin{aligned}f(\theta) &= \sin\theta \\f'(0) &= \cos\theta \\f''(0) &= -\sin\theta \\f'''(0) &= -\cos\theta\end{aligned}$$

$$\begin{aligned}f(0) &= 0 \\f'(0) &= 1 \\f''(0) &= 0 \\f'''(0) &= -1\end{aligned}$$

$$\Rightarrow \sin\theta \approx \delta\theta + \frac{1}{6}\delta\theta^3 \approx \delta\theta$$

$$\begin{aligned}\bullet \text{ At } \theta = \pi/2, \quad \sin\theta &= \sin(\frac{\pi}{2}) + \frac{\cos(\frac{\pi}{2})}{0!}\delta\theta + \frac{-\sin(\frac{\pi}{2})}{1!}(\delta\theta)^2 + \dots \\&= 1 - \frac{\pi}{2}(\delta\theta)^2 \Rightarrow \text{linearization fails}\end{aligned}$$