J1
SNES socket (console-replacement, 7.0 mm rows)

SNES_SYSTEM_CLK	1	SYSTEM_CLK	/WRAMSEL	32	SNES_WRAMSEL_N
SNES_EXPAND	2	EXPAND	REFRESH	33	SNES_REFRESH
SNES_PA6	3	PA6	PA7	34	SNES_PA7
SNES_PRD_N	4	/PRD	/PWR	35	SNES_PWR_N
GND	5	GND	GND	36	GND
SNES_A11	6	A11	A12	37	SNES_A12
SNES_A10	7	A10	A13	38	SNES_A13
SNES_A9	8	A9	A14	39	SNES_A14
SNES_A8	9	A8	A15	40	SNES_A15
SNES_A7	10	A7	A16	41	SNES_A16
SNES_A6	11	A6	A17	42	SNES_A17
SNES_A5	12	A5	A18	43	SNES_A18
SNES_A4	13	A4	A19	44	SNES_A19
SNES_A3	14	A3	A20	45	SNES_A20
SNES_A2	15	A2	A21	46	SNES_A21
SNES_A1	16	A1	A22	47	SNES_A22
SNES_A0	17	A0	A23	48	SNES_A23
SNES_IRQ_N	18	/IRQ	/ROMSEL	49	SNES_ROMSEL_N
SNES_D0	19	D0	D4	50	SNES_D4
SNES_D1	20	D1	D5	51	SNES_D5
SNES_D2	21	D2	D6	52	SNES_D6
SNES_D3	22	D3	D7	53	SNES_D7
SNES_RD_N	23	/RD	/WR	54	SNES_WR_N
SNES_CIC_DATA1	24	CIC_DATA1	CIC_DATA0	55	SNES_CIC_DATA0
SNES_CIC_SLAVE_RESET	25	CIC_SLAVE_RESET	CIC_CLK	56	SNES_CIC_CLK
SNES_RESET_N	26	/RESET	PHI2	57	SNES_PHI2
SNES_5V_CART	27	+5V_CART	+5V_CART	58	SNES_5V_CART
SNES_PA0	28	PA0	PA1	59	SNES_PA1
SNES_PA2	29	PA2	PA3	60	SNES_PA3
SNES_PA4	30	PA4	PA5	61	SNES_PA5
SNES_AUDIO_L_IN	31	AUDIO_L_IN	AUDIO_R_IN	62	SNES_AUDIO_R_IN

J2
SN64_Socket_Joint_2x40

SNES_SYSTEM_CLK	1	SYSTEM_CLK	/WRAMSEL	32	SNES_WRAMSEL_N
SNES_EXPAND	2	EXPAND	REFRESH	33	SNES_REFRESH
SNES_PA6	3	PA6	PA7	34	SNES_PA7
SNES_PRD_N	4	/PRD	/PWR	35	SNES_PWR_N
GND	5	GND	GND	36	GND
SNES_A11	6	A11	A12	37	SNES_A12
SNES_A10	7	A10	A13	38	SNES_A13
SNES_A9	8	A9	A14	39	SNES_A14
SNES_A8	9	A8	A15	40	SNES_A15
SNES_A7	10	A7	A16	41	SNES_A16
SNES_A6	11	A6	A17	42	SNES_A17
SNES_A5	12	A5	A18	43	SNES_A18
SNES_A4	13	A4	A19	44	SNES_A19
SNES_A3	14	A3	A20	45	SNES_A20
SNES_A2	15	A2	A21	46	SNES_A21
SNES_A1	16	A1	A22	47	SNES_A22
SNES_A0	17	A0	A23	48	SNES_A23
SNES_IRQ_N	18	/IRQ	/ROMSEL	49	SNES_ROMSEL_N
SNES_D0	19	D0	D4	50	SNES_D4
SNES_D1	20	D1	D5	51	SNES_D5
SNES_D2	21	D2	D6	52	SNES_D6
SNES_D3	22	D3	D7	53	SNES_D7
SNES_RD_N	23	/RD	/WR	54	SNES_WR_N
SNES_CIC_DATA1	24	CIC_DATA1	CIC_DATA0	55	SNES_CIC_DATA0
SNES_CIC_SLAVE_RESET	25	CIC_SLAVE_RESET	CIC_CLK	56	SNES_CIC_CLK
SNES_RESET_N	26	/RESET	PHI2	57	SNES_PHI2
SNES_5V_CART	27	+5V_CART	+5V_CART	58	SNES_5V_CART
SNES_PA0	28	PA0	PA1	59	SNES_PA1
SNES_PA2	29	PA2	PA3	60	SNES_PA3
SNES_PA4	30	PA4	PA5	61	SNES_PA5
SNES_AUDIO_L_IN	31	AUDIO_L_IN	AUDIO_R_IN	62	SNES_AUDIO_R_IN

SNES_5V_CART	63	SNES_5V_CART	SNES_5V_CART	64	SNES_5V_CART
SNES_5V_CART	65	SNES_5V_CART	SNES_5V_CART	66	SNES_5V_CART
GND	67	GND	GND	68	GND
GND	69	GND	GND	70	GND
GND	71	GND	GND	72	GND
GND	73	GND	GND	74	GND
GND	75	GND	GND	76	GND
GND	77	GND	GND	78	GND
GND	79	GND	GND	80	GND

SNES_5V_CART — C1 — GND
100nF 16V X7R

SNES_5V_CART — C2 — GND
100nF 16V X7R

Socket footprint: console-replacement family, OpenSFC geometry (7.0 mm rows, ears 95 mm). Unverif
SNES/SFC socket on its own horizontal board; joined to the main board by a 2x40 2.00 mm header (

Sheet: /
File: sn64-socket.kicad_sch

Title: SN 64 socket board

Size: A3	Date:	**Rev: 0.1-socket**
KiCad E.D.A. 10.0.6		Id: 1/1