




Schematic Content: Group: http://www.hqyj.com/ Page 01: Cover sheet Page 02: Block diagram Project:FS MP157 MARS Page 03: Power Supply Description Page 04: CPU Power Revision Date Drawn Page 05: CPU Peripheral Ver 1.0 2019.07.19 Releas version szl Page 06: CPU DDR3 RGB/HDMI signal correction 2020.04.08 Ver 2.0 szl Page 07: Flash Memory Page 08: Gigabit Ethernet Page 09: USB/TF/ KEY/LED Page 10: HDMI Page 11: Audio Page 12: WiFi/BLE Page 13: LCD/Camera/Touch Notes: Page 14: GPIO/UART/BOOT/JTAG FS MP157 MARS Description: 01 Cover sheet Revision: Date: Thursday, April 09, 2020






































BOOT Mode	BOOT2	BOOT1	BOOT0
Reserver	1	0	0
Serial NOR-Flash on QUADSPI	0	0	1
Serial NAND-Flash on QUADSPI	1	1	1
NAND-Flash	0	1	1
eMMC	0	1	0
SD-Card	1	0	1
UART and USB	1	1	0
	0	0	0

"0" is floating signal or grounded

"1" is signal with pullup or tied to VDD



