

USER MANUAL

Tennibot

Partner



haithame@tennibot.com



(251)-277-8022




Use these QR codes to download the Tennibot app!

TABLE OF CONTENTS

PRODUCT OVERVIEW	1
SETTING UP YOUR PARTNER	3
SAFETY INSTRUCTIONS	9
CERTIFICATIONS	11
SPECIFICATIONS	12


1




2




3




4




5



7



6



1) Partner

2) Station


3) Station Holder

4) Station Case

5) Ball Hopper


6) Battery

7) Dual Battery Charger




SETTING UP YOUR PARTNER

- 1 Plug the fully charged battery into the back of your Partner and press the power button.




- 2** Place the Partner on the court, at the designated spot.



3

Attach the ball hopper netting to the Partner





Pro tip:

Make sure the ball agitator is tucked out from under the netting so it doesn't get stuck.

- 4** Mount the Station Holder to either net post using the belts.

Make sure the Holder is mounted level and the cameras are facing both sides of the court.

Turn on the Station




Pro tip:

Choose a net post facing opposite of the sun so the cameras can see properly.

5

Open the app and follow the directions to connect it to your Partner!

Still need help?



Scan Me!

https://youtu.be/tpKediX_cVs



Have a question?

✉ haithame@tennibot.com

☎ (251)-277-8022

www.tennibot.com