Document Type: GENERAL CHAPTER

@2021 USPC

1

## (1181) SCANNING ELECTRON MICROSCOPY

### INTRODUCTION

Over the last few decades, electron microscopy has become a reliable investigative tool for the study of solid and semi-solid materials. Since the invention of the electron microscope attributed to Max Knoll in 1935 and commercialization in the 1960's by Cambridge Instrument Co. and JEOL, recent improvements in resolution, stability, and specimen accommodation have resulted in a robust array of commercial instrumentation that spans a wide range of capabilities. This chapter provides a review of the common electron microscopy technologies and techniques.

## **UTILITY OF THE TECHNIQUE**

## **General Description of the Technique**

Scanning electron microscopy (SEM) is an electron optical imaging technique that yields both topographic images and elemental information and is used in conjunction with a variety of detection systems and elemental detectors. All electron microscopy systems utilize a high energy, focused electron beam as source illumination with concurrent increase in resolution compared to photon (light) microscopy. The resolution increase is realized by electron beam wavelength being three orders of magnitude smaller than that of visible light. The optics consist of condenser and objective lenses in conjunction with selected apertures. A focused e-beam is rastered over the surface of a specimen, generating a variety of signals from which an image is collected.

## **Traditional High Vacuum SEM**

Traditional SEM systems operate at high vacuum, so specimens must be clean, dry, and able to withstand imaging at high vacuum, up to 10<sup>-6</sup> torr. Additionally, the specimens must be inherently conductive or coated to conduct the high surface charges. Four general principles of these systems are:

- e-beam generation
- image formation
- specimen preparation
- elemental composition.

Typically, SEM analysis requires only a small amount  $(10^{-3} \text{ to } 10^{-12} \text{ g}, \text{ depending on the application})$  of a solid specimen. The specimen is presented to the collimated e-beam and scanned in a controlled raster pattern. Images, or micrographs, are generated using secondary electron (SE) and/or back-scattered electron (BSE) detection. Specimen detail may be resolved to 10 nm even in the most simple systems. The collimation of the e-beam also yields great depth of field that is evident in a wide dynamic range of magnification, practically spanning five orders of magnitude (5×–100,000×).

The size of the final aperture controls the beam diameter and, accordingly, the image resolution and total current at a specimen. Small apertures are required for high resolution and large apertures provide high current for optimal X-ray emission intensity. In many systems, the objective aperture can be adjusted during use with a sliding or rotating holder. Flexibility in trading resolution for specimen current is also important because specimen characteristics affect these two criteria differently.

Image magnification is controlled by altering the area of the electron beam raster; smaller areas yield higher magnification. An Everhart-Thornley (ET) detector is used for electron detection; the resultant images are most similar to those of reflected light microscopy. An ET detector consists of a Faraday cage and a scintillator disk connected by a light pipe to a photomultiplier tube. The Faraday cage serves three functions: (1) at positive bias it attracts SE; (2) at negative bias it repels SE to enable the ET detector to collect BSE signals alone; and (3) it shields the primary electron (PE) beam from the scintillator potential. Various scintillator coatings are used. For example, phosphorus-based coatings yield intense, high-contrast images. Aluminum-based coatings, although less sensitive, can withstand the high SE flux generated during elemental analyses. Additionally, solid-state detectors provide up to 10 times greater sensitivity for BSE collection. They can be placed at a variety of positions and distances with respect to a specimen and used in conjunction with ET detectors.

## Variable Pressure or Environmental Scanning Electron Microscopy (ESEM)

Robust and common variations of the traditional high vacuum system prevail in today's labs. So-called variable pressure, "environmental" or low vacuum systems (LVSEM) appeared in the mid 1980s. These are electron microscope systems operating at a much higher, near ambient pressure state (up to 50 torr) at the specimen site, plus gas over-blanketing (almost any may be used) and temperature control to 1500°C as well.

Theré are two key advantages for ESEM's: First, non-conducting samples do not require a conductive carbon or metal thin film to be applied. The gas in the sample chamber is ionized by the electrons generated from the beam/sample interaction. These ions will diffuse to the sample surface, thereby dissipating any negative charge buildup. Secondly, if the sample in question is prone to outgassing volatile substances such as solvents and water, the near-ambient pressures used in the sample chamber can greatly diminish the likelihood of this occurring.

Dec-2014 Document Type: GENERAL CHAPTER

2

## **Scanning Transmission Electron Microscopy**

The combination of a traditional transmission electron microscope system with scanning control yields specimen analysis with high micrograph resolution, information at the atomic scale such as atomic structure, chemical information, and interfacial bonding. Image acquisition is conducted in the same manner as SEM; however, use of thin specimens allows collection of transmission images as well. Great increase in resolution is attained by controlling the e-beam probe volume, to atomic dimensions. Figure 1 shows the lattice image of a ceramic that was obtained using a scanning transmission electron microscopy (STEM) instrument. As with any electron- or ion-beam method, the sample must be able to withstand the electron bombardment. This may not always be the case with pharmaceutical materials, as they can degrade in the e-beam during the analysis.




Figure 1. Scanning transmission electron micrograph of an oxide ceramic (perovskite), shown in both dark field (left) and bright field (right) imaging modes. Image courtesy of "... © Carl Hanser Verlag, Muenchen".

### **ELECTRON BEAM GENERATION**

The basis for the formation of an electron image is the generation of an energetic flux of electrons that impinge upon the sample surface. If the beam is too energetic, the sample will be burned as the beam is rastered across the sample's surface. This is an important consideration when analyzing pharmaceutical materials.

Electron guns can be classified into two types: thermionic emitters and field emitters. With the former, the filament is heated under high vacuum, and a large potential is applied. The field that is created, combined with the heated filament, "boils" off electrons that are subsequently focused in the microscope optics. To increase the flux of electrons from thermionic emitters, one must increase the potential that is applied across the filament, which also increases the kinetic energy of the electrons and the likelihood that the sample surface will be burned.

Another method used to produce electronic beams is to apply a large electric field across an electronic emitter. The filament can have a current passing through it or not. Where surface damage is a prime consideration, cold emitters are the best way to obtain a clear image at high magnification without burning the surface or damaging the material. Typically tungsten is used as the electron emitter, as it is strong enough to withstand the mechanical forces. When using a field emission gun, the cathode must be kept at very high vacuum, and no foreign contaminants must be allowed to deposit on the filament. For these reasons, the column must be differentially pumped. Field emission instruments are better suited for the analysis of pharmaceutical compounds, as they produce a very bright beam that is less damaging to the sample. Additionally, field emission electron SEMs have higher spatial resolution, making them better suited for the identification of foreign particulate matter.

## **Electron Beam–Sample Interactions**

Interaction of the electron beam (PE) with the specimen produces a variety of physical phenomena that, when detected, are used to form images and provide elemental information about the specimen. These phenomena include:

- · emission of inelastic scattered secondary electrons (SE), proportional to specimen topography
- reflection of elastically scattered back-scattered electrons (BSE), proportional to the atomic number (Z) of the specimen
- component X-ray emission (XRE, X in Figure 2)
- emission of Auger electrons (AE)
- cathodoluminescence (CL)
- conduction of current (specimen current)
- charging from induced voltages (IV) or adsorbed electrons

@2021 USPC

Official Date: Official as of 01-Dec-2014

3

- · electron transmission
  - heat generation
  - electromotive forces (see Figure 2).




Figure 2. Interaction diagram.

SE are emitted from a specimen surface as the result of inelastic collisions between primary (incident) electrons and the specimen. When the energy imparted to a specimen electron exceeds the work function of a specimen, that electron is emitted as SE. Most secondary electrons have energies of 5–20 eV; electrons in this low-energy range can be efficiently collected, yielding high signal-to-noise images. Because such low-energy electrons can penetrate only short distances through the specimen, SE originate from within 2–30 nm of the surface and generate highly resolved images. The actual e-beam penetration depth is dependent on e-beam accelerating voltage, specimen elemental composition, specimen density, and specimen mounting angle. Excitation volumes of 0.5–5 µm in diameter (dark gray) are typical for a wide range of materials from metallic to biological.

Back-scattered electrons are primaries that have been reflected from the specimen. The primary electrons can undergo multiple collisions prior to exiting from the specimen; therefore, BSE have energies over a broad range and emerge from relatively deep specimen penetration (≈0.1–5 µm) (see Figure 3).


Official Date: Official as of 01-Dec-2014

Document Type: GENERAL CHAPTER

@2021 USPC

Printed by: Le Tran 4





# Excitation volume is dependent upon accelerating voltage and material density

Figure 3. Bulk penetration.

These high-energy (15–25 keV) BSE are collected less efficiently than SE, and they yield images with poorer resolution. The efficiency of BSE reflection is a function of the atomic number (Z) of the specimen atoms; thus, the contrast of BSE images depends on elemental composition. The penetration depth of all electrons is affected by elemental composition, specimen density, specimen tilt, and incident beam energy (accelerating voltage). There are a number of software algorithms to correct for these influences, when known such as ZAF, Bence-Albee, etc. For example, the SE images of sodium phosphate and zinc phosphate crystals are quite similar. However, the heavier nuclei of the zinc species produce more efficient BSE reflection, and BSE images will reveal higher contrast. BSE images of heavy- versus light-element phases, or mixtures of species, show dramatic contrast differences that are representative of elemental heterogeneity. Elemental mapping by energy dispersive X-ray spectroscopy (EDS), discussed later, can provide complementary information.

#### SAMPLE PREPARATION

As scanning electron microscopy has advanced as an analytical technique, different options have become available for sample preparation. Ideally, the objective is to obtain the required image or chemical analysis of the material to be examined with as little intervention as possible. Additionally, one must consider the purpose of the analysis and the amount of material that is available. If the material to be examined is a foreign particulate in a parenteral product, sample preparation could be quite different than if one is intending to image a bulk drug substance material or excipients. The decision tree (see Figure 4) below represents a simplified version of the available sample preparation method and is one possible construct to determine the appropriate sample preparation method.

For example, in addition to metal (primarily aluminum) sample stubs there are also various metal meshes that can be used to support samples. If the particle in question is isolated from liquid, the filter itself may serve as a suitable substrate for the powder without having to transfer the sample to another sample holder. Additionally, adhesive carbon tabs are a common means to secure the sample to the stub. There are a variety of other adhesive materials such as double-sided copper, silver and aluminum tape, or carbon and silver paint for this purpose.

### Sample Coating

Historically, pharmaceutical materials, which are typically poor electrical conductors, had to be coated with a very thin layer of conductive material (carbon, gold, platinum, or other metals) to ensure that the electron beam used for imaging could be

Official Date: Official as of 01-Dec-2014

Docld: 1\_GUID-9E4C5824-3F98-4E82-A79F-D38EA11AD2A3\_1\_en-US

Document Type: GENERAL CHAPTER

@2021 USPC

5

dissipated from the sample surface. Coating was also used to create a layer of "electron rich" material that would serve as a source for secondary electron emission.

With the advent of environmental scanning electron microscopy (ESEM) or variable pressure scanning electron microscopes, coating of non-conductive materials is no longer a prerequisite. The atmosphere in the sample chamber itself generates positively charged ions that will dissipate any charge that accumulates on the sample surface.



Official Date: Official as of 01-Dec-2014

Document Type: GENERAL CHAPTER

@2021 USPC




Figure 4. Decision tree for SEM sample preparation.

@2021 USPC 7

## X-RAY GENERATION AND ELEMENTAL COMPOSITIONAL ANALYSIS

When a PE encounters an orbital electron in an atom, the resultant collision can either promote that orbital electron to a higher energy level or ionize the atom. Stabilization of an atom by relaxation of a higher energy electron to fill a vacancy results in the emission of an X-ray photon. These X-ray energies are discrete and element-specific; they equal the differences between the shell electron energies for the various shells of a given element. For instance, an ejected K-shell electron can be stabilized by a higher energy L-shell electron, yielding a net energy ( $E_L - E_K$ ), which is specific for the X-ray photon energy of the elemental K line. X-ray emission lines are classified according to the electron shell in which the vacancy existed, e.g., K, L, M. The lines are further categorized according to the shell from which the relaxing electron originates. Thus, a Kα X-ray line will arise from a vacancy in a K-shell that is filled from an L-shell; a  $K\beta$  X-ray line will arise from a K-shell vacancy filled from an M-shell, and so on (see Figure 5).




Figure 5. Atom model.

Detection of the generated X-rays and subsequent elemental analysis of the feature of interest can be accomplished by two different kinds of detectors: wavelength and energy dispersive X-ray spectrometers (WDS and EDS, respectively). Each has its individual benefits and challenges. Historically, wavelength dispersive detectors are much less susceptible to spectral artifacts that can create incorrect peak identification such as peak broadening and distortion, silicon escape peaks, absorption, etc. Additionally, most Si(Li) EDS detectors require liquid nitrogen cooling, which can cause ice build-up on the detector window in the sample chamber. The much larger EDS collection angle makes it more robust and less susceptible to detector misalignment than WDS. Figure 6 illustrates the superior spectral resolution that is obtained with WDS. With WDS, it is much easier to detect characteristic X-rays that are energetically similar. The EDS exhibits peak broadening due to the close proximity of the peaks.

Official Date: Official as of 01-Dec-2014

Document Type: GENERAL CHAPTER

@2021 USPC

Printed by: Le Tran 8




Figure 6. Example of spectral resolution obtained with wavelength-dispersive detectors where S  $K\alpha$  and Mo  $L\alpha$  can be clearly resolved by WDS (gray peaks) but are not resolved by EDS (broad yellow peak). "Used by Permission. Courtesy of Oxford Instruments.'

Advantages of EDS reside in the ease of use and speed to collect the entire X-ray spectrum making it ideal for the routine identification of particles and features within a sample. The two types of detector technology most widely available for energy dispersive X-ray spectroscopy (EDS) analysis are based on lithium-drifted silicon [Si(Li)] and silicon drift technology. While Si(Li)

@2021 USPC

Official Date: Official as of 01-Dec-2014

Document Type: GENERAL CHAPTER

detectors have been around for the last 40 years, silicon drift detectors (SDD) have recently emerged as the preferred type due to several key advantages including better detection of light elements ( $Z \ge 4$ ), ability to handle high count rates, excellent energy resolution even at high count rates, and even elimination of the need for liquid nitrogen to cool the detector prior to use due to the use of Peltier cooling systems. While Si(Li) detectors were generally recommended to be run at 1,000–2,500 counts per second with an energy resolution of 129 eV at Mn-Ka, current SDD technology has superior energy resolution of 121 eV even at the high count rate of 600,000 cps. For the average user, this means that the SDD detector may drastically shorten analysis time provided that a high count rate may be obtained and with significantly better resolution for detection of light elements. In practicality, the achievable count rate is determined by the accelerating voltage and probe current, solid angle of the detector and working distance to the sample, and ability of the sample to survive the electron beam without charging or material change. Whether the user has an Si(Li) or SDD detector, it is a good rule of thumb to keep the dead time to 30% or below.

The elemental content of a specimen has a bearing on the selection of conditions for analysis. The most useful range of accelerating voltage is approximately 3–20 kV; most elements of interest can be ionized by electrons with energies in this range. The energy required in order to excite X-ray emission from a given line is termed its critical excitation potential. The critical excitation potential for a K line can be approximated by the sum of the primary line energies  $(K\alpha + L\alpha + M\alpha)$ . Selection of an accelerating voltage equal to 1.5 times this sum is usually sufficient for semi-quantitative analysis. For example, copper has  $K\alpha$ at  $8.05 \text{ keV} + L\alpha$  at 0.93 keV = 8.98 keV: and  $1.5 \times 8.98 \text{ keV} = 13.47 \text{ keV}$ . Selection of 15-kV accelerating voltage yields sufficient energy to ionize the K-shell of copper atoms and generate a useful analytical signal. It is generally suggested that EDS practitioners should use the minimum accelerating voltage necessary to adequately excite the elements of interest (typically 1.5–10 times the critical excitation energy). The interaction volume increases with increasing accelerating voltage, thus better spatial resolution can be achieved by using lower accelerating voltage. Depending on the dimensions and density of the particles, a signal from the substrate may be detected. Additionally, larger interaction volume causes increased absorbance and fluorescence within the sample volume. Several accelerating voltages may be experimented with to determine the minimum accelerating voltage required. Routine use of a copper and a lighter metal standard such as aluminum allows quick verification of elemental primary line energies bracketing the 0- to 10-keV range. An elemental collection for the metal standard prior to or within the experimental protocol is conducted to verify the primary line is ±0.04 keV of reference (but may depend upon the detector manufacturer specification). This is a practical internal standard practice.

Inter-element interferences originate from many effects. High-energy X-rays emitted from heavy atoms can ionize lighter elements to produce secondary X-ray emission from the lighter species. Lower high-Z element fluorescence and higher low-Z element fluorescence can be observed, in contrast to that expected from the PE-induced signal of a pure element. Conversely, X-ray emission from a light element may be absorbed by a heavier matrix to yield a negative bias in the light-element signal. These effects always exist in heterogeneous specimens and must be corrected for during any quantitative analysis. A common algorithm, ZAF, may be used to correct for Z-dependent interferences due to absorption and secondary X-ray emission.

Point analysis and mapping are common analysis modes available for the identification of particles by EDS regardless of detector type. Most modern user interfaces allow the user to view a region of interest with secondary electron imaging and collect a spectrum for the entire region or a defined sub-region. Upon collecting an initial spectrum, it is important the user check that it appears satisfactory in terms of energy range for the elements present, optimum count rate, and is free from artifacts such as charging. Once optimized for collection, the user can choose their preferred analysis mode to identify their sample. Point analysis is generally useful if different particle morphologies can be readily observed by SEM. The user can place a cross-hair at the center of each particle to collect a spectrum for later comparison. Care should be taken for the analysis of particles less than 5 µm since the interaction volume may spread in the sample combined with the beam/sample interaction and can excite electrons from the surrounding environment. This will produce spectral peaks that are not native to the feature of interest. For this reason, chemical analysis of small objects in an SEM is difficult. Other more surface-sensitive techniques such as X-ray photoelectron spectroscopy (XPS), scanning auger spectroscopy, and others provide more accurate spectral information. Orthogonal analysis, both within and outside any given technique, is of great value.

When there is no obvious morphological difference for a collection of particles, EDS mapping may be the best mode of analysis. In this mode, the EDS detector collects information as the electron beam rasters across the sample, thus the elemental information is in registry with the SE/BSE image. The user can define the region of interest from the entire region observable in the SE/BSE image to a sub-region. Additionally, the user can define the scan speed, dwell time/pixel, and resolution of the map to suit their needs in terms of speed or resolution. A significant factor to consider for EDS mapping is that the X-ray signal will vary based on the surface texture and slope of the particle's surface. In the most severe case, a shadow may be observed if that surface is no longer within the line of sight of the detector. It may be possible to minimize these artifacts due to tilting the sample further towards the detector. It is often useful to map the elements of interest versus an element that does not exist in the sample. The X-ray counts for the non-existent element should provide a uniform background across the entire region if the surface is level.

Examples of elemental maps overlaid on the SE image are shown in *Figure 7*. The first image (*Figure 7*, left) shows maps for barium and potassium overlaid on the corresponding SE image, thus showing that the particles represent an inhomogeneous mixture of barium/potassium precipitates (left). For the second example, EDS mapping was used with Cryo-SEM to examine a cryo-fractured silicone/water emulsion where the Si map represents silicone and the O map represents water. The internal structure of a large silicone droplet within a continuous water phase can be observed in *Figure 7* (right) where it is apparent the silicone droplet contains several internal water droplets. Many current EDS interfaces allow the user to extract a spectrum from any location within the map.

Document Type: GENERAL CHAPTER

Printed by: Le Tran 10




Figure 7. Left: Potassium and barium maps overlaid on the SE image of a mixed potassium/barium precipitate. Right: Oxygen and silicon maps overlaid on SE image of a vitrified silicone/water emulsion.

## **IMAGE OPTIMIZATION**

Instrumental parameters needed to acquire a quality image can be highly dependent on sample type and sample preparation. Some important aspects with regard to the sample include the form (powders, monoliths, fibers, vitrified liquids, etc.), overall dimensions, texture, atomic composition, and inherent conductivity. Since many instrumental parameters for a modern SEM can be readily modified with the PC-based user interface with only slight re-optimization, it is highly suggested that the operator experiment with operating conditions in order to choose the best imaging conditions for the features of interest. Parameters that affect image quality can be further categorized as instrumental settings and observation settings.

Common instrumental settings that may affect image quality include accelerating voltage, emission current, working distance, SE/BSE detectors (if multiple modes are used), condenser lens current setting, and objective lens aperture diameter. Of these, the accelerating voltage may be the most important instrumental parameter since it directly affects the penetration depth of incident electrons thereby determining the features that can be observed. In general, choosing the optimal accelerating voltage is a balance of achieving the best contrast for the features that the user is most interested in, while minimizing unwanted effects such as loss of topographic information or charging. The best approach to choosing an ideal accelerating voltage for an unknown sample is to experiment with up to 3 accelerating voltages (e.g., 1, 3, and 10 kV), then choose the best one to continue to further optimize the image. The working distance and choice of SE/BSE detector are normally chosen in combination depending on the desired resolution, depth of focus, and sample tilt. Generally, shorter working distances result in higher resolution but less depth of focus. Likewise, based on the position the SE detectors are placed in the column, a tradeoff exists for spatial resolution versus surface topography, where upper detectors generally detect a high resolution SE signal and lower detectors show more surface topography. Lastly, the condenser lens setting and objective lens aperture diameter can be optimized to provide the ideal specimen current, resolution, and depth of focus required for a specific sample type.

Upon choosing an initial set of instrumental conditions as mentioned above, basic image observation can be optimized in the following manner:

- 1. Select a low magnification (1000-3000×) initially
- 2. Course adjust image brightness
- 3. Course adjust focus
- 4. Select an easy-to-visualize area of the specimen
- 5. Check/adjust to optimize the electromagnetic alignment of the electron optics (beam, aperture, stigmation)
- 6. Select a feature of interest at higher magnification
- 7. Adjust focus and astigmatism
- 8. Adjust image brightness and contrast
- 9. Collect image.

Image collection can be accomplished using different resolutions (1280 × 960 is most common) and capture speeds using either slow scan collection or frame integration. In general, slow scan collection is used to collect high-resolution images whereas frame integration is used for specimen types that have charging or stability issues. A collection using a higher capture resolution, slower scan speed, or additional frames may improve the image resolution, however the user must take caution of the increased likelihood of specimen drift over this period which would negate any benefit.

Document Type: GENERAL CHAPTER

11

@2021 USPC

Official Date: Official as of 01-Dec-2014

## **FORENSIC ANALYSIS OF PARTICLES**


## **Shape Analysis**

Because of the three-dimensional nature of images obtained via scanning electron microscopy, particle shape provides a great deal of information about the composition and source of the particle without obtaining a chemical analysis via EDS.

The most commonly identified particles found in pharmaceutical compounds generally fall into several distinct categories. Note that particles in parenteral products arise from three general sources: (a) extrinsic or outside of the product, as truly foreign solids; (b) intrinsic or associated with the product, its package or manufacture; (c) inherent particles expected to compose the formulation, such as proteins in biotherapeutic products (see Subvisible Particulate Matter in Therapeutic Protein Injections (787)), and may be encountered when probing those formulae. Some examples of extrinsic particles are the following:

- Corrosion products from one or more equipment sources, and may occur from formulation interaction
- Materials from the manufacturing environment such as cellulose (from paper bags), extraneous fibers (clothing, filters,
- Inhomogeneities in the product, specifically incomplete mixing (for solid oral dosage products) that can create cosmetic or elegance issues with tablets
- Environmentally-sourced biological materials
- Material that has been exposed to extreme heat that might char. The causes for this can vary from paper pyrolized during depyrogenation to material sticking to components that are exposed to friction (powder milling, compaction, etc.). If residue unintentionally builds up in these areas, the exposure to friction can decompose the material, making it appear

Figure 8 shows representative images of some of the particulate matter mentioned above that the user might encounter in a forensic investigation.



Official Date: Official as of 01-Dec-2014

Document Type: GENERAL CHAPTER

@2021 USPC

Printed by: Le Tran 12




Figure 8. Scanning electron micrographs of commonly found particles in pharmaceutical manufacturing areas: A. cotton

13

@2021 USPC

Printed by: Le Tran

Official Date: Official as of 01-Dec-2014

Document Type: GENERAL CHAPTER

fibers, B. glass particles, C. Teflon shavings, D. aluminum shavings. (All of the images provided courtesy of McCrone Atlas (www.mccroneatlas.com.)

Interpretation of a particle's origin from characteristics observed by SEM analysis depends on the particle features; for instance, any particle with sharp corners and well-defined edges is made from a material that is not soluble in the product liquid. If it is transparent to the beam, then the user could conclude it consists of very low Z elements. Crystalline particles exhibit obvious symmetry and growth patterns. Slow growth is characterized by large crystals and fast growth by small, often aggregated crystal masses.

Particle morphology and surface characteristics may be helpful in sourcing unknowns. Aspect ratio, or the ratio of the length of a particle divided by its width, indicates fibrous materials. Analysis by optical microscopy often serves as a more effective tool to analyze fibers by determining diagnostic optical properties (refractive indices, birefringence, elongation, etc.) using plane and crossed polarized light that can distinguish among various possible sources. With a scanning electron microscope, however, elemental analysis can determine (a) if the fiber is inorganic or organic and (b) the presence of surface additives. Scanning electron microscopy also offers the added benefit of being able to image at much higher magnification to reveal morphological structures of biological origin or features indicative of commercial manufacture.

As mentioned previously, different kinds of electrons are emitted when an electron beam interacts with a solid surface. The two most useful types of electrons are secondary and back-scattered. By choosing the appropriate detector or instrument set up, the image can be biased towards one or the other. Back-scattered electrons can provide useful information regarding the chemical composition of the feature in question. If the instrument is set up to use BSE to form the image, elements possessing higher atomic mass will appear brighter than those having a lower atomic mass. By selecting this imaging mode, organic particles are easily distinguished from metallic debris, for example. For instance, at low kV, glass or plastic may appear as solid objects, whereas at higher kV they may appear somewhat transparent. Further, appearance at low kV on a tungsten filament SEM may mean something completely different than that at low kV on an FE SEM or environmental SEM. Different materials require different operating conditions to suitably image using SE, to prevent charging and to improve contrast. Typically, use low kV (3 kV or less using a semi-in-lens or in-lens FE SEM) for non-conductive materials such as glass and plastic. If the material is extremely thin (<100 nm), the material can be visualized in transmission mode (STEM) as well as SE mode.

### GENERAL REFERENCES

- 1. Goldstein, J., et al., Scanning Electron Microscopy and X-ray Microanalysis. Third ed. 2003, New York: Springer.
- 2. Echlin, P., Handbook of Sample Preparation for Scanning Electron Microscopy and X-ray Microanalysis. 2010, New York: Springer. 330.
- 3. Reimer, L., Scanning Electron Microscopy: Physics of Image Formation and Microanalysis. Springer Series in Optical Sciences, ed. H.K.V. Lotsch. Vol. 45. 1998, New York: Springer.