

1 ITEM NOT SHOWN

(14)

3

- NOTES:
 1. USE EPOXY ADHESIVE (MIS1004) TO SECURE TRIM SIDE RAIL (EXT1005) TO EXTRUDED HEATSINK (EXT1003).
 2. USE THERMAL ADHESIVE TAPE (MIS1002) TO SECURE LED PCB (PCB1002) TO EXTRUDED HEATSINK (EXT1003).
 3. REFERENCE 3D MODELS AND PCB DESIGN FILES AT:
- https://github.com/Faust-Lighting



CRR 3/5/17 DIMENSIONS ARE IN INCHES TOLERANCES:
FRACTIONAL±1/64
ANGULAR: ±1.00
TWO PLACE DECIMAL ±.01
THREE PLACE DECIMAL ±.005

SIZE DWG. NO. ASM1001 0.2 SCALE: 1:2 SHEET 1 OF 1