

- armaMeasurement
  - isInitialized
  - armaSpeed
- isEnabled
- + addMeasurement() + noMeasurementsAvailable()

+ enableArmaFilter()

- + calculateRssi() + setArmaSpeed()
- + getArmaSpeed()