## Official firmware/driver & notes (handy links)

- Broadcom/LSI MegaRAID 5.x/6.x firmware history (covers 9340/9361 families).
  Broadcom
- Where to find latest Broadcom MegaRAID software/drivers. <u>Broadcom</u>
- Dell PERC H740P firmware package **51.16.0-4076** (current as of Dell page). Dell
- Dell Windows Server 2025 PERC driver 7.730.02.00 (H740P/H840/H7xx/H7x5/H75x/H35x). Dell
- HPE Smart Array P408i-a firmware package (Gen10 controllers) + release notes. <u>HPE Support+1</u>
- Intel VROC release notes (Windows v8.0 series; ESXi driver 9.0.0.1021).
  downloadmirror.intel.com+1
- LSI 9361-8i firmware (example Dell-hosted package 24.3.0-0049). Dell
- Broadcom MSM/MegaCLI/storcli download hub (tools you'll use for screenshots + versions). <u>Broadcom</u>
- (Bonus) HPE iLO Gen10 firmware guide noting Smart Array status fixes—useful when correlating array health in screenshots. HPE Aruba Networking

## "Raw RAID notes" — checklist to capture for each run

- Platform: chassis, backplane, BIOS/UEFI rev, CPU, RAM, PCle slot/width, power profile.
- **Controller/VROC:** model, cache size/type, **firmware** (exact package), **driver** (module + version/build), battery/CacheVault status, readahead/write policy.
- **Array config:** RAID level, stripe/chunk size, number of drives, drive model/firmware, secure erase/TRIM state, initialization (BGI/CC/rebuild idle).
- **OS stack:** kernel/build, scheduler, NVMe/megaraid\_sas/hpsa/vroc versions, multipath/offload settings, filesystems and mount options.
- **Workloads:** tools/versions (fio, vdbench, diskspd), block sizes, queue depths, runtime, warmup, threads, alignment, direct I/O vs buffered.
- Metrics: seq R/W MB/s; rand 4K/QD1 & QD32 IOPS; average/99th latency; CPU utilization; cache hit % (if available); thermals.
- **Health/events:** SMART before/after, CC/BGI status, patrol read, error counters.
- **Screenshots filenames:** tie each to the row in the log (e.g., 2025-09-07\_H740P\_RAID10\_8xSAS\_WB.png).

## Screenshots to grab every time

- Controller summary (MSM/SSA/VROC GUI) showing **firmware**, **cache policy**, **battery**, and **driver**.
- Array properties panel (RAID level, stripe size, read/write policy).
- Background tasks (BGI/CC/rebuild) status page.
- OS device view:
  - Linux: lspci -nn, uname -a, modinfo megaraid\_sas|hpsa|vmd, storcli show all/ssacli ctrl all show config.
  - Windows: Device Manager → Storage controllers + Driver Details;
    Get-PhysicalDisk, Get-Volume.
- Benchmark tool output (fio/diskspd) including the full command line.

## How to fill the driver/firmware fields quickly

- **Broadcom/LSI (9361-8i):** use storcli /c0 show all and cross-check versions with Broadcom's firmware history & Dell's package page. <u>BroadcomDell</u>
- **Dell PERC H740P:** perccli /c0 show or iDRAC; compare to Dell's 51.16.0-4076 page & Server 2025 driver page. Dell+1
- **HPE P408i-a:** ssacli ctrl slot=0 show detail and HPE package notes. <u>HPE Support+1</u>
- Intel VROC: UEFI VROC page or Windows VROC GUI "About"; align with Intel's Windows/ESXi release notes.