



Window Type Air Conditioner


Models

MAW08V1QWT

MAW10V1QWT


MAW12V1QWT

version A – 03 – 2020



Installation Guide

Scan the following QR code for an installation video.



You must follow the user manual for detailed installation instructions. Before using your air conditioner, please read the user manual carefully and keep for future reference. For additional support, please call version A – 03 – 2020 customer service at 1-[866-646-4332](tel:866-646-4332).


Contents [[hide](#)]

- [1 TOOL & HARDWARE](#)
- [2 WINDOW REQUIREMENTS](#)
- [3 INSTALL THE SUPPORT BRACKET](#)
- [4 INSTALL THE SUPPORT BRACKET \(cont.\)](#)
- [5 SECURE THE UNIT ON THE BRACKET](#)
- [6 SEAL AND CLOSE THE WINDOW](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



TOOL & HARDWARE

Required Installation Hardware

	1/2" Type B Screw	2
	1/4" Type B Screw	2
	Main Bracket	1
	Right Extension Arm (For 26"-36" windows)	1
	Right Extension Arm – Short (For 22"-26" windows)	1

	Main Support Pin	2
	Cotter Pin	2
	1/2" Type A Screw	3
	Open Window Bracket – RH	1
	Open Window Bracket – LH	1
	Side Arm Foam	2

Optional Installation Hardware





	Window Sash Lock	1
	Thick Window Sash Seal Foam	1
	Thin Window Sash Seal Foam	1
	Miscellaneous Sealing Foam	1
	Additional Side Arm Foam	2
	1" Type A Screw	2



WARNING

Do not use any devices or materials for installation that are not recommended in this manual.

WINDOW REQUIREMENTS




NOTICE

Maximum window thickness including non-removable handle: 2-7/8"


INSTALL THE SUPPORT BRACKET

! WARNING

- Bracket should only be used for its intended purpose. If not, the warranty will be voided.
- You must follow the detailed installation instructions in the user manual.




- 1.1 Adjust the left extension arm out and install the right extension arm. Set the bracket in your window.





! WARNING

Maintain control of the bracket until installation is complete.




- 1.2** Adjust the angled support arms until they touch the exterior wall. Check that the bracket is properly tilted downwards toward the outdoors. Install the support pins and cotter pins then extend the left and right extension arms.




INSTALL THE SUPPORT BRACKET (cont.)

- 1.3** Secure the bracket to the window with a screw at the end of each extension arm as shown. Holes at the end or bottom of the Extension Arms can be used to secure the Support Bracket to the window.



SECURE THE UNIT ON THE BRACKET


- 2.1** Set the air conditioner on the support bracket and fold down the sidearm hinges.



WARNING

Do not leave the unit unattended during installation.

2.2 You must install the Open Window Brackets.




! WARNING

Failing to do this could cause injury or property damage.

SEAL AND CLOSE THE WINDOW


3.1 Measure, cut and install the side arm foam.



WARNING

Do not leave the unit unattended during installation.

3.2 Secure the anti-tip brackets into the window track and then close the window.



WARNING

You must extend the Anti-Tip Brackets into the Window Track Opening. Failure to follow this warning may cause serious injury.

3.3 Use the included foam to seal any gaps between the window and the air conditioner.



3.4 Extend both window locks located in the window slot. For additional security, install the window sash lock.

Midea MAW08V1QWT Window Type Air Conditioner -- Extend both window

FAQ Why does the air conditioner not start?

- Wall plug disconnected. Push plug firmly into a wall outlet.
- House fuse has blown or circuit breaker tripped. Replace the fuse with time delay type or reset circuit breaker.
- Check if the light on the plug is on. If it is off, press the RESET button.
- Power is OFF. Turn power ON.

FAQ Why is there noise during cooling?

- It is normal to hear airflow, set to a slower fan setting if too loud.
- Window vibration – poor installation. Refer to installation instructions or check with the installer.

FAQ Unit will not connect to Wifi or App does not work?

For additional support and troubleshooting tips, follow the link in this QR code.



<https://l.ead.me/bbO81S>

Documents / Resources

	Midea MAW08V1QWT Window Type Air Conditioner [pdf] Installation Guide MAW08V1QWT, MAW10V1QWT, MAW12V1QWT, Window Type Air Conditioner
---	---