Generator GEN-15 Service Manual

1. Specifications

The GEN-15 generator has a rated output of 15 kW.

The generator produces 230 V single-phase and 400 V three-phase power.

The operating frequency is 50 Hz.

The fuel tank holds 60 liters of diesel.

2. Maintenance schedule

Change the engine oil every 250 operating hours.

Replace the oil filter every 500 operating hours.

Change the coolant every 1000 operating hours.

Check the battery electrolyte level every month.

3. Error codes and warranty

E01 means low oil pressure. Stop the engine and check the oil level.

E02 means high coolant temperature. Check the coolant level and radiator.

E03 means generator overvoltage. Check the automatic voltage regulator.

To reset the controller, turn the key to OFF and wait 30 seconds.

The warranty period is 24 months for the generator.