Air Compressor AC-75 Service Manual

1. Specifications

The AC-75 compressor has a 75 kW motor.

The maximum discharge pressure is 10 bar.

The free air delivery is 500 CFM.

Use ISO VG 46 compressor oil.

2. Maintenance

Change the compressor oil every 2000 operating hours.

Replace the oil filter every 500 operating hours.

Drain the condensate from the receiver tank daily.

Inspect the drive belt every 250 operating hours.

3. Troubleshooting and warranty

High discharge temperature usually means a blocked oil cooler.

A pressure drop usually means a leak in the air line.

To reset the compressor, press the red reset button for five seconds.

The warranty period is 24 months for the compressor unit.