Typical stages in digital signal processing

Dr. Ing. Rodrigo Gonzalez

rodrigo.gonzalez@ingenieria.uncu.edu.ar

Control y Sistemas


Facultad de Ingeniería, Universidad Nacional de Cuyo



Summary

- Why DSP in a the context of control?
- Sampling signals in the frequency domain
- Digital processing of analog signals
- Aliasing prefiltering
- 6 A/D Conversion
- 6 D/A Conversion

Why DSP in a control course?



Periodic sampling

The discrete-time representation of a continuous-time signal is obtained through periodic sampling from a continuous-time signal $x_c(t)$ according to,

$$x[n] = x_c(nT), \quad -\infty < n < \infty, \tag{1}$$

where T is the sampling period, and $f_s=1/T$ is the sampling frequency, or $\Omega_s=2\pi/T$ in radians/s




Figure 4.1 Block diagram representation of an ideal continuous-to-discrete-time (C/D) converter.

Sampling process

It is convenient to represent the sampling process mathematically in the two stages.

- An impulse train s(t) is multiplied by a continuous-time signal x_c(t).
- The continuous-time signal x_s(t) is transformed to a discrete-time sequence x[n].




Figure 4.2 Sampling with a periodic impulse train, followed by conversion to a discrete-time sequence. (a) Overall system. (b) $x_3(t)$ for two sampling rates. (c) The output sequence for the two different sampling rates.

Frequency-domain representation of sampling

 $x_s(t)$ is obtained multiplying $x_c(t)$ by a periodic impulse train s(t),

$$s(t) = \sum_{n = -\infty}^{\infty} \delta(t - nT), \qquad (2)$$

$$x_s(t) = x_c(t) s(t), (3)$$

$$=x_{c}(t)\sum_{n=-\infty}^{\infty}\delta(t-nT),$$
(4)

$$= \sum_{n=-\infty}^{\infty} x_{c}(nT) \, \delta(t-nT) \qquad \text{by sifting property.}$$
 (5)

The Fourier transform of the periodic impulse train s(t) is the periodic impulse train,

$$S(j\Omega) = \frac{2\pi}{T} \sum_{k=-\infty}^{\infty} \delta(\Omega - k\Omega_s), \quad \text{where } \Omega_s = \frac{2\pi}{T}.$$
 (6)

The Fourier transform of $x_s(t)$ is the continuous-variable convolution of $X_c(j\Omega)$ and $S(j\Omega)$,

$$X_{s}(j\Omega) = \frac{1}{2\pi} X_{c}(j\Omega) * S(j\Omega), \qquad (7)$$


$$X_s(j\Omega) = \frac{1}{T} X_c[j(\Omega - k\Omega_s)]. \tag{8}$$

Frequency-domain representation of sampling, II


- Fourier transform of $x_s(t)$ consists of periodically repeated copies of $X_c(j\Omega)$
- These copies are shifted by integer multiples of the sampling frequency.
- It is evident that

$$\Omega_s - \Omega_N \geq \Omega_N$$
, or,

$$\Omega_s \geq 2\Omega_N$$










Figure 4.3 Frequency-domain representation of sampling in the time domain. (a) Spectrum of the original signal. (b) Fourier transform of the sampling function. (c) Fourier transform of the sampled signal with $\Omega_S > 2\Omega_N$. (d) Fourier transform of the sampled signal with $\Omega_S < 2\Omega_N$.

Nyquist-Shannon Sampling Theorem

Let $x_c(t)$ be a bandlimited signal with,


$$X_c(j\Omega) = 0 \text{ para } |\Omega| \ge \Omega_N.$$
 (9)

Then $x_c(t)$ is uniquely determined by its samples $x[n] = x_c(nT), n = 0, \pm 1, \pm 2, ...$ si

$$\Omega_{s} = \frac{2\pi}{T} \ge 2\Omega_{N} \,. \tag{10}$$

The frequency Ω_N is commonly referred to as the **Nyquist frequency**, and the frequency $2\Omega_N$ as the **Nyquist rate**.

Digital processing of analog signals






Figure 4.47 (a) Discrete-time filtering of continuous-time signals. (b) Digital processing of analog signals.

Aliasing prefiltering, motivation




Figure 4.3 Frequency-domain representation of sampling in the time domain. (a) Spectrum of the original signal. (b) Fourier transform of the sampling function. (c) Fourier transform of the sampled signal with $\Omega_S>2\Omega_N$. (d) Fourier transform of the sampled signal with $\Omega_S<2\Omega_N$.

Aliasing prefiltering, example




Figure 9.8 Example of aliasing: a sinusoid at 8400 Hz, $x(t) = \cos(2\pi \cdot 8400t)$ (solid line) is sampled at $F_s = 8000$ Hz. The sampled values (dots) are indistinguishable from those of at 400 Hz sinusoid sampled at F_s .

Aliasing prefiltering

- Even if the signal is naturally bandlimited (as music), wideband additive noise may fill in the higher frequency range, and as a result of sampling, these noise components would be aliased into the low-frequency band.
- (Play video).




Figure 4.48 Use of prefiltering to avoid aliasing.

Oversampling





Figure 4.49 Using oversampled A/D conversion to simplify a continuous-time antialiasing filter.


Oversampling frequency response



gure 4.50 Use of oversampling followed by decimation in C/D conversion.

A/D Conversion Stages

- The A/D converter is a physical device that converts a voltage or current amplitude at its input into a binary code representing a quantized amplitude value closest to the amplitude of the input.
- The sample-and-hold stage can be a zero-order-hold.



Quantizer

- Uniformly spaced quantizer.
- The number of quantization levels will be a power of two (2^N) .





Figure 4.54 Typical quantizer for A/D conversion.

Quantizer Error example






Figure: 12.1 [2]

Quantizer Error example, II




Figure 4.57 (continued) (b) Quantized samples of the cosine waveform in part (a) with a 3-bit quantizer. (c) Quantization error sequence for 3-bit quantization of the signal in (a). (d) Quantization error sequence for 8-bit quantization of the signal in (a).

Quantizer Error model




Figure 4.56 Additive noise model for quantizer.

ADC Signal-to-Noise relationship

The precision of the quantizer is given by [2]:


$$q = \frac{\text{full voltage range}}{2^{\text{word lenght}}} = \frac{2V_{\rho}}{2^{B}}. [mV]$$
 (11)

- $SNR = (P_{signal})/(P_{noise})$ relates two powers.
- Since q is defined as a random variable, its power cannot be represented explicitly.
- A statistical version of SNR is used,

$$SNR_{ADC} = 10 \cdot \log_{10} \left(\frac{\text{input signal variance}}{\text{A/D quantization noise variance}} \right), \quad [dB]$$
 (12)

$$= 10 \cdot \log_{10} \left(\frac{\sigma_{signal}^2}{\sigma_{ADC}^2} \right) . \tag{13}$$

ADC Signal-to-Noise relationship, II



$$\sigma_{ADC}^2 = \int_{-q/2}^{q/2} (e - \mu)^2 p(e) de = \int_{-q/2}^{q/2} e^2 p(e) de = \frac{1}{q} \int_{-q/2}^{q/2} e^2 de = \frac{q^2}{12}, \quad (14)$$

$$\sigma_{ADC}^{2} = \left(\frac{2V_{p}}{2^{B}}\right)^{2} \cdot \frac{1}{12} = \boxed{\frac{V_{p}^{2}}{3 \cdot 2^{2B}}},\tag{15}$$

$$LF = \frac{rms_{signal}}{V_p} = \frac{\sigma_{signal}}{V_p} \implies \sigma_{signal}^2 = \boxed{LF^2 \cdot V_p^2}, \text{ (Load Factor)}$$
 (16)

$$SNR_{ADC} = 10 \cdot \log_{10} \left[\left(LF^2 \cdot V_p^2 \right) \cdot \frac{3 \cdot 2^{2B}}{V_p^2} \right] = 10 \cdot \log_{10} \left[\left(LF^2 \cdot 3 \cdot 2^{2B} \right) \right],$$
 (17)

$$= 10 \cdot \left[\log_{10}(LF^2) + \log_{10}(3) + 2\log_{10}(2) \cdot B \right], \tag{18}$$

$$= 20 \cdot \log_{10}(LF) + 4.77 + 6.02 \cdot B. \quad [dB]$$
 (19)

ADC Signal-to-Noise relationship considerations

$$SNR_{ADC} = 20 \cdot \log_{10}(LF) + 4.77 + 6.02 \cdot B$$
, [dB]
= $20 \cdot \log_{10}\left(\frac{rms_{signal}}{V_p}\right) + 4.77 + 6.02 \cdot B$. [dB]

Considerations about LF:

- Ideally, if rms_{signal} >> V_p, SNR_{ADC} increases, but this will produce a severe distortion in the sampling signal (saturation).
- On the other hand, if $rms_{signal} \ll V_p$, SNR_{ADC} decreases.
- Eq. 19 was obtained for an ideal ADC. Other sources of error should be taken into account.
- Moreover, it was considered that ADC's $V_{MAX} = V_{p}$.
- Therefore, calculated *SNR_{ADC}* should be decreased by 3 or 6 dB.

Considerations about numbers of bits:

- SNR_{ADC} increases 6 dB by each bit in ADC's quantizer.
- So, the more bits the better, isn't it?

ADC Signal-to-Noise relationship for a sinusoidal signal

For a sinusoidal signal, $rms_{signal} = V_p/\sqrt{2}$.

$$SNR_{ADC} = 20 \cdot \log_{10} \left(\frac{rms_{signal}}{V_{\rho}} \right) + 4.77 + 6.02 \cdot B,$$

$$= 20 \cdot \log_{10} \left(\frac{V_{\rho} / \sqrt{2}}{V_{\rho}} \right) + 4.77 + 6.02 \cdot B.$$
(20)

Thus, the maximum SNR_{ADC} is,

$$\textit{SNR}_{\textit{ADC}} = 20 \cdot \log_{10} \left(1/\sqrt{2} \right) + 4.77 + 6.02 \cdot \textit{B} \,, \tag{22} \label{eq:22}$$

$$= -3.01 + 4.77 + 6.02 \cdot B, \tag{23}$$

$$= 1.76 + 6.02 \cdot B$$
. [dB] (24)

ADC resolution for a particular signal

Consider the following example:

- The SNR for an audio output amplifier is 110 dB.
- A 24-bits ADC is chosen to sample the output amplifier (professional audio).

$$SNR_{ADC} = 1.76 + 6.02 \cdot 24 - 3 = 143.24 \text{ dB}$$
.


- How many bits are used to measure noise? $(143 110)/6 \simeq 5.5$ bits!.
- In a control loop, picking a bad ADC resolution could lead to a catastrophic scenario.


Summary: the number of bits in an ADC must match the SNR of the signal to be sampled.

- Rule of thumb: the ADC resolution should be choose in order to provide 6 dB (1 bit) above the SNR of the signal to be sample.
- Additional bits (noisy bits) can be eliminated by right shifting (In C: adc_read >>= 5).

Ideal D/C Converter


- The DAC reverses the ADC process.
- It decodes the signal making a conversion from a bit sequence to an impulse train.






Ideal D/C Converter, II

- The signal is reconstructed with an analog low-pass filter to remove the frequencies about 1/2 the sampling rate.
- After filtering the impulse train with a such a low-pass filter.






 However, the ideal operation just described assumes availability of infinitely many samples. Not realistic!


Zero-order holder

- Practical operation uses only a finite number of samples.
- Many techniques can be used to approximately reconstruct the signal.
- One such technique is a zero-order holder (ZOH).

Modulated impulses




After Zero-Order Holder



Sampling with Zero-order Holder

The impulse response of a zero-order holder.




In the frequency domain:

$$H(f) = F\left\{rect\left(\frac{t - T_S/2}{T_S}\right)\right\} = e^{-j\pi f T_S} sinc(fT_S)$$
 (25)

sinc: cardinal sine function.

Sampling with Zero-order Holder, II

A sampled signal through a zero-order holder:





In the frequency domain:

$$H(f) = F\left\{x_{\delta}(t) * rect\left(\frac{t - T_{S}/2}{T_{S}}\right)\right\} = \frac{e^{-j\pi f T_{S}} sinc(fT_{S})}{T_{S}} \sum_{k=-\infty}^{\infty} X(f - nf_{S})$$
 (26)

Sampling with Zero-order Holder, III

In the frequency domain, the zero-order holder translates into a multiplication of the real signal spectrum by a sinc function!







The zero-order holder produce a gain drop!

Reconstruction Filter

- The reconstruction filter compensates the gain drop.
- It is also known as invert sinc filter (inv sinc).





Reconstruction Filtering Strategies

- 1) Ignore the effect of the zero-order holder and accept the consequences.
- 2) Design a digital filter to remove the sinc effect (pre-equalizing) [4].
- 3) Design an analog filter to remove the sinc effect (post-equalizing) [4].





Figure 4. A pre-equalization digital filter is used to cancel the effect of sinc rolloff in a DAC (a). As an alternative, you can use a post-equalization analog filter for the same purpose (b).

Reconstruction Filtering Strategies, II

4) Oversampling [4].

CD players example:

- In CD players, data sampling rate is 44.1 kHz.
- At 80 % of Nyquist frequency, the output amplitude is attenuated by 2.42dB.
- Data is oversampled by a factor of 8 to 352.8 kHz.
- Now, distortion for ZOH is effectively eliminated.



Bibliografía

- 1 Alan V. Oppenheim and Ronald W. Schafer. *Discrete-time signal processing, 3rd Ed.* Prentice Hall. 2010. Sections 4.1, 4.2, 4.3 and 4.8.
- 2 Richard G. Lyons. Understanding Digital Signal Processing, 3rd Ed. Prentice Hill. 2010. Section 12.3.1.
- 3 Paolo Prandoni and Martin Vetterli. Signal processing for communications. Taylor and Francis Group, LLC. 2008. Section 9.6.
- 4 Maxim Integrated. Equalizing Techniques Flatten DAC Frequency Response. Application Note 3853. August 2012.