

🔧 Full Windows 11 Reinstallation on a DELL Laptop

Description:

A personal laptop (Dell Latitude 14 7400 2-in-1) had been unused for approximately two years. The system was outdated, and the hard drive contained old, irrelevant, and potentially corrupted data. The goal was to perform a clean installation of Windows 11, completely wiping the drive and preparing the system for educational use.

📄 Project Objectives:

- Fully format the internal drive
- Install Windows 11 from scratch
- Reinstall essential system drivers

Item	Value
OS Name	Microsoft Windows 11 Pro
Version	10.0.26100 Build 26100
Other OS Description	Not Available
OS Manufacturer	Microsoft Corporation
System Name	FERNANDO_CRUZ
System Manufacturer	Dell Inc.
System Model	Latitude 7400 2-in-1
System Type	x64-based PC
System SKU	08E2
Processor	Intel(R) Core(TM) i7-8665U CPU @ 1.90GHz, 2112 Mhz, 4 Core(s), 8 Logical Pro...
BIOS Version/Date	Dell Inc. 1.34.0, 3/7/2025
SMBIOS Version	3.2
Embedded Controller Version	255.255
BIOS Mode	UEFI
BaseBoard Manufacturer	Dell Inc.
BaseBoard Product	0HCNR3
BaseBoard Version	A00
Platform Role	Mobile
Secure Boot State	Off
PCR7 Configuration	Elevation Required to View
Windows Directory	C:\WINDOWS
System Directory	C:\WINDOWS\system32
Boot Device	\Device\HarddiskVolume1
Locale	United States
Hardware Abstraction Layer	Version = "10.0.26100.1"
User Name	Fernando Cruz ferna

System Specifications Summary

Item	Value
 System Name	FERNANDO_CRUZ
 System Manufacturer	Dell Inc.
 System Model	Latitude 7400 2-in-1
 Processor	Intel® Core™ i7-8665U @ 1.90GHz, 4 cores, 8 threads
 System Type	x64-based PC
 BIOS Mode	UEFI
 Current BIOS Version	Dell Inc. 1.17.0 →1.34.0 3/7/2025
 SMBIOS Version	3.2
 Baseboard Version	Dell Inc. A00
 Baseboard Product	0HCNR3
 Windows Version	Windows 11 Pro (Build 26100)

▼ Step 1: Downloading Rufus

1. Go to the official website: <https://rufus.ie>
2. Scroll down to the “Download” section.
3. Click the latest stable version (e.g., Rufus 4.5).
4. Rufus is portable; no installation is required.

Create bootable USB drives the easy way



Rufus is a utility that helps format and create bootable USB flash drives, such as USB keys/pendrives, memory sticks, etc.

It can be especially useful for cases where:

- you need to create USB installation media from bootable ISOs (Windows, Linux, UEFI, etc.)
- you need to work on a system that doesn't have an OS installed
- you need to flash a BIOS or other firmware from DOS
- you want to run a low-level utility

Despite its small size, Rufus provides everything you need!

A non exhaustive list of Rufus supported ISOs is also provided at the bottom of this page. ⁽¹⁾

Download

Latest releases:

Link	Type	Platform	Size	Date
rufus-4.8.exe	Standard	Windows x64	2 MB	2025.06.11
rufus-4.8p.exe	Portable	Windows x64	2 MB	2025.06.11
rufus-4.8_x86.exe	Standard	Windows x86	1.9 MB	2025.06.11
rufus-4.8_arm64.exe	Standard	Windows ARM64	6 MB	2025.06.11

▼ Step 2: Download Windows 11 ISO

- Visit: <https://www.microsoft.com/software-download/windows11>
- Scroll down to “Download Windows 11 Disk Image (ISO)”
- Select: Windows 11 (multi-edition ISO) – x64
- Choose your preferred language and download the .iso file.

Download Windows 11 Disk Image (ISO) for x64 devices

This option is for users that want to create a bootable installation media (USB flash drive, DVD) or create a virtual machine (.ISO file) to install Windows 11. This download is a multi-edition ISO which uses your product key to unlock the correct edition.

Windows 11 ISOs for Arm64 devices are available [here](#).

Windows 11 (multi-edition ISO for x64 devices) ▾

Download Windows 11 Disk Image (ISO) for x64 devices

This option is for users that want to create a bootable installation media (USB flash drive, DVD) or create a virtual machine (.ISO file) to install Windows 11. This download is a multi-edition ISO which uses your product key to unlock the correct edition.

Windows 11 ISOs for Arm64 devices are available [here](#).

Select Download ▾

Download - Windows 11 English

64-bit Download



Step 3: Create Bootable USB with Rufus


Plug in a USB drive (minimum 8GB).

Launch Rufus and configure as follows:

Field	Selection
Device	Your USB drive
Boot selection	Choose the Windows 11 .iso file
Image option	Standard Windows Installation
Partition scheme	GPT (for UEFI systems)
Target system	UEFI (non-CSM)
File system	NTFS
Cluster size	Default


Click **Start** → Accept the warning that all USB contents will be erased.

Wait until it says “Ready” or “Done.”




Step 4: Boot and Install Windows 11

1. Insert the USB into the laptop.
2. Power on the device and press F12 to access the boot menu.
3. Select the USB drive to begin installation.
4. Follow the on-screen instructions:




- Choose system language, time, and keyboard layout.
 - Select "Install Windows 11" and agree to erase everything (files, apps, settings).
5. Accept terms and conditions.

6. At the partition screen, delete all existing partitions and proceed.
 - Optional: You can create multiple partitions if needed (e.g., one for Windows, one for files or Linux).



- In this demonstration, a single partition was used for simplicity.

7. Click Next to begin installation (may take several minutes depending on hardware).




⚙ Step 5: Initial Configuration After Installation




After reboot:



- Choose region and keyboard layout




- Connect to a Wi-Fi network




- Decide if the PC is for personal use, work, or school
- Sign in with a Microsoft Outlook account or create one
- Choose whether to recover from backup or start fresh
- Create a PIN or password
- Disable or configure privacy settings (I chose to disable all)
- Windows may ask for your usage preferences (e.g., development, entertainment, school)



Step 6: Post-Installation Setup





1. Go to Settings → Windows Update → Advanced Options
2. Install all pending updates, including optional drivers.



3. Restart the system to apply updates.


Note: My system automatically updated the BIOS during this process.



Create a Restore Point

Always create a system restore point after updates and driver installation.



This serves as a fallback in case of errors or instability.



Step 7: Driver Installation


Dell Support Assistant

- Download and install the Dell Support Assistant from the official Dell website.
- Run the tool and go to Software Updates to install any missing drivers.
- Restart the device after completion.



Snappy Driver Installer (Alternative Tool)

- Download from: <https://sdi-tool.org>
- Use it to scan for additional or outdated drivers.
- Select and install updates → Restart after completion.



Final Result

The Dell Latitude 7400 2-in-1 laptop is now fully functional, running the latest version of Windows 11 with all drivers updated. This project demonstrates proficiency in system formatting, OS installation, driver configuration, and documentation—key skills in technical support and IT administration.