

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 1: Fuselage, Wings and Stabilizing Surfaces

Syllabus Source: CAE Oxford (pp. 1-46) | Pass Target: >= 90% AviationExam

1. STRUCTURAL LOADS, STRESSES & COMBINATION FORCES

Aircraft structures must withstand five primary mechanical stresses during flight and ground maneuvers. Every structural component is engineered to maintain aerodynamic integrity without permanent deformation up to the Limit Load, and without catastrophic structural failure up to the Ultimate Load (Ultimate Load = 1.5 x Limit Load):

Stress Type	Mechanical Action	Aircraft Structural Examples & Occurrence
Tension	Forces acting along the same axis pulling apart (stretching).	Lower wing skin during positive-g flight (+2.5g); fuselage skin under cabin pressurization.
Compression	Forces acting along the same axis pushing together (shortening).	Upper wing skin during positive-g flight; landing gear shock struts on touchdown.
Shear	Forces acting in opposite parallel directions causing sliding of adjacent planes.	Riveted joints and bolts securing skin panels to spar booms; wing spar webs.
Torsion	Twisting moment caused by an externally applied torque.	Wing structure when ailerons deflect; propeller blades; engine torque reaction on engine mounts.
Bending	Combination of tension on one side and compression on the opposite side.	Wing flexure in flight: upper skin experiences compression (buckling risk), lower skin experiences tension (fatigue cracking risk).

[!] EXAM TRAP (AVIATIONEXAM) - Structural Safety Margins (CS-25 / FAR-25)

- Limit Load: The maximum load anticipated in normal operational service. The structure must withstand limit load without PERMANENT DEFORMATION. - Ultimate Load: Limit Load multiplied by the Factor of Safety (Factor of Safety = 1.50). The structure must withstand ultimate load for AT LEAST 3 SECONDS without failure/rupture, though permanent deformation is permitted! - Positive Limit Load Factor for Transport Category (CS-25): Clean configuration = +2.5g; Flaps extended = +2.0g.

2. FUSELAGE CONSTRUCTION & PRESSURIZATION FEATURES

Modern transport aircraft utilize semi-monocoque construction to achieve an optimal balance between structural rigidity, useful cabin internal volume, and damage tolerance:

- Truss (Framework): Welded steel-tubing structure with non-structural fabric covering. Used only in vintage or light aerobatic aircraft.
- True Monocoque: The skin carries all tensile, compressive, and shear loads. Light formers provide cross-sectional shape, but there are no longitudinal stringers. Highly vulnerable: any localized dent or scratch causes catastrophic buckling under compression.
- Semi-Monocoque: The modern commercial standard. The thin metal or composite skin carries shear and cabin hoop stress, while longitudinal stringers and longerons carry bending/axial tension and compression. Transverse frames and bulkheads maintain cross-sectional circular profile.

Component	Structural Role	Operational & Failure Nuance
Longerons & Stringers	Longitudinal stiffeners running along the fuselage.	Longerons carry heavy bending loads; stringers prevent skin wrinkling and divide skin into smaller panels.
Frames & Formers	Transverse structural rings maintaining fuselage shape.	Distribute concentrated floor, wing, and tail loads into the skin.
Pressure Bulkheads	Dome-shaped (spherical/toroidal) front and rear pressure caps.	Converts internal cabin differential air pressure into pure membrane TENSION (domed shape prevents bending stresses).
Plug-Type Doors	Passenger and cargo doors designed larger than the fuselage frame cutout.	Internal cabin pressure forces the door firmly into its tapered surround. Impossible to open in flight when cabin is pressurized. Inward-moving or rotating stops mandatory.
Pressurized Windows	Multi-layer acrylic window assemblies.	Consists of outer structural pane (holds 1.5x max diff), inner structural pane (also holds 1.5x max diff), and non-structural scratch pane. A small breather hole in the inner pane ensures outer pane carries normal pressure load.

3. WING STRUCTURAL ARCHITECTURE & CANTILEVER DESIGN

Commercial transport wings are cantilever beams (internally supported without external bracing struts or wires). The wing internal structure consists of three principal structural members:

- Wing Spars: Primary longitudinal structural members extending root-to-tip. Composed of upper and lower spar booms (caps) that resist wing bending moments, connected by a vertical shear web that resists vertical aerodynamic shear loads.
- Wing Ribs: Transverse chordwise members that maintain aerodynamic camber, transfer skin airloads into the spars, and act as tank surge baffles to prevent dynamic fuel sloshing during turbulence and maneuvers.
- Torsion Box (Wing Box): Enclosed structural cell formed by front spar, rear spar, ribs, and upper/lower skins. Resists severe torsional twisting moments generated by ailerons, spoilers, and aerodynamic center-of-pressure shifts.

4. STRUCTURAL DESIGN PHILOSOPHIES: SAFE-LIFE VS FAIL-SAFE VS DAMAGE TOLERANT

Design Concept	Engineering Principle	Maintenance & Operational Criterion
Safe-Life	Component is certified to operate for a fixed, predetermined number of flight hours/landings, after which it MUST BE DISCARDED regardless of condition.	Applies to high-stress landing gear components, engine mounts, and helicopter rotor hubs where alternate load paths are physically impossible.
Fail-Safe	Structure incorporates multiple redundant load paths or structural dividers.	If one structural element fractures (e.g. one cap of a multi-part spar), the remaining structure carries the load safely until the next scheduled maintenance check.
Damage Tolerant	Modern CS-25/FAR-25 philosophy. Assumes micro-cracks and flaws WILL develop in service.	Structure incorporates crack-stoppers and low crack-propagation materials. Crack growth rates are scientifically calculated to guarantee cracks remain detectable before reaching critical length.

5. AIRCRAFT MATERIALS, COMPOSITES & CORROSION MECHANISMS

Modern airframes blend aluminum alloys, titanium, and advanced composite materials (CFRP, GFRP, Kevlar):

- Aluminum Alloys: 2000 series (Copper) and 7000 series (Zinc). Excellent strength-to-weight ratio, but highly susceptible to corrosion. Protected by Alclad (pure aluminum protective skin coating) and anodizing.
- Titanium Alloys: High tensile strength, exceptional corrosion resistance, and retains structural strength at elevated temperatures (up to 400°C). Used for engine firewalls, pylon attachments, and heavy landing gear truck beams.
- Composites (CFRP / Kevlar): Carbon fibers embedded in epoxy resin matrix. High specific strength, zero corrosion, and fatigue-resistant. Disadvantages: low impact resistance (internal delamination without visible surface damage from tool drops) and non-conductive (requires embedded bronze/copper wire mesh for lightning dissipation).
- Galvanic Corrosion: Occurs when two dissimilar metals (e.g. aluminum and steel or carbon composite) are in electrical contact in the presence of an electrolyte (moisture). The more active metal (anode, e.g. aluminum) corrodes rapidly.

6. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is the primary operational advantage of a 'plug-type' passenger cabin door in a pressurized transport aircraft?

[A] It opens faster in an emergency evacuation [B] Cabin internal pressure forces the door firmly into its tapered frame, preventing accidental opening in flight [C] It requires no mechanical hinges [D] It allows lower fuselage aerodynamic drag

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Plug-type doors are sized larger than their frame cutouts. Internal cabin differential pressure pushes the door outwards against the fuselage frame stops, making mechanical opening physically impossible at cruising altitude.

Q2: Under CS-25 certification specifications, what is the definition of 'Ultimate Load'?

[A] Limit load multiplied by a safety factor of 1.50 [B] The maximum load expected in normal operational life [C] The load at which permanent deformation first occurs [D] Twice the limit load

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [A]. Ultimate Load = Limit Load x 1.50 (Factor of Safety). The airframe must withstand ultimate load for at least 3 seconds without catastrophic structural failure.

Q3: What is the primary structural function of wing ribs in a transport category aircraft?

[A] Carrying the primary wing bending moment [B] Giving the wing its aerodynamic profile and transferring skin loads to the spar booms [C] Acting as engine pylon attachments only [D] Preventing flutter at high Mach numbers

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Wing ribs define the camber/profile of the airfoil, support the skin against buckling, and transmit distributed aerodynamic lift forces directly to the spar webs and booms.

Q4: Which design philosophy is characterized by mandating the retirement of a component after a specified number of cycles?

[A] Damage Tolerant [B] Fail-Safe [C] Safe-Life [D] On-Condition

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [C]. The Safe-Life philosophy requires mandatory component retirement upon reaching a specified service life (hours or cycles), regardless of physical appearance or condition.

Q5: In a pressurized aircraft passenger window, what is the operational purpose of the tiny breather hole in the outer pane?

[A] To let fresh air into the passenger cabin [B] To equalize pressure so the outer pane carries normal cabin differential pressure and prevent misting [C] To allow flight attendants to clean between panes [D] To relieve cabin overpressure during rapid ascent

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The breather hole vents the cavity between panes to cabin pressure, ensuring the thicker outer pane carries the full differential load while keeping the space dry and clear of condensation.

Q6: Why must an electrical conductive wire mesh be embedded in the outer composite skin of modern aircraft?

[A] To increase cabin Wi-Fi reception [B] To conduct and dissipate lightning strike currents safely to the static dischargers, preventing explosive delamination [C] To heat the skin for de-icing [D] To add tensile strength to the carbon fibers

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Carbon fiber composite has high electrical resistance. A lightning strike without a protective conductive surface mesh (copper/bronze) would cause explosive vaporization of the epoxy resin matrix.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 2: Basic Hydraulics (Fluids, Pumps & Accumulators)

Syllabus Source: CAE Oxford (pp. 47-98) | Pass Target: >= 90% AviationExam

1. FUNDAMENTAL HYDRAULIC PRINCIPLES & PASCAL'S LAW

Hydraulic systems transmit power through the medium of an incompressible liquid. Under Pascal's Law, pressure applied to an enclosed liquid is transmitted equally and undiminished in all directions, acting at right angles to the container walls:

- Formula for Pressure: Pressure (P) = Force (F) / Area (A). Units: PSI (Pounds per Square Inch) or Bar (1 bar = 14.5 psi). Standard commercial aircraft operate at 3,000 psi (e.g. A320, B737, B777) or 5,000 psi (A380, B787, A350).
- Mechanical Advantage: Force Out = Pressure x Area Out. By using a small input piston and a large actuator piston, massive output forces are generated, allowing effortless movement of primary flight controls under heavy aerodynamic loads.
- Work & Displacement: Work In = Work Out (Force x Distance). Liquid displaced by the small piston equals liquid moved into the large actuator: a small force moved over a long distance creates a large force moved over a short distance.

2. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Pascal's Law and Hydraulic Force Multiplier

SCENARIO (Fundamental Aviation Hydraulic Calculation): A transport aircraft hydraulic system operates at 3,000 PSI (Pounds per Square Inch): - A flight control actuator cylinder has a piston face area A = 5 square inches (sq in) - The pilot commands an elevator deflection under high dynamic pressure cruise QUESTION: What is the total linear mechanical force generated by this hydraulic actuator on the flight control surface? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Identify Pascal's Master Equation: - Pressure = Force / Area --> Force = Pressure x Area Step 2: Plug in the Known Operating Values: - Hydraulic Operating Pressure (P) = 3,000 PSI - Actuator Working Area (A) = 5 sq in Step 3: Calculate the Resulting Output Force: - Force = 3,000 lb/sq in x 5 sq in = 15,000 POUNDS OF FORCE (lbf)! - In metric conversion (1 lbf = 4.448 N): - Force = 15,000 x 4.448 N = 66,720 Newtons (~66.7 kN)! FINAL ANSWER: The actuator exerts 15,000 lbs (over 6.8 tonnes) of force on the elevator surface! This demonstrates how a compact 5-inch piston under 3,000 PSI effortlessly deflects massive flight surfaces against high-speed aerodynamic slipstream loads that no human pilot could move manually!

3. HYDRAULIC FLUIDS: MINERAL VS SYNTHETIC (SKYDROL)

Aviation hydraulic fluids must possess low viscosity change across extreme temperature ranges (-55°C to +130°C), high flash points, anti-foaming characteristics, and high lubricity. Two incompatible fluid types exist:

Parameter	Mineral Fluid (MIL-PRF-5606)	Synthetic Phosphate-Ester (Skydrol / HyJet)
Base Composition	Refined petroleum mineral base with chemical additives.	Synthetic phosphate-ester chemical base.
Color Code	DYED RED (to prevent servicing errors).	DYED PURPLE (or green in older Type IV formulations).

Flammability	Flammable! Flash point ~105°C; auto-ignition ~230°C.	Fire-resistant! Flash point > 175°C; auto-ignition > 475°C.
Seal Compatibility	Nitrile rubber (Buna-N), Neoprene.	Ethylene Propylene Diene Monomer (EPDM), Butyl, Teflon. DESTROYS natural rubber and Neoprene!
Toxicity & Hazards	Low toxicity; mild skin irritation.	HIGHLY TOXIC & CORROSIVE! Causes severe eye pain/stinging; damages aircraft acrylics and paint (requires polyurethane paint). Flush immediately with copious water!

[!] EXAM TRAP (AVIATIONEXAM) - Fluid Incompatibility & Seal Destruction

- NEVER MIX hydraulic fluids! If Skydrol is inadvertently serviced into a mineral system, the Nitrile/Neoprene seals swell, soften, and dissolve within minutes, causing total system failure. - If mineral oil is added to a Skydrol system, the EPDM seals rapidly degrade and fail. - Contaminated systems must be completely drained, flushed with chemical solvent, and have all seals replaced!

3. RESERVOIRS & PRESSURIZATION METHODS

The hydraulic reservoir stores fluid, accommodates thermal expansion, compensates for volume changes during jack extension/retraction, and permits air bubbles to separate out. In commercial aircraft, reservoirs MUST BE PRESSURIZED:

- Why Pressurize?: At high flight altitudes (FL 350+), low atmospheric ambient pressure would cause the hydraulic fluid to boil and cause cavitation (vapor pocket collapse) in the hydraulic pump suction inlet, leading to immediate pump destruction!
- Pressurization Sources: 1. Engine bleed air regulated to 30-50 psi; 2. Bootstrap reservoir (differential area piston utilizing system hydraulic pressure to pressurize the return fluid).

4. HYDRAULIC PUMPS: CONSTANT VS VARIABLE DISPLACEMENT

Pump Type	Operational Characteristics	Control Mechanism & Aircraft Use
Gear / Hand Pump	Constant volume displacement. Output flow is directly proportional to RPM.	Requires an Automatic Cut-Out Valve (ACOV) and system pressure relief valve to unseat and return fluid to reservoir when no actuators are moving.
Axial Piston Pump (EDP)	Variable volume displacement. Rotating cylinder block with angled swashplate (cam plate).	Swashplate angle modulates automatically via an internal pressure-compensating servo spool. At 3,000 psi demand satisfied, swashplate moves to 0° (zero delivery, zero power draw). Standard engine-driven pump (EDP).

5. HYDRAULIC ACCUMULATORS & EMERGENCY POWER SOURCES

A hydraulic accumulator is a rigid pressure vessel divided into two chambers by a floating piston, flexible diaphragm, or bladder:

- Gas Chamber: Pre-charged with DRY NITROGEN (never compressed air or oxygen, which would cause an explosion in contact with hydraulic fluid mist!). Pre-charge is typically 1,000 to 1,500 psi.

- Functions of Accumulator: 1. Dampens pressure spikes and hydraulic hammering from rapid valve closure; 2. Supplements pump delivery during high transient flow demand (e.g. gear retraction); 3. Provides emergency pressure reserve to operate brakes or deploy gear following complete engine pump failure.
- Power Transfer Unit (PTU): A hydraulic motor driven by one system mechanically coupled to a pump in another system. Transfers HYDRAULIC POWER without any fluid transfer or intermixing!
- Ram Air Turbine (RAT): A deployable slipstream-driven air turbine that drives an emergency hydraulic pump, supplying essential flight controls in the event of dual engine flameout or total AC electrical failure.

6. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: Why must hydraulic reservoirs in jet transport aircraft operating at high altitudes be pressurized?

[A] To prevent fluid freezing at -50°C [B] To prevent hydraulic pump cavitation caused by low atmospheric ambient pressure at high altitudes [C] To force fluid through the return filters [D] To operate the landing gear emergency extension

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. At high altitudes, low ambient pressure can cause the fluid to vaporize at the pump inlet. Pressurizing the reservoir (with engine bleed air to 30-50 psi) provides a positive head of pressure, preventing destructive cavitation.

Q2: What gas must be used to pre-charge a hydraulic accumulator, and why?

[A] Pure oxygen, to improve compressibility [B] Compressed ambient air [C] Dry nitrogen, because it is inert and will not support combustion or explode in contact with hydraulic oil [D] Carbon dioxide

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [C]. Accumulators are pre-charged exclusively with dry nitrogen. Using compressed air or oxygen could cause diesel-effect auto-ignition or catastrophic explosion when mixed with hydraulic fluid mist.

Q3: What occurs if a mineral-based hydraulic fluid is accidentally serviced into an aircraft system using Skydrol?

[A] The fluid turns yellow but functions normally [B] The seals (EPDM) in the Skydrol system swell, dissolve, and fail, causing rapid fluid loss and system destruction [C] System operating pressure increases to 5,000 psi [D] The fluid boils at 0°C

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Mineral oil and phosphate-ester (Skydrol) fluids are completely chemically incompatible. Adding mineral oil to a Skydrol system rapidly attacks and destroys the Ethylene Propylene seals.

Q4: What is the primary operational function of a Power Transfer Unit (PTU)?

[A] Transferring hydraulic fluid from a full system to a leaking system [B] Transferring power between two independent hydraulic systems without transferring or mixing fluid [C] Charging the nitrogen bottle [D] Disconnecting the EDP during engine start

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. A PTU consists of a hydraulic motor in one system connected via a mechanical shaft to a pump in another system. It allows power transfer without any fluid mixing.

Q5: In a variable displacement axial-piston hydraulic pump, what happens to the swashplate angle as system pressure increases?

[A] Swashplate angle increases to maximum [B] Swashplate moves to approximately zero angle (perpendicular to piston axis), reducing pump output flow to zero [C] Swashplate reverses rotation direction [D] Swashplate disconnects from the driveshaft

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. When system pressure satisfies the demand (3,000 psi), the pressure compensator moves the swashplate to near 0°, reducing piston stroke and output flow to zero, minimizing engine load.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 3: Landing Gear, Wheels, Tyres & Brakes

Syllabus Source: CAE Oxford (pp. 99-148) | Pass Target: >= 90% AviationExam

1. OLEO-PNEUMATIC SHOCK STRUT MECHANICS

Modern transport aircraft undercarriages use oleo-pneumatic shock absorber struts. The strut absorbs the kinetic energy of landing touchdown and dissipates it, while providing resilient cushioning during surface taxiing:

- Operating Mediums: Strut contains two distinct fluids: 1. Hydraulic fluid (oil) in the lower cylinder; 2. Compressed dry nitrogen gas in the upper chamber.
- Compression Stroke (Touchdown): During landing impact, the strut telescopes. The lower piston forces hydraulic oil upward through a small calibrated metering orifice into the upper cylinder, compressing the nitrogen. Oil forced through the restricted orifice transforms kinetic energy into heat (dissipated damping), while nitrogen compression cushions the impact.
- Rebound Damping: A recoil valve or tapered metering pin restricts the return flow of oil as the strut extends, preventing violent spring-back oscillations.
- Maintenance Servicing Order: CRITICAL EXAM POINT: Oleo struts must always be serviced with HYDRAULIC OIL FIRST until full to the level plug, and then inflated with DRY NITROGEN to achieve the specified chrome extension height!

2. RETRACTION SYSTEMS, LOCKS & EMERGENCY EXTENSION

Landing gears are retracted hydraulically into aerodynamically sealed wheel wells in flight, locked mechanically, and provided with emergency extension backup:

- Uplocks & Downlocks: Hydraulic actuators hold the gear in transit. Once fully retracted or extended, over-center mechanical locks (uplocks and downlocks) engage. The gear is held down by MECHANICAL LOCKS, not hydraulic pressure!
- Ground Safety Pins: Mechanical lock pins inserted into gear drag struts while parked on ground to physically prevent accidental gear retraction.
- Emergency Extension Methods: 1. Gravity Free-Fall: Uplocks are mechanically or electrically released; gear doors open and the gear falls and locks down under gravity and aerodynamic airflow; 2. Emergency pneumatic nitrogen blow-down.
- Nose Wheel Centering: Nose gear shock struts feature an internal mechanical centering cam. As the nose strut extends after take-off, the internal cams align the nose wheels perfectly fore-and-aft before entering the wheel well, preventing catastrophic jamming.

3. AIRCRAFT WHEELS, TYRES & THERMAL FUSIBLE PLUGS

Feature	Engineering Design	Operational & Safety Rule
Wheel Construction	Two-piece split-hub design made of forged aluminum or magnesium alloy.	Sealed by an elastomer O-ring. Assembled with tie-bolts. Always deflate tyre before loosening wheel tie-bolts!

Thermal Fusible Plugs	Hollow threaded brass bolts filled with a eutectic metal alloy plug.	Melt at a predetermined high temperature (~150°C to 180°C) resulting from heavy or rejected take-off (RTO) braking. Releases tyre nitrogen pressure slowly into the brake assembly, PREVENTING CATASTROPHIC TYRE EXPLOSION and shrapnel damage!
Tyre Inflation Gas	Nitrogen is mandatory for all commercial transport aircraft tyres.	Nitrogen is inert and contains no moisture; will not support combustion, maintains stable pressure across temperature extremes, and prevents oxidation of the inner tyre carcass rubber.
Tyre Wear & Creep	Chine tyres used on nose wheels to deflect runway water away from rear-mounted jet engines.	Tyre creep (slipping of tyre around the rim under heavy braking) is monitored by matching white creep marks painted across tyre and rim.

4. HYDROPLANING (AQUAPLANING) FORMULAS & PHENOMENA

Hydroplaning occurs when aircraft tyres become separated from the paved runway surface by a continuous fluid film of water, reducing braking coefficient of friction and directional control to virtually zero:

Hydroplaning Type	Physics & Water Depth	Critical Speed Formula (Knots)
Dynamic Hydroplaning	Standing water on runway (> 3 mm depth). Water inertia builds up a hydrodynamic wedge that lifts tyre completely off pavement.	Rotating Tyre: $V_p = 9 \times \sqrt{P}$ [psi] Non-Rotating (Skidding): $V_p = 7.7 \times \sqrt{P}$ [psi]
Viscous Hydroplaning	Very thin film of moisture (< 0.1 mm) on smooth pavement (paint markings, rubber deposits). Oil and dust create a soapy lubricating film.	Can occur at MUCH LOWER SPEEDS than dynamic hydroplaning; persists down to low taxi speeds!
Reverted Rubber	Prolonged wheel lockup during skid. Friction heat boils trapped water into high-pressure steam, vulcanizing and burning tyre rubber into soft white seal.	Steam cushion supports aircraft; tyre shows distinctive burnt/scalded oval rubber patch.

[!] EXAM TRAP (AVIATIONEXAM) - Dynamic Hydroplaning Calculation Examples

- Example 1 (Rotating Tyre): Tyre pressure = 144 psi. Dynamic hydroplaning speed = $9 \times \sqrt{144} = 9 \times 12 = 108$ KNOTS!
 - Example 2 (Non-Rotating Tyre / Spin-up on Touchdown): Tyre pressure = 100 psi. Speed = $7.7 \times \sqrt{100} = 7.7 \times 10 = 77$ KNOTS!
 Note: A skidding (locked) wheel hydroplanes at a LOWER speed (7.7) than a rolling wheel (9.0)!

5. ANTI-SKID SYSTEMS & CARBON BRAKE PACKS

Modern multi-disc brakes use multiple rotating discs keyed to the wheel and stationary stator discs keyed to the axle torque tube. Carbon brake discs provide superior heat capacity, lighter weight, and wear less at high operating temperatures compared to steel brakes:

- Anti-Skid Operating Principle: Wheel speed transducers monitor rotational deceleration. If wheel deceleration exceeds a predetermined threshold (indicating imminent skid), the anti-skid valve dumps hydraulic brake pressure instantly, allowing the wheel to spin back up, then smoothly reapplies modulated pressure.

- Anti-Skid Functions: 1. Normal skid control; 2. Touchdown protection (prevents brake pressure application before touchdown, even if pilot presses pedals, until wheel spin-up reaches 30-50 kt or squat switch signals ground mode); 3. Locked wheel crossover protection; 4. Gear retraction braking (automatically applies low pressure to stop wheel rotation before entering wheel well).

6. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is the primary purpose of thermal fusible plugs installed in aircraft wheels?

[A] To melt and rapidly inflate the tyre during high-speed take-offs [B] To melt and release tyre pressure safely if brake and wheel temperatures exceed limits, preventing catastrophic tyre explosion [C] To lock the brakes when parked [D] To indicate brake pad wear limits

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Fusible plugs contain a low-melting-point alloy (150-180°C). During severe braking or an RTO, high brake heat conducts to the wheel rim; the plug melts, venting tyre nitrogen harmlessly before the tyre explodes.

Q2: An aircraft has a main tyre pressure of 144 psi. What is the calculated dynamic hydroplaning speed for a runway?

[A] 77 kt [B] 95 kt [C] 108 kt [D] 144 kt

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [C]. Formula for rotating tyre: $V_p = 9 \times \sqrt{P} = 9 \times \sqrt{144} = 9 \times 12 = 108$ knots.

Q3: In an oleo-pneumatic shock absorber strut, what primary medium absorbs and dissipates the initial impact energy?

[A] Nitrogen gas compression [B] Hydraulic oil forced through a restricted metering orifice [C] Steel coil springs [D] Rubber snubber blocks

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Nitrogen compression stores energy and provides spring cushioning, but the initial impact energy is absorbed and DISSIPATED as heat by hydraulic oil being forced through the calibrated metering orifice.

Q4: Why are commercial aircraft tyres inflated with dry nitrogen rather than compressed ambient air?

[A] Nitrogen is lighter than air [B] Nitrogen is completely inert, dry (prevents rim corrosion and pressure fluctuations), and eliminates the risk of tyre explosion at high temperatures [C] Nitrogen increases braking friction [D] Nitrogen is cheaper than air

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Nitrogen contains no oxygen or moisture. It prevents rim corrosion, avoids high internal steam pressure rises from moisture at high brake temperatures, and eliminates internal combustion/explosion risks.

Q5: How does the anti-skid 'touchdown protection' feature function?

[A] It deploys the ground spoilers automatically [B] It inhibits brake application until the main wheels have spun up to a minimum speed or ground squat switches confirm weight on wheels [C] It lowers the nose wheel gently to the runway [D] It disconnects nose wheel steering

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Touchdown protection prevents hydraulic pressure from reaching the brakes even if the pilot inadvertently presses the brake pedals before touchdown, ensuring the tyres do not blow out upon contacting the runway.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 4: Flight Control Systems (Primary, Secondary & Powered)

Syllabus Source: CAE Oxford (pp. 149-198) | Pass Target: $\geq 90\%$ AviationExam

1. PRIMARY VS SECONDARY FLIGHT CONTROLS & AXES OF MOTION

Aircraft maneuvering is governed by aerodynamic control surfaces positioned along the three orthogonal axes intersecting at the Center of Gravity (CG):

Control Surface	Aircraft Axis of Motion	Type of Motion & Cockpit Input
Ailerons (and Roll Spoilers)	Longitudinal Axis (Nose to Tail)	ROLL (Lateral control) via control wheel rotation or sidestick lateral deflection.
Elevator (or Variable Tailplane / Stabilator)	Lateral Axis (Wingtip to Wingtip)	PITCH (Longitudinal control) via control column push/pull or sidestick longitudinal deflection.
Rudder	Normal / Vertical Axis (Through CG)	YAW (Directional control) via left/right rudder pedal deflection.

2. MANUAL VS REVERSIBLE VS IRREVERSIBLE POWER-ASSISTED CONTROLS

As aircraft airspeed and mass increase, aerodynamic hinge moments exceed human muscular capability, requiring powered actuation:

- Manual / Reversible Controls: Aerodynamic hinge forces acting on control surfaces are transmitted directly back through cables and push-pull rods to the cockpit controls. The pilot directly 'feels' aerodynamic resistance.
- Fully Powered / Irreversible Controls (PFCUs): Hydraulic actuators (Power Flight Control Units) drive the control surfaces. Aerodynamic airloads are absorbed entirely by the hydraulic actuators and airframe structure. ZERO aerodynamic feedback reaches the pilot's controls!
- Artificial Feel Units (Q-Feel): Because irreversible controls lack natural tactile feedback, artificial feel units must be installed. A dynamic pressure capsule ('Q-pot') fed by pitot and static pressure increases control centering spring resistance proportionally to dynamic pressure ($q = \frac{1}{2} \rho V^2$). As airspeed increases, controls stiffen, preventing structural over-stressing!

[!] EXAM TRAP (AVIATIONEXAM) - Artificial Feel Unit (Q-Feel) Characteristics

- At low airspeeds (take-off/landing): Control resistance is light, allowing full control deflection. - At high airspeeds (cruise/dive): Control resistance is very stiff. The pilot cannot easily over-deflect controls and exceed airframe limit load factor (+2.5g)! - If the Q-feel pitot line becomes blocked by ice in cruise, control feel remains erroneously stiff during subsequent descent and approach!

3. AERODYNAMIC BALANCE & CONTROL TABS

Tab / Device Type	Operating Principle	Operational Function & Purpose
Inset Hinge / Horn Balance	Surface area placed ahead of the hinge line.	Aerodynamic airloads ahead of the hinge help rotate the surface, reducing pilot control effort.

Trim Tab	Small auxiliary surface hinged at trailing edge of primary control.	Deflects opposite to desired surface deflection, generating aerodynamic force that holds the primary control in position, trimming control forces to ZERO.
Balance Tab	Mechanically linked to move OPPOSITE to the primary control surface.	Reduces pilot control stick forces by providing an assisting aerodynamic moment.
Anti-Balance Tab	Mechanically linked to move in the SAME DIRECTION as primary surface.	Increases control stick forces. Mandatory on all-moving tailplanes (stabilators) to prevent pilot over-controlling and structural damage.
Servo Tab	Directly linked to cockpit controls; primary surface is completely free-floating.	Pilot moves the servo tab; aerodynamic lift generated by the tab drives the main control surface in the opposite direction. Used on large vintage aircraft (e.g. Britannia).
Spring Tab	Incorporates a torsion spring in the control linkage.	Acts as a rigid connection at low speeds (manual control), but spring compresses at high speeds, converting the tab into an assisting servo tab under heavy aerodynamic loads.

4. SECONDARY CONTROLS: SPOILERS, AIRBRAKES & HIGH-LIFT SYSTEMS

Spoilers are rectangular hinged panels mounted on the upper surface of the wing. They perform three distinct functions:

- Roll Spoilers (Flight Spoilers): Deflect asymmetrically on the down-going wing only during roll commands, assisting ailerons and eliminating adverse yaw.
- Speedbrakes (In-Flight Deceleration): Deflect symmetrically on both wings in flight. Increases parasite drag and reduces lift, steepening descent path without increasing airspeed.
- Ground Spoilers (Lift Dumpers): Deploy to maximum deflection (up to 50-60°) automatically upon main wheel touchdown or rejected take-off (RTO). Dumps virtually all wing lift instantly, transferring aircraft weight fully onto the landing gear wheels for maximum anti-skid tyre braking traction, while adding massive aerodynamic drag.

5. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: In an aircraft equipped with irreversible hydraulic powered flight controls, how does the pilot receive tactile feedback?

[A] Through direct mechanical cable feedback from the elevators [B] Through an artificial feel unit (Q-feel) that increases control resistance proportionally to dynamic pressure ($\frac{1}{2} \rho V^2$) [C] By engine thrust levers vibrating [D] Through aerodynamic tabs on the rudder

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Irreversible PFCUs isolate the control column from aerodynamic hinge loads. An artificial feel unit (Q-pot) uses pitot/static dynamic pressure to stiffen controls as airspeed increases.

Q2: What is the primary operational purpose of an anti-balance tab fitted to an all-flying tailplane (stabilator)?

[A] To reduce pilot control stick forces [B] To increase stick forces and prevent the pilot from over-controlling the sensitive stabilator [C] To trim the aircraft for zero pitch force [D] To improve low-speed lift

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. All-moving tailplanes have very low hinge moments. An anti-balance tab moves in the SAME direction as the stabilator, generating resistance that increases pilot stick force to provide tactile feel and prevent structural damage.

Q3: What is the primary operational effect of ground spoiler (lift dumper) deployment upon touchdown?

[A] Decreasing wheel brake temperature [B] Destroying wing lift instantly to transfer aircraft weight onto wheels, dramatically improving wheel braking friction [C] Pitching the nose down onto the runway [D] Cooling the engine reverse thrust ducts

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Ground spoilers destroy wing lift immediately upon touchdown, shifting full aircraft weight onto tyres so multi-disc brakes achieve maximum anti-skid friction efficiency.

Q4: Which direction does a conventional pitch trim tab deflect relative to the elevator when trimming for nose-

[A] In the same direction (upwards) [B] In the opposite direction (downwards) [C] It remains neutral [D] It oscillates continuously

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. To hold the elevator deflected UPWARDS (nose-up pitch), the trim tab at the trailing edge deflects DOWNWARDS. The upward aerodynamic force on the tab holds the elevator up without pilot force.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 5: Pneumatic Systems & Air Conditioning (Packs)

Syllabus Source: CAE Oxford (pp. 199-216) | Pass Target: >= 90% AviationExam

1. ENGINE BLEED AIR SOURCES & PRECOOLERS

Pressurized hot air is extracted from the compressor stages of gas turbine engines to power pneumatic systems, cabin air conditioning, wing thermal anti-icing, and engine starting:

- **Bleed Ports:** Intermediate Pressure (IP) stage used during high thrust (take-off, climb, cruise); High Pressure (HP) stage tapped automatically at low thrust (descent, idle) via an HP bleed valve when IP pressure is insufficient.
- **Bleed Parameters:** Raw bleed air leaves the compressor at high temperature (up to 400°C) and pressure (up to 200 psi).
- **Precooler:** An air-to-air heat exchanger located in the engine pylon. Uses cool engine fan bypass air to reduce bleed air temperature down to ~200°C before entering the main pneumatic manifold.
- **Manifold Isolation:** A crossbleed valve allows one engine to supply both sides of the aircraft pneumatic manifold, or isolates left/right systems during pneumatic leak detection.

2. THE AIR CYCLE MACHINE (ACM) & AIR CONDITIONING PACK

The Air Conditioning Pack converts hot, high-pressure pneumatic bleed air into cold, dry conditioned air for the cabin and flight deck. Commercial jet transports use an Air Cycle Machine (ACM) operating on the reverse Brayton cycle:

Component	Thermodynamic Function & Process	Airflow & Temperature State
Pack Flow Control Valve	Regulates incoming pneumatic bleed mass flow into the pack.	Modulates mass flow based on passenger load and cooling demand.
Primary Heat Exchanger	Hot bleed air is cooled by external ambient RAM AIR in ram air duct.	Air temperature drops significantly while pressure remains high.
Centrifugal Compressor	ACM compressor compresses the air again, increasing its pressure and temperature.	Prepares air for maximum energy extraction across turbine.
Secondary Heat Exchanger	Further cools high-pressure air using external ram air.	Removes compression heat before air enters the expansion turbine.
Expansion Turbine	High-pressure air expands rapidly across turbine blades to drive the compressor and ram air cooling fan.	ULTRA-COLD AIR GENERATION: Air temperature drops precipitously (down to -10°C to +2°C) as internal heat energy is converted into mechanical work to spin the shaft!
Water Separator	Removes condensed moisture via swirling centrifugal coalescer bag.	Prevents fog, snow, or ice pellets from entering passenger cabin distribution ducts.

[!] EXAM TRAP (AVIATIONEXAM) - ACM Boot-Strap Cycle (Compounding Work)

- The compressor and turbine of the Air Cycle Machine are mounted on a COMMON SHAFT. - The turbine extracts heat energy from the air to spin the shaft. That shaft power directly DRIVES THE PACK COMPRESSOR and the ram air cooling fan! - This self-sustaining thermodynamic loop is known as the 'bootstrap cycle'.

3. CABIN TEMPERATURE CONTROL & TRIM AIR SYSTEM

Modern commercial aircraft divide the fuselage into distinct temperature zones (Flight Deck, Forward Cabin, Aft Cabin):

- Cold Base Supply: The air conditioning packs output conditioned air at a cold baseline temperature corresponding to the zone demanding the most cooling.
- Trim Air Valves: Uncooled, hot bleed air from upstream of the packs ('trim air') is piped to individual distribution ducts. Modulating trim air valves mix hot air with cold pack air to satisfy specific zone thermostat demands.
- Cabin Air Recirculation: High-efficiency particulate air (HEPA) fans recirculate approximately 50% of cabin air, blending it with 50% fresh outside pack air. This reduces engine bleed air consumption, saving significant fuel while maintaining optimal ventilation rates.

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: In an Air Cycle Machine (ACM) air conditioning pack, what thermodynamic component produces the dramatic temperature drop?**

[A] The primary heat exchanger [B] The expansion turbine, where air expands and does mechanical work spinning the shaft [C] The centrifugal compressor [D] The water separator

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The expansion turbine forces the air to perform work (spinning the compressor and fan). The energy consumed to perform work comes directly from the heat energy of the air, causing its temperature to plummet below 0°C.

Q2: What is the primary operational function of the 'trim air' system in a modern commercial airliner?

[A] To vent excess cabin pressure overboard [B] To add hot engine bleed air to cold pack air in individual duct zones to achieve selected cabin temperatures [C] To heat the engine cowl [D] To de-ice the wing leading edge

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The packs deliver cold air sized for the zone needing the most cooling. Individual zone trim air valves inject hot bleed air to modulate the temperature in each zone independently.

Q3: Why is engine bleed air cooled in an engine pylon precooler before entering the pneumatic distribution manifold?

[A] To prevent cabin air from smelling like jet fuel [B] To reduce raw bleed air temperature (which can reach 400°C) down to ~200°C to protect aluminum ducting and valves [C] To condense water out of the air [D] To increase engine fuel efficiency

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Raw compressor bleed air is dangerously hot (up to 400°C). The precooler uses engine fan bypass air to bring it down to ~200°C, ensuring ducting and valves are not damaged.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 6: Pressurisation Systems (Regimes & Outflow Valves)

Syllabus Source: CAE Oxford (pp. 217-234) | Pass Target: >= 90% AviationExam

1. PRESSURIZATION PRINCIPLES & DIFFERENTIAL PRESSURE LIMITS

Passenger transport aircraft fly in the thin upper atmosphere (FL 300 to FL 430) for engine fuel efficiency and to avoid adverse weather. The cabin must be pressurized to maintain physiological oxygen saturation without requiring oxygen masks:

- Cabin Altitude: The equivalent altitude inside the passenger cabin corresponding to the internal pressure. Under CS-25/FAR-25, normal maximum cabin altitude is 8,000 ft (ambient pressure ~750 hPa). Modern airliners (A350, B787) maintain 6,000 ft cabin altitude due to composite fuselage strength.
- Differential Pressure (Delta-P): The difference between internal cabin pressure (P_{int}) and external atmospheric ambient pressure (P_{amb}): $\Delta P = P_{int} - P_{amb}$. Maximum design differential pressure is typically 8.0 to 9.0 psi (aluminum airframes) and up to 9.4 psi (composite airframes).
- Cabin Rate of Climb / Descent: Rate of change of cabin pressure expressed in feet per minute. Normal passenger comfort limits: +500 ft/min during climb; -300 ft/min during descent.

2. OUTFLOW VALVE & PRESSURE REGULATION ARCHITECTURE

A common misconception is that pressurization is controlled by varying incoming air supply. In reality, incoming air conditioning pack mass flow is CONSTANT; cabin pressure is regulated entirely by controlling the EXHAUST RATE of air overboard:

Valve / Unit	Engineering Location	Operational Function & Pressure Limit
Outflow Valve (OFV)	Lower rear fuselage (under pressure bulkhead).	Modulates exhaust area from fully open (ground) to nearly closed (cruise). Controlled by dual digital pressurization controllers.
Positive Relief Valves	Fuselage pressure shell.	Spring-loaded mechanical safety valves. Open automatically if cabin differential pressure exceeds maximum structural limit (e.g. 8.6 to 9.1 psi) to PREVENT FUSELAGE EXPLOSION!
Negative Relief Valves (Inward)	Fuselage pressure shell.	Inward-opening spring valves. Open if ambient pressure exceeds cabin pressure (e.g. in rapid emergency dive), preventing fuselage structural crushing (max negative diff ~ -0.5 psi).
Dump Valve (Safety Valve)	Electrically or pneumatically signaled.	Dumps all cabin pressure to ambient when aircraft touches down on runway or when pilot selects DUMP switch.

[!] EXAM TRAP (AVIATIONEXAM) - Cabin Altitude Warning & Passenger Oxygen Trigger Points

- 8,000 ft: Normal maximum cabin altitude in commercial cruise. - 10,000 ft: CABIN ALTITUDE WARNING! Audio horn / master warning light triggers. Flight crew must immediately don oxygen masks (100% oxygen) and initiate emergency descent if uncontrollable! - 14,000 ft: AUTOMATIC PASSENGER OXYGEN MASK DEPLOYMENT. Chemical generator masks drop automatically from overhead passenger service units (PSU).

3. DECOMPRESSION CATEGORIES & PHYSIOLOGICAL RISKS

Loss of cabin pressurization can occur through seal failure, door release, or structural breach:

- Slow / Gradual Decompression: Loss of pressure takes longer than 10 seconds. Extremely insidious: flight crew may succumb to hypoxia without recognizing symptoms unless instrument warnings are monitored.
- Rapid Decompression: Loss of pressure occurs between 1 and 10 seconds. Accompanied by loud bang, rush of air toward breach, sudden fogging (moisture condensation as temperature drops), and drop in cabin temperature.
- Explosive Decompression: Loss of pressure occurs in LESS THAN 0.5 SECONDS (faster than lungs can decompress without damage). Lungs suffer trauma if pilot holds breath; Time of Useful Consciousness (TUC) is slashed by 33% to 50%!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: How is cabin pressure regulated in a modern jet transport aircraft during normal flight?**

[A] By varying the engine bleed air mass flow rate entering through the packs [B] By modulating the position of the outflow valve(s) to control the rate of air escaping overboard [C] By opening and closing cabin passenger doors [D] By throttling the engine fuel pumps

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The air conditioning packs deliver a constant mass flow of fresh air. The digital pressurization controller commands the outflow valve to open or close, regulating the rate of air exhausted overboard.

Q2: At what cabin pressure altitude does the master cabin altitude warning horn activate under commercial traffic conditions?

[A] 8,000 ft [B] 10,000 ft [C] 14,000 ft [D] 18,000 ft

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. At 10,000 ft cabin altitude, an intermittent audio horn and visual warning alert the pilots to don oxygen masks immediately. (Passenger masks deploy automatically at 14,000 ft).

Q3: What is the primary operational purpose of inward-opening negative relief valves on a pressurized aircraft?

[A] To prevent cabin overpressure in cruise [B] To prevent external atmospheric ambient pressure from exceeding internal cabin pressure, which would crush the fuselage inward [C] To allow passenger cabin smoke evacuation [D] To supply ram air to the engines

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Aircraft fuselage structures are designed as pressure vessels to withstand internal pressure (tension). They have poor resistance to external pressure (compression/crushing). Negative relief valves open inwards to equalize pressure if ambient exceeds cabin pressure.

Q4: Why does explosive decompression reduce the Time of Useful Consciousness (TUC) by 33% to 50% compared to normal?

[A] The blood freezes instantly [B] Ambient pressure drops faster than alveolar partial pressure, causing reverse diffusion of oxygen from the blood into the lungs [C] Adrenaline blocks hemoglobin [D] Heart rate drops to zero

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. In explosive decompression, alveolar oxygen pressure drops instantly below blood capillary oxygen pressure. Oxygen diffuses backwards out of the venous blood into the lungs, draining oxygen from the brain rapidly.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 7: Ice and Rain Protection Systems

Syllabus Source: CAE Oxford (pp. 235-258) | Pass Target: >= 90% AviationExam

1. ANTI-ICING VS DE-ICING PHILOSOPHIES

Ice accumulation on aerodynamic surfaces reduces maximum lift by up to 30%, increases parasite drag by over 100%, and increases stall speed significantly. Commercial aircraft utilize two distinct operational methods:

- Anti-Icing (Preventative): Operates CONTINUOUSLY before entering suspected icing conditions (OAT $\leq +10^{\circ}\text{C}$ in visible moisture) to PREVENT any ice formation from ever adhering to protected surfaces.
- De-Icing (Remedial): Operates INTERMITTENTLY to break off and shed ice layers AFTER a predetermined thickness (e.g. 6 to 12 mm / 1/4 to 1/2 inch) has accumulated.

System Type	Operating Medium & Mechanism	Aircraft Protected Areas & Operational Limits
Thermal Anti-Ice	Hot engine bleed air ($\sim 200^{\circ}\text{C}$) piped through Piccolo tubes inside leading edge.	Slats and wing leading edges; engine nacelle intake cowlings. Engine anti-ice uses raw bleed air directly and operates independently of wing anti-ice.
Pneumatic De-Ice Boots	Inflatable neoprene rubber boots bonded to leading edges. Inflated cyclically by bleed air / vacuum pump.	Wings and tail empennage on turboprop and commuter aircraft. Must allow ice to build up before inflating; premature cycling can cause 'ice bridging' (ice forms a rigid shell around inflated boot).
Electrical Heating	Embedded resistive heating elements (AC or DC powered).	Pitot probes, static ports, TAT sensors, AOA vanes, propeller blade boots, flight deck windshields, and waste water drain masts.
Fluid (Weeping Wing)	Ethylene glycol fluid pumped through microscopic laser-drilled pores in titanium panels (TKS system).	General aviation and light turboprops. Provides both anti-icing and de-icing; limited by fluid reservoir quantity.

[!] EXAM TRAP (AVIATIONEXAM) - Engine Anti-Ice vs Wing Anti-Ice Selection Rules

- Engine Anti-Ice: MUST BE SELECTED ON whenever OAT (on ground) or TAT (in flight) is $+10^{\circ}\text{C}$ OR BELOW in visible moisture (clouds, fog with visibility $< 1,000$ m, rain, snow, slush)! - Wing Anti-Ice: Selected on in flight when ice accumulation is observed, or continuously in severe icing. Usually inhibited automatically on the ground via squat switch (except for brief functional test) to prevent overheating leading-edge slats!

2. WINDSCREEN HEATING & RAIN REMOVAL

Transport aircraft flight deck windshields are multi-laminated glass-vinyl sandwiches with two critical operational requirements:

- Electrical Demisting / De-icing: A transparent conductive metallic coating (e.g. gold film or Stannic oxide) laminated inside the glass is heated with AC power. Thermistors embedded in the vinyl modulate power to maintain $\sim 35^{\circ}\text{C}$ to 45°C . This prevents icing and demists the inner pane.

- Bird-Strike Impact Resistance: At cruising temperatures (-50°C), vinyl interlayers become brittle. Electrical heating softens the vinyl interlayer, making it pliable and ductile, allowing it to absorb a 4-lb bird impact at V_c without cockpit penetration!
- Rain Removal Systems: 1. Mechanical windshield wipers (limited to V_{max_wiper}, ~250 kt); 2. Rain repellent liquid sprayed onto glass (banned in dry conditions: smears into opaque grease); 3. Hydrophobic chemical surface coating that makes water bead off aerodynamically.

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: Why must flight deck windshield electrical heating remain powered during normal cruise at high altitudes?

[A] To prevent cockpit glass fogging only [B] To warm the vinyl interlayer, maintaining elasticity and shatterproof impact resistance against bird-strikes at freezing temperatures [C] To supply emergency AC power [D] To improve cockpit night vision

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. At -50°C in cruise, cold vinyl is brittle. Windscreen heating keeps the vinyl core pliable and elastic, which is mandatory to certify bird-strike impact resistance under CS-25.

Q2: What operational hazard is associated with operating pneumatic de-ice boots prematurely before sufficient ice has accumulated?

[A] The rubber boot will blow off the wing [B] Ice bridging: ice can freeze over the inflated boot shape, forming a hollow shell that subsequent boot cycles cannot break [C] Engine bleed air pressure drops to zero [D] The boots will overheat

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. If inflated when only a thin slushy film exists, water can freeze over the extended contour, creating an 'ice bridge'. Subsequent inflations occur inside the cavity without shedding the outer ice shell.

Q3: When must engine cowl thermal anti-icing be turned ON in flight?

[A] Only when ice chunks are visibly flying into the engine [B] Whenever Total Air Temperature (TAT) is +10°C or below and visible moisture (clouds, rain, snow) is present [C] At all times above FL 250 [D] Only during descent

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Under EASA standards, engine anti-ice must be on whenever TAT is +10°C or colder in any visible moisture, preventing ice buildup on cowl lips that could shed into engine fan blades.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 8: Aircraft Oxygen Equipment (Crew & Passenger)

Syllabus Source: CAE Oxford (pp. 259-280) | Pass Target: >= 90% AviationExam

1. FLIGHT CREW VS PASSENGER OXYGEN REQUIREMENTS

Aviation oxygen systems are divided into two completely segregated architectures due to differing physiological and emergency demands:

System Feature	Flight Crew Oxygen System	Passenger Emergency Oxygen System
Supply Source	High-pressure gaseous oxygen cylinder (1,800 to 2,000 psi) painted green.	Chemical oxygen generators (sodium chlorate candles) mounted in PSUs; or central gaseous cylinder in some widebodies.
Delivery Mode	Diluter-Demand (normal) or 100% Continuous Pressure-Demand (smoke/fire or cabin alt > 39,000 ft).	Continuous flow into a rebreather bag mask.
Deployment	Manual donning. Quick-donning masks stowed beside pilot seats; must be don-able in LESS THAN 5 SECONDS with one hand!	Automatic drop-down when cabin pressure altitude exceeds 14,000 ft; can also be deployed manually from cockpit switch.
Duration	Sized for entire emergency descent down to 10,000 ft plus prolonged cruise at 10,000 ft (typically > 2 hours).	12 to 15 minutes minimum duration (sufficient for emergency descent from FL 410 down to safe breathing altitude < 10,000 ft).
Smoke Protection	Provides positive overpressure inside mask to prevent toxic cockpit smoke/fumes from entering. Built-in smoke goggles.	NOT suitable for smoke/toxic fumes (ambient air enters dilution holes).

[!] EXAM TRAP (AVIATIONEXAM) - Chemical Oxygen Generators (Sodium Chlorate Candles) Hazards

- Chemical Reaction: Sodium Chlorate (NaClO_3) + Iron (Fe) $\rightarrow$ Sodium Chloride (salt) + Oxygen (O_2) + Heat! - The reaction is EXOTHERMIC. Generator core temperatures reach 230°C to 260°C (450°F)! - Activation: Pulling the mask lanyard releases a spring-loaded firing pin that strikes a percussion cap. - CRITICAL: Once initiated, a chemical oxygen generator CANNOT BE SHUT OFF OR EXTINGUISHED until fully consumed (12-15 min)!

2. FLIGHT CREW MASK MODES: NORMAL VS 100% VS EMERGENCY

The flight crew oxygen regulator provides three selectable switch positions:

- **NORMAL (Diluter Demand):** Supplies a variable mix of ambient cabin air and pure oxygen. The regulator automatically increases oxygen concentration as cabin altitude increases, reaching 100% oxygen at approximately 32,000 ft cabin altitude.
- **100% OXYGEN:** Supplies 100% pure oxygen on inhalation demand, bypassing all ambient cabin air. Selected immediately in rapid decompression or contamination.
- **EMERGENCY (Pressure Demand):** Supplies 100% pure oxygen under continuous POSITIVE PRESSURE into the mask. Forces oxygen into the pilot's lungs and forces any smoke or toxic fumes out around mask edges. Mandatory when flying through dense cockpit smoke or above 39,000 ft cabin altitude.

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: Once initiated by pulling the mask lanyard, can a passenger chemical oxygen generator be turned off by the pilot?

[A] Yes, by turning off the passenger oxygen switch in the cockpit [B] No, the chemical reaction is exothermic and self-sustaining; it cannot be stopped until all chemical fuel is exhausted (12-15 minutes) [C] Yes, by closing the overhead PSU door [D] Yes, by dumping cabin pressure

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Chemical oxygen generators use an exothermic chemical burning process (sodium chlorate and iron). Once the firing pin is released, the reaction produces oxygen and intense heat (~250°C) continuously until depleted.

Q2: Under EASA CS-25 certification requirements, a flight crew quick-donning oxygen mask must be capable of being donned within:

[A] 3 seconds [B] 5 seconds [C] 10 seconds [D] 15 seconds

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Regulations mandate that a pilot must be able to don and latch a quick-donning oxygen mask using only one hand within 5 seconds, while continuing to fly and communicate.

Q3: What is the primary purpose of the 'EMERGENCY' setting on a flight crew oxygen regulator?

[A] To save oxygen supply during long descents [B] To provide 100% oxygen under continuous positive pressure, preventing toxic fumes and smoke from entering the mask [C] To inflate the passenger cabin [D] To heat the oxygen gas

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The Emergency mode delivers continuous positive pressure, which prevents toxic smoke, carbon monoxide, or irritant gases from seeping past the mask facial seal into the pilot's respiratory tract.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 9: Smoke & Fire Detection and Protection Systems

Syllabus Source: CAE Oxford (pp. 281-308) | Pass Target: >= 90% AviationExam

1. FIRE CLASSIFICATIONS & EXTINGUISHING AGENTS

Aircraft fires present an immediate mortal threat in flight. Extinguishing agents must extinguish fire rapidly without generating toxic byproducts or causing electrical short circuits:

Fire Class	Combustible Material Type	Authorized Aeronautical Extinguishing Agent
Class A	Solid combustibles (wood, paper, fabrics, upholstery).	Water with antifreeze, or Halon followed by water dousing to quench deep embers.
Class B	Flammable liquids (aviation kerosene, hydraulic oil, lubricating grease).	Halon 1211 (BCF) or Halon 1301. Smothers flame; NEVER USE WATER (causes explosive liquid spread)!
Class C	Energized electrical equipment (avionics, circuit breaker panels).	Halon 1211 / 1301 or CO ₂ . Non-conductive agent mandatory to prevent pilot electrocution and equipment corrosion.
Class D	Combustible metals (magnesium wheels, titanium engine components).	Dry powder extinguishing agents (sand, copper powder). Very difficult to extinguish; water reacts violently!

2. FIRE DETECTION SYSTEMS: CONTINUOUS THERMAL LOOPS

Engine nacelles and APU compartments use continuous loop thermal detectors routed around high-risk zones:

- **Fenwal System (Resistance):** A continuous Inconel tube packed with a ceramic thermistor core surrounding a central nickel conductor wire. As temperature rises anywhere along the loop, electrical resistance of the ceramic drops exponentially, allowing current to flow and triggering the fire alarm.
- **Kidde System (Dual Element):** Two wire conductors embedded in a thermistor material inside an Inconel tube, measuring resistance and capacitance changes.
- **Systron-Donner (Pneumatic Pressure):** Stainless steel tube sealed with a helium gas charge and a central core saturated with titanium hydride (releasing hydrogen at high temperatures). Average overheat expands the helium gas (closing a low-pressure switch); localized fire releases hydrogen gas (closing a high-pressure fire switch). If the tube is severed, helium leaks out, triggering a FAULT/INTEGRITY warning!
- **Dual-Loop Logic (AND vs OR):** Engines feature two independent loops (Loop A and Loop B). Normal logic is 'A AND B' (both loops must sense fire to trigger cockpit alarm, eliminating false warnings). If one loop fails, logic switches automatically to single loop ('A OR B').

[!] EXAM TRAP (AVIATIONEXAM) - Engine Fire Drill Sequence (The Fire Handle Pull)

Pulling an Engine Fire Shutoff Handle accomplishes five vital isolation actions mechanically and electrically: 1. Shuts the engine fuel low-pressure (LP) firewall shutoff valve; 2. Shuts the engine hydraulic supply firewall shutoff valve; 3. Closes the engine pneumatic bleed air valve; 4. De-excites the engine AC generator (trips generator breaker and field breaker); 5. ARMS the fire extinguisher bottle discharge squibs (cartridges)!

3. SMOKE DETECTION & CARGO COMPARTMENT CLASSIFICATIONS

Cargo compartments under CS-25 / FAR-25 are classified according to accessibility and fire suppression capabilities:

Class	Accessibility & Suppression	Aviation Regulations & Examples
Class A	Readily accessible to crew in flight (e.g. cockpit coat closet).	Fire easily discovered; hand fire extinguisher sufficient.
Class B	Accessible to crew in flight with sufficient access to reach any part.	Equipped with smoke/fire detection and separate hand fire extinguishing access.
Class C	INACCESSIBLE lower cargo holds on passenger airliners (standard baggage hold).	MANDATORY: 1. Separate smoke/fire detector system; 2. Built-in built-in Halon extinguishing system controlled from cockpit; 3. Means to control ventilation to starve fire of oxygen.
Class D	Obsolete class (unventilated, relied on oxygen starvation). Banned following ValuJet 592 crash!	All former Class D holds have been retrofitted to Class C standards with active fire extinguishing.
Class E	Main deck cargo cabins on ALL-CARGO freighter aircraft.	Equipped with smoke detection; crew shuts down ventilation and depressurizes cargo cabin in flight to starve fire.

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What does pulling an engine fire shutoff handle in the cockpit accomplish?

[A] Discharges both fire bottles immediately into the engine core [B] Shuts off fuel, hydraulics, bleed air, trips the generator, and arms the fire bottle squibs [C] Feather the opposite engine [D] Extends the landing gear

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The fire handle isolates all fluid and electrical supplies to the engine (fuel, hydraulics, pneumatic bleed, generator) and arms the explosive squibs. Rotating the handle then discharges the extinguisher bottle.

Q2: In a dual-loop engine fire detection system (Loop A and Loop B), what is the normal alarm logic to prevent

[A] Loop A must detect fire, while Loop B must detect smoke [B] Both Loop A AND Loop B must detect the fire condition simultaneously [C] Either Loop A OR Loop B is sufficient [D] Loop A tests Loop B every 30 seconds

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Dual-loop systems require 'AND' logic to trigger master warning bells and lights. If both loops agree, a fire is confirmed. If only one triggers, a loop fault is annunciated unless manual override is selected.

Q3: Which cargo compartment class applies to the inaccessible lower underfloor baggage holds of modern pa

[A] Class A [B] Class B [C] Class C [D] Class E

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [C]. Class C cargo holds are inaccessible in flight and must have smoke/fire detection, built-in cockpit-controlled extinguishing systems (Halon flooding and metering bottles), and ventilation shutoff controls.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 10: Aircraft Fuel Systems (Tanks, Pumps & Jettison)

Syllabus Source: CAE Oxford (pp. 309-338) | Pass Target: >= 90% AviationExam

1. AVIATION TURBINE FUELS: JET A-1 VS JET A VS JET B

Jet engines burn kerosene-type aviation fuels possessing high energy density, low freezing points, and clean combustion characteristics:

Fuel Designation	Chemical Base & Composition	Freezing Point & Flash Point Specification
Jet A-1	Civil standard kerosene used worldwide (except domestic USA).	Freezing Point: -47°C maximum. Flash Point: +38°C (100°F) minimum. Nominal Density: 0.80 kg/litre (6.7 lb/US Gal).
Jet A	Civil kerosene used primarily in the domestic United States.	Freezing Point: -40°C maximum (7°C higher than Jet A-1!). Flash Point: +38°C minimum. Density: 0.80 kg/litre.
Jet B (Wide-Cut)	Blend of gasoline and kerosene (military equivalent JP-4).	Freezing Point: -60°C maximum. Flash Point: VERY LOW (-20°C). Highly volatile and hazardous; used only in extreme Arctic/polar operations.

[!] EXAM TRAP (AVIATIONEXAM) - Fuel Temperature & Freezing Monitoring in Long-Range Cruise

- Minimum Fuel Temperature Limit: Fuel temperature in flight must not be allowed to drop closer than 3°C above the fuel freezing point (e.g. For Jet A-1 with freezing point -47°C, minimum allowable fuel temp is -44°C)! - Corrective Actions for Cold Fuel: 1. Accelerate to higher Mach number (increases kinetic Ram rise heating: $TAT = SAT \times (1 + 0.2 M^2)$); 2. Descend to a lower, warmer altitude.

2. TANK ARCHITECTURE, BOOST PUMPS & CROSSFEED

Commercial airliners store fuel primarily in the wings (wet wing integral tanks) and center fuselage tank:

- **Integral Tanks (Wet Wing):** The wing structure itself (spars, skin, ribs) forms the fuel tank, sealed with polysulfide sealant. Saves massive weight compared to separate fuel cells.
- **Wing Bending Relief:** Fuel in the wings counteracts upward aerodynamic wing bending moments during flight, reducing stress on the wing root! For this reason, fuel from the CENTER TANK is always burned FIRST, keeping wing fuel loaded until later in the flight.
- **Submerged Fuel Boost Pumps:** Each tank contains AC motor-driven submerged centrifugal pumps. Center tank pumps have higher output pressure (override/jettison pumps) than wing pumps, ensuring center tank fuel feeds engines preferentially.
- **Crossfeed Valve:** Allows any fuel tank to feed any engine, permitting lateral fuel balance corrections in flight, or allowing remaining engines to feed from all tanks during engine-out operations.
- **Fuel Jettison (Dumping):** Mandatory on aircraft whose Maximum Take-Off Mass (MTOM) significantly exceeds Maximum Landing Mass (MLM). Must be capable of dumping fuel rapidly down to maximum landing mass within 15 minutes, while maintaining sufficient fuel reserve to fly to an alternate.

3. AIRCRAFT REFUELING SAFETY & NITROGEN INERTING (OBIGGS)

Ground refueling presents extreme fire and static discharge hazards:

- Electrical Bonding: Before fuel hose connection, a grounding/bonding wire must be attached between the fuel truck and aircraft to equalize electrostatic potential and prevent sparks.
- Nitrogen Inerting (OBIGGS): On-Board Inert Gas Generating Systems separate nitrogen from bleed air and pump nitrogen-enriched air (NEA, oxygen < 9%) into fuel tank vapor ullage spaces, eliminating flammable oxygen mixtures (preventing TWA 800 center tank explosion scenario).

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: Why is center tank fuel burned before wing tank fuel during normal flight in transport aircraft?

[A] Because center tank fuel freezes faster [B] To preserve fuel mass in the wings as long as possible, providing upward wing-bending relief against aerodynamic lift forces [C] Because center tank fuel cannot be jettisoned [D] To keep the center of gravity as far aft as possible

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The weight of fuel stored inside the wings opposes upward aerodynamic lift, reducing bending moments at the wing root. Consuming center tank fuel first preserves this structural wing-bending relief.

Q2: What is the specified maximum freezing point of standard international Jet A-1 fuel?

[A] -40°C [B] -47°C [C] -50°C [D] -60°C

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Jet A-1 has a mandatory maximum freezing point of -47°C. (Jet A, used in the US, has a freezing point of -40°C).

Q3: In a long-range jet flying in polar airspace, fuel temperature indicates -43°C while burning Jet A-1 (freezing

[A] Jettison the cold fuel immediately [B] Descend to a warmer altitude or increase Mach number to increase aerodynamic kinetic heating [C] Turn off the fuel boost pumps [D] Shut down one engine to heat the wing

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Fuel temp must remain at least 3°C above freezing point (minimum -44°C for Jet A-1). At -43°C, fuel is dangerously close to waxing. Pilots must accelerate (higher Mach = higher TAT ram rise) or descend into warmer air.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 11: DC Principles, Components & Circuit Protection

Syllabus Source: CAE Oxford (pp. 1-42 (Elec)) | Pass Target: >= 90% AviationExam

1. FUNDAMENTAL DC ELECTRICAL LAWS & UNITS

Direct Current (DC) flows continuously in one direction from positive to negative (conventional current flow) or negative to positive (electron flow). Aeronautical DC systems operate at a standard 28 Volts DC (nominal):

- Ohm's Law: Voltage (V) = Current (I) x Resistance (R). Current is directly proportional to voltage and inversely proportional to resistance.
- Electrical Power: Power (P) = Voltage (V) x Current (I) = I^2 x R = V^2 / R. Measured in Watts (W) or Kilowatts (kW). 1 Horsepower (HP) = 746 Watts.
- Kirchhoff's Current Law (KCL): The algebraic sum of currents entering and leaving any electrical node is zero (Total current in = Total current out).
- Kirchhoff's Voltage Law (KVL): The directed sum of electrical potential differences (voltage) around any closed loop is zero.
- Resistance Combinations: Series: R_total = R1 + R2 + R3 (current identical through all, voltages add). Parallel: 1/R_total = 1/R1 + 1/R2 + 1/R3 (voltage identical across all, currents add; total resistance is always LESS than the smallest individual resistor).

2. CIRCUIT PROTECTION: FUSES VS CIRCUIT BREAKERS (TRIP-FREE)

Electrical conductors are sized according to current rating and allowable voltage drop. Circuit protection devices protect the WIRING against excessive current and fire, not the downstream consumer device:

Device	Operating Principle	Aeronautical Rule & Reset Philosophy
Thermal Circuit Breaker	Bimetallic strip heats up under excessive current (I^2 x R), bends, and trips mechanical latch.	Standard aircraft cockpit protection. Push-pull button with white indicator collar exposed when tripped.
Trip-Free Circuit Breaker	Internal mechanism trips contacts open even if the pilot physically holds or tapes the button in!	MANDATORY CS-25 requirement for flight deck circuit breakers. Prevents crew from overriding an active electrical short-circuit and setting fire to aircraft wiring!
Resetting Policy (SOP)	Commercial airline Standard Operating Procedures strictly regulate resetting tripped CBs.	CRITICAL: Tripped CBs must NEVER be reset in flight unless deemed essential for safe continuation of flight (e.g. landing gear extension), and then ONCE ONLY after a 3-minute cooling period!
Static Dischargers (Wicks)	Conductive carbon fibers mounted at wingtips, elevator tips, and rudder trailing edge.	Discharges accumulated electrostatic precipitation static (P-static) harmlessly into ambient slipstream at low current density, eliminating VHF/HF radio interference.

[!] EXAM TRAP (AVIATIONEXAM) - Trip-Free Circuit Breaker CS-25 Mandate

- Definition: A 'Trip-Free' circuit breaker will open the circuit and trip even if the operating knob or lever is held mechanically in the 'ON' (pushed) position! -

Reason: Guarantees that an electrical short circuit or severe wiring overheat cannot be forced to remain energized by a crew member holding the breaker in.

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What is the primary purpose of a circuit breaker in an aircraft electrical distribution system?**

[A] To protect the electrical wiring against overheating and electrical fire caused by excessive current [B] To protect the generator against overvoltage [C] To convert AC to DC [D] To regulate bus voltage

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [A]. Circuit breakers are engineered and sized primarily to protect the aircraft wiring harness from drawing excessive current, overheating, and igniting an in-flight fire.

Q2: What is the defining characteristic of a 'trip-free' circuit breaker as mandated by CS-25 regulations?

[A] It can be reset an unlimited number of times [B] It trips automatically under fault current even if the reset button is held depressed manually [C] It trips with zero time delay [D] It requires no physical reset

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. A trip-free breaker has an internal linkage that will trip open regardless of whether the pilot holds the external button down, preventing forced overload of shorted wiring.

Q3: What happens to the total resistance of an electrical circuit when additional resistors are connected in PARALLEL?

[A] Total resistance increases [B] Total resistance decreases and is always less than the lowest individual resistor value [C] Total resistance remains constant [D] Total resistance becomes zero

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. In parallel circuits ($1/R_{tot} = 1/R1 + 1/R2...$), adding parallel pathways provides more routes for current to flow, which always reduces total overall resistance below that of any individual resistor.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 12: Aircraft Batteries & Thermal Runaway

Syllabus Source: CAE Oxford (pp. 43-68 (Elec)) | Pass Target: >= 90% AviationExam

1. AIRCRAFT BATTERY CHEMISTRIES: LEAD-ACID VS NICKEL-CADMIUM (NI-CAD)

Aviation storage batteries supply emergency DC electrical power, APU/engine starting current, and stabilize DC bus voltage. Two incompatible electrochemical battery chemistries are used in transport aviation:

Feature	Lead-Acid Battery	Nickel-Cadmium (Ni-Cad) Battery
Electrolyte	Dilute Sulphuric Acid (H ₂ SO ₄) in water (S.G. ~1.280 fully charged).	Potassium Hydroxide (KOH) in water (~30% solution). DOES NOT CHANGE S.G. during charge/discharge!
Cell Voltage	2.0 Volts per cell nominal (12 cells in series = 24V battery).	1.2 Volts per cell nominal (20 cells in series = 24V battery).
Discharge Curve	Voltage drops progressively and steadily throughout discharge.	Maintains virtually FLAT constant voltage output until 90% discharged, then drops precipitously.
State of Charge Check	Measured accurately using a hydrometer to check electrolyte Specific Gravity (S.G. drops as battery discharges).	CANNOT be checked by hydrometer or voltage! (KOH is only a catalytic medium; voltage remains constant). Must undergo controlled workshop discharge test.
Cold Weather Performance	Discharged battery can freeze at -10°C (electrolyte becomes pure water).	Superior cold-weather starting performance; electrolyte freezing point is -60°C.

[!] EXAM TRAP (AVIATIONEXAM) - Thermal Runaway in Nickel-Cadmium (Ni-Cad) Batteries

- Mechanism: Ni-Cad batteries have a **NEGATIVE TEMPERATURE COEFFICIENT OF RESISTANCE!**
 As battery temperature rises, internal electrical resistance **DECREASES**. - The Vicious Cycle: At constant-voltage charging, lower resistance draws **HIGHER** charging current -> generates **MORE** heat -> resistance drops further -> draws even **MORE** current -> violently boils electrolyte, releases explosive hydrogen gas, and causes violent battery explosion/fire! - Protection: Ni-Cad battery compartments **MUST** be equipped with battery temperature sensors and thermal cut-off switches!

2. BATTERY CAPACITY & EMERGENCY STANDBY DURATION

Battery capacity is rated in Ampere-Hours (Ah). A 40 Ah battery can theoretically supply 40 Amperes for 1 hour, or 4 Amperes for 10 hours:

- CS-25 Emergency Duration: In the event of complete primary electrical power generation failure (dual generator loss), aircraft emergency batteries **MUST** supply essential flight deck instruments, emergency lighting, and VHF comms for **AT LEAST 30 MINUTES**.
- Separation of Maintenance Shops: Lead-acid and Ni-Cad batteries must be serviced in **COMPLETELY SEPARATE** battery servicing rooms. Acid fumes from lead-acid neutralize alkaline KOH electrolyte in Ni-Cad cells, destroying both batteries!

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is the fundamental electro-chemical mechanism that triggers thermal runaway in an aircraft Nickel-Cadmium battery?

[A] High internal resistance at freezing temperatures [B] A negative temperature coefficient of resistance, where increasing internal temperature causes internal resistance to drop, drawing exponentially higher charging current under constant voltage [C] Acid vaporization [D] Over-dilution of sulfuric acid

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Ni-Cad cells have a negative temperature coefficient. As they heat up, internal resistance drops, causing the battery to draw more current from the constant-voltage bus, producing more heat in an uncontrollable thermal runaway cycle.

Q2: How can the state of charge of an aircraft lead-acid battery be determined accurately in a maintenance facility?

[A] By measuring the specific gravity of the electrolyte with a hydrometer [B] By shaking the battery [C] By weighing the battery plates [D] By checking battery temperature

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [A]. As a lead-acid battery discharges, sulfuric acid is consumed to form lead sulfate and water, dropping electrolyte specific gravity from 1.280 to 1.150. S.G. directly indicates state of charge.

Q3: Under CS-25 certification requirements, for what minimum time period must emergency aircraft batteries supply power to essential instruments and equipment?

[A] 10 minutes [B] 15 minutes [C] 30 minutes [D] 60 minutes

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [C]. Transport category aircraft batteries must provide at least 30 minutes of emergency power to essential flight instruments, standby attitude indicator, and communication equipment.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 13: Magnetism, DC Generation & Starter-Generators

Syllabus Source: CAE Oxford (pp. 69-96 (Elec)) | Pass Target: >= 90% AviationExam

1. ELECTROMAGNETIC INDUCTION & DC GENERATOR PRINCIPLES

Electrical generation is based on Faraday's Law of Electromagnetic Induction: when an electrical conductor cuts magnetic lines of flux, an Electromotive Force (EMF / Voltage) is induced in the conductor:

- Fleming's Right-Hand Rule (Generators): Thumb = Motion of conductor; First finger = Magnetic Field (North to South); Second finger = Induced Current direction.
- Fundamental AC Generation in Armature: ALL rotating generators fundamentally produce ALTERNATING CURRENT (AC) inside the spinning armature coils as the wire alternates cutting north and south magnetic poles!
- The Commutator (Mechanical Rectifier): In a DC generator, the rotating armature is connected to a split copper cylinder called a COMMUTATOR. Stationary carbon brushes ride on the commutator segments, mechanically switching connections at the exact instant induced voltage reverses, outputting pulsing DIRECT CURRENT (DC) to the busbar.

2. DC VOLTAGE REGULATION & SHUNT GENERATORS

Aircraft DC generators are self-exciting shunt generators (field coils connected in parallel with the armature). Generated EMF is proportional to: 1. Magnetic field strength (flux); 2. Rotational speed (RPM); 3. Number of armature conductor turns:

- Voltage Control Mechanism: Because engine RPM varies widely across flight regimes (idle to take-off), generator output voltage MUST BE REGULATED by controlling FIELD CURRENT in the stationary field windings.
- Carbon Pile Voltage Regulator: Contains a stack of carbon discs in series with the field winding. An electromagnet sensing bus voltage compresses or releases spring pressure on the carbon stack. Higher voltage -> electromagnet pulls against spring -> decompresses carbon discs -> stack resistance increases -> field current drops -> generator voltage drops back to 28V.
- Reverse Current Circuit Breaker (RCCB): Prevents the battery from discharging backward into the generator when engine RPM drops below generator cut-in speed (motoring the generator). Disconnects generator automatically if current reverses.

[!] EXAM TRAP (AVIATIONEXAM) - Starter-Generator Operating Modes in Turboprops

- Twin-role machine: Acts as a powerful DC electric motor during engine start, then switches automatically to become a 28V DC generator once engine accelerates past self-sustaining starter cut-out speed! - During Start: Series field windings engaged for maximum high-torque starting power. - During Generation: Switches to shunt field windings with voltage regulator active to supply steady 28V DC.

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is the primary operational function of the commutator in a DC aircraft generator?

[A] To increase rotational speed [B] To act as a mechanical rotary rectifier, converting the alternating current (AC) naturally produced in the armature into direct current (DC) [C] To regulate system voltage [D] To insulate the brushes

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. All rotating armatures induce AC. The commutator is a split copper ring that mechanically reverses contact polarity twice per revolution, rectifying AC into pulsating DC.

Q2: How is the output voltage of an aircraft DC generator regulated as engine RPM changes in flight?

[A] By altering the number of windings on the armature [B] By varying the strength of the magnetic field current [C] By moving the carbon brushes mechanically [D] By changing battery electrolyte levels

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Output voltage = $k \times \text{Flux} \times \text{RPM}$. Because RPM varies with engine throttle, the voltage regulator modulates the current flowing through the shunt field coils to keep bus voltage constant at 28V.

Q3: What device prevents an aircraft battery from discharging back into a DC generator when engine RPM drops?

[A] A carbon pile [B] A Reverse Current Circuit Breaker (RCCB) or reverse current diode [C] A static inverter [D] A transformer rectifier unit

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. If generator voltage drops below battery voltage, current would reverse and try to drive the generator as an electric motor. The RCCB detects reverse current flow and instantly opens the contactor.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 14: AC Generation, Alternators & CSD / IDG

Syllabus Source: CAE Oxford (pp. 97-138 (Elec)) | Pass Target: >= 90% AviationExam

1. AERONAUTICAL AC SPECIFICATIONS: 115V / 200V AT 400 HZ

Transport aircraft utilize 3-phase Alternating Current (AC) as the primary electrical generation medium due to dramatic weight savings and superior motor/transformer efficiency compared to DC systems:

- Voltage Specification: Standard commercial aircraft AC power is 115 Volts RMS Phase-to-Neutral (Star configuration) and 200 Volts RMS Line-to-Line (Phase-to-Phase):
 $V_{line} = \sqrt{3} \times V_{phase} = 1.732 \times 115V = 200V$.
- Frequency Specification (400 Hz): Commercial aircraft operate at 400 Hertz (cycles per second), compared to 50/60 Hz domestic ground mains. High 400 Hz frequency allows transformers, alternators, and motors to be manufactured with dramatically smaller, lighter magnetic iron cores, saving tons of aircraft weight!
- Frequency Formula: Frequency (f) = (P x N) / 120, where P = number of magnetic poles and N = generator rotational speed in RPM. For an 8-pole generator to produce 400 Hz: N = (120 x 400) / 8 = 6,000 RPM (CONSTANT)!

2. MODERN BRUSHLESS AC GENERATOR ARCHITECTURE

High-altitude sparking and rapid carbon brush wear in thin air led to the universal adoption of brushless AC generators, housing three distinct electrical machines on a single rotating rotor shaft:

Stage	Rotating Rotor Element	Stationary Stator Element & Function
1. Pilot Exciter	Permanent Magnet Rotor (spinning magnets).	Permanent Magnet Generator (PMG) 3-phase stator. Induces AC voltage to power the Generator Control Unit (GCU) independently without battery power!
2. Main Exciter	3-phase AC armature winding feeding rotating rectifier diodes.	DC Field Winding controlled by the GCU. GCU varies DC current to regulate main output voltage.
3. Rotating Rectifier	Six silicon diodes mounted on the rotating shaft.	Rectifies 3-phase AC from main exciter rotor into DC, directly feeding the main generator field WITHOUT BRUSHES!
4. Main Generator	Heavy DC magnetic field windings (poles).	Main 3-phase Star-connected stator. Delivers primary 115V / 200V 400 Hz power to the main aircraft busbars.

3. CONSTANT SPEED DRIVE (CSD) & INTEGRATED DRIVE GENERATOR (IDG)

Because jet engine accessory gearbox speed varies constantly (from ~4,500 to ~9,000 RPM), an intermediate hydromechanical transmission is mandatory to drive the generator at an EXACT, UNVARYING 6,000 RPM to maintain 400 Hz (+/- 1% / 396 to 404 Hz):

- Constant Speed Drive (CSD): A variable hydromechanical transmission (hydraulic pump and motor linked through a differential planetary gear train) that adds or subtracts speed to keep the output shaft locked at 6,000 RPM.

- Integrated Drive Generator (IDG): The modern standard (e.g. A320, B737NG, B777). Integrates the CSD transmission and the brushless AC generator inside a single, common oil-cooled casing, saving weight and maintenance.
- CSD / IDG In-Flight Disconnect: If CSD oil temperature exceeds limits or oil pressure drops, a cockpit DISCONNECT switch fires an electro-mechanical solenoid that physically disengages a dog-clutch from the engine gearbox. CRITICAL EXAM POINT: Once disconnected in flight, the CSD / IDG CANNOT BE RECONNECTED IN FLIGHT! It can ONLY be reset manually by ground mechanics after landing!

[!] EXAM TRAP (AVIATIONEXAM) - CSD / IDG Disconnect Rules & Warnings

- Cockpit Disconnect Switch: Protected by a red guarded cover. Activated when high oil temperature or low oil pressure is annunciated. - Thermal Disconnect: Many IDGs incorporate a eutectic solder plug that automatically disconnects the drive if case temperature exceeds ~180°C. - STRICT EXAM RULE: The CSD CANNOT be reconnected in flight under any circumstances!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: Why do commercial transport aircraft use an electrical AC frequency of 400 Hz instead of standard commercial power?

[A] To prevent radio interference [B] Because 400 Hz allows transformers, motors, and magnetic components to be engineered with much smaller and lighter iron cores, saving substantial aircraft weight [C] Because 400 Hz does not cause electrical shocks [D] To improve generator brush life

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The size and weight of electromagnetic iron cores (in transformers, generators, and electric motors) is inversely proportional to frequency. 400 Hz allows miniature, lightweight components compared to bulky 50/60 Hz industrial equipment.

Q2: In a 3-phase 115V AC star-connected aircraft generator, what is the line-to-line (phase-to-phase) voltage?

[A] 115 V [B] 200 V [C] 230 V [D] 345 V

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Line-to-line voltage is related to phase-to-neutral voltage by $V_{line} = \sqrt{3} \times V_{phase}$. Thus: $1.732 \times 115V = 199.2 V$ (~200 Volts AC).

Q3: Can an Integrated Drive Generator (IDG) that has been disconnected in flight by the pilot be reconnected by the pilot?

[A] Yes, by pressing the IDG reset button on the overhead panel [B] Yes, once the oil cools below 100°C [C] No, mechanical reconnection is physically impossible in flight and can only be performed manually on the ground by maintenance personnel [D] Yes, by recycling the engine master switch

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [C]. The CSD/IDG disconnect separates a mechanical spring-loaded dog clutch. Once pulled out of mesh, it cannot be engaged while running and must be reset manually on the ground.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 15: AC Distribution, TRUs, Inverters & Architecture

Syllabus Source: CAE Oxford (pp. 139-166 (Elec)) | Pass Target: >= 90% AviationExam

1. BUSBAR ARCHITECTURES: SPLIT-BUS VS PARALLEL SYSTEMS

Commercial aircraft distribute electrical power through rigid copper or aluminum conductor rails called busbars (buses). Two distinct system philosophies govern AC generator connection:

Distribution System	Operating Philosophy & Generator Connection	Aircraft Examples & Nuances
Split-Bus System (Isolated)	Generators NEVER operate in parallel! Each AC generator powers its own independent AC busbar.	Standard on twin-engine aircraft (A320, B737, B777, B787). If one generator fails, a Bus Tie Breaker (BTB) closes automatically so the remaining generator powers both sides. Paralleling is strictly prohibited!
Parallel System	All AC generators are synchronized in frequency, voltage, and phase angle, connected to a common tie busbar.	Four-engine heavy transports (B747-400, older widebodies). Requires complex real (kW) and reactive (kVAR) load sharing circuitry in the GCU.

2. POWER CONVERSION UNITS: TRUS & STATIC INVERTERS

Modern airliners carry both AC and DC equipment, requiring two-way electrical power conversion:

- Transformer Rectifier Unit (TRU): Converts primary 115V AC (400 Hz) into 28V DC (nominal) to power DC busbars, charge batteries, and supply DC avionics. Contains a step-down transformer and a 6-phase bridge silicon diode rectifier. Has NO MOVING PARTS and requires cooling airflow.
- Static Inverter: Converts 28V DC (from aircraft batteries or DC buses) into 115V AC (single-phase, 400 Hz) to power essential flight instruments (standby attitude indicator, flight controls, navigation radios) during complete AC generator failure.

[!] EXAM TRAP (AVIATIONEXAM) - TRU vs Inverter Conversion Direction Trap

- TRU (Transformer Rectifier Unit): Converts AC -> DC (115V AC in -> 28V DC out)! - Static Inverter: Converts DC -> AC (28V DC in -> 115V AC out)! - Mnemonic: Inverter INVERTS the normal flow (takes battery DC and produces AC)!

3. GENERATOR CONTROL UNIT (GCU) & AUTOMATIC LOAD SHEDDING

Each AC generator is supervised by an electronic Generator Control Unit (GCU) providing protection and switching:

- GCU Protective Trips: Monitors for Overvoltage, Undervoltage, Overfrequency, Underfrequency, Feeder Fault (differential current between neutral and bus), and Reverse Power. If a fault occurs, the GCU opens the Generator Breaker (GB) and de-excites the generator field.

- Automatic Load Shedding: If an electrical generator is lost in flight, the remaining generator may exceed 100% rated capacity. The electrical system automatically sheds non-essential utility loads (galley ovens, cabin entertainment, passenger seat power, secondary water heaters) to preserve electrical power for flight instruments and safety systems!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is the operational function of a Transformer Rectifier Unit (TRU) in an aircraft electrical system?

[A] To convert 28V DC into 115V AC [B] To convert 115V AC into 28V DC [C] To regulate generator frequency at 400 Hz [D] To charge oxygen cylinders

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. A TRU steps down 115V AC power and rectifies it through solid-state silicon diodes into 28V DC power for the aircraft's DC busbars.

Q2: In a twin-engine jet aircraft featuring a 'split-bus' electrical architecture, what prevents two AC generators from operating in parallel?

[A] A reverse current relay [B] Interlocked Bus Tie Breakers (BTBs) that ensure generators operate completely isolated and never in parallel [C] Static inverters [D] Thermal fuses

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. In split-bus systems, parallel connection is prohibited. Control logic interlocks ensure that when an external generator or second engine generator connects, the bus tie opens or isolates.

Q3: Following an in-flight generator failure on a commercial airliner, what occurs automatically during 'load shedding'?

[A] Fuel is jettisoned from the wings [B] Non-essential electrical consumers (galley equipment, passenger entertainment) are disconnected automatically to prevent overloading the remaining generator [C] The APU shuts down [D] Flight controls switch to manual reversion

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Load shedding disconnects high-draw commercial utility loads (galleys) to guarantee sufficient capacity for essential flight guidance, instruments, and pumps.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 16: Semiconductors, Logic Gates & ARINC 429 Buses

Syllabus Source: CAE Oxford (pp. 167-200 (Elec)) | Pass Target: >= 90% AviationExam

1. SOLID-STATE SEMICONDUCTOR DEVICES

Solid-state electronics form the core of aircraft digital control units (FADEC, FMS, Fly-by-Wire FCCs, EGPWS):

- PN Junction Diode: Allows current to flow in one direction only (forward bias); blocks current in reverse. Used for rectification and reverse current protection.
- Zener Diode: Operates in reverse breakdown mode at an exact, predetermined voltage (Zener voltage). Used as high-precision VOLTAGE REGULATORS and voltage reference standards.
- Transistors (BJT / MOSFET): Three-terminal semiconductor devices (Base, Collector, Emitter or Gate, Drain, Source). Used as electronic solid-state switches and amplifiers.

2. DIGITAL LOGIC GATES: TRUTH TABLES & AERONAUTICAL LOGIC

Flight control computers and warning systems utilize Boolean logic gates to evaluate flight parameters:

Gate Type	Boolean Equation	Output Condition & Aircraft System Application
AND Gate	Output = A . B	Output is HIGH (1) ONLY IF ALL inputs are HIGH (1). Example: Cabin altitude horn = Cabin Alt > 10,000 ft AND Aircraft Airborne.
OR Gate	Output = A + B	Output is HIGH (1) IF ANY input is HIGH (1). Example: Master Caution = Low Hyd Press OR Low Fuel Press OR Gen Trip.
NOT Gate (Inverter)	Output = NOT A	Output is the exact opposite of input (1 becomes 0; 0 becomes 1).
NAND Gate	Output = NOT (A . B)	Output is LOW (0) ONLY if all inputs are HIGH (1). Inverted AND gate.
NOR Gate	Output = NOT (A + B)	Output is HIGH (1) ONLY if all inputs are LOW (0). Inverted OR gate.

3. AVIONICS DIGITAL DATA BUSES: ARINC 429 STANDARD

Modern avionics units (LRUs) communicate digitally over standardized serial data buses rather than individual heavy point-to-point analog wiring harnesses:

- ARINC 429 Architecture: The universal commercial standard. It is a SIMPLEX (one-directional) data bus. Transmits data from one single transmitter to up to 20 receivers across a twisted shielded wire pair.
- Word Structure (32 Bits): Every ARINC 429 transmission is an uncompressed 32-bit digital word: Bits 1-8: Label (identifies parameter, e.g. 203 = Pressure Altitude, 310 = Present Position Latitude); Bits 9-10: SDI (Source/Destination Identifier); Bits 11-29: Data Field (BCD or BNR numeric value); Bits 30-31: SSM (Sign/Status Matrix: Normal, Test, Failure Warning); Bit 32: Parity Bit (Odd parity standard to detect transmission errors).
- Transmission Speeds: Low-speed mode: 12.5 to 14.5 kbps; High-speed mode: 100 kbps.

- Advanced Aircraft Buses: Boeing 777 uses ARINC 629 (bidirectional, multi-transmitter); Airbus A380 / A350 and Boeing 787 use AFDX (Avionics Full-Duplex Switched Ethernet, 100 Mbps).

[!] EXAM TRAP (AVIATIONEXAM) - ARINC 429 Exam Traps Summary

- Simplex Bus: Data flows in ONE DIRECTION ONLY! (Two-way communication requires two separate wire pairs). - Word Length: Exactly 32 bits! - Parity: Bit 32 is always ODD parity. - Physical Wire: Twisted shielded pair with 78-ohm characteristic impedance.

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What is the bit structure length of a standard ARINC 429 digital avionics data bus word?**

[A] 16 bits [B] 32 bits [C] 64 bits [D] 128 bits

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The standard ARINC 429 data word consists of exactly 32 bits, comprising an 8-bit label, 2-bit SDI, 19-bit data field, 2-bit SSM, and a 1-bit parity check.

Q2: Which type of semiconductor diode is specifically engineered to operate in reverse breakdown mode to provide a stable reference voltage?

[A] Photodiode [B] Zener diode [C] Light Emitting Diode (LED) [D] Germanium power diode

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Zener diodes are designed to conduct in reverse once a specific breakdown voltage is reached, maintaining a stable reference voltage regardless of current variations.

Q3: How many transmitters can be connected to a single ARINC 429 digital data bus wire pair?

[A] Only ONE transmitter (simplex operation) [B] Up to 20 transmitters [C] Unlimited transmitters [D] Exactly two transmitters in full-duplex

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [A]. ARINC 429 is strictly point-to-point or point-to-multipoint SIMPLEX: it permits ONLY ONE single transmitter per bus line, driving up to 20 listening receivers.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 17: Piston Engines Structure & 4-Stroke Cycle

Syllabus Source: CAE Oxford (pp. 1-48 (Pwr)) | Pass Target: >= 90% AviationExam

1. THE FOUR-STROKE OTTO CYCLE & VALVE TIMING

Aero piston engines operate on the 4-stroke constant-volume Otto cycle. One complete engine cycle requires four piston strokes (two complete 360° revolutions of the crankshaft / 720° total rotation):

Stroke Name	Piston Travel Direction	Crankshaft Rotation & Valve Position
1. Induction	TDC to BDC (Top to Bottom Dead Center)	0° to 180°. Inlet valve open, exhaust valve closed. Low cylinder pressure draws in air-fuel mixture.
2. Compression	BDC to TDC	180° to 360°. Both valves closed. Piston compresses mixture into combustion chamber (~7:1 to 9:1 compression ratio). Ignition fires ~20-25° BEFORE TDC!
3. Power (Combustion)	TDC to BDC	360° to 540°. Both valves closed. Burning fuel gases expand rapidly, driving piston down to generate mechanical crankshaft torque.
4. Exhaust	BDC to TDC	540° to 720°. Exhaust valve open, inlet valve closed. Piston sweeps burned combustion gases out through exhaust manifold.

- Valve Lead & Lag: Inlet valve opens before TDC (valve lead) and closes after BDC (valve lag) to capitalize on incoming gas inertia, maximizing cylinder volumetric filling.
- Valve Overlap: The period around TDC at the end of the exhaust stroke and start of the induction stroke when BOTH inlet and exhaust valves are open simultaneously. Incoming fresh charge assists scavenging of exhaust gases and cools valve heads.

2. POWER TERMINOLOGY, EFFICIENCIES & BMEP

Engine performance is measured across different efficiency boundaries:

- Indicated Horsepower (IHP): Theoretical power developed by expanding combustion gases inside the cylinders: $IHP = (P_{LANK}) / 33,000$, where P = Indicated Mean Effective Pressure (IMEP).
- Brake Horsepower (BHP): Actual usable mechanical power delivered at the propeller drive shaft, measured with a dynamometer: $BHP = IHP - FHP$ (Friction Horsepower lost to bearing friction, oil pumping, and driving accessories).
- Mechanical Efficiency: BHP / IHP (typically 80% to 90%).
- Brake Mean Effective Pressure (BMEP): The average effective combustion pressure acting on the piston throughout the power stroke that produces the shaft BHP output.

3. SUPERCHARGING & TURBOCHARGING MECHANICS

Naturally aspirated engines lose power as altitude increases (~3% power loss per 1,000 ft) due to decreasing atmospheric density. Forced induction restores manifold pressure (MAP):

- Supercharger (Mechanically Driven): Centrifugal compressor driven by engine crankshaft gears. Draws significant engine power (parasitic loss) to spin compressor.
- Turbocharger (Exhaust Driven): Exhaust gas spins an exhaust turbine wheel connected via a common shaft to a centrifugal compressor. Harnesses normally wasted exhaust gas energy with minimal parasitic shaft load.
- Wastegate Controller: A butterfly or poppet valve that modulates how much exhaust gas passes across the turbo turbine vs bypassing directly overboard. Modulated by an oil-pressure actuator to maintain selected manifold pressure.
- Critical Altitude: The maximum altitude at which a turbocharged engine can maintain its maximum rated sea-level manifold pressure (or rated BHP) with the wastegate fully closed. Above critical altitude, manifold pressure and power decline steadily with altitude.

[!] EXAM TRAP (AVIATIONEXAM) - Critical Altitude Definition & Behavior

- Definition: The maximum altitude at which a turbocharged engine can produce its maximum rated continuous power / sea level manifold pressure. - Below Critical Altitude: The wastegate is PARTIALLY OPEN and closes progressively as altitude increases to maintain constant MAP. - At Critical Altitude: The wastegate reaches its FULLY CLOSED position! - Above Critical Altitude: The wastegate cannot close any further; MAP and engine power drop with further climb exactly like a naturally aspirated engine!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is 'valve overlap' in a four-stroke aero piston engine?

[A] The time when both spark plugs fire together [B] The angular period of crankshaft rotation around TDC when both the inlet and exhaust valves are open simultaneously [C] The time when both valves are closed on the power stroke [D] The clearance between valve rocker and stem

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Valve overlap occurs at the end of the exhaust stroke and start of the induction stroke when the inlet valve opens before the exhaust valve has completely seated, enhancing scavenging.

Q2: In a turbocharged aircraft piston engine, what is the 'Critical Altitude'?

[A] The altitude where detonation always occurs [B] The maximum altitude at which the engine can maintain its maximum rated power or sea-level manifold pressure with the wastegate fully closed [C] The altitude where the turbocharger compressor stalls [D] The service ceiling of the aircraft

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Critical altitude is reached when the turbo wastegate is 100% closed. Below this altitude, full rated power can be maintained; above it, manifold pressure declines as ambient density drops.

Q3: How does Brake Horsepower (BHP) compare mathematically to Indicated Horsepower (IHP)?

[A] BHP is always greater than IHP [B] $BHP = IHP - \text{Friction Horsepower (FHP)}$ [C] BHP is unrelated to IHP [D] $BHP = IHP \text{ multiplied by } 1.5$

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Indicated Horsepower is the total chemical energy converted in the cylinders. Brake Horsepower is the net usable shaft power delivered to the propeller after deducting internal friction horsepower losses.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 18: Aviation Gasoline, Carburation & Lubrication

Syllabus Source: CAE Oxford (pp. 49-92 (Pwr)) | Pass Target: >= 90% AviationExam

1. AVIATION GASOLINE (AVGAS): GRADES, COLOR CODES & DETONATION

Piston aircraft burn Aviation Gasoline (AVGAS) engineered for high volatility resistance and anti-knock stability:

Fuel Grade	Identification Dye Color	Octane / Performance Rating & Typical Use
AVGAS 100LL (Low Lead)	DYED BLUE	Most common aviation gasoline worldwide. 100 octane rating; contains limited tetraethyl lead (TEL) anti-knock additive. Density ~0.72 kg/litre.
AVGAS 100 (Green)	DYED GREEN	High-lead 100/130 aviation gasoline. Used in high-power supercharged vintage piston engines.
AVGAS 80/87	DYED RED	Low-octane fuel for vintage low-compression light aircraft engines.
Jet A-1 (Kerosene)	CLEAR / STRAW (Colorless)	STRICT PROHIBITION: NEVER PUT JET FUEL IN A PISTON ENGINE! Causes immediate catastrophic engine detonation, complete power loss, and engine destruction on take-off!

- **Detonation (Knocking):** Uncontrolled explosive auto-ignition of the remaining unburned end-gas ahead of the normal flame front. Creates supersonic shockwaves, extreme cylinder head temperatures (CHT), and can burn holes through piston crowns within seconds! Caused by: low fuel octane, excessively lean mixture, high MAP with low RPM, or high CHT.
- **Pre-Ignition:** Combustion initiated BEFORE the spark plug fires, caused by an incandescent hotspot in the cylinder (glowing carbon deposit, cracked spark plug insulator). Can lead directly to violent detonation.

2. CARBURETTOR ICING: TYPES & AMBIENT CONDITIONS

Float-type carburettors are highly susceptible to ice formation even in warm, sunny weather:

- **Fuel Evaporation Ice:** Liquid gasoline vaporizing in the venturi absorbs latent heat of vaporization, dropping air temperature inside the carburettor throat by up to 20°C to 25°C!
- **Throttle Ice:** Pressure drop across a partially closed throttle butterfly valve causes adiabatic expansion cooling, causing moisture to freeze directly onto the throttle valve.
- **Icing Risk Envelope:** Carburettor icing can occur with Outside Air Temperature (OAT) as high as +25°C or even +30°C if relative humidity is above 80%! Most severe risk occurs between -7°C and +21°C at moderate-to-high humidity and low power settings (descent/glide).
- **Carb Heat Operation:** Selects unfiltered air ducted across the hot exhaust shroud. When carb heat is selected ON: 1. Manifold pressure / RPM drops initially (hot air is less dense); 2. Engine runs rough as melted ice passes through; 3. RPM / MAP then rises higher than original as ice clears.

[!] EXAM TRAP (AVIATIONEXAM) - Carburettor Heat Application Sequence Trap

- Carburettor heat is an ANTI-ICING and DE-ICING control. When selected ON, it admits hot, UNFILTERED air into the engine. - Ground Rule: Do NOT use carb heat on the ground in dusty conditions (unfiltered air sucks grit into cylinders) except for brief pre-take-off functional check! - Throttle Rule: Carb heat should ALWAYS be applied BEFORE reducing power for descent, because exhaust shrouds cool rapidly at low throttle!

3. ENGINE LUBRICATION SYSTEMS: WET VS DRY SUMP

Engine oil cools internal components, lubricates bearing journals to reduce friction, cleans away carbon particles, cushions impact loads, and forms a gas seal between piston rings and cylinder walls:

- Wet-Sump System: Oil is stored in the crankcase oil pan (sump) beneath the engine. Used on light aircraft (Lycoming O-320/O-360). Simple, but oil sloshes during aerobatics/maneuvers, risking pump cavitation.
- Dry-Sump System: Oil is stored in an external separate oil tank. A scavenge pump (with capacity 25-50% larger than the pressure pump) draws oil from the shallow crankcase pan, routes it through an oil cooler, and pumps it back to the tank.

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What ambient weather conditions present the highest risk for severe carburettor icing in an aircraft piston engine?**

[A] OAT -20°C with 10% relative humidity [B] OAT between -7°C and +21°C with high relative humidity (>80%), especially at low power settings [C] OAT +35°C in dry desert air [D] Only when flying through freezing rain

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Fuel vaporization drops air temperature by up to 25°C. When ambient air is between -7°C and +21°C with high humidity, this temperature drop freezes moisture rapidly, choking the carburettor venturi.

Q2: What is the aviation dye color code for AVGAS 100LL (Low Lead)?

[A] Green [B] Red [C] Blue [D] Amber

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [C]. AVGAS 100LL is dyed BLUE worldwide. (AVGAS 100 is green, AVGAS 80 is red, and Jet A-1 is clear/straw).

Q3: Why does engine RPM drop slightly when carburettor heat is selected ON in an aircraft with a fixed-pitch propeller?

[A] The ignition timing retards [B] Hot air is less dense than cold ambient air, reducing charge mass entering the cylinders and producing a richer, less powerful mixture [C] The throttle valve closes partially [D] The exhaust valve sticks open

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Hot air ducted from the exhaust shroud has lower density, which reduces the mass of air entering the engine, slightly enriching the mixture and causing an immediate small drop in power/RPM.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 19: Propellers & Constant Speed Governors

Syllabus Source: CAE Oxford (pp. 93-138 (Pwr)) | Pass Target: $\geq 90\%$ AviationExam

1. PROPELLER AERODYNAMICS: BLADE ANGLE VS ANGLE OF ATTACK

A propeller blade is a rotating airfoil that converts engine shaft torque into forward aerodynamic thrust:

- **Blade Element Theory:** The blade is twisted from root to tip. Because rotational speed ($\omega \times r$) increases towards the tip while forward airspeed is constant, the blade angle must decrease progressively toward the tip to maintain an optimal aerodynamic Angle of Attack (α) along the entire blade length.
- **Blade Angle (Pitch):** The acute angle between the blade chord line and the propeller plane of rotation.
- **Angle of Attack (α):** The angle between the blade chord line and the **RELATIVE AIRFLOW** (which is the vector sum of rotational velocity and forward airspeed).
- **Propeller Slip:** Geometric Pitch (theoretical distance advanced in one revolution with zero slip) minus Effective Pitch (actual distance advanced in flight). $\text{Slip} = \text{Geometric Pitch} - \text{Effective Pitch}$.

2. CONSTANT SPEED UNIT (CSU / GOVERNOR) OPERATION

A Constant Speed Propeller maintains an exact, selected engine RPM automatically regardless of aircraft airspeed or throttle position, modulating blade pitch hydraulically via an engine-driven governor (CSU):

Flight Condition	Governor Flyweights & Valve State	Propeller Blade Pitch Response
ON-SPEED	Centrifugal force on rotating flyweights EXACTLY BALANCES speeder spring tension.	Pilot valve lands cover oil metering ports; oil trapped in propeller cylinder; blade pitch remains constant.
OVER-SPEED (Dive / Throttle Advance)	Rotational RPM increases $\rightarrow$ flyweights tilt OUTWARDS against spring, lifting pilot valve.	Meters high-pressure engine oil to/from propeller hub to COARSE (increase) blade pitch. Increased aerodynamic load slows engine back down to selected RPM!
UNDER-SPEED (Climb / Throttle Retard)	Rotational RPM drops $\rightarrow$ speeder spring overcomes flyweights and pushes pilot valve DOWN .	Changes oil flow to FINE (decrease) blade pitch. Reduced aerodynamic drag allows engine to accelerate back to selected RPM!

3. FEATHERING SYSTEMS & WINDMILLING DRAG

If a multi-engine aircraft suffers an engine failure in flight, a windmilling propeller creates massive parasite drag and severe yaw:

- **Feathering (Blade Angle $\sim 85^\circ$ to 90°):** Blades are aligned parallel to the relative airflow, stopping propeller rotation and minimizing aerodynamic drag to the lowest possible value.
- **Feathering Mechanism:** Multi-engine propellers use heavy counterweights and internal feathering springs to drive blades into feather. Oil pressure opposes the springs to move blades toward fine pitch. Therefore, if engine oil pressure is lost, the propeller **FEATHERS AUTOMATICALLY** for safety!

- Centrifugal Latch Pins: Prevent the propeller from feathering when the engine is shut down on the ground below ~800-1,000 RPM. (If blades feathered on the ground, starting loads on the electric starter motor would be dangerously excessive).
- Unfeathering Accumulator: Stores high-pressure oil during normal flight. When the pilot moves the propeller lever out of feather in flight, an unfeathering solenoid releases accumulator oil back to the prop cylinder, driving blades back to fine pitch to windmill and air-start the engine.

[!] EXAM TRAP (AVIATIONEXAM) - Single-Engine vs Multi-Engine Propeller Pitch Failure Modes

- Single-Engine Propeller: Engineered to fail toward FINE PITCH (low pitch) upon oil loss, ensuring maximum power remains available for safe landing! - Multi-Engine Propeller: Engineered to fail toward FEATHER (high pitch) upon oil loss (driven by counterweights and springs), preventing catastrophic windmilling drag and uncontrollable asymmetric yaw!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: In a multi-engine aircraft equipped with constant speed propellers, what happens to blade pitch if engine oil is lost?**

[A] The propeller drives to full reverse pitch [B] The propeller drives automatically to the FEATHERED position under the action of mechanical counterweights and feathering springs [C] The propeller remains locked in fine pitch [D] The propeller falls off

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Multi-engine propellers use oil pressure to maintain fine pitch. If oil pressure drops to zero, internal springs and counterweights drive the blades to full feather (~90°) to prevent high windmilling drag.

Q2: In a constant speed propeller governor (CSU), what directly balances the centrifugal force generated by the flyweights?

[A] Propeller blade torque [B] The tension of the pilot-controlled speeder spring [C] Atmospheric ambient air pressure [D] High-pressure nitrogen

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The speeder spring tension (controlled by the cockpit blue propeller lever) pushes down on the flyweights. Flyweights spin with engine RPM and tilt outward with centrifugal force, balancing at 'on-speed'.

Q3: Why are propeller blades manufactured with an aerodynamic twist from root to tip?

[A] To make the blades stronger near the tip [B] To maintain a relatively constant aerodynamic Angle of Attack along the entire length of the blade as rotational velocity increases toward the tip [C] To reduce manufacturing cost [D] To improve ground clearance

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Linear rotational speed is lowest at the hub and fastest at the blade tip. To prevent tip stall and maintain uniform lift distribution, blade angle is twisted (highest at root, lowest at tip).

Chapter 20: Gas Turbines: Inlets & Compressors

Syllabus Source: CAE Oxford (pp. 139-194 (Pwr)) | Pass Target: >= 90% AviationExam

1. THE BRAYTON CYCLE & ENGINE INLETS

Gas turbine engines operate on the open Brayton cycle (continuous combustion at constant pressure). Intake ducts must deliver undisturbed, subsonic air uniformly to the first compressor stage at approximately Mach 0.4 to 0.5:

- Subsonic Air Inlets: CONVERGENT-DIVERGENT geometry on supersonic aircraft, but a simple DIVERGENT DUCT on subsonic airliners. As subsonic air flows through a divergent intake: Air velocity DECREASES while static pressure and temperature INCREASE (diffuser effect).
- Ram Recovery: At high forward airspeed, ram compression inside the intake restores total pressure above ambient atmospheric pressure, enhancing mass airflow and engine thrust.

2. COMPRESSOR TYPES: CENTRIFUGAL VS AXIAL FLOW

Compressors compress air prior to combustion to maximize thermal efficiency (Pressure Ratio = P_{exit} / P_{inlet}):

Feature	Centrifugal Flow Compressor	Axial Flow Compressor
Design Elements	Impeller (rotor), Diffuser (stator), Manifold.	Alternating rows of rotating Rotor Blades and stationary Stator Vanes.
Airflow Path	Air enters eye, accelerated radially outwards 90°.	Air flows parallel to engine centerline; cross-sectional annulus tapers.
Stage Pressure Ratio	High per single stage (~4:1 to 5:1).	Low per stage (~1.2:1), but cumulative multi-stage pressure ratio exceeds 30:1 to 45:1!
Frontal Area & Drag	Large frontal area; high aerodynamic drag.	Small frontal area; low drag; ideal for high-speed transonic flight.
FOD Resistance	High resistance to foreign object damage and ice.	Susceptible to blade damage, tip rubbing, and aerodynamic stalls.

3. COMPRESSOR STALL & COMPRESSOR SURGE

Compressor blades are miniature aerodynamic airfoils operating at an angle of attack (Alpha = Vector sum of rotational velocity and axial airflow):

- Compressor Stall: Localized aerodynamic stall of one or more rotor blades. Airflow separates from the suction side of the blade, forming rotating stall cells that propagate around the annulus in the direction opposite to rotation relative to the blades.
- Compressor Surge: Complete catastrophic breakdown of airflow across the entire compressor! High-pressure air from the combustion chamber rushes violently forward in reverse out the engine intake with loud bangs, violent airframe vibrations, rapid EGT spikes, and power loss!
- Anti-Stall / Anti-Surge Devices: 1. Multi-Spool Design (separates N1 Low Pressure and N2 High Pressure shafts so each spool runs at optimal aerodynamic speed); 2. Variable Stator Vanes (VSVs) and Variable Inlet Guide Vanes (VIGVs) that modulate stator vane angles; 3. Compressor Bleed Valves that dump excess intermediate stage air overboard at low RPM.

[!] EXAM TRAP (AVIATIONEXAM) - Axial Compressor Blade Angle of Attack Dynamics

- Blade Angle of Attack depends on: 1. Rotational Speed (RPM); 2. Axial Airflow Velocity (V_{axial}). - STALL RISK: If axial airflow DECREASES (e.g. crosswinds, inlet distortion) or if rotational RPM INCREASES rapidly, blade Angle of Attack INCREASES toward critical stall angle! - High stage compression causes compressor rear stages to be prone to choke at low RPM, while front stages are prone to stall!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: In an axial flow compressor of a gas turbine engine, what happens to the velocity and static pressure of the flow as it passes through the compressor?**

[A] Velocity increases and static pressure decreases [B] Velocity decreases (diffuser action) and static pressure increases [C] Both velocity and static pressure increase [D] Velocity remains constant while pressure drops

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The passages between stator vanes form divergent ducts. As air passes through, kinetic energy is converted into static pressure: air velocity decreases while static pressure increases.

Q2: What is the primary operational difference between a compressor stall and a compressor surge?

[A] A stall occurs on the turbine, a surge occurs on the fan [B] A stall is a localized aerodynamic breakdown on individual compressor blades, while a surge is a complete reversal of airflow across the entire engine [C] A surge occurs only when descending [D] A stall increases engine thrust

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. A stall affects isolated blades or rotating cells. Surge is the complete loss of pressure containment, where combustion chamber pressure forces air explosively backward out the intake.

Q3: What device prevents front-stage compressor stalling during engine acceleration or low RPM operation?

[A] Fuel jettison valves [B] Variable Stator Vanes (VSVs) and compressor inter-stage bleed valves [C] Thrust reversers [D] Active clearance control

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. At low RPM, rear stages restrict flow, backing up air and causing front stages to stall. Bleed valves open to vent air overboard, while VSVs tilt to maintain optimum blade angle of attack.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 21: Combustion, Turbines & Exhaust / Reversers

Syllabus Source: CAE Oxford (pp. 195-256 (Pwr)) | Pass Target: >= 90% AviationExam

1. COMBUSTION CHAMBER ARCHITECTURE & AIR DISTRIBUTION

Combustion chambers burn fuel continuously to add thermal energy at constant pressure. Air entering from the compressor (at ~150 m/s) is slowed down by a diffuser to ~25 m/s to prevent blowing the flame out (flame speed is only ~2 to 5 m/s!):

Airflow Division	Percentage of Total Bleed Air	Operational Combustion Function
Primary Air	20% to 25%	Enters flame tube snout through swirl vanes to create a toroidal recirculation vortex. Mixes stoichiometrically (~15:1 air-fuel ratio) to support sustained ignition and stable core burning.
Secondary Air	15% to 20%	Enters through intermediate liner holes to complete combustion of unburned hydrocarbons.
Tertiary / Dilution Air	55% to 60% (The Majority!)	Enters downstream liner holes. Cools burning gases from ~2,000°C down to acceptable turbine entry temperatures (~1,200°C to 1,600°C) and forms an insulating film along chamber walls.

2. AXIAL FLOW TURBINES & BLADE COOLING

Turbines extract kinetic and heat energy from hot expanding combustion gases to drive the compressor and engine accessories:

- Nozzle Guide Vanes (NGVs): Stationary vanes positioned immediately upstream of the turbine rotor. Passages form CONVERGENT DUCTS that accelerate the gas to high velocity and deflect it at the optimum angle onto the turbine blades. Experiences highest thermal and aerodynamic stresses in the entire engine!
- Impulse vs Reaction Blading: Impulse: Gas pressure drops exclusively across NGVs, expanding as high-speed jets against curved blades. Reaction: Pressure drops across BOTH the NGVs and the rotating turbine blades (convergent blade passages). Modern engines use impulse blade roots transitioning to reaction blade tips.
- Turbine Blade Cooling: Blades are cast from single-crystal nickel superalloys. Cooled by compressor bleed air: 1. Internal convection passages; 2. Transpiration/film cooling where bleed air bleeds out through laser-drilled leading-edge holes, forming a protective microscopic thermal air cushion over the blade surface.
- Active Clearance Control (ACC): Engine casing cooling system that blows fan bypass air onto the turbine casing, matching thermal casing shrinkage to turbine rotor growth, maintaining microscopic blade-tip clearances (minimizing gas leakage).

3. EXHAUST SYSTEMS & THRUST REVERSERS

Exhaust nozzles accelerate combustion gases overboard to create forward thrust (Gross Thrust $F = \dot{m} \times V_{jet}$):

- Convergent Nozzle: Used on all commercial subsonic airliners. Accelerates subsonic exhaust gas up to sonic velocity (Mach 1.0) at the nozzle throat (choked nozzle condition).

- Thrust Reversers: Redirect fan bypass air (or core exhaust) forward to provide aerodynamic deceleration on landing: 1. Clamshell / Bucket doors (deflects core exhaust); 2. Cascade Vane / Translating Sleeves (aerodynamic blocker doors block fan duct, directing bypass air forward through cascade vanes). In-flight deployment is physically blocked by multiple mechanical and electrical interlocks.

[!] EXAM TRAP (AVIATIONEXAM) - Thrust Reverser Interlocks & In-Flight Safety

- Deployment on Ground: Requires weight-on-wheels (squat switch confirmation), throttle levers at idle, and reverse levers pulled. - In-Flight Protection: Features dual mechanical latches, hydraulic isolation valves, and auto-restow circuitry. If a reverser unlatches inadvertently in flight (e.g. Lauda Air 004 scenario), FADEC automatically reduces that engine's fuel flow to flight idle!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What percentage of total compressor air entering a gas turbine combustion chamber is used as 'primary a**

[A] 10% to 15% [B] 20% to 25% [C] 50% to 60% [D] 85% to 90%

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Only about 20-25% of the total air is primary air used directly for burning fuel at stoichiometric ratio. The remaining 75-80% is used for combustion completion and cooling dilution.

Q2: What is the primary operational function of turbine Nozzle Guide Vanes (NGVs)?

[A] To cool the exhaust gases [B] To accelerate the hot gases through convergent passages and direct them at the optimum angle onto the rotating turbine blades [C] To drive the engine oil pump [D] To reverse engine thrust

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. NGVs are stationary nozzles ahead of the turbine rotor. Their convergent shape converts gas pressure into high-velocity kinetic energy, directing the jet at the ideal impingement angle onto the blades.

Q3: How are modern high-pressure turbine blades protected against melting at temperatures exceeding the all

[A] By thermal paint only [B] By internal convection passages and external film cooling using relatively cool compressor bleed air [C] By injecting water into the fuel [D] By flying only in sub-zero ambient air

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Bleed air from the HP compressor is routed through internal labyrinth passages in the blade and exits through micro-holes to create a boundary film of cooler air shielding the metal from 1,500°C gases.

ATPL EASA STUDY GUIDE | 021 - AIRFRAME & SYSTEMS

Chapter 22: FADEC, Starting Systems & Parameters (N1, EGT, EPR)

Syllabus Source: CAE Oxford (pp. 257-310 (Pwr)) | Pass Target: >= 90% AviationExam

1. FULL AUTHORITY DIGITAL ENGINE CONTROL (FADEC)

FADEC has complete, unrestricted digital electronic control over all engine fuel metering, geometry, and operational functions with NO MECHANICAL BACKUP:

- Dual-Channel Redundancy: Consists of an Electronic Engine Controller (EEC) with two identical, independent digital channels (Channel A and Channel B). One channel is active while the other is in hot standby. Channels alternate control automatically on each engine start.
- Dedicated Power (PMA): FADEC is completely self-powered above ~10-15% N2 by its own engine-driven Permanent Magnet Alternator (PMA). Even if aircraft dual AC/DC electrical systems fail completely, FADEC continues operating with zero interruption!
- FADEC Control Functions: 1. Fuel metering (FMV); 2. Idle speed control (Flight idle, Ground idle, Reverse idle); 3. Transient bleed valves & VSVs; 4. Turbine active clearance control (ACC); 5. Thrust reverser deployment; 6. Engine limit protection (prevents N1/N2 over-speed and EGT over-temperature during auto-starts).

2. ENGINE STARTING SYSTEMS & ABNORMAL START DRILLS

Modern jet engines use a pneumatic starter motor powered by APU, crossbleed, or ground air cart to spin the HP spool (N2):

- Standard Start Sequence: 1. Pneumatic starter valve opens -> Starter cranks HP spool (N2 rotation); 2. At maximum motoring speed (typically 15% to 25% N2), fuel flow and ignition are switched on; 3. Light-off occurs -> EGT rises rapidly; 4. At self-sustaining idle speed (~50% N2), starter valve closes and ignition turns off.

Abnormal Start Condition Cockpit Instrument Symptoms		Immediate Flight Crew Emergency Action
Hot Start	EGT rises rapidly and threatens or exceeds maximum start limit before reaching idle speed.	ABORT START! Cut off fuel immediately; continue dry motoring engine with starter to blow cooling air through core.
Hung Start	Engine lights off and EGT rises, but RPM stabilizes well below self-sustaining idle speed (N2 hangs).	ABORT START! Cut off fuel; starter alone cannot overcome compressor drag.
Wet Start	Fuel is injected and flows into engine, but NO IGNITION occurs within specified time (EGT does not rise).	ABORT START! Cut off fuel; motor engine for at least 30-60 seconds to clear unburned fuel vapor before reattempt!

3. PRIMARY ENGINE THRUST PARAMETERS: N1, EPR & EGT

Turbine thrust cannot be measured directly in flight. Cockpit instruments indicate computed thrust indicators:

- N1 (Low Pressure Spool / Fan Speed %): PRIMARY thrust setting parameter on high-bypass turbofan engines (CFM56, GE90, LEAP). Because 80% of total thrust is produced by the cold bypass fan, N1 RPM correlates directly with aerodynamic thrust.

- Engine Pressure Ratio (EPR): PRIMARY thrust setting parameter on Rolls-Royce (Trent) and Pratt & Whitney engines. $EPR = \text{Total Pressure at Turbine Exhaust (P}_{t7}) / \text{Total Pressure at Engine Compressor Inlet (P}_{t2})$. An EPR of 1.50 means exhaust pressure is 1.5 times inlet ram pressure.
- Exhaust Gas Temperature (EGT): Measured between turbine stages or at turbine exhaust by chromel-alumel thermocouples. Indicates the thermal stress and health of the turbine. The primary life-limiting factor of gas turbine engines.

[!] EXAM TRAP (AVIATIONEXAM) - N1 vs EPR Engine Pressure Probe Icing Trap

- EPR engines rely on a heated P_{t2} pitot probe in the engine intake nose cone. - If the P_{t2} probe inlet blocks with ice in icing conditions: The probe senses artificially high pressure -> EPR indicates ERRONEOUSLY HIGH -> Pilot throttles back -> Engine delivers dangerously insufficient take-off thrust! - (This was the fatal primary cause of the Air Florida Flight 90 crash in Washington D.C.)!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What is a 'hung start' on a jet transport engine?**

[A] The starter motor fails to engage [B] The engine ignites normally, but rotational RPM fails to accelerate up to self-sustaining idle speed, stabilizing at an intermediate sub-idle value [C] EGT exceeds limits immediately [D] The propeller fails to unfeather

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. In a hung start, fuel lights off and EGT rises, but the engine lacks sufficient torque to accelerate past starter cut-out speed up to self-sustaining idle, hanging at low RPM.

Q2: In a Full Authority Digital Engine Control (FADEC) system, what is the dedicated source of electrical power?

[A] The aircraft main 28V DC battery [B] An engine-driven Permanent Magnet Alternator (PMA) mounted on the engine accessory gearbox [C] The aircraft TRU [D] The APU generator

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. FADEC incorporates its own dedicated PMA generator on the gearbox. Once above ~10-15% N2, FADEC is 100% self-powered, immune to any aircraft electrical failures.

Q3: On an aircraft that uses Engine Pressure Ratio (EPR) as its primary thrust indication, what is the mathematical formula for EPR?

[A] Ratio of compressor exit pressure to burner pressure [B] Ratio of turbine exhaust total pressure (P_{t7}) to compressor inlet total pressure (P_{t2}) [C] Ratio of fan speed to core speed [D] Fuel flow divided by air flow

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. EPR is defined as the total pressure at the turbine discharge / exhaust nozzle divided by the total pressure at the engine intake face (P_{t7} / P_{t2}).