

ATPL EASA STUDY GUIDE | 033 - FLIGHT PLANNING

Chapter 1: VFR Flight Planning & Navigational Calculations

Syllabus Source: CAE Oxford (pp. 1-40) | Pass Target: $\geq 90\%$ AviationExam

1. THE NAVIGATIONAL VECTOR TRIANGLE & TERMINOLOGY

Navigation is the geometric combination of aircraft heading/airspeed with the wind vector:

- True Track (TR): The actual path over the earth's surface that the aircraft intends to follow or is tracking.
- True Airspeed (TAS): The calibrated airspeed corrected for altitude and temperature. Represents speed through undisturbed air.
- Wind Vector (W/V): Given as direction (degrees True) FROM WHICH the wind blows, and speed (knots).
- Drift Angle & Wind Correction Angle (WCA): The angle between True Heading and True Track. Drift is Right (+) if wind pushes aircraft right of track. WCA opposes drift: Heading = Track - (+- Drift).
- Groundspeed (GS): The actual speed of the aircraft across the ground: $GS = TAS \pm \text{Wind Component}$.
- Conversion Chain: True Heading (TH) $\pm$ Magnetic Variation = Magnetic Heading (MH) $\pm$ Compass Deviation = Compass Heading (CH) ('Variation West, Magnetic Best; Variation East, Magnetic Least').

2. ETE & FUEL CONSUMPTION FORMULAS

- Estimated Time En Route (ETE): Time (hours) = Distance (NM) / Groundspeed (kt). Time (minutes) = (Distance / GS) $\times$ 60.
- Leg Fuel Burn: Fuel (liters or kg) = Time (hours) $\times$ Fuel Consumption Rate (liters/hr or kg/hr).

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: VFR Leg Heading, Groundspeed, ETE & Fuel

SCENARIO (Standard Navigation Flight Planning Drill): A pilot plans a cross-country leg: - True Track = 090° - Distance = 160 NM - True Airspeed (TAS) = 120 knots - Forecast Wind = 360° at 30 knots (Direct crosswind from the Left!) - Magnetic Variation = 5° West - Fuel Flow = 40 liters/hour QUESTION: Calculate (1) Wind Correction Angle & True Heading, (2) Magnetic Heading, (3) Groundspeed, (4) ETE, (5) Fuel Burned. SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Calculate Wind Correction Angle (WCA): - Wind is from 360° against a Track of 090° (Wind angle = 90° direct from Left). - Crosswind component = $30 \text{ kt} \times \sin(90^\circ) = 30 \text{ knots}$. - Headwind component = $30 \text{ kt} \times \cos(90^\circ) = 0 \text{ knots}$. - Rule of Thumb: Drift (degrees) ~ (Crosswind kt / TAS kt) x 60 - Drift = $(30 / 120) \times 60 = 0.25 \times 60 = 15^\circ$ to the RIGHT. - To counter a 15° Right drift, you must steer 15° to the LEFT (-15° WCA)! - True Heading (TH) = Track - Drift = $090^\circ - 15^\circ = 075^\circ$ True! Step 2: Calculate Magnetic Heading (MH) ('Variation West, Magnetic Best' -> ADD!): - MH = True Heading + Var West = $075^\circ + 5^\circ = 080^\circ$ Magnetic! Step 3: Calculate Groundspeed (GS) using Pythagoras Theorem on the vector triangle: - $GS = \sqrt{TAS^2 - Crosswind^2}$ - Headwind - $GS = \sqrt{120^2 - 30^2} = 0 = \sqrt{14,400 - 900} = \sqrt{13,500} = 116.2$ knots. Step 4: Calculate Estimated Time En Route (ETE): - Time = (Distance / GS) x 60 = $(160 \text{ NM} / 116.2 \text{ kt}) \times 60 = 1.377 \text{ hours} \times 60 = 82.6 \text{ minutes}$ (1h 23 min). Step 5: Calculate Leg Fuel Burn: - Fuel = Time (hours) x Fuel Flow = $1.377 \text{ hours} \times 40 \text{ L/hr} = 55.1 \text{ liters}$. FINAL ANSWER: True Heading = 075°; Magnetic Heading = 080°; GS = 116 kt; ETE = 83 minutes; Fuel = 55 liters.

[!] EXAM TRAP (AVIATIONEXAM) - Variation East vs West Memory Aid

- 'Variation West, Magnetic Best' -> Magnetic is BIGGER (ADD West variation to True Heading). - 'Variation East, Magnetic Least' -> Magnetic is SMALLER (SUBTRACT East variation from True Heading).

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: If True Track is 180°, True Airspeed is 150 kt, wind is 090°/30 kt, and variation is 10° East, what is the MAGNETIC HEADING?

[A] 160° [B] 170° [C] 190° [D] 180°

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [A]. Wind from 090° pushes aircraft to the Right (Drift +). Crosswind = 30 kt. Drift = $(30/150) \times 60 = 12^\circ$ Right. True Heading = $180^\circ - 12^\circ = 168^\circ$ True. Magnetic Heading = $168^\circ - 10^\circ$ East (East is least!) = 158° (~160°).

Q2: What is the effect of a 90° pure crosswind on aircraft Groundspeed compared to True Airspeed?

[A] Groundspeed equals TAS [B] Groundspeed is SLIGHTLY LESS than TAS, because aircraft nose must angle into the wind [C] Groundspeed is higher than TAS [D] Groundspeed drops to zero

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Because the aircraft points into the wind to maintain track (WCA), a portion of its forward TAS vector is angled sideways, reducing the forward groundspeed vector: $GS = \sqrt{TAS^2 - XW^2}$.

Q3: In navigational flight planning, how is 'DRIFT' defined?

[A] The angle between True North and Magnetic North [B] The angular difference between the Heading (aircraft longitudinal axis) and the Track (actual flight path over the ground) [C] The climb angle [D] The compass error

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Drift is the angle between heading and track caused by crosswind pushing the aircraft sideways.

ATPL EASA STUDY GUIDE | 033 - FLIGHT PLANNING

Chapter 2: EASA IFR Fuel Policy (AIR-OPS CAT.OP.MPA.180)

Syllabus Source: CAE Oxford (pp. 41-82) | Pass Target: >= 90% AviationExam

1. THE EASA REGULATORY FUEL BREAKDOWN

Under EASA AIR-OPS (CAT.OP.MPA.180), an IFR commercial flight is legally prohibited from departing without carrying minimum certified fuel reserves:

Fuel Component	Regulatory Definition & Calculation Basis	Operational Role & Minimum Rules
Fuel Component	Regulatory Definition & Calculation Basis	Operational Role & Minimum Rules
1. Taxi Fuel	Fuel consumed before take-off (APU burn, engine start, taxiing to runway).	Standard allowance: typically 150 to 300 kg for twin-jets (12-15 min).
2. Trip Fuel	Fuel required from brake release at departure to touchdown at destination.	Includes take-off, climb, cruise, descent, approach, and landing at destination.
3. Contingency Fuel	Buffer for unforeseen deviations (weather, ATC routing, lower flight level).	HIGHER OF: 5% of Trip Fuel, OR 3% with En-Route Alternate (ERA), OR 20 min flight time.
4. Destination Alternate Fuel	Fuel required to divert from missed approach at destination to alternate.	Missed approach + climb + cruise to alternate + descent + approach + landing.
5. Final Reserve Fuel	Fuel to hold at 1,500 ft AGL over alternate in ISA conditions.	MANDATORY: 30 minutes for turbine / jet aircraft (45 minutes for piston aircraft)!
6. Additional Fuel	Required only if aircraft must comply with depressurization or OEI drift down.	Ensures reaching a safe airport if engine fails or cabin depressurizes at critical point.
7. Extra Fuel	Discretionary fuel loaded at Commander's authority for anticipated delays.	Added for holding, thunderstorm circumnavigation, or tankering.

2. THE MASTER FUEL EQUATIONS

- Minimum Required Take-Off Fuel: $\text{Take-Off Fuel} = \text{Trip Fuel} + \text{Contingency Fuel} + \text{Alternate Fuel} + \text{Final Reserve Fuel} (+ \text{Additional Fuel})$.
- Minimum Required Block Fuel (Ramp Fuel): $\text{Block Fuel} = \text{Taxi Fuel} + \text{Minimum Required Take-Off Fuel} (+ \text{Extra Fuel})$.

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Compiling an EASA IFR Fuel Plan

SCENARIO (Classic ATPL Flight Planning Exam Question): An Airbus A320 is planned for an IFR passenger flight from Madrid to Paris: - Planned Taxi Fuel: 200 kg - Calculated Trip Fuel: 5,000 kg - Diversion fuel to Paris Alternate (Only to Beauvais): 1,200 kg - Holding fuel consumption at 1,500 ft AGL: 2,400 kg/hour - No En-Route Alternate (ERA) is designated (standard 5% contingency applies) - Commander requests 300 kg Extra Fuel for holding QUESTION: Calculate (1) Contingency Fuel, (2) Final Reserve Fuel, (3) Minimum Take-Off Fuel, and (4) Total Block Fuel. SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Calculate Contingency Fuel (Standard 5% of Trip Fuel): - Contingency = 5% of 5,000 kg = $0.05 \times 5,000 \text{ kg} = 250 \text{ kg}$. Step 2: Calculate Final Reserve Fuel (30 minutes of holding for jet!): - Holding fuel burn = 2,400 kg/hour. - Final Reserve (30 min = 0.5 hour) = $0.5 \text{ hr} \times 2,400 \text{ kg/hr} = 1,200 \text{ kg}$! Step 3: Calculate Minimum Required Take-Off Fuel: - Take-Off Fuel = Trip + Contingency + Alternate + Final Reserve - Take-Off Fuel = $5,000 \text{ kg} + 250 \text{ kg} + 1,200 \text{ kg} + 1,200 \text{ kg} = 7,650 \text{ kg}$. Step 4: Calculate Total Required Block Fuel (Add Taxi and Extra Fuel): - Block Fuel = Taxi (200 kg) + Take-Off Fuel (7,650 kg) + Extra (300 kg) - Block Fuel = $200 + 7,650 + 300 = 8,150 \text{ kg}$! FINAL ANSWER: Contingency = 250 kg; Final Reserve = 1,200 kg; Min Take-Off Fuel = 7,650 kg; Total Block Fuel = 8,150 kg.

[!] EXAM TRAP (AVIATIONEXAM) - Final Reserve: 30 Min Turbine vs 45 Min Piston Trap

- For TURBINE / JET aircraft: Final Reserve is 30 MINUTES holding at 1,500 ft. - For PISTON aircraft: Final Reserve is 45 MINUTES holding! - Final Reserve is SACROSANCT: If you calculate that you will land with less than Final Reserve, you MUST DECLARE 'MAYDAY MAYDAY MAYDAY FUEL'!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: Under EASA AIR-OPS, what is the minimum duration of FINAL RESERVE FUEL required for a commercial flight?**

[A] 45 minutes [B] 30 MINUTES holding at 1,500 ft AGL above the alternate aerodrome under ISA conditions [C] 20 minutes [D] 60 minutes

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. For turbine-powered aeroplanes, final reserve fuel is calculated for 30 minutes of holding at 1,500 ft (450 m) above aerodrome elevation in standard ISA conditions.

Q2: What is the standard CONTINGENCY FUEL percentage required on an IFR flight when no en-route alternate is available?

[A] 10% of Trip Fuel [B] 5% OF TRIP FUEL (or 5 minutes, whichever is greater) [C] 3% of Trip Fuel [D] 20%

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The baseline contingency fuel required by EASA CAT.OP.MPA.180 is 5% of the planned trip fuel (reduced to 3% only if an en-route alternate is nominated).

Q3: When MUST a flight crew legally declare 'MAYDAY MAYDAY MAYDAY FUEL' to Air Traffic Control?

[A] When diverting to any alternate [B] When the estimated usable fuel upon landing at the nearest suitable aerodrome is calculated to be LESS THAN the planned Final Reserve Fuel [C] When contingency fuel is exhausted [D] On any missed approach

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Under ICAO Annex 6 and EASA regulations, MAYDAY FUEL is an explicit declaration of emergency that must be transmitted whenever calculated fuel on touchdown is less than the mandatory 30-minute final reserve.

ATPL EASA STUDY GUIDE | 033 - FLIGHT PLANNING

Chapter 3: Critical Points: Point of No Return (PNR) & Equi-Time Point (ETP)

Syllabus Source: CAE Oxford (pp. 83-120) | Pass Target: >= 90% AviationExam

1. POINT OF NO RETURN (PNR / POINT OF SAFE RETURN)

The Point of No Return (PNR) is the furthest point along track to which an aircraft can fly and still return to the departure aerodrome (or en-route base) with mandatory reserves intact:

- PNR Concept: Beyond the PNR, the aircraft CANNOT RETURN to base; it is committed to flying forward. PNR depends exclusively on: (1) Safe Endurance (E), (2) Groundspeed Out (GS_out), and (3) Groundspeed Home (GS_home).
- Safe Endurance (E): Total fuel on board MINUS (Alternate Fuel + Final Reserve Fuel + Taxi Fuel). Only usable cruise fuel can be spent flying to PNR and back.
- The PNR Master Formula: $\text{Time to PNR (T_out)} = (\text{Safe Endurance (E)} \times \text{GS_home}) / (\text{GS_out} + \text{GS_home})$
- Distance to PNR: $\text{Distance_PNR} = \text{Time to PNR} \times \text{GS_out}$

2. EQUI-TIME POINT (ETP / CRITICAL POINT)

The Equi-Time Point (ETP) is the point along track from which it takes EQUAL FLYING TIME to continue to destination or to return to departure:

- ETP Concept: In zero wind, ETP is exactly half-way (50% distance). BUT WITH WIND, ETP MOVES INTO THE WIND! (A headwind on the way out shifts ETP closer to destination; a tailwind shifts ETP closer to departure).
- The ETP Master Formula: $\text{Distance to ETP (D_ETP)} = (\text{Total Leg Distance (D)} \times \text{GS_home}) / (\text{GS_out} + \text{GS_home})$
- Time to ETP: $\text{Time to ETP} = \text{D_ETP} / \text{GS_out}$

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Finding PNR and ETP with Wind

SCENARIO (Classic Exam Problem): An oceanic flight is planned between Airport A and Airport B: - Total Distance (D) = 1,200 NM - Aircraft TAS = 400 knots - En-route Wind: 50 knots direct Headwind on outbound leg (Tailwind returning home!) - Total Safe Endurance (E) = 4.0 hours QUESTION: Calculate (1) Distance to ETP from Airport A, and (2) Time and Distance to PNR. SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Calculate Outbound and Inbound Groundspeeds: - $\text{GS_out} = \text{TAS} - \text{Headwind} = 400 \text{ kt} - 50 \text{ kt} = 350 \text{ knots}$. - $\text{GS_home} = \text{TAS} + \text{Tailwind} = 400 \text{ kt} + 50 \text{ kt} = 450 \text{ knots}$. - $\text{GS_sum} = \text{GS_out} + \text{GS_home} = 350 + 450 = 800 \text{ knots}$. Step 2: Calculate Distance to ETP (Equi-Time Point): - Formula: $\text{D_ETP} = (\text{Total Distance} \times \text{GS_home}) / (\text{GS_out} + \text{GS_home})$ - $\text{D_ETP} = (1,200 \text{ NM} \times 450 \text{ kt}) / 800 \text{ kt} = 675 \text{ NM}$ from Airport A! - (Notice: Because of the headwind, ETP shifted forward from 600 NM to 675 NM!) Step 3: Calculate Time to PNR (Point of No Return): - Safe Endurance (E) = 4.0 hours. - Formula: $\text{T_out} = (\text{E} \times \text{GS_home}) / (\text{GS_out} + \text{GS_home})$ - $\text{T_out} = (4.0 \text{ hrs} \times 450 \text{ kt}) / 800 \text{ kt} = 2.25 \text{ hours}$ (2 hrs 15 min)! Step 4: Calculate Distance to PNR: - $\text{Distance_PNR} = \text{T_out} \times \text{GS_out} = 2.25 \text{ hrs} \times 350 \text{ kt} = 787.5 \text{ NM}$ from Airport A! FINAL ANSWER: Distance to ETP = 675 NM. Time to PNR = 2.25 hours (787.5 NM).

[!] EXAM TRAP (AVIATIONEXAM) - The ETP Moves Into the Wind Trap

- If you have a HEADWIND outbound: GS_home is FASTER than GS_out. Therefore, ETP shifts FORWARD (closer to destination)! - If you have a TAILWIND outbound: GS_home is SLOWER. Therefore, ETP shifts BACKWARD (closer to departure)! - Always remember: In the formula numerator, it is ALWAYS GS_home! ($D_{ETP} = D \times GS_{home} / \text{Sum}_{GS}$).

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: In the formula for calculating distance to the Equi-Time Point (ETP), which groundspeed appears in the NUMERATOR?

[A] GS outbound [B] GS HOME (return groundspeed) [C] Average TAS [D] Crosswind component

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The formula is: Distance to ETP = (Total Distance x GS_home) / (GS_out + GS_home). GS_home is in the numerator.

Q2: On an oceanic flight with a strong HEADWIND on the outbound leg, where will the Equi-Time Point (ETP) be located?

[A] Exactly at the midpoint of the route [B] Displaced TOWARDS THE DESTINATION (into the wind) [C] Displaced towards departure [D] ETP ceases to exist

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Because returning home has a tailwind (faster GS), you can fly further towards destination before reaching the point where flying forward takes the same time as flying back.

Q3: What single factor determines the location of the POINT OF NO RETURN (PNR) for a given aircraft and wind conditions?

[A] Only aircraft mass [B] The SAFE ENDURANCE of the aircraft (usable fuel available to return) [C] Runway length [D] Flap angle

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. PNR is purely fuel-limited. It is the furthest point from which the aircraft can return with mandatory reserve fuel intact: $T = (E \times GS_{home}) / (GS_{out} + GS_{home})$.

ATPL EASA STUDY GUIDE | 033 - FLIGHT PLANNING

Chapter 4: ICAO ATS Flight Plan (FPL) Form
Item-by-Item

Syllabus Source: CAE Oxford (pp. 121-164) | Pass Target: >= 90% AviationExam

1. THE ICAO MODEL FLIGHT PLAN FORM STRUCTURE

The standard ICAO Flight Plan Form is used globally for Air Traffic Control coordination. Every item must be encoded precisely:

Item Number & Title	Regulatory Code Formats & Allowed Entries	Operational Significance & Rules
Item Number & Title	Regulatory Code Formats & Allowed Entries	Operational Significance & Rules
Item 7: Aircraft ID	Max 7 alphanumeric characters (e.g. IBE3412 or EC-MZZ).	Exact callsign matching radio communication.
Item 8: Flight Rules & Type	Rules: I (IFR), V (VFR), Y (IFR changing to VFR), Z (VFR changing to IFR). Type: S (Scheduled), N (Non-scheduled), G (General), M (Military), X (Other).	Y and Z flights require specifying the changeover point in Item 15!
Item 9: Type & Wake Cat	Number + 4-letter ICAO type (e.g. A320, B738). Wake turbulence: L (<7,000 kg), M (7,000 to 136,000 kg), H (>=136,000 kg), J (Super A380).	Dictates ATC wake separation intervals!
Item 10: Equipment & Cap	10a COM/NAV (S for standard VHF/VOR/ILS, D, G for GNSS, R for PBN approved). 10b SSR (Mode S, ADS-B).	R requires PBN/ specification in Item 18!
Item 13: DEP & EOBT	4-letter ICAO departure aerodrome (e.g. LEMD) + 4-digit Estimated Off-Block Time (UTC).	If no ICAO code, enter ZZZZ and specify in Item 18 DEP/.
Item 15: Speed, Level & Route	Speed: N (knots, 4 digits, e.g. N0450) or M (Mach, 3 digits, e.g. M078). Level: F (Flight Level, 3 digits, e.g. F350) or A (Altitude in 100s ft). Route: ATS airways and waypoints.	Speed must be initial true airspeed (TAS).
Item 16: DEST, EET & Alternates	4-letter destination (e.g. LFPG) + Total EET (hours:min, e.g. 0145) + 4-letter Alternate 1 & 2.	Total EET is time from take-off to overhead destination.
Item 18: Other Information	PBN/ (e.g. B1D1O1S2), DOF/ (Date of Flight YYMMDD), REG/ (Registration), EET/ (FIR boundary estimates), RVR/.	0 (zero) indicates no special information.
Item 19: Supplementary Info	E/ (Endurance hhmm), P/ (Persons on board), R/ (Emergency radio), S/ (Survival equipment), J/ (Jackets), D/ (Dinghy).	Transmitted only for Search and Rescue (SAR).

2. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Filling an ICAO ATS Flight Plan

SCENARIO (Standard EASA FPL Encoding Drill): A scheduled commercial flight is operated by Iberia: - Callsign: IBE6501, Aircraft: Airbus A350-900 (MTOM = 280,000 kg) - Flight Rules: Entirely IFR - Initial Cruising Speed: TAS 480 knots; Cruising Level: FL 390 - Departure: Madrid Barajas (LEMD) at 14:30 UTC - Destination: New York JFK (KJFK); Total Estimated En-Route Time: 7 hours 45 minutes - Alternate: Boston Logan (KBOS) - Usable Fuel Endurance on board: 10 hours 30 minutes; Total Persons on Board: 312 QUESTION: How are Items 7, 8, 9, 13, 15, 16, and 19 encoded? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Item 7 (Aircraft Identification) = IBE6501 Step 2: Item 8 (Flight Rules & Type): - Flight Rules: I (IFR) - Type of Flight: S (Scheduled air service) - Entry: I S Step 3: Item 9 (Number, Type & Wake Turbulence): - Type: A359 - Wake Turbulence Category: MTOM = 280,000 kg (> 136,000 kg) -> Category H (HEAVY)! - Entry: A359 / H Step 4: Item 13 (Departure Aerodrome & Time): - LEMD 1430 Step 5: Item 15 (Speed & Level): - Speed: TAS 480 kt -> N0480 (N followed by 4 digits) - Level: FL 390 -> F390 (F followed by 3 digits) - Entry: N0480 F390 [Route...] Step 6: Item 16 (Destination, Total EET & Alternate): - KJFK 0745 KBOS Step 7: Item 19 (Endurance & POB): - E/ 1030 P/ 0312 FINAL ANSWER: Encoded exactly as above! Zero errors, fully compliant with ICAO Doc 4444.

[!] EXAM TRAP (AVIATIONEXAM) - The FPL Speed & Wake Turbulence Traps

- Speed Format: 'N' (Knots) MUST have 4 digits (e.g. 120 kt = N0120; 450 kt = N0450)! - Wake Turbulence: Heavy (H) is $\geq 136,000$ kg (136 tonnes). Medium (M) is 7,000 to 136,000 kg. Super (J) is Airbus A380 only! - Flight Rules Y vs Z: Y = IFR changing to VFR. Z = VFR changing to IFR (Remember: Alphabetical order V->Z!).

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: On an ICAO Flight Plan Form, what does flight rule code 'Y' indicate?**

[A] Pure VFR flight [B] A flight planned to operate initially under IFR, followed by one or more subsequent changes of flight rules to VFR [C] A flight in yellow airspace [D] Military flight

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Code Y indicates an IFR flight that changes to VFR en-route. Code Z indicates a VFR flight that changes to IFR en-route.

Q2: In Item 9 of the ICAO Flight Plan, what is the Wake Turbulence Category for an aircraft with a Maximum Ce

[A] M (Medium) [B] H (HEAVY), because MTOM is greater than or equal to 136,000 kg [C] J (Super) [D] L (Light)

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The Heavy (H) wake turbulence category applies to all aircraft with an MTOM of 136,000 kg (300,000 lb) or more.

Q3: How must an initial true airspeed of 210 knots be entered into Item 15 of an ICAO Flight Plan?

[A] 210K [B] N0210 (the letter N followed by exactly four digits) [C] TAS210 [D] KT0210

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Airspeed in knots must be expressed by the letter N followed by 4 digits, padding with leading zeros if necessary (e.g. N0210).

ATPL EASA STUDY GUIDE | 033 - FLIGHT PLANNING

Chapter 5: Jeppesen En-Route Charts & Airway Dimensions

Syllabus Source: CAE Oxford (pp. 165-208) | Pass Target: >= 90% AviationExam

1. AIRWAY ALTITUDES & DEFINITIONS ON JEPPESEN CHARTS

Airways on IFR en-route charts (LO and HI) are published with exact altitude constraints ensuring terrain clearance and radio reception:

Altitude Type Code	Jeppesen Representation & Meaning	Guaranteed Protection (Terrain vs Signal)
Altitude Type Code	Jeppesen Representation & Meaning	Guaranteed Protection (Terrain vs Signal)
MEA (Minimum En-route Alt)	Printed as bold number (e.g. 8000). Lowest published altitude between fixes.	Guarantees BOTH acceptable navigational signal reception AND mandatory obstacle clearance.
MOCA (Min Obstacle Clr Alt)	Printed with an asterisk * (e.g. *4500).	Guarantees obstacle clearance along entire airway, but signal reception ONLY within 22 NM of VOR!
MORA (Route MORA)	Printed with an 'a' (e.g. 7200a).	Guarantees obstacle clearance within 10 NM of airway centerline, regardless of route width.
Grid MORA	Large bold numbers inside each latitude/longitude quadrangle (e.g. 64 = 6,400 ft).	Clears all terrain/structures in the quadrangle by 1,000 ft (areas <= 5,000 ft) or by 2,000 ft in mountainous areas.
MAA (Max Authorized Alt)	Prefixed by 'MAA' (e.g. MAA FL 280).	Highest altitude allowed on the airway to prevent radio frequency interference with adjacent stations.

2. AIRWAY STRUCTURE & WAYPOINTS

- Airway Width: Standard ICAO airway corridor width is 10 NM total (5 NM on either side of centerline).
- Compulsory Reporting Point: Solid filled black triangle. Aircraft MUST report position, time, and level to ATC when crossing.
- On-Request Reporting Point: Open hollow triangle. Report position only if specifically requested by ATC.
- Changeover Point (COP): Indicates where pilots must switch NAV frequency from the behind station to the ahead station. If no COP is shown, change over occurs at the EXACT MIDPOINT of the airway leg!

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Reading En-Route Altitudes & Frequency Change

SCENARIO (Standard En-Route Chart Reading Drill): A pilot is planning an IFR flight along airway V12 between VOR Alfa and VOR Bravo: - Total distance between VORs = 90 NM - Along the airway segment, the chart displays: '7000' and '*4200' - No Changeover Point (COP) symbol is depicted along the route

QUESTION 1: What do the numbers '7000' and '*4200' mean? QUESTION 2: At what distance from VOR Alfa must the pilot switch navigation receivers to VOR Bravo? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Decode '7000' and '*4200': - '7000' without an asterisk is the MEA (Minimum En-route Altitude) = 7,000 ft. - '*4200' with an asterisk is the MOCA (Minimum Obstacle Clearance Altitude) = 4,200 ft. - Operational Meaning: To fly legally with reliable radio navigation, you must cruise at or above 7,000 ft (MEA). If descending in an emergency, you are guaranteed terrain clearance down to 4,200 ft (MOCA), but VOR signal is only guaranteed within 22 NM of the VOR! Step 2: Determine the Changeover Point (COP): - Rule: When no COP symbol is published, the frequency changeover MUST take place at the EXACT MIDPOINT of the leg! - Total distance = 90 NM - Midpoint = $90 \text{ NM} / 2 = 45 \text{ NM}$ from VOR Alfa! FINAL ANSWER: 7000 = MEA; *4200 = MOCA. Switch navigation frequency to VOR Bravo at exactly 45 NM from VOR Alfa.

[!] EXAM TRAP (AVIATIONEXAM) - The MOCA 22 NM Signal Reception Trap

- MOCA guarantees OBSTACLE CLEARANCE along the entire airway. - But MOCA guarantees NAVIGATION SIGNAL RECEPTION only within 22 NAUTICAL MILES (40 km) of the VOR transmitter! Beyond 22 NM, you may lose the VOR radial!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: On a Jeppesen en-route chart, what does an altitude preceded by an ASTERISK (*) (e.g. *3500) signify?

[A] Maximum Authorized Altitude [B] MOCA (Minimum Obstacle Clearance Altitude) [C] Transition altitude [D] Minimum crossing altitude

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The asterisk denotes MOCA. It guarantees terrain clearance along the entire segment, but navigational signal coverage only within 22 NM of the facility.

Q2: In the absence of a published Changeover Point (COP) on an airway between two VORs, where should the

[A] At 20 NM from the first VOR [B] At the EXACT MIDPOINT between the two facilities [C] Only upon ATC instruction [D] Over the next reporting point

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. By standard ICAO rules, if no COP is shown on the chart, the frequency changeover must be performed halfway between the two navigational aids.

Q3: In a Grid MORA quadrangle over mountainous terrain, what vertical clearance above the highest obstacle i

[A] 1,000 ft [B] At least 2,000 FT vertically [C] 500 ft [D] 35 ft

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Grid MORA provides 1,000 ft clearance in non-mountainous terrain, and at least 2,000 ft clearance in designated mountainous areas (terrain elevation above 5,000 ft).

ATPL EASA STUDY GUIDE | 033 - FLIGHT PLANNING

Chapter 6: Standard Departures (SID), STARs & Holding Entries

Syllabus Source: CAE Oxford (pp. 209-248) | Pass Target: >= 90% AviationExam

1. STANDARD INSTRUMENT DEPARTURES (SID) & TRANSITIONS

A SID links the take-off runway to the en-route airway structure, ensuring safe obstacle clearance:

- Design Climb Gradient (PDG): Standard ICAO procedure design climb gradient is 3.3% (approx 200 ft/NM). If close-in obstacles exist, a steeper gradient (e.g. 5.5%) is published with an altitude up to which it must be maintained.
- Altitude Restrictions: At or Above (bar under number: _5000_), At or Below (bar over number), Mandatory Crossing Altitude (bars above and below), Altitude Window (e.g. FL 110 - FL 130).

2. HOLDING PATTERN GEOMETRY & STANDARD SPEEDS

Standard holding pattern is an oval with RIGHT-HAND TURNS (non-standard is left-hand turns):

- Leg Timings: Inbound leg timing: 1.0 MINUTE at or below 14,000 ft MSL; 1.5 MINUTES above 14,000 ft (FL 140).
- ICAO Maximum Holding Speeds: Up to 14,000 ft: 230 kt (turboprops 170 kt); 14,000 to 20,000 ft: 240 kt; Above FL 200: 265 kt (or 0.83 Mach).

3. THE THREE HOLDING ENTRY SECTORS

Entry Sector	Angular Width & Relative Heading	Standard Entry Maneuver Procedure
Entry Sector	Angular Width & Relative Heading	Standard Entry Maneuver Procedure
Sector 1: Parallel Entry	110° sector on the holding side.	Fly to fix, turn to parallel the outbound track (heading reciprocal of inbound) on the non-holding side for 1 min, turn left toward holding side to intercept inbound track.
Sector 2: Teardrop (Offset)	70° sector on the non-holding side.	Fly to fix, turn outbound at 30° OFFSET into the holding area for 1 min, then turn right to intercept the inbound track.
Sector 3: Direct Entry	180° sector (the entire remaining half).	Fly directly to the fix, turn right onto the outbound heading, and enter the race-track pattern directly!

4. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Determining Holding Entry Sector

SCENARIO (Classic ATPL Exam Question): An aircraft is flying on a heading of 350° toward VOR 'ZUR'. ATC instructs: 'Hold at ZUR on the 090° radial, inbound track 270°, right-hand turns.' QUESTION: What is the correct ICAO holding entry procedure? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Identify Inbound Track and Turn Direction: - Inbound Track = 270° - Turn direction = Standard RIGHT-HAND turns. - Outbound Track = 090° (reciprocal of 270°). Step 2: Draw the 3 Entry Sectors relative to Inbound Track (270°): - For standard right-hand turns: * Sector 1 (Parallel - 110°): From 270° to (270° - 110°) = 270° to 160° clockwise (160° to 270°). * Sector 2 (Teardrop - 70°): From 270° to (270° + 70°) = 270° to 340° (clockwise 270° to 340°). * Sector 3 (Direct - 180°): From 340° to 160° (the entire remaining arc: 340° through North/360° to 160°). Step 3: Check Aircraft Inbound Heading (350°): - Aircraft is arriving on heading 350°. - Compare 350° with the sectors: * 350° falls squarely inside Sector 3 (which spans from 340° through 360° to 160°)! FINAL ANSWER: Sector 3 (DIRECT ENTRY)! Upon reaching ZUR, the pilot turns right directly onto the outbound heading of 090°.

[!] EXAM TRAP (AVIATIONEXAM) - The Right-Hand vs Left-Hand Holding Rule

- For RIGHT-HAND turns: Sector 1 (Parallel) is on the left (110°); Sector 2 (Teardrop) is on the right (70°). - For LEFT-HAND turns: The sectors are MIRRORED! Sector 1 is 110° on the right, Sector 2 is 70° on the left! - Sector 3 (Direct) is always the large 180° sector opposite the entry.

5. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What is the standard outbound leg TIMING for a holding pattern at or below 14,000 ft MSL?**

[A] 1.5 minutes [B] 1.0 MINUTE (60 seconds) [C] 2.0 minutes [D] 45 seconds

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Under ICAO PANS-OPS, the outbound leg is timed for 1.0 minute up to and including 14,000 ft (FL 140), and 1.5 minutes above 14,000 ft.

Q2: In a standard right-hand holding pattern, what is the angular width of SECTOR 1 (Parallel Entry)?

[A] 70° [B] 110 DEGREES [C] 180° [D] 90°

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Sector 1 (Parallel) covers an arc of 110°; Sector 2 (Teardrop) covers 70°; Sector 3 (Direct) covers 180°.

Q3: What is the maximum ICAO holding speed for aircraft holding at 10,000 ft MSL?

[A] 250 kt [B] 230 KNOTS (or 170 kt for normal turboprops) [C] 200 kt [D] 265 kt

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Under ICAO Doc 8168, maximum holding speed up to 14,000 ft is 230 kt for jet aircraft.

ATPL EASA STUDY GUIDE | 033 - FLIGHT PLANNING

Chapter 7: Meteorological Planning Charts (WITEM & SIGWX)

Syllabus Source: CAE Oxford (pp. 249-290) | Pass Target: >= 90% AviationExam

1. UPPER WIND & TEMPERATURE CHARTS (WITEM)

WITEM charts display forecast wind arrows and outside temperatures at specific flight levels (FL 050, 100, 180, 240, 300, 340, 390):

- Wind Arrow Decoding: Shaft points in the direction the wind is blowing. Barb markings:
Triangular pennant = 50 knots; Long barb = 10 knots; Short barb = 5 knots.
- Temperature Labels: At and above FL 240, temperatures are universally NEGATIVE; the minus sign is omitted! (e.g. '56' at FL 340 means -56°C!).

2. SIGNIFICANT WEATHER CHARTS (SIGWX)

High-level SIGWX charts (FL 250 to FL 630) show critical en-route flight hazards:

- Jet Streams: Represented by heavy black lines with arrows showing direction. Core speed: Double slash // indicates speed change of 20 kt. Hatching indicates CAT (Clear Air Turbulence) boundaries.
- Tropopause Heights: Printed in small rectangular boxes (e.g. '380' means tropopause is at FL 380). High tropopause = warm air mass (equatorial); Low tropopause = cold polar air mass.
- Cumulonimbus (CB): Identified as ISOL CB (isolated), OCNL CB (occasional), or FRQ CB (frequent) embedded in layer clouds.

3. COLD WEATHER ALTIMETER TEMPERATURE CORRECTIONS

In extreme cold temperatures, the barometric altimeter OVER-READS (indicates higher than true altitude!): 'High to low, look out below!'

- Master Cold Temperature Correction Formula: $\text{Correction (ft)} = 4 \text{ ft} \times (\text{Height above altimeter station} / 1,000 \text{ ft}) \times (\text{ISA Deviation in } ^\circ\text{C below standard})$

4. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Cold Weather Altimeter Correction on Final Approach

SCENARIO (Safety-Critical ICAO Winter Operation Drill): An aircraft is on an ILS approach to an airport in Scandinavia in winter: - Airport Elevation = 1,000 ft MSL - Outside Air Temperature (OAT) at the surface = -25°C - Decision Altitude (DA) on chart = 1,200 ft MSL (Height above runway = 200 ft) - Minimum Safe Altitude (MSA) = 4,000 ft MSL (Height above station = 3,000 ft) QUESTION: What is the true altitude of the aircraft if it levels at indicated MSA 4,000 ft? What indicated altitude must the pilot fly to maintain true MSA 4,000 ft? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Calculate ISA Temperature at Airport Elevation (1,000 ft): - ISA at Sea Level = +15°C. - ISA lapse rate = -2°C per 1,000 ft. - ISA at 1,000 ft = +15°C - 2°C = +13°C. Step 2: Calculate ISA Deviation (Delta ISA): - Actual OAT = -25°C. - Delta ISA = Actual OAT - ISA = -25°C - (+13°C) = -38°C (38°C COLDER than standard!). Step 3: Calculate Altimeter Error at MSA (Height above station = 4,000 - 1,000 = 3,000 ft): - Rule: 4 ft per 1,000 ft of height per °C of cold deviation. - Correction = 4 ft x (3,000 ft / 1,000 ft) x 38°C - Correction = 4 ft x 3 x 38 = 12 x 38 = 456 ft error! Step 4: Determine True Altitude vs Required Indicated Altitude: - Because the air is cold, the altimeter over-reads by 456 ft! If flying at indicated 4,000 ft, TRUE ALTITUDE IS ONLY 3,544 ft (456 ft dangerously closer to mountains!). - To guarantee 4,000 ft of true clearance, the pilot MUST ADD 456 ft to the altimeter! - Minimum Indicated Altitude to fly = 4,000 ft + 456 ft = 4,456 ft! FINAL ANSWER: True altitude is 3,544 ft without correction. Pilot must fly indicated 4,460 ft.

[!] EXAM TRAP (AVIATIONEXAM) - The Cold Weather Altimeter Trap

- Cold air contracts the atmospheric column: True altitude is LOWER than indicated altitude! - When OAT is below 0°C, temperature corrections MUST BE ADDED to published altitudes (DA, MDA, MSA) so you don't hit the ground early!

5. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: On an upper wind WINTEN chart at FL 340, a temperature is labeled '48' next to a wind arrow. What is the actual temperature?

[A] +48°C [B] -48°C (minus sign is universally omitted at high flight levels) [C] 48 Kelvin [D] 48% relative humidity

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Above FL 240 in mid-latitudes, temperatures are permanently below zero. To reduce chart clutter, the negative minus sign is omitted.

Q2: In extremely cold weather (OAT substantially below ISA), how does an uncorrected pressure altimeter read?

[A] It reads lower than true altitude [B] It reads HIGHER than true altitude (the aircraft is physically lower than the altimeter indicates!) [C] It reads accurately [D] It fails completely

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Cold air is dense, causing pressure levels to compress closer to the ground. The altimeter reads higher than actual true altitude ('high to low, look out below').

Q3: On a high-level SIGWX chart, what does a heavy black line with an arrow and a double slash // indicate?

[A] A thunderstorm front [B] A JET STREAM, with the double slash indicating a speed change of 20 knots along the jet axis [C] An oceanic boundary [D] Volcanic ash

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Jet stream cores are depicted by heavy arrows. A double bar // represents a change in core wind speed of 20 kt.

ATPL EASA STUDY GUIDE | 033 - FLIGHT PLANNING

Chapter 8: Fuel Monitoring, Bogey Curves & Decision Point (DPP)

Syllabus Source: CAE Oxford (pp. 291-340) | Pass Target: $\geq 90\%$ AviationExam

1. IN-FLIGHT FUEL MONITORING & BOGEY CURVES

Under EASA AIR-OPS, flight crews must record fuel remaining at each designated en-route waypoint and compare it against the operational flight plan (OFP):

- Fuel Bogey Curve (Howgozit): A graphical chart plotting Fuel Remaining versus Distance/Time. A falling curve steeper than planned indicates higher fuel consumption, headwind increase, or fuel leak!
- Minimum Fuel Declaration: 'MINIMUM FUEL' informs ATC that all planned aerodrome options have been committed to, and any unexpected delay will result in landing with less than planned final reserve fuel. (It is NOT an emergency, but priority is requested).
- Mayday Fuel Declaration: 'MAYDAY MAYDAY MAYDAY FUEL' is a distress emergency declared when estimated usable fuel on landing will be less than the 30-minute final reserve fuel. ATC will clear all conflicting traffic!

2. THE DECISION POINT PROCEDURE (DPP) / PREDETERMINED POINT (PDP)

On long-range flights, carrying 5% contingency fuel for the entire 10-hour trip creates a huge mass penalty. The Decision Point Procedure (DPP) solves this legally:

- The DPP Concept: The flight plan is split into two co-existing plans through an en-route 'Decision Point' (DP): (1) Flight to Destination via DP, with contingency fuel calculated ONLY from the Decision Point to Destination! (2) Flight to an En-Route Alternate via DP. Because contingency fuel applies only to the short leg from DP to destination, thousands of kilograms of contingency fuel are saved at take-off!

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Fuel Savings using Decision Point Procedure (DPP)

SCENARIO (Long-Range Flight Fuel Optimization Drill): A Boeing 787 is flying from London to Tokyo: - Total Trip Fuel = 60,000 kg - A Decision Point (DP) is selected along track over Siberia - Trip Fuel from Departure to DP = 40,000 kg - Remaining Trip Fuel from DP to Tokyo Destination = 20,000 kg - Under standard fuel policy, Contingency Fuel is 5% of Total Trip Fuel - Under DPP, Contingency Fuel is 5% of Trip Fuel FROM DP TO DESTINATION! QUESTION: How much contingency fuel is saved at take-off by using the Decision Point Procedure? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Calculate Standard 5% Contingency Fuel for entire flight: - Standard Contingency = 5% of Total Trip Fuel (60,000 kg) - Standard Contingency = $0.05 \times 60,000 \text{ kg} = 3,000 \text{ kg}$. Step 2: Calculate DPP Contingency Fuel (5% from DP to Tokyo): - Trip Fuel from DP to Tokyo = 20,000 kg - DPP Contingency = 5% of 20,000 kg = $0.05 \times 20,000 \text{ kg} = 1,000 \text{ kg}$! Step 3: Calculate Fuel Savings at Take-Off: - Fuel Saved = Standard Contingency - DPP Contingency - Fuel Saved = $3,000 \text{ kg} - 1,000 \text{ kg} = 2,000 \text{ kg}$! Step 4: Operational Benefit for Dummies: - Saving 2,000 kg of contingency fuel reduces aircraft take-off mass, allowing the airline to carry 20 additional passengers or 2 tonnes of high-yield cargo, while remaining 100% compliant with EASA safety regulations! FINAL ANSWER: The Decision Point Procedure saves exactly 2,000 kg of contingency fuel at take-off.

[!] EXAM TRAP (AVIATIONEXAM) - The Decision Point Action Trap

- When reaching the Decision Point en-route: - If actual fuel remaining is AT OR ABOVE the required fuel to reach Tokyo -> CONTINUE TO DESTINATION! - If actual fuel remaining is BELOW the required fuel to reach Tokyo -> DIVERT TO EN-ROUTE ALTERNATE!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What is the primary operational advantage of using the DECISION POINT PROCEDURE (DPP) under EASA**

[A] Eliminates the need for an alternate [B] It reduces the required CONTINGENCY FUEL at take-off by calculating 5% contingency only from the Decision Point to Destination, saving aircraft mass [C] Allows flying without final reserve [D] Permits landing in zero visibility

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Under CAT.OP.MPA.180, DPP permits basing contingency fuel only on the stage from the decision point to destination (or alternate), saving substantial fuel mass at take-off.

Q2: What is the difference between declaring 'MINIMUM FUEL' and declaring 'MAYDAY MAYDAY MAYDAY FUEL'

[A] Minimum fuel is declared after touchdown [B] 'MINIMUM FUEL' is an advisory to ATC that delay will compromise reserves (not an emergency); 'MAYDAY FUEL' is a formal distress emergency declared when estimated landing fuel is below 30-min final reserve [C] There is no difference [D] Minimum fuel requires immediate evacuation

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Minimum fuel warns ATC that any unexpected delay will cause a fuel emergency; it does not grant priority. Mayday fuel is an emergency declaration demanding immediate priority.

Q3: On an in-flight fuel log, what does a sudden downward divergence of the actual fuel curve below the planned

[A] Stronger tailwind than forecast [B] An abnormal fuel burn caused by higher engine fuel consumption, lower cruise level, or a severe FUEL LEAK [C] Lighter aircraft [D] Cabin heating failure

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. A steep drop in the fuel curve indicates fuel is being depleted faster than planned, requiring the crew to verify engine parameters and check for fuel leaks.