

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 1: Radio Wave Propagation, Antennas & Frequencies

Syllabus Source: CAE Oxford (pp. 1-44) | Pass Target: >= 90% AviationExam

1. THE ELECTROMAGNETIC SPECTRUM & FREQUENCY BANDS

Radio waves travel at the speed of light ($c = 300,000 \text{ km/s} = 3 \times 10^8 \text{ m/s}$). Wavelength is inversely proportional to frequency: $\lambda \text{ (meters)} = c / \text{frequency (Hz)}$:

Frequency Band	Frequency Range & Wavelength	Aviation Navigational Aids & Communications
Frequency Band	Frequency Range & Wavelength	Aviation Navigational Aids & Communications
VLF (Very Low)	3 to 30 kHz (100 to 10 km)	Submarine communications, Omega navigation (obsolete).
LF (Low Frequency)	30 to 300 kHz (10 to 1 km)	NDB (Non-Directional Beacons), commercial AM radio.
MF (Medium Frequency)	300 to 3,000 kHz (1 km to 100 m)	NDB, Locator beacons, maritime radio.
HF (High Frequency)	3 to 30 MHz (100 to 10 m)	Long-range transoceanic voice communications (Sky wave).
VHF (Very High)	30 to 300 MHz (10 to 1 m)	VHF Comms (118-137 MHz), VOR (108-118 MHz), ILS Localizer (108-112 MHz).
UHF (Ultra High)	300 to 3,000 MHz (1 m to 10 cm)	ILS Glide Path (329-335 MHz), DME (960-1215 MHz), SSR (1030/1090 MHz), GPS L1 (1575 MHz).
SHF (Super High)	3 to 30 GHz (10 to 1 cm)	Airborne Weather Radar (AWR 9.3 GHz), MLS (5 GHz), Radar Altimeter (4.3 GHz).

2. WAVE PROPAGATION MODES & MAXIMUM RANGE

- Ground Wave (Surface Wave): Follows the curvature of the Earth. Dominant in LF and MF bands (NDB). Range is greatest over seawater (high conductivity) and lowest over dry sand/ice.
- Sky Wave (Ionospheric Reflection): Reflected by ionosphere layers (D, E, F1, F2). Dominant in HF band. Subject to skip distance, skip zones, and severe night effect fading.
- Space Wave (Line-of-Sight): Straight-line propagation in VHF, UHF, and SHF bands. Limited by atmospheric refraction and Earth curvature: Maximum Theoretical Range (NM) = $1.23 \times (\sqrt{h_{\text{transmitter}}} + \sqrt{h_{\text{receiver}}})$ [heights in feet]!

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: VHF Maximum Line-of-Sight Radio Range

SCENARIO (Fundamental AviationExam Question): An aircraft is cruising at FL 360 (36,000 ft). A VOR ground station antenna is located at an elevation of 900 ft MSL. QUESTION: What is the maximum theoretical range in Nautical Miles at which the aircraft can receive the VOR signal? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Identify Transmitter and Receiver Heights in feet: - Aircraft Height (h_{rx}) = 36,000 ft - VOR Ground Antenna Height (h_{tx}) = 900 ft Step 2: Recall the Master VHF Line-of-Sight Range Formula: - Formula: $\text{Range (NM)} = 1.23 \times [\sqrt{h_{tx}} + \sqrt{h_{rx}}]$ Step 3: Calculate the square roots of each height: - $\sqrt{900} = 30$ - $\sqrt{36,000} = 189.74$ - Sum of square roots = $30 + 189.74 = 219.74$. Step 4: Multiply by the atmospheric refraction constant (1.23): - $\text{Range (NM)} = 1.23 \times 219.74 = 270.28 \text{ NM}$ (~270 Nautical Miles)! FINAL ANSWER: The maximum theoretical VOR reception range is approximately 270 Nautical Miles.

[!] EXAM TRAP (AVIATIONEXAM) - The 1.05 vs 1.23 Range Constant Trap

- If both antennas are optical line-of-sight in a vacuum: constant = 1.05. - In the Earth's atmosphere, radio waves BEND SLIGHTLY downwards due to atmospheric refraction: constant = 1.23 (or 1.25)! - EASA exams universally use 1.23: $\text{Range} = 1.23 \times (\sqrt{h_1} + \sqrt{h_2})$.

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: In which frequency band does the Instrument Landing System (ILS) LOCALIZER operate?**

[A] UHF [B] VHF (108.10 MHz to 111.95 MHz, odd tenths) [C] SHF [D] LF

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The ILS Localizer operates in the VHF band between 108.10 and 111.95 MHz on odd-tenth frequencies (e.g. 109.10, 109.30). The Glide Path operates in UHF.

Q2: Over which surface type does an LF/MF Ground Wave travel with the GREATEST range and minimum signal loss?

[A] Dry desert sand [B] SEAWATER (due to high electrical conductivity) [C] Dense forest [D] Mountainous rocky terrain

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Seawater has the highest electrical conductivity of any natural Earth surface, producing minimum ground attenuation and maximum surface wave range.

Q3: What is the wavelength of a radar operating on a frequency of 10 GHz (10,000 MHz)?

[A] 3 meters [B] 3 CENTIMETERS ($\lambda = 300,000,000 \text{ m/s} / 10,000,000,000 \text{ Hz} = 0.03 \text{ m} = 3 \text{ cm}$) [C] 30 cm [D] 30 meters

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Formula: $\lambda = c / f$. For 10 GHz: $3 \times 10^8 / 10 \times 10^9 = 0.03 \text{ m} = 3 \text{ cm}$ (standard Airborne Weather Radar X-band).

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 2: Non-Directional Beacon (NDB) & ADF Navigation

Syllabus Source: CAE Oxford (pp. 45-88) | Pass Target: $\geq 90\%$ AviationExam

1. NDB GROUND STATION & ADF AIRBORNE RECEIVER

The NDB is an omnidirectional transmitter operating in the LF/MF bands (190 to 1750 kHz). The airborne receiver is the Automatic Direction Finder (ADF):

- **Antenna Principle:** Uses a combined Loop Antenna (figure-8 reception pattern with two nulls) and Sense Antenna (circular pattern). Combining them produces a CARDIOID (heart-shaped) pattern with a single unique null, eliminating 180° ambiguity.
- **Relative Bearing (RB):** The angle measured clockwise from the aircraft's nose to the station.
- **Magnetic Bearing TO Station (QDM):** $QDM = \text{Magnetic Heading (MH)} + \text{Relative Bearing (RB)}$
(If sum $> 360^\circ$, subtract 360° !).
- **Magnetic Bearing FROM Station (QDR):** $QDR = QDM \pm 180^\circ$.

2. ADF OPERATIONAL ERRORS & LIMITATIONS

- **Night Effect (The Biggest Hazard):** At night (especially dawn/dusk), sky waves reflected by the ionosphere interfere with the ground wave. The ADF needle hunts, oscillates violently, or points 30° to 90° off course!
- **Coastal Refraction:** Radio waves travel faster over water than over land. When crossing a coastline obliquely, the wave bends TOWARDS THE COASTLINE NORMAL. The needle indicates the station is closer to the coast than it actually is!
- **Thunderstorm / Static Error:** Lightning discharges emit massive LF/MF radio noise. The ADF needle swings away from the NDB and POINTS DIRECTLY TOWARDS THE CUMULONIMBUS CLOUD!
- **Mountain Effect & Quadrantal Error:** Mountain reflections create false nulls. Quadrantal error is caused by aircraft metal bending the incoming wave (zero at nose, tail, and wingtips; maximum on quadrants: 045° , 135° , 225° , 315°).

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Calculating QDM and Intercepting NDB Inbound Radial

SCENARIO (Classic AviationExam Navigation Problem): An aircraft is flying on Magnetic Heading (MH) = 040° : - The Relative Bearing Indicator (RBI) needle points to 220° ATC instructs: 'Intercept and track inbound on the 070° QDM to the NDB with a 30° intercept angle.' QUESTION 1: What is the current QDM and QDR? QUESTION 2: What heading should the pilot turn to intercept the 070° QDM at 30° ? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Calculate current QDM (Bearing TO the station): - Formula: $QDM = \text{Magnetic Heading (MH)} + \text{Relative Bearing (RB)}$ - $QDM = 040^\circ + 220^\circ = 260^\circ$! - ($QDR = 260^\circ - 180^\circ = 080^\circ$ from the station). Step 2: Understand where you are relative to target QDM (070°): - Current QDM = 260° (You are Southwest of the station, bearing 260° to it). - Target QDM = 070° (You need to fly inbound towards 070°). Step 3: Calculate Intercept Heading (Inbound track 070° with 30° intercept): - Target Track Inbound = 070° . - You are on the right/south side of the desired track. - Intercept Heading = Inbound Track - $30^\circ = 070^\circ - 30^\circ = 040^\circ$ Magnetic! FINAL ANSWER: Current QDM = 260° . Intercept heading = 040° Magnetic.

[!] EXAM TRAP (AVIATIONEXAM) - QDM vs QDR Memory Trap

- QDM = Bearing TO the station (Inbound track to fly in zero wind). - QDR = Bearing FROM the station (Radial outbound from station). - Always check if the question asks for QDM or QDR: QDR = QDM +/- 180°!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: An aircraft is flying on a magnetic heading of 120°. The ADF needle points to relative bearing 080°. What is

[A] 040° [B] 200° (QDM = MH + RB = 120° + 080° = 200°) [C] 020° [D] 300°

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Formula: QDM = MH + RB = 120° + 80° = 200° magnetic bearing to the station.

Q2: Why does the ADF suffer from severe 'NIGHT EFFECT' errors at dawn and dusk?

[A] Cold air bends the wave [B] SKY WAVES reflected by the ionosphere interfere with the ground wave, causing needle hunting and wild bearing errors [C] Aircraft generators produce static [D] Moisture in the antenna

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. At night and twilight, ionospheric reflection permits sky waves to reach the receiver with shifting polarization, degrading the loop antenna null.

Q3: When flying in the vicinity of active thunderstorm activity, what does an ADF needle tend to do?

[A] Points to Magnetic North [B] POINTS TOWARDS THE LIGHTNING ELECTRICAL DISCHARGES in the Cumulonimbus cloud [C] Spins continuously at 100 rpm [D] Freezes at 000°

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Lightning creates powerful electromagnetic pulses in the LF/MF band, causing the ADF sense loop to track the storm cell rather than the NDB.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 3: VHF Omnidirectional Range (VOR) & Doppler DVOR

Syllabus Source: CAE Oxford (pp. 89-130) | Pass Target: >= 90% AviationExam

1. VOR OPERATING PRINCIPLE & FREQUENCIES

VOR operates in the VHF band from 108.000 to 117.950 MHz (50 kHz channel spacing). It transmits 360 magnetic radials originating from the station:

- **Phase Comparison Principle:** The VOR transmits two separate 30 Hz signals: (1) Reference Signal: 30 Hz FM omnidirectional pulse transmitted simultaneously in all directions; (2) Variable Signal: 30 Hz AM directional beam rotating clockwise at 30 revolutions per second (1,800 rpm).
- **Radial Determination:** The phase difference between the Reference and Variable signals EXACTLY EQUALS THE MAGNETIC BEARING (RADIAL) from the station! At Magnetic North (000°), the signals are in phase (0° phase difference); at 090° Radial, phase difference is 90°.

2. CONVENTIONAL VOR (CVOR) VS DOPPLER VOR (DVOR)

Conventional VOR suffers from site error caused by ground reflections (buildings, mountains, trees) producing 'scalping' (needle oscillation) and course bends:

- **Doppler VOR (DVOR) Superiority:** DVOR uses a wide-aperture circular antenna array (~13.5 m diameter, 50 antennas) simulating counter-clockwise rotation at 30 revs/sec. The simulated motion creates a 30 Hz FM Doppler shift. Because of the wide aperture, DVOR is VIRTUALLY IMMUNE TO SITE REFLECTION ERRORS!

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Reading Course Deviation Indicator (CDI)

SCENARIO (Standard EASA VOR Instrument Drill): An aircraft is flying on Magnetic Heading 360° (due North): - The pilot tunes the VOR and selects Omni-Bearing Selector (OBS) = 270° - The Course Deviation Indicator (CDI) needle deflects 3 DOTS TO THE RIGHT - The indicator displays a 'FROM' flag - Standard VOR CDI sensitivity: Full-scale deflection (5 dots) = 10° (2° per dot) QUESTION: On which radial is the aircraft currently located? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Determine the Angular Displacement from the needle deflection: - Needle is deflected 3 dots to the RIGHT. - Rule: 1 dot = 2.0 degrees. - Displacement = 3 dots x 2.0°/dot = 6.0° off course. Step 2: Understand the CDI with a 'FROM' Flag: - With a FROM flag and OBS selected to 270°: - Center needle = You are on Radial 270°. - Needle deflected RIGHT = The selected radial (270°) is to your RIGHT. - Therefore, your current position is to the LEFT of Radial 270°! - (Remember: On a compass rose, moving left/counter-clockwise from 270° means LOWER numbers: 270° - 6° = 264°). Step 3: State the Current Aircraft Radial: - Current Radial = 270° - 6° = Radial 264°! FINAL ANSWER: The aircraft is located on Radial 264° from the VOR station.

[!] EXAM TRAP (AVIATIONEXAM) - Reverse Sensing VOR Trap

- If you fly TOWARDS a VOR with a FROM flag selected: - The CDI gives REVERSE SENSING (if the needle is left, the track is to your right)! - To prevent reverse sensing: When flying inbound, ALWAYS select the inbound course with a TO flag!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is the phase relationship between the reference signal and variable signal of a VOR on Radial 090°?

[A] In phase (0°) [B] The variable signal lags the reference signal by EXACTLY 90 DEGREES [C] 180° out of phase [D] 270°

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The phase difference between the reference and variable 30 Hz signals matches the radial angle from magnetic north: on radial 090°, phase difference is 90°.

Q2: Why is a Doppler VOR (DVOR) significantly more accurate than a Conventional VOR (CVOR) in mountainous terrain?

[A] It uses UHF frequencies [B] Its wide-aperture simulated rotating antenna array greatly REDUCES SITE AND REFLECTION ERRORS (scalloping) [C] It uses satellite links [D] It has higher transmitter power

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. DVOR's 13.5 m wide aperture antenna array creates a signal that is remarkably resilient against terrain and building multipath reflections.

Q3: On a standard VOR Course Deviation Indicator (CDI), what angular displacement is represented by FULL SCALE deflection?

[A] 5° [B] 10 DEGREES (2.0° per dot) [C] 2.5° [D] 20°

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Standard VOR CDI sensitivity is 2.0° per dot, meaning full-scale 5-dot deflection represents a 10° angular displacement off track.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 4: Distance Measuring Equipment & Slant Range Geometry

Syllabus Source: CAE Oxford (pp. 131-168) | Pass Target: $\geq 90\%$ AviationExam

1. DME OPERATING PRINCIPLES & UHF FREQUENCIES

DME operates in the UHF band from 960 to 1215 MHz (1 MHz spacing). It is a secondary radar system measuring line-of-sight distance:

- **Pulse Pair Interrogation:** Airborne interrogator transmits pulse pairs (12 microsecond spacing). Ground transponder receives them, delays reply by exactly 50 microseconds, and re-transmits on a frequency offset by +63 MHz.
- **Slant Range Formula:** Total Elapsed Time = Round-trip propagation time + 50 microsecond transponder delay. Distance (NM) = (Elapsed Time - 50 microsec) / 12.36 microseconds (since radio waves travel 1 NM round-trip in 12.36 microseconds).
- **Capacity & Saturation:** A DME ground beacon can handle up to 100 AIRCRAFT SIMULTANEOUSLY. If overloaded, it reduces receiver sensitivity, cutting off weaker (distant) interrogators.

2. SLANT RANGE ERROR (OVERHEAD GEOMETRY)

DME measures direct line-of-sight hypotenuse distance (Slant Range), NOT horizontal ground distance:

- **The Pythagoras Geometry:** Ground Distance = $\sqrt{\text{Slant Range}^2 - \text{Height}^2}$ [Height in NM: Height (NM) = Altitude in feet / 6,076 ft].
- **Overhead Station Indication:** When passing DIRECTLY OVERHEAD the DME station, Ground Distance is ZERO, but the DME indicates the aircraft's ALTITUDE ABOVE THE STATION IN NAUTICAL MILES (e.g. at FL 360, DME reads 6.0 NM overhead!)

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Calculating True Ground Distance from DME Slant Range

SCENARIO (Standard EASA DME Geometry Problem): An airliner is descending at FL 240 (24,000 ft above a sea-level DME station): - The cockpit DME indicator reads 5.0

NM QUESTION: What is the aircraft's actual HORIZONTAL GROUND DISTANCE from the station? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Convert Aircraft Height from

feet into Nautical Miles: - Rule: 1 Nautical Mile = approx 6,000 feet (exact 6,076 ft). - Height (NM) = 24,000 ft / 6,000 ft = 4.0 NM! Step 2: Draw the Right-Angled

Triangle: - Hypotenuse (DME Slant Range) = 5.0 NM - Vertical leg (Height) = 4.0

NM - Horizontal leg (Ground Distance) = ? Step 3: Apply Pythagoras' Theorem ($A^2 +$

$B^2 = C^2$): - Ground Distance = $\sqrt{\text{Slant Range}^2 - \text{Height}^2}$ - Ground Distance

= $\sqrt{5.0^2 - 4.0^2} = \sqrt{25.0 - 16.0} = \sqrt{9.0} = 3.0$ NM! FINAL ANSWER:

The actual horizontal ground distance to the station is ONLY 3.0 Nautical Miles (even though the DME reads 5.0 NM!).

[!] EXAM TRAP (AVIATIONEXAM) - The Slant Range Error Vanishes at Distance Trap

- When Slant Range is greater than 10 times the height (e.g. 40 NM range at 4 NM height): - Slant range error is less than 0.5% (negligible)! - Slant range error is ONLY dangerous close to or directly overhead the station.

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What will a DME indicator read when an aircraft is flying directly overhead a sea-level DME beacon at FL 360?**

[A] Exactly 0.0 NM [B] APPROXIMATELY 6.0 NM (36,000 ft / 6,000 ft/NM = 6.0 NM slant range) [C] 36 NM [D] The indicator displays dashes

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Because DME measures line-of-sight distance, passing overhead produces a reading equal to the aircraft's vertical altitude in Nautical Miles: 36,000 / 6,000 = 6.0 NM.

Q2: In which frequency band does Distance Measuring Equipment (DME) operate?

[A] VHF [B] UHF (960 to 1215 MHz) [C] SHF [D] HF

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. DME operates in the UHF band, paired with VOR channels so tuning the VOR frequency automatically tunes the DME interrogator.

Q3: What is the maximum number of aircraft that a standard DME ground transponder can track simultaneously?

[A] Unlimited [B] APPROXIMATELY 100 AIRCRAFT [C] 25 aircraft [D] 500 aircraft

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. DME ground transponders are designed to handle up to 100 aircraft interrogations simultaneously by limiting pulse reply rates to ~2,700 pulse pairs per second.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 5: Instrument Landing System (ILS: LOC, GP & Markers)

Syllabus Source: CAE Oxford (pp. 169-216) | Pass Target: >= 90% AviationExam

1. THE ILS TRI-COMPONENT ARCHITECTURE

The Instrument Landing System provides precision lateral, vertical, and distance guidance during final approach:

ILS Subsystem	Frequency Band & Modulation Carrier	Beam Dimensions & Guaranteed Coverage
ILS Subsystem	Frequency Band & Modulation Carrier	Beam Dimensions & Guaranteed Coverage
Localizer (LOC)	VHF (108.10 to 111.95 MHz, odd tenths). 90 Hz (Left) / 150 Hz (Right) DDM.	Course width: ~5° (total 350 ft at threshold). Coverage: 35° each side to 17 NM; 10° each side to 25 NM.
Glide Path (GP)	UHF (329.15 to 335.00 MHz, paired with LOC). 90 Hz (Above) / 150 Hz (Below) DDM.	Slope: Standard 3.0°. Beam thickness: ~1.4° (0.7° above/below). Coverage: 8° each side to 10 NM. False slopes at 6° and 9°!
Marker Beacons	VHF 75.0 MHz (vertical fan beam).	Outer (OM: 400 Hz, blue dashes, 4-7 NM); Middle (MM: 1300 Hz, amber dot-dashes, 0.5-0.8 NM); Inner (IM: 3000 Hz, white dots).

2. GLIDE PATH RATE OF DESCENT (ROD) FORMULA

- Master ROD Formula (3.0° Glide Path): $\text{Rate of Descent (ft/min)} = \text{Groundspeed (knots)} \times 5$
(e.g. at 140 kt GS: $\text{ROD} = 140 \times 5 = 700 \text{ ft/min!}$).
- Non-Standard Slope Formula: $\text{ROD (ft/min)} = \text{Groundspeed (knots)} \times \text{Glide Angle (degrees)} \times 100 / 60$.

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Calculating Target Rate of Descent on ILS

SCENARIO (Everyday Airline Flying Drill): An airliner is established on an ILS approach with a 3.0° glide slope: - Target approach speed (Vref) = 140 knots Indicated Airspeed - Headwind component on final approach = 20 knots QUESTION: What target Rate of Descent (ft/min) must the flight crew maintain on the vertical speed indicator (VSI)? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Calculate the Groundspeed (GS):
- Remember: Rate of descent depends on GROUND SPEED, not airspeed! - Groundspeed = TAS - Headwind - At sea level, TAS ~ IAS = 140 kt. - Groundspeed = 140 kt - 20 kt = 120 knots! Step 2: Recall the Master 3.0° Glide Path Formula: - Rate of Descent (ft/min) = Groundspeed (kt) x 5! Step 3: Calculate Target ROD: - ROD = 120 knots x 5 = 600 ft/min! FINAL ANSWER: Target Rate of Descent is 600 ft/min. If headwind decreases, groundspeed rises and ROD must increase proportionally.

[!] EXAM TRAP (AVIATIONEXAM) - False Glide Path Trap

- False glide paths are generated at HARMONIC MULTIPLES (typically $2 \times 3^\circ = 6^\circ$, and $3 \times 3^\circ = 9^\circ$)! - The first false glide path at 6° has NORMAL SENSING (90 Hz above, 150 Hz below)! - If intercepted from above, you will descend at double the normal rate (1,400 ft/min)!

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: At what angle does the lowest FALSE GLIDE PATH occur on a standard 3.0° ILS installation?**

[A] 4.5° [B] At DOUBLE the nominal glide path angle: 6.0 DEGREES [C] 9.0° [D] 1.5°

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. False glide paths occur at multiples of the true angle; the lowest false path is at twice the true slope ($2 \times 3^\circ = 6^\circ$).

Q2: In which frequency band does the ILS GLIDE PATH transmitter operate?

[A] VHF [B] UHF (329.15 to 335.00 MHz) [C] SHF [D] LF

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The Glide Path operates in the UHF band, while the Localizer operates in the VHF band.

Q3: What is the audio modulation frequency and visual color of the ILS OUTER MARKER (OM)?

[A] 1300 Hz amber [B] 400 HZ with BLUE light flashing dashes (two per second) [C] 3000 Hz white [D] Continuous tone red

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The Outer Marker is identified by a 400 Hz tone keyed as low-pitched dashes with a flashing blue light.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 6: Microwave Landing System (MLS) & GLS/SBAS

Syllabus Source: CAE Oxford (pp. 217-252) | Pass Target: $\geq 90\%$ AviationExam

1. MICROWAVE LANDING SYSTEM (MLS)

MLS was developed to overcome ILS frequency saturation and multipath limitations. It operates in the SHF (C-band) from 5030 to 5091 MHz (200 channels):

- Time-Referenced Scanning Beam (TRSB): A narrow beam sweeps back-and-forth across the coverage sector (TO and FRO scan). The time interval between the TO and FRO beam pulses received by the aircraft directly indicates azimuth and elevation angles!
- Operational Capabilities: Azimuth coverage: $\pm 40^\circ$ (up to $\pm 60^\circ$); Elevation: 0.9° to 15° ; Range: 20 NM. Enables CURVED AND SEGMENTED APPROACHES for noise abatement and terrain clearance.

2. SATELLITE-BASED LANDING SYSTEMS (GLS / GBAS)

The Ground-Based Augmentation System (GBAS) provides differential GPS corrections enabling GLS (GBAS Landing System) Cat I, II, and III precision approaches:

- How GLS Works: 4 reference GPS receivers on the airport measure satellite pseudo-range errors. A ground station calculates corrections and broadcasts them along with Final Approach Segment Data Blocks (FASB) over a VHF Data Broadcast (VDB, 108-118 MHz).
- Pilot Interface: The pilot selects a 5-digit channel number on the nav control panel. The cockpit display is identical to ILS, but with pinpoint differential accuracy and zero beam scalloping!

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: In which frequency band does the Microwave Landing System (MLS) operate?

[A] UHF [B] SHF (C-Band: 5030 MHz to 5091 MHz) [C] VHF [D] EHF

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. MLS operates in the SHF C-band, rendering it immune to low-frequency site reflections and FM radio interference.

Q2: What is the primary operational advantage of MLS over conventional ILS?

[A] Lower cost [B] Wide-angle proportional coverage permitting CURVED AND SEGMENTED APPROACH PATHS with variable glide slope angles [C] Operates without electricity [D] Long-range en route guidance

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. MLS provides wide azimuth ($\pm 40^\circ$) and elevation coverage, allowing aircraft to fly curved noise-abatement profiles down to touchdown.

Q3: In a GBAS Landing System (GLS), how are the ground differential corrections transmitted to the aircraft?

[A] Via satellite phone [B] Via a VHF DATA BROADCAST (VDB) in the 108.000 to 117.975 MHz band [C] Via HF sky wave [D] Via primary radar

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The GBAS ground station broadcasts corrections via an omnidirectional VHF Data Broadcast antenna at the airport.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 7: Primary Pulse Radar & Airborne Weather Radar (AWR)

Syllabus Source: CAE Oxford (pp. 253-296) | Pass Target: $\geq 90\%$ AviationExam

1. PRIMARY RADAR EQUATIONS & PRINCIPLES

Primary radar relies on the reflection of transmitted radio frequency pulses by a target:

- Pulse Recurrence Frequency (PRF): Number of pulses transmitted per second. Maximum Unambiguous Range: $R_{\max} = c / (2 \times \text{PRF})$. E.g. $\text{PRF} = 500 \text{ Hz} \rightarrow R_{\max} = 300,000 / 1,000 = 300 \text{ km}$.
- Pulse Length (tau): Duration of the pulse (microseconds). Minimum Blind Range: $R_{\min} = (c \times \tau) / 2$. Range Resolution = $(c \times \tau) / 2$.
- Beam Width & Angular Resolution: Beam Width = $(70 \times \lambda) / \text{Antenna Diameter}$. Angular resolution improves with a larger antenna and shorter wavelength!

2. AIRBORNE WEATHER RADAR (AWR) OPERATIONS

AWR operates in the SHF X-band at $\sim 9,375 \text{ MHz}$ (wavelength $\lambda = 3.2 \text{ cm}$), calibrated to reflect off wet precipitation droplets:

- Color Coding: Green (Light rain), Yellow (Moderate rain), Red (Heavy rain / CB core), Magenta (Severe turbulence detected by Doppler shift).
- Radar Shadow (Attenuation): A massive storm cell completely absorbs the radar beam. Behind the red core, a black shadow appears on the display. **NEVER FLY INTO A RADAR SHADOW:** A lethal second storm is hiding inside!
- Tilt Formula: Antenna Tilt (degrees) = $(\text{Height Difference in feet} / \text{Distance in NM} \times 100) - (\text{Beam Width} / 2)$.

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Calculating AWR Antenna Tilt Setting

SCENARIO (Weather Radar Tilt Drill): An airliner is cruising at FL 330 (33,000 ft) -

A severe storm cell is detected 40 NM ahead - The freezing level (cloud base of hazard) is at 13,000 ft MSL - The radar antenna has a 4.0° beam width QUESTION: What

antenna TILT angle must the pilot select so the BOTTOM of the radar beam sweeps

through the 13,000 ft level at 40 NM? SOLUTION PASO A PASO (FOR DUMMIES): Step 1:

Calculate the Height Difference between aircraft and target level: - Aircraft

Altitude = 33,000 ft - Target Altitude = 13,000 ft - Height Difference = 33,000 ft

- 13,000 ft = 20,000 ft (target is BELOW aircraft). Step 2: Calculate the Depression

Angle (degrees) to the target level: - Rule of Thumb: $1^\circ = 100 \text{ ft per Nautical}$

Mile! - Depression Angle = Height Difference / (Distance x 100) - Depression Angle

= $20,000 \text{ ft} / (40 \text{ NM} \times 100) = 20,000 / 4,000 = 5.0^\circ \text{ DOWN } (-5.0^\circ)$. Step 3: Adjust for

Half the Beam Width (Beam Width = 4.0°): - Beam Width / 2 = $4.0^\circ / 2 = 2.0^\circ$. - To

place the BOTTOM of the beam at the target, the center of the beam must aim 2.0°

HIGHER: - Tilt Setting = Depression Angle + Half Beam Width = $-5.0^\circ + 2.0^\circ = -3.0^\circ$

(3° DOWN)! FINAL ANSWER: Set antenna tilt to -3.0° DOWN .

[!] EXAM TRAP (AVIATIONEXAM) - The Radar Shadow Trap

- If a storm displays a deep black notch or blind zone directly behind a red cell: -
- That black area is NOT clear air! It is a RADAR SHADOW caused by beam attenuation! -
- Flying into a radar shadow is one of the most fatal thunderstorm traps in aviation.

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What wavelength is used by standard Airborne Weather Radar (AWR) systems operating in the X-band?**

- [A] 10 meters [B] APPROXIMATELY 3.2 CENTIMETERS (frequency ~9,375 MHz) [C] 10 cm [D] 1 mm

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The 3 cm X-band provides optimal reflectivity from liquid raindrops while maintaining an antenna dish size that fits within an aircraft nose radome.

Q2: On an Airborne Weather Radar display, what does a completely BLACK area situated immediately behind a

- [A] A cloud-free valley [B] A RADAR SHADOW caused by heavy rain completely absorbing and attenuating the radar beam [C] Safe flying zone [D] Ground return

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The radar pulse cannot penetrate through dense water cores, creating a blind shadow where severe convective storms remain hidden.

Q3: What radar parameter determines the MINIMUM BLIND RANGE of a primary pulse radar?

- [A] Antenna rotation speed [B] PULSE LENGTH (tau) (the receiver cannot receive while the transmitter is transmitting) [C] PRF only [D] Wavelength

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. During pulse transmission (pulse duration tau), the receiver is disconnected to prevent damage: $R_{min} = (c \times \tau) / 2$.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 8: Secondary Surveillance Radar, Mode S & ADS-B

Syllabus Source: CAE Oxford (pp. 297-340) | Pass Target: >= 90% AviationExam

1. SECONDARY SURVEILLANCE RADAR (SSR) PRINCIPLES

Unlike primary radar which depends on passive echoes, SSR relies on active cooperation between ground interrogator and aircraft transponder:

- Frequencies: Interrogation uplink = 1030 MHz (UHF). Transponder reply downlink = 1090 MHz (UHF). (Separate frequencies completely eliminate ground clutter and weather reflections!).
- Mode A (Identity): 4-digit octal code (0000 to 7777, 4,096 combinations). Special Emergency Squawks: 7700 (General Emergency / Mayday), 7600 (Radio Communications Failure), 7500 (Unlawful Interference / Hijacking!).
- Mode C (Pressure Altitude): Automatically encodes pressure altitude referenced to 1013.25 hPa in 100 ft increments (Gillham code). (Always reports standard pressure altitude, regardless of cockpit altimeter subscale setting!).

2. MODE S TRANSPONDER & ADS-B OUT

Mode S provides selective interrogation and high-capacity data link communication:

- Unique 24-Bit ICAO Address: Over 16 million unique aircraft addresses permanently assigned to the airframe registration. Eliminates identity confusion.
- Altitude Resolution: Reports altitude in 25 ft increments (compared to 100 ft in Mode C).
- ADS-B Out (Automatic Dependent Surveillance-Broadcast): The transponder automatically broadcasts aircraft GPS position, velocity, and intent over the 1090 MHz Extended Squitter once per second without requiring ground interrogation.

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What are the uplink (interrogation) and downlink (reply) frequencies used by Secondary Surveillance Radar?

[A] 108 MHz and 118 MHz [B] 1030 MHz uplink and 1090 MHz downlink [C] 960 MHz and 1215 MHz [D] 5 GHz

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. By international standard, SSR interrogates on 1030 MHz and transponders reply on 1090 MHz.

Q2: When a transponder transmits MODE C altitude information to ATC, to what barometric pressure datum is it referenced?

[A] Local aerodrome QNH [B] STANDARD 1013.25 hPa (permanently, regardless of the subscale set on the altimeter) [C] Aerodrome QFE [D] Zero pressure

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Mode C reports uncorrected pressure altitude referenced strictly to standard 1013.25 hPa. Ground ATC radar computers convert this to indicated altitude using local QNH.

Q3: Which transponder squawk code MUST a pilot select immediately following a complete loss of two-way radio communication?

[A] 7500 [B] 7600 [C] 7700 [D] 2000

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Emergency transponder codes: 7700 = Emergency; 7600 = Radio Communications Failure; 7500 = Hijack / Unlawful Interference.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 9: Global Navigation Satellite Systems (GNSS & GPS)

Syllabus Source: CAE Oxford (pp. 341-384) | Pass Target: $\geq 90\%$ AviationExam

1. THE NAVSTAR GPS ARCHITECTURE

GPS is a satellite-based radio navigation system operated by the US Space Force, structured into three segments:

- **Space Segment:** Baseline of 24 operational satellites distributed in 6 orbital planes inclined at 55° to the equator at an altitude of 20,200 km (semi-synchronous 12-hour orbit). Transmits on L1 (1575.42 MHz) and L2 (1227.60 MHz).
- **Control Segment:** Master Control Station (Schriever AFB, Colorado) and global monitor stations tracking orbits, updating clock corrections, and uploading ephemeris data.
- **User Segment:** Airborne receiver measuring Time of Arrival (TOA) of pseudo-random noise (PRN) codes from each satellite.

2. THE 4 SATELLITES FIX & CLOCK BIAS

Because the aircraft receiver clock is an inexpensive quartz crystal (not an atomic clock), it contains an unknown time error (clock bias):

- **Mathematical Requirement:** There are 4 unknown variables to solve: Latitude (X), Longitude (Y), Altitude (Z), and Receiver Clock Error (Delta t). Therefore, A MINIMUM OF 4 SATELLITES IS MANDATORY FOR A 3D POSITION FIX!
- **Dilution of Precision (DOP):** Measures the geometric strength of satellite distribution. Best geometry (Low PDOP < 3): One satellite directly overhead, and three satellites spaced 120° apart near the horizon. Poor geometry (High PDOP > 6): Satellites bunched close together in the sky.

3. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Satellite Ranging & Pseudo-Range Correction

SCENARIO (GNSS Clock Bias Principle Drill): A GPS receiver measures time of signal arrival from a satellite: - The raw measured transit time indicates a distance of 21,000,000 meters (Pseudo-range) - The receiver clock has an internal bias of +0.000010 seconds (10 microseconds fast) - Speed of light $c = 300,000,000$ m/s **QUESTION:** What is the distance error caused by this 10 microsecond clock bias, and what is the true corrected range? **SOLUTION PASO A PASO (FOR DUMMIES):** Step 1: Calculate the distance error created by the clock bias: - Formula: Distance Error = Speed of Light (c) x Clock Bias (Delta t) - Distance Error = $300,000,000 \text{ m/s} \times 0.000010 \text{ s} = 3,000 \text{ meters (3.0 km)}$! Step 2: Understand why 4 satellites are needed: - A tiny clock error of only 10 microseconds causes a massive 3-kilometer position error! - The 4th satellite provides the algebraic equation that solves for this exact 10 microsecond bias, eliminating the 3,000 m error completely! Step 3: Calculate the True Range: - True Range = Measured Pseudo-range - Distance Error - True Range = $21,000,000 \text{ m} - 3,000 \text{ m} = 20,997,000 \text{ meters}$. **FINAL ANSWER:** Distance error = 3,000 meters. True range = 20,997 km. The 4th satellite eliminates receiver clock bias.

[!] EXAM TRAP (AVIATIONEXAM) - 3 Satellites vs 4 Satellites Trap

- 3 satellites provide a 2D FIX (Latitude and Longitude ONLY), assuming altitude is already known! - 4 satellites are REQUIRED FOR A FULL 3D FIX (Latitude, Longitude, Altitude, and Clock Bias)! - Never answer 3 satellites when the question asks for a full 3D fix.

4. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What is the MINIMUM number of satellites required by an unaugmented airborne GPS receiver to compute**

[A] 3 satellites [B] AT LEAST 4 SATELLITES (to resolve X, Y, Z coordinates and receiver clock bias) [C] 5 satellites [D] 24 satellites

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The 4 unknowns (latitude, longitude, altitude, and receiver clock offset) require at least 4 independent pseudo-range equations from 4 visible satellites.

Q2: In satellite navigation, what does a LOW value of Position Dilution of Precision (PDOP < 3) indicate?

[A] Weak satellite signals [B] EXCELLENT SATELLITE GEOMETRY (satellites widely spaced across the sky), yielding high navigational accuracy [C] Clock failure [D] High ionospheric delay

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Lower DOP values represent stronger geometric triangulation. PDOP < 3 represents ideal geometry with wide angular separation.

Q3: What is the primary source of pseudo-range ERROR in standard unaugmented single-frequency GPS?

[A] Rain attenuation [B] IONOSPHERIC DELAY (refraction of radio waves through charged free electrons in the ionosphere) [C] Relativistic error [D] Antenna drag

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Ionospheric delay introduces unmodeled propagation delays of 5 to 30 meters, representing the largest single pseudo-range error source.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 10: Satellite Integrity Monitoring (RAIM & SBAS/GBAS)

Syllabus Source: CAE Oxford (pp. 385-424) | Pass Target: >= 90% AviationExam

1. RECEIVER AUTONOMOUS INTEGRITY MONITORING (RAIM)

GPS satellites can transmit erroneous ranging signals without immediate warning. RAIM is an internal airborne algorithm that cross-checks satellite ranges for consistency:

- Fault Detection (FD): REQUIRES A MINIMUM OF 5 SATELLITES (or 4 satellites + Barometric VNAV aiding). Detects if a faulty satellite is providing corrupt data, alerting the pilot with an integrity warning.
- Fault Detection and Exclusion (FDE): REQUIRES A MINIMUM OF 6 SATELLITES (or 5 satellites + Baro-VNAV). Identifies WHICH satellite is faulty, excludes it from the navigation solution, and continues navigation without interruption!
- Mask Angle: Satellites within 5° of the horizon are rejected (masked) due to excessive tropospheric refraction.

2. SATELLITE-BASED AUGMENTATION SYSTEMS (SBAS)

SBAS uses ground reference networks and geostationary satellites to broadcast wide-area differential corrections:

- Systems: EGNOS (Europe), WAAS (USA), MSAS (Japan), GAGAN (India).
- Capability: Eliminates ionospheric delay errors. Enables LPV (Localizer Performance with Vertical Guidance) approaches down to ILS Cat I decision height (200 ft) without ground ILS equipment!

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is the MINIMUM number of operational satellites required for RAIM to perform FAULT DETECTION (FD)?

[A] 4 satellites [B] AT LEAST 5 SATELLITES (or 4 with Barometric Altimeter aiding) [C] 6 satellites [D] 3 satellites

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Fault Detection requires 5 visible satellites with suitable geometry to detect an anomalous pseudo-range error.

Q2: How many satellites are required for RAIM to perform FAULT DETECTION AND EXCLUSION (FDE)?

[A] 5 satellites [B] AT LEAST 6 SATELLITES (or 5 with Baro-VNAV aiding) [C] 8 satellites [D] 4 satellites

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. FDE requires 6 satellites: 4 to solve the 3D position/time, a 5th to detect the fault, and a 6th to isolate and exclude the corrupt satellite.

Q3: What is the European Satellite-Based Augmentation System (SBAS) called?

[A] WAAS [B] EGNOS (European Geostationary Navigation Overlay Service) [C] Galileo [D] GLONASS

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. EGNOS is the European SBAS system that augments GPS signals to provide safety-of-life LPV approach capabilities.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 11: Performance-Based Navigation (PBN) & Specifications

Syllabus Source: CAE Oxford (pp. 425-472) | Pass Target: >= 90% AviationExam

1. THE PBN REVOLUTION: RNAV VS RNP

Performance-Based Navigation specifies aircraft Required Navigation Performance rather than mandating specific ground sensors:

- The Fundamental Distinction: RNP REQUIRES ON-BOARD PERFORMANCE MONITORING AND ALERTING (OPMA)! RNAV DOES NOT! Under RNP, the system continuously monitors containment and alerts the crew if Total System Error exceeds the containment boundary.
- Containment Standard: The aircraft navigation system must keep the aircraft within the designated accuracy value (e.g. +/-1.0 NM for RNP 1) for AT LEAST 95% OF TOTAL FLIGHT TIME, and within twice that value (2 x RNP) for 99.999% of time!

2. SUMMARY OF OFFICIAL PBN SPECIFICATIONS

PBN Specification	Accuracy Limit (95% Containment)	Flight Phase & Operational Application
PBN Specification	Accuracy Limit (95% Containment)	Flight Phase & Operational Application
RNAV 10 (RNP 10)	+/- 10 Nautical Miles	Oceanic and remote continental airspace (e.g. Pacific routes).
RNAV 5 (B-RNAV)	+/- 5 Nautical Miles	En-route continental airspace (Mandatory in European airspace).
RNAV 1 & RNAV 2 (P-RNAV)	+/- 1 NM or +/- 2 NM	Terminal arrivals (STAR) and departures (SID) with radar coverage.
RNP 4	+/- 4 Nautical Miles	Oceanic operations with reduced separation (30/30 NM).
RNP 1	+/- 1 Nautical Mile	Terminal arrivals (STAR) and departures (SID) without radar.
RNP APCH	+/- 0.3 NM on final approach	Non-precision approaches: LNAV, LNAV/VNAV, and LPV.
RNP AR APCH	Down to +/- 0.1 NM (Authorisation Required)	Complex terrain procedures with constant Radius-to-Fix (RF) curved legs!

3. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)

Q1: What is the fundamental operational difference between an 'RNAV' specification and an 'RNP' specification?

[A] RNP uses only satellites [B] RNP REQUIRES ON-BOARD PERFORMANCE MONITORING AND ALERTING (OPMA), whereas RNAV does not [C] RNAV is more accurate than RNP [D] RNAV is for military only

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. Under ICAO Doc 9613, the presence of real-time on-board performance monitoring and alerting (OPMA) is the sole distinguishing feature that defines an RNP specification.

Q2: In European en-route airspace, what is the mandatory minimum navigation specification known as Basic R

[A] RNAV 1 [B] RNAV 5 (requiring aircraft to maintain track within +/- 5 NM for at least 95% of flight time) [C] RNP 4 [D] RNAV 10

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. B-RNAV in Europe is formally designated as RNAV 5, mandating a lateral accuracy of 5 NM for 95% of the flight duration.

Q3: What unique procedure design capability is enabled by RNP AR APCH (Authorisation Required)?

[A] Vertical take-offs [B] RADIUS-TO-FIX (RF) CURVED LEGS in the final approach and missed approach segments to skirt around high terrain [C] Supersonic flight [D] Zero fuel reserves

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. RNP AR allows precise curved RF turns in mountainous terrain with containment down to RNP 0.1.

ATPL EASA STUDY GUIDE | 062 - RADIO NAVIGATION

Chapter 12: RNAV Architecture, FMS Sensors & Total System Error

Syllabus Source: CAE Oxford (pp. 473-520) | Pass Target: $\geq 90\%$ AviationExam

1. FMS MULTI-SENSOR POSITION UPDATING HIERARCHY

Modern Flight Management Systems (FMS) compute a continuous best-estimate position by fusing inputs from multiple sensors:

- 1. GNSS (GPS / Galileo): Primary sensor offering highest continuous accuracy (< 5 m).
- 2. DME / DME Updating: Secondary terrestrial sensor. Requires at least two DME stations whose intersecting radials cross at an angle between 30° and 150° (optimal 90°)! Sub-mile accuracy.
- 3. VOR / DME Updating: Single VOR/DME co-located station providing bearing and distance. Lower accuracy due to VOR angular divergence at range.
- 4. Inertial Reference Systems (IRS): Provides continuous dead-reckoning position during GNSS or DME reception loss. IRS position drifts over time.

2. TOTAL SYSTEM ERROR (TSE) COMPONENTS

Under ICAO PBN definitions, the lateral error of an aircraft relative to the intended track consists of three statistically independent errors combined using root-sum-square:

- The TSE Master Formula: $TSE = \sqrt{PDE^2 + FTE^2 + NSE^2}$
- Path Definition Error (PDE): Discrepancy between the defined path in the navigation database and the intended true flight path (virtually zero in modern digital databases).
- Flight Technical Error (FTE): Pilot or autopilot accuracy in tracking the indicated path on the flight director/CDI.
- Navigation System Error (NSE): The difference between actual aircraft position and the position computed by the navigation sensors.

3. FLY-BY VS FLY-OVER WAYPOINTS

- Fly-By Waypoint (Standard): Depicted as an open 4-point star. The FMS initiates turn anticipation BEFORE reaching the waypoint, cutting the corner smoothly without overshoot.
- Fly-Over Waypoint: Depicted as a 4-point star enclosed in a circle. The aircraft MUST FLY DIRECTLY OVERHEAD the waypoint before initiating the turn, followed by an overshoot and intercept.

4. STEP-BY-STEP WORKED EXAMPLE (FOR DUMMIES / PASO A PASO)

[*] OFFICIAL DEFINITION - PRACTICAL CALCULATION: Calculating Total System Error (TSE)

SCENARIO (EASA PBN Total System Error Drill): During an RNP 1 terminal departure, the FMS computes the error components: - Path Definition Error (PDE) = 0.10 NM - Flight Technical Error (FTE) = 0.50 NM - Navigation System Error (NSE) = 0.60 NM QUESTION: What is the Total System Error (TSE), and is it compliant with the RNP 1 specification (+/- 1.0 NM)? SOLUTION PASO A PASO (FOR DUMMIES): Step 1: Recall the Master TSE Root-Sum-Square Formula: - Formula: $TSE = \sqrt{PDE^2 + FTE^2 + NSE^2}$ Step 2: Square each error component: - $PDE^2 = 0.10^2 = 0.01$ - $FTE^2 = 0.50^2 = 0.25$ - $NSE^2 = 0.60^2 = 0.36$ Step 3: Sum the squared values: - $Sum = 0.01 + 0.25 + 0.36 = 0.62$ Step 4: Take the square root: - $TSE = \sqrt{0.62} = 0.787 \text{ NM} (\sim 0.79 \text{ NM})$ Step 5: Compare with RNP 1 Containment Limit (1.0 NM): - $0.79 \text{ NM} \leq 1.0 \text{ NM} \rightarrow$ COMPLIANT! FINAL ANSWER: Total System Error is 0.79 NM, which is well within the 1.0 NM legal limit for RNP 1.

[!] EXAM TRAP (AVIATIONEXAM) - The DME/DME Intersection Angle Trap

- For an FMS to accept a DME/DME position update: - The angle between the two DME station lines of position MUST be between 30° and 150°! - Angles under 30° or over 150° create severe geometric dilution and are automatically rejected.

5. AVIATIONEXAM PRACTICE QUESTIONS (WITH EXPLANATIONS)**Q1: What are the acceptable intersection angles between two DME stations for an FMS DME/DME position update?**

[A] Exactly 90° only [B] BETWEEN 30 DEGREES AND 150 DEGREES (with optimal geometry at 90°) [C] Any angle [D] Less than 15°

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. The FMS rejects DME pairs intersecting at angles shallower than 30° or wider than 150° to avoid geometric position stretching.

Q2: In Performance-Based Navigation, what are the three components of TOTAL SYSTEM ERROR (TSE)?

[A] Wind error, drift error, clock error [B] PATH DEFINITION ERROR (PDE), FLIGHT TECHNICAL ERROR (FTE), and NAVIGATION SYSTEM ERROR (NSE) [C] Altimeter error, speed error, heading error [D] Magnetic error only

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. By ICAO definition, $TSE = \sqrt{PDE^2 + FTE^2 + NSE^2}$, combining database, pilot/autopilot tracking, and sensor errors.

Q3: What symbol on an instrument flight chart depicts a 'FLY-OVER' waypoint?

[A] A plain 4-point star [B] A 4-point star ENCLOSED WITHIN A CIRCLE [C] A solid black triangle [D] An open square

[*] OFFICIAL DEFINITION - Detailed Answer Explanation

CORRECT: [B]. A fly-by waypoint is an unenclosed star; enclosing the star in a circle mandates flying directly overhead before turning.