

### II. 80x86 Family of Microprocessors

**Programming Model** 





At the end of the lecture, the students should be able to:

- discuss the 80x86 Family of Microprocessors,
- differentiate: Real Mode vs. Protected Mode, and
- discuss different addressing modes used in assembly programming.



# The 80x86 Family

Processor	Data Bus	Address Bus	Maximum Addressable Memory
8088	8	20	1MB
8086	16	20	1MB
80286	16	24	16MB
80386	32	32	4GB
80486	32	32	4GB
Pentium	64	32	4GB






### Intel and Intel-compatible Processors

Processor	Data Bus	Register Size
8088	8-bit	16-bit
8086	16-bit	16-bit
286	16-bit	16-bit
386	32-bit	32-bit
486/AMD-5x86	32-bit	32-bit
Pentium/AMD-K6	64-bit	32-bit
Pentium Pro/Celeron/II/III	64-bit	32-bit
AMD Duron/Athlon/Athlon XP	64-bit	32-bit
Pentium 4	64-bit	32-bit
Itanium	64-bit	64-bit
AMD Athlon 64	64-bit	64-bit




### Intel Family Register Organization



Note: 32 bit registers are not available on 8086, 8088, or 80286



### Memory Organization



(Ref: Aurora Simionescu, Memory organization and access of 80x86 processors)



### Real Mode and Protected Mode

- are operational modes of x86-compatible CPUs
- Real mode was invented first, original segment:offset addressing
- Protected mode is a modification of real mode addressing.





**Address** 

**MEMORY** 

16-bit Register 0001h 0002h 0003h Instruction # 1
Instruction # 2
Instruction # 3
Instruction # 4

Instruction # 4


Data # 1

FFFFh

Data # 2




 Characterized by a 20 bit segmented memory address space











- instruction can address any space within the 1 MB of RAM
- programs in real mode are typically part of OS or a special application
- Ex. 1000:1F00





- instruction can address any space within the 1 MB of RAM
- programs in real mode are typically part of OS or a special application
- Ex. 1000:1F00

First, multiply the segment value by 10h. Then add in the offset portion. Their sum produces the physical address.





- instruction can address any space within the 1 MB of RAM
- programs in real mode are typically part of OS or a special application
- Ex. 1000:1F00

10000 + 1F00 11F00

First, multiply the segment value by 10h. Then add in the offset portion. Their sum produces the physical address.






#### Disadvantage:

- Many segment:offset pairs refer to the same exact memory locations.
- For example, the segment:offset address 047C:0048, 047D:0038 or 047E:0028 all refer to the physical address: 04808
- This can complicate the comparison of segmented addresses.





### Protected Mode Memory Addressing




Has features
 designed to
 enhance
 multitasking and
 system stability,
 memory protection
 and support for
 virtual memory.





### Protected Mode Memory Addressing

- the mode that computer runs in when it has to support multiple users
- Linux, UNIX, Windows 9x, Windows NT uses protected mode



Use the segment as an index into the segment descriptor array.

Fetch the value at this location and add it to the offset to obtain the physical address.





### II. 80x86 Family of Microprocessors

Addressing Modes





# Addressing Modes

the way we address/specify operands in instructions

#### Three general types:

- Immediate
- Register
- Memory/Direct





# Addressing Modes

 Immediate - transfers an immediate byte or word of data into the destination register or memory location

ex. mov cx, 10

 Register - transfers a byte or word from the source register to the destination register

ex. mov ax, bx





# Addressing Modes

 Memory/Direct - moves a byte or word between a memory location and a register

```
ex. mov ax, [num1] mov cx, [B800h]
```





 Register Indirect - transfers a byte or word of data between a register and the memory location addressed by an index register(DI or SI) or base register (BP or BX)

ex. mov ax, [bx]





 Base Indexed - transfers a byte or word of data between a register and the memory location addressed by a base register (BP or BX) plus index (DI or SI) register

ex. mov dx, [bx + di]





• Register Relative - transfers a byte or word of data between a register and the memory location addressed by an index register (DI or SI) or base register (BP or BX) plus displacement

ex. mov dx, [bx + 1000h]





 Base Relative Plus Index - transfers a byte or word of data between a register and the memory location addressed by a base register (BP or BX) plus index register (DI or SI) plus displacement ex. mov ax, [bx + si + 100h]





- 1. In real mode addressing, if the segment:offset address is 1234:1001, what is its equivalent physical address?
- 2. Given the following registers and memory segments,

		1234h	11
DI	1234h	1235h	6
SI	1236h	1236h	27
		1237h	19

what would be the value of AL after the assembly code **mov AL, [SI]** is executed?