Primer on Semiconductors

Unit 5: The Semiconductor Equations

Lecture 5.1: Mathematical formulation

Mark Lundstrom

Iundstro@purdue.edu
Electrical and Computer Engineering
Purdue University
West Lafayette, Indiana USA



Solving semiconductor problems

For a uniform semiconductor in equilibrium, we can assume space-charge neutrality:

$$\rho = q(p_0 - n_0 + N_D^+ - N_A^-) = 0$$

We also know that in equilibrium:

$$n_0 p_0 = n_i^2$$

In general, neither one of the above equations is valid, so how do we solve for the electron and hole concentrations and for the electric field too?

Equilibrium vs. non-equilibrium

equilibrium

$$n_0 = n_i e^{(E_F - E_i)/k_B T}$$

$$p_0 = n_i e^{(E_i - E_F)/k_B T}$$

$$n_0 p_0 = n_i^2$$

$$f_0 = \frac{1}{1 + e^{(E - E_F)/k_B T}}$$

non-equilibrium

$$n = n_i e^{(F_n - E_i)/k_B T}$$

$$p = n_i e^{\left(E_i - F_p\right)/k_B T}$$

$$np \neq n_i^2$$

$$f_c = \frac{1}{1 + e^{(E - F_n)/k_B T}}$$

$$1 + e^{(E-F_n)/k_B T}$$

$$1 - f_v = 1 - \frac{1}{1 + e^{(E-F_p)/k_B T}}$$
2018

The unknowns

$$p(\vec{r}) = n_i e^{(E_i(\vec{r}) - F_p(\vec{r}))/k_B T}$$

$$n(\vec{r}) = n_i e^{(F_n(\vec{r}) - E_i(\vec{r}))/k_B T}$$

$$E_i(\vec{r}) = E_i^{ref} - qV(\vec{r})$$

3 unknowns

$$p(\vec{r}), n(\vec{r}), V(\vec{r})$$

or


$$F_p(\vec{r}), F_n(\vec{r}), V(\vec{r})$$

We need to formulate 3 equations in 3 unknowns.

First equation: Continuity equation for holes

$$\frac{\partial p}{\partial t} = \text{in-flow - out-flow + } G - R$$

$$\frac{\partial p}{\partial t} = -\nabla \cdot \frac{\vec{J}_p}{q} + G_p - R_p$$




One equation in 3 unknowns

$$\frac{\partial p}{\partial t} = -\nabla \cdot \frac{\vec{J}_p}{q} + G_p - R_p$$

$$\vec{J}_p = pq\mu_p \vec{\mathcal{E}} - qD_p \vec{\nabla} p$$

optical generation or impact ionization




Radiative, Auger or defect-assisted processes


Need equation for the electric field

Need equation for electrons

Gauss's Law



Gauss's Law in 1D



The Poisson equation

$$\oint \vec{D} \cdot d\vec{S} = Q \iff \nabla \cdot \vec{D} = \rho(x)$$

$$D = K_{S} \varepsilon_{0} \mathcal{E}$$

$$\nabla \cdot \left(K_{S} \varepsilon_{0} \vec{\mathcal{E}} \right) = \rho(\vec{r})$$

$$\rho(\vec{r}) = q \left[p(\vec{r}) - n(\vec{r}) + N_D^+(\vec{r}) - N_A^-(\vec{r}) \right]$$

The "semiconductor equations"

$$\frac{\partial p}{\partial t} = -\nabla \cdot \left(\frac{\vec{J}_p}{q}\right) + G_p - R_p$$

$$\frac{\partial n}{\partial t} = -\nabla \cdot \left(\frac{\vec{J}_n}{-q}\right) + G_n - R_n$$

$$\nabla \cdot \left(K_{S} \varepsilon_{0} \vec{\mathcal{E}} \right) = \rho$$

Three equations in three unknowns:

$$p(\vec{r}), n(\vec{r}), V(\vec{r})$$

$$\vec{J}_p = pq\mu_p \vec{\mathcal{E}} - qD_p \vec{\nabla} p$$

$$\vec{J}_n = nq\mu_n \vec{\mathcal{E}} + qD_n \vec{\nabla} n$$

$$\rho = q \left(p - n + N_D^+ - N_A^- \right)$$

$$\vec{\mathcal{E}}(\vec{r}) = \nabla V(\vec{r})$$

Semiconductor equations

$$\frac{\partial p}{\partial t} = -\nabla \cdot \left(\frac{\vec{J}_p}{q}\right) + G_p - R_p$$

$$\frac{\partial n}{\partial t} = -\nabla \cdot \left(\frac{\vec{J}_n}{-q}\right) + G_n - R_n$$

$$\nabla \bullet \left(K_{S} \varepsilon_{0} \vec{\mathcal{E}} \right) = \rho$$

Not as fundamental as Maxwell's equations, but these equations are the starting point for the analysis of most semiconductor devices.

Discussion: Equilibrium

$$\frac{\partial p}{\partial t} = -\nabla \cdot \left(\frac{\vec{J}_p}{q}\right) + G_p - R_p$$

$$0 = -\nabla \left(\frac{0}{q} \right) + 0 - 0$$

$$\frac{\partial n}{\partial t} = -\nabla \cdot \left(\frac{\vec{J}_n}{-q}\right) + G_n - R_n$$



$$0 = -\nabla \left(\frac{0}{-q} \right) + 0 - 0$$


$$\nabla \bullet \left(K_{S} \varepsilon_{0} \vec{\mathcal{E}} \right) = \rho$$

$$\nabla \bullet \left(K_{S} \varepsilon_{0} \vec{\mathcal{E}} \right) = \rho$$

What can we learn from equilibrium?

$$p_0 = n_i e^{(E_i - E_F)/k_B T}$$
 $n_0 = n_i e^{(E_F - E_i)/k_B T}$ $n_0 p_0 = n_i^2$

Reminder: Generation and recombination



other generation processes

e.g. optical generation impact ionization

Band-to-band SRH Auger


recombination:

$$R_p > 0$$

generation:

$$R_p < 0$$

Discussion




requires energy to break covalent bonds

releases energy

In equilibrium: R = 0

Why is $n_0 p_0 = n_i^2$?



In equilibrium:

$$g = r$$

$$n_0 p_0 = \frac{g(T)}{C} = n_i^2(T)$$

$$n_0 p_0 = n_i^2 (T)$$

Summary: The semiconductor equations

$$\frac{\partial p}{\partial t} = -\nabla \cdot \left(\frac{\vec{J}_p}{q}\right) + G_p - R_p$$

$$\frac{\partial n}{\partial t} = -\nabla \cdot \left(\frac{\vec{J}_n}{-q}\right) + G_n - R_n$$

$$\nabla \cdot \left(K_{S} \varepsilon_{0} \vec{\mathcal{E}} \right) = \rho$$

Three equations in three unknowns:

$$p(\vec{r}), n(\vec{r}), V(\vec{r})$$

$$\vec{J}_p = pq\mu_p \vec{\mathcal{E}} - qD_p \vec{\nabla} p$$

$$\vec{J}_n = nq\mu_n \vec{\mathcal{E}} + qD_n \vec{\nabla} n$$

$$\rho = q \left(p - n + N_D^+ - N_A^- \right)$$

$$\vec{\mathcal{E}}(\vec{r}) = \nabla V(\vec{r})$$