



Asset Performance:

Wat 02 Water efficient equipment: toilets



Credits



No Minimum Standard

Aim

To reduce water consumption by encouraging the specification of water efficient toilets.

Question

What percentage of toilets have been fitted with low flush technologies?

Credits	Answer	Select a single answer option
0	A.	Question not answered
0	B.	Asset contains toilets which are >6 litres per flush
1	C.	All toilets ≤6 litres per flush
2	D.	≥75% of toilets ≤4.5 litres per flush (all remaining toilets ≤6 litres per flush)
3	E.	All toilets ≤4.5 litres per flush
4	F.	≥50% of toilets ≤3 litres per flush (all remaining toilets ≤4.5 litres per flush)

Assessment criteria

Criterion	Assessment criteria	Applicable Answer
1.	For dual flush toilets the effective flush volume will need to be calculated. An explanation and worked example is available in the Methodology section.	C – F

Specific notes

Asset type specific	
1.	No facilities Where the asset under assessment contains no water using equipment and therefore there is no water supply to the building, identify and assess the facilities most likely to be used by the occupants and visitors to the asset under assessment.

Asset type specific	
	This rule also applies where the assessment consists solely of an extension to an existing building, i.e. where the extended building contains no new water using equipment because there are facilities present within the existing building.

Methodology

Effective Flush Volume of a Dual Flush Toilet

The effective flush volume of a **dual flush toilet** is the ratio of full flush to reduced flush. This is taken to be one full flush for every three reduced flushes for non-domestic buildings.

The effective flush volume would therefore be calculated as follows, using a 6/4 litre dual flush volume toilet as an example:

$$\frac{(6L \times 1) + (4L \times 3)}{4} = 4.5L \text{ EFV}$$

Assessor checks

An adequate proportion of toilets within the asset need to be checked. It is not necessary to check all toilets. At least 10% of toilets within the building should be observed.

Evidence

Criteria	Evidence requirement
-	The evidence below is not exhaustive, please also refer to the 'BREEAM evidential requirements' section in the scope of the Guidance for appropriate evidence types which can be used to demonstrate compliance.
All	Manufacturer/supplier literature of installed toilets (if available).
All	Photographic evidence of low flush toilets; a representative sample is sufficient.
All	Copies of asset floor plans and/or an inventory of sanitary elements indicating the location and quantity of toilets.
All	If manufacturer information is unavailable: a) Photographic evidence of information on the cistern to identify flow rate b) Copy of liaisons with manufacturer confirming the toilet is low flush c) Assessor comment to justify the reason why the toilet is deemed to be low flush d) EFV calculation.

Definitions

Effective flush volume (EFV):

Effective flush volume is the volume of water needed to clear the toilet and transport any contents far enough to avoid blocking the drain. The effective flush volume of a single flush toilet is the volume of water used for one flush.