



Asset Performance:

Wat 04 Water efficient equipment: hand washing basins taps



Credits



No Minimum Standard

Aim

To reduce water consumption by encouraging specification of water efficient hand washing basin taps.

Question

What percentage of the hand washing basin taps are designed for low water use?

Credits	Answer	Select a single answer option
0	A.	Question not answered
0	B.	The asset contains wash basin taps which are ≥ 6 litres/min
1	C.	100% have ≤ 6 litres/min
2	D.	50% have ≤ 4 litres/min and the remaining have ≤ 6 litres/min
3	E.	100% have ≤ 4 litres/min
4	F.	100% have ≤ 4 litres/min and have automatic control

Assessment criteria

Criterion	Assessment criteria	Applicable Answer
1.	Hand washing basin taps must have automatic control equipped with a proximity sensor (e.g. Active Infrared Taps). Hand washing taps which run for pre-set periods of time (e.g. push button with an auto shutoff) are not compliant with this issue.	F
2.	Exceptions: Only taps that are specifically used in hand washing basins are applicable. This requirement does not apply to: a) 'Scrub' facilities in clinical areas of healthcare buildings b) Taps provided to cleaners c) Kitchen and external taps	B – F

Criterion	Assessment criteria	Applicable Answer
	d) Other instances where such fittings would be inappropriate for medical/health-related reasons (such instances must be justified by the design specification/the building management).	

Specific notes

Asset type specific	
1.	No facilities Where the asset under assessment contains no water using equipment and therefore there is no water supply to the building, identify and assess the facilities most likely to be used by the occupants and visitors to the asset under assessment. This rule also applies where the assessment consists solely of an extension to an existing building, i.e. where the extended building contains no new water using equipment because there are facilities present within the existing building.

Methodology

Assessor checks

An adequate proportion of hand washing basins within the asset need to be checked to determine whether they are low water use, although it is not necessary to check them all. At least 10% of hand washing basins within the asset must be observed.

Evidence

Criteria	Evidence requirement
-	The evidence below is not exhaustive, please also refer to the 'BREEAM evidential requirements' section in the scope of the Guidance for appropriate evidence types which can be used to demonstrate compliance.
All	Photographic evidence of installed hand washing basins; a representative sample is sufficient.
All	Manufacturer/supplier literature of water efficient specifications installed (including flow regulators).
All	Copies of asset floor plans and/or an inventory of sanitary elements identifying the location and quantity of hand wash basins.
All	Where manufacturer information is not available, evidence must be provided that confirms that the taps meet the stated criteria. This could include measured flow rates or confirmation from the manufacturer that the installed taps meet the criteria.

Additional information

Examples of low water taps

Types of low water use hand washing basin taps include, but are not limited to:

- a) Spray taps
- b) Aerated taps.